lars zumpe
MEDIENPRODUKTION

USER MANUAL

Plan, document and hand over broadcast and AV cabling: signal flow, rooms and floors, cable lengths, patch lists and the paperwork for the build day.

Contents

1. Getting started
   - Installation
   - First project
2. The interface
   - Main window layout
   - Arranging the side panels
   - Edit menu
   - View menu
   - Help menu
   - Status bar
   - Phone access
   - First start
3. Canvas
   - The empty plan and the example project
   - The toolbar
   - Defaults
   - Selecting devices
   - Aligning devices
   - Saving a device group
   - Arranging the selection in the rack builder
   - Several cables between two devices
   - Cables by voice
   - Keyboard shortcuts on the canvas
   - Drawing cables
   - Editing cables
   - Off-page connectors
   - Frames
   - Rooms, floors and the 3D building view
   - Layers
   - Signal path
   - Operating modes: schematic, circuit, test pattern
   - Locking
   - Finalising the plan
   - Annotations
   - Floor plan
   - Plan symbols
   - Device search
   - Zoom and navigation
   - Context menus
   - Selection bar at the device
   - Still image under the device
   - Adapters and converters in the cable
4. Library
   - The library column
   - Equipment
   - Cables
   - Groups
   - Racks
5. Inspector
   - Nothing selected
   - Device properties
   - Cable properties
   - Frame properties
6. File and Import
   - New project
   - New from template

  - Open
  - Save and Save as
  - Autosave and status bar
  - The `.cableplan` file format
  - Import yEd / GraphML
  - Import MultiCam cameras
  - Import equipment from CSV
  - Rentman import
  - NetBox import
  - Exporting and importing a whole project (`.avplan`)
  - Identity map (`.avsourcemap`)
  - View linked venue plan
7. Export & Print
  - Patch list
  - Fixed install: docs & handover
  - Stage plot
  - Export & Print
  - Cloud & share link
  - Viewer file
  - Import annotations
  - Compare plan revisions
  - Documents handed out
  - Way back to Rentman
8. Tools: Plan
  - Calculate
  - Check
  - Plan
9. Tools: Build
  - LED wall
  - Faceplate editor
  - Report editor
  - Conductors and colour standards
  - Received show-control messages
  - Connect multiple cables
  - Create new rack
  - Generate AI plan
  - Revisions & snapshots
  - Inventory / stock
  - Device configuration
10. Settings
  - Opening the settings
  - Project
  - Modules
  - Appearance
  - Editing
  - Hotkeys
  - Integrations
  - Device library
  - MCP
  - Configurations
  - Cable types
  - Master data
  - Categories & fields
  - Network sync
  - Credentials
  - Advanced
11. Claude (MCP)
12. Web edition and tablet

13. Data, safety and troubleshooting

1. Getting started

Installation

Download the installer from the latest release:

- **macOS**: `.dmg` for Apple Silicon and Intel
- **Windows**: `.exe`

The app runs fully offline. An internet connection is only needed for the device library, the cloud copy and live sessions across networks.

Without installing anything, the web edition runs at **https://larszu.github.io/cable-planner/** (see chapter 21 for what it cannot do).

First project

- **File → New** starts an empty plan. **Open**, **Save** and **Save As** work as usual; the recent projects list fills itself.
- A project is a single JSON file (`.cableplan`). It can be versioned with git and diffed like text.
- While you work, the plan is auto-saved into a recovery copy every few hundred milliseconds. If the project grows beyond what that store holds (about 5 MB), the status bar shows **"No recovery copy"** with the project size — then save to a file. The plan itself is unaffected.
- Undo and redo cover the last 100 steps.



2. The interface

Main window layout



The main window has five areas:

AREA	POSITION	CONTENTS
Header	top	menus ***File***, ***Edit***, ***Tools***, ***View***, ***Help***, project name, undo/redo, theme button, ***Phone access***, ***Settings***
Library	left	equipment, cables, groups and racks to place in the plan
Canvas	centre	the plan with devices and cables, toolbar, search field, zoom buttons, overview map
Inspector	right	properties of the selection
Status bar	bottom	figures and notices about the project

Header

Clicking the project name in the centre opens the dialog ***Edit project metadata***.



FIELD	EFFECT
Project name (required)	name in the header, status bar and printouts
Contractor (company), Client, Planner / author, Project / job no.	details for the plan footer
Event/rental start, Event/rental end	period of the job
Description	free text
Company logo, Client logo	image file via ***Choose logo...***

These fields appear in the plan footer when exporting to PDF. ***Save*** applies them, ***Cancel*** discards them.

The undo and redo buttons sit on the right of the header. They are greyed out while there is no step to take.

In a narrow window the header contracts; the menus stay available.

File and Tools menus

The ***File*** menu holds new, open, save, the imports and the exports. Its entries are described in the chapters File and Import and Export & Print.



The ***Tools*** menu is divided into groups, among them ***Calculate***, ***Check*** and ***Plan***. The tools are described in the tools chapters.



Inspector with nothing selected

With nothing selected, the inspector shows ***Nothing selected***, the block ***Photos of the project*** with ***Add photo…*** and ***Quick orientation*** with four starting hints.



Arranging the side panels

The library and the inspector can be collapsed, undocked, moved into a window of their own and resized.

Window menu

1. Click ***Window*** at the top of the side panel.

1. Choose ***Undock (floating)***. The library floats above the canvas as a movable panel. ***Dock*** puts it back in place.



Open in its own window opens the side panel as a separate application window. The ***Window*** button can also be dragged. The menus of the inspector and of the annotations panel offer the same entries.

Collapsing and width

– The arrow button next to ***Window*** collapses the side panel. Clicking the arrow at the edge expands it again.





– The divider between side panel and canvas can be dragged with the mouse to change the width.



– **Ctrl+B** hides and shows the library, **Ctrl+I** the inspector.

The **P** key opens the patch list.

Edit menu

ENTRY	SHORTCUT	EFFECT
Undo	Ctrl+Z	reverts the last step
Redo	Ctrl+Y	restores the reverted step
Duplicate	Ctrl+D	copies the selected elements
Delete selection	Del	deletes the selected elements
Select all	Ctrl+A	selects all elements of the plan
Clear selection	Esc	clears the selection


Defaults
Frame
Video
Audio
Control
Network
Power
Other
More
Find device...
Camera 1
Cameras
BNC · SDI Out
CAM 1 → mixer (12m)
Vision mixer
Mixer
In 1 · BNC
In 2 · BNC
In 3 · BNC
In 4 · BNC
BNC · PGM Out
BNC · Multiview Out
Multiviewer
Monitors
SDI In · BNC
PGM → control
CAM 2 → mixer (18m)
Camera 2
Cameras
BNC · SDI Out
Control room
Monitors
SDI In · BNC

View menu


Fit to view
Zoom 100 %
Zoom in
Zoom out
Fullscreen
Theme: follow system
Light theme
Dark theme
Snap to grid
Hide cable labels
Show off-page names
Color cables by length
Color cables by discipline
Find device Ctrl+F
Canvas toolbar
Annotations panel
Floor plan
Symbols

Zoom

ENTRY	EFFECT
Fit to view	zooms so that all elements are visible
Zoom 100 %	sets the zoom to 100 %
Zoom in	zooms in
Zoom out	zooms out
Fullscreen	switches the window to fullscreen and back

The current zoom level is shown in the status bar.

Theme

ENTRY	EFFECT
Theme: follow system	light or dark according to the operating system
Light theme	always light
Dark theme	always dark

The same choice is offered by the theme button in the header (sun, moon or screen) and by ***Settings*** → ***Appearance***. The choice is remembered.



Grid and labels

ENTRY	EFFECT
Snap to grid	devices snap to the grid while being moved
Hide cable labels	hides the labels on the cables
Show off-page names	shows the cable number or cable name on off-page connectors permanently; without the option it appears only on mouse-over

A check mark in front of the entry shows that the option is on.



Color cables by length

Color cables by length colours the cables with the broadcast length colour code. The stored colour of each cable stays unchanged; a second click switches back.

LENGTH	COLOUR
1 m	red
2 m	yellow
3 m	green
5 m	white
10 m	red
20 m	yellow
25 m	yellow/white dashed
50 m	white
100 m	red

Cables of any other length appear grey.



Color cables by discipline

Color cables by discipline colours each cable by its discipline: Video blue, Audio red, Control orange, Network green, Power violet, Other grey. Here too the stored colour stays unchanged. The two colour modes exclude each other.



Search field, toolbar and panels

ENTRY	SHORTCUT	EFFECT
Find device	Ctrl+F	shows and hides the search field above the canvas
Canvas toolbar		shows and hides the canvas toolbar
Annotations panel		opens and closes the ***Annotations*** panel
Floor plan		shows and hides the floor plan panel
Symbols		shows and hides the symbols panel



The ***Annotations*** panel appears on the right. It filters by status with ***all***, ***offen***, ***gebaut*** and ***erledigt***; ***+ New annotation*** creates an annotation. ***Close*** hides it.



Help menu



ENTRY	SHORTCUT	EFFECT
Command palette...	Ctrl+K	opens the command palette
Keyboard shortcuts...	?	opens the keyboard shortcut overview
Getting-started tour...		starts the tour of the interface
Check for updates...		asks for a newer version and reports the result
About LZ Cable Planner...		opens the dialog with version and build

Command palette



The command palette lists the commands from ***Edit***, ***View***, ***File***, ***Tools*** and ***Help***; each command shows its group on the right, some a short description below. Commands of disabled modules are left out.

1. Open the palette with **Ctrl+K** or via ***Help*** → ***Command palette...***.
2. Type one or more search words. The search checks command name, group, short description and stored synonyms; every word must occur. Matches in the command name come first.



1. Pick a command with the arrow keys and run it with **Enter**.

Synonyms work in both languages: ***qr***, for example, finds ***Share to phone...***.



If nothing matches, the list shows ***No commands found***.

Keyboard shortcuts

Help → ***Keyboard shortcuts...*** or the **?** key opens the overview.

The ***Keyboard*** view shows a keyboard; highlighted keys have an action, shown on mouse-over or click. The ***List*** view lists all shortcuts. They include:

SHORTCUT	ACTION
Ctrl+N, Ctrl+O, Ctrl+S, Ctrl+Shift+S	New project, Open, Save, Save as
Ctrl+C, Ctrl+V	Copy, Paste
Ctrl+K	Command palette
Ctrl+F	Find device
Ctrl++	New device at cursor
Ctrl+B, Ctrl+I	Show/hide library or inspector
P	Open patch list
A	Toggle arrow display
?	this overview

Getting-started tour

The tour takes five steps through the interface: Library on the left, Properties on the right, Plan check, Export menu, Find any function. ***Next*** and ***Back*** page through it, ***End tour*** stops it. On the last step ***Open command palette*** ends the tour and opens the command palette. On the first start the tour opens by itself.



About LZ Cable Planner



The dialog shows:

- Version
- Build: date and time the program was built
- Author
- Repository (github.com/larszu/cable-planner)
- Platform (Electron, React, ReactFlow, Vite, Tailwind)
- the note to report issues and feature requests on GitHub

The same dialog opens when you click the version number on the right of the status bar.

Status bar

From left to right the status bar shows:

ELEMENT	MEANING	CLICK
Project name	name of the project	
devices, cables	count in the plan	
frames	number of room frames	
packed	devices marked as packed in their properties, e.g. ***0/5 packed***; grey for none, yellow for some, green for all	
Complexity	size estimate of the plan	
Plan check	result of the running plan check	opens the plan check
Rentman	connection to Rentman	
Zoom	current zoom level	
Version	program version	opens ***About LZ Cable Planner***

In a narrow window the status bar hides frames, packed and Rentman.

Complexity

The badge adds up devices and cables:

SUM	BADGE
below 8	New
from 8	Small
from 30	Medium
from 80	Large
from 200	XL

The badge is only a guide to readability and working speed.

Plan check

The badge has three states:

COLOUR	MEANING
green, ***OK***	no findings
yellow with a number	warnings only
red with a number	at least one error

The number is the sum of errors and warnings.

A click opens the plan check with all findings. Clicking a finding selects the affected element.



Notices that appear only when needed

BADGE	APPEARS WHEN	CLICK
Network with a number	there are network findings: missing or duplicate addresses, masks, segments	opens the analyses on the network tab
No recovery copy	the browser store refused the project's recovery copy; the plan itself is not affected, save it to a file	
Photos with MB	the photos in the plan exceed 40 MB; the file still opens but is hard to send by mail	
Due with a number	returns, check-outs, hours, receipts or costs are overdue or due today	opens the analyses on ***What is due***
Live with participant count	a live collaboration is running	opens the settings on the network sync tab
MCP	the local MCP server is running; next to it ***· read only*** or ***· can edit***, during an active request ***MCP · asking***	opens the settings on the MCP tab

Rentman indicator

The Rentman indicator appears only when the Rentman module is enabled. It shows the name of the linked Rentman project, otherwise ***Token ready*** when an access token is stored, otherwise ***Standalone***.

Phone access

The ***Phone access*** button in the header opens the dialog ***Mobile access***. It starts a small web server on the local network; a phone opens the mobile view of the project via the QR code.



ELEMENT	EFFECT
Feedback from the phone: ***Read only***	the phone cannot write anything back
Feedback from the phone: ***Contribute: ticks, cables, photos, new devices***	the phone may send back ticks, cables, photos and new devices
Start LAN server	starts the server and shows the QR code
Make system access codes retrievable	releases intercom access codes via a second code; selectable only for projects with an intercom configuration
Security notes	expands the security notes

The server stops when the app closes or via the Stop button. The mobile view is described in the chapter Web edition and tablet.



First start

On the first start with an empty project the dialog ***Welcome — what are you planning?*** appears.



1. Optionally choose one or more use cases. They enable the matching modules:

USE CASE	ENABLES THE MODULES
Show / Event	Mobile-Companion, Rentman
Fixed installation	Fixed installation, Mobile-Companion, NetBox
Rental	Rental / Stock, Rentman



1. Choose how to begin:

BUTTON	EFFECT
New project	opens the project metadata for a new project
Load example project	loads the example project and fits the view
Open project...	opens an existing `.cableplan` file
Decide later	closes the dialog

Without a use case the modules stay as they are. Everything can be changed under ***Settings*** → ***Modules***.

1. The Getting-started tour starts afterwards.



3. Canvas

The canvas is the working area on which devices stand, cables run and frames form rooms. This chapter describes the area itself, the floating toolbar, selection, drawing and editing cables, frames, floors, layers, operating modes, annotations, floor plan and plan symbols. The properties of a selected device, cable or frame are described in the chapter Inspector; the library on the left in the chapter Library.

The empty plan and the example project

A plan without devices shows the note ***No devices yet*** in the middle: drag a device from the library on the left onto the canvas. Below it is ***Load example project***.

1. Start with an empty plan.



1. Click ***Load example project***. The plan then shows Camera 1, Camera 2, Vision mixer, Multiviewer and Control room monitor with four cables. The following sections work on this example.



The area can be moved by dragging on empty ground, zoomed with the mouse wheel, and shows an overview map at the bottom right.

The toolbar

The toolbar floats at the top left above the plan. From left to right it contains:

- the grip for moving and the close button,
- ***Defaults*** (presets for new cables and the appearance),
- ***Frame***,
- ***Voice*** (create cables from a sentence),
- buttons for the selection while devices are selected (connect cables, save group, rack, align),
- the layer chips ***Video***, ***Audio***, ***Control***, ***Network***, ***Power***, ***Other*** and custom layers,
- the chip of the operating mode that is switched on (signal path, circuit, test pattern),
- ***More***.

Under ***More*** are the less frequent switches: ***Layers*** ⋯ (manage layers), ***Lock***, ***Schematic*** or ***Live***, ***Circuit***, ***Test pattern***, ***Finalise***, ***Badges***, ***Annotations***, ***Floor plan*** and ***Symbols***. The buttons ***Rooms*** and ***3D*** appear there as soon as the plan contains frames.



On a phone the toolbar shows only the grip, ***Defaults*** and ***More***; frame, layers and selection buttons are then under ***More***.

Moving, closing and reopening the toolbar

1. Drag the toolbar by the grip (six dots on the left) to another place.
2. The **×** next to the grip closes the toolbar.
3. Open the menu ***View***.



1. Choose ***Canvas toolbar***. The toolbar reappears.

Defaults

Defaults (tooltip: ***Default behaviour for new cables + appearance***) determines how new cables are created and how the plan looks. A dot on the button shows that at least one value has been changed.



GROUP	OPTION	EFFECT
Cable routing	***Ortho***	New cables run horizontally and vertically.
	Direct	New cables run in a straight line.
	Curved	New cables run as a curve.
Cable colour	***By type***	The colour comes from the cable type.
	By length	The colour depends on the length; the ***?*** button shows the legend ***Length colours***.
Other	***Arrow at cable end***	Newly drawn cables get an arrow.
	Cable bumps at crossings	Crossings are drawn as a small bump. This can be overridden per cable in the context menu.
	Hide all cable labels	The labels of all cables disappear; their position stays saved.
	Cable labels: short form	The format suffix (for example "(1080p50/60)") is removed from the display. The full name stays in the cable properties.
	Colour ports by connector type	Ports take the colour of their connector type (SDI amber, HDMI violet, Ethernet green and so on).

The routing applies to cables created afterwards. Cables already drawn keep their shape (see Editing cables).

1. Under ***Cable colour*** choose ***By length***. The cables appear in length colours.



1. The ***?*** button next to ***By length*** shows the legend ***Length colours***: 1 m red, 2 m yellow, 3 m green, 5 m white, 10 m red, 20 m yellow, 25 m yellow/white dashed, 50 m white, 100 m red. ***Close*** hides it.



1. ***Cable bumps at crossings*** draws a bump at crossings.



1. ***Colour ports by connector type*** colours the ports by connector type.



In addition, the entry ***Color cables by discipline*** in the ***View*** menu colours the cables by their layer (video, audio and so on).

Selecting devices

- **Click** on a device selects it; the inspector on the right shows its properties.
- **Shift**, **Ctrl** or **Cmd** plus click adds further devices or removes them again.
- Holding **Shift** and dragging on empty area draws a selection rectangle.
- ***Edit*** → ***Select all*** selects all devices.
- A click on empty area clears the selection.

1. Click Camera 2.



1. Click the Vision mixer while holding Shift.



1. Drag a rectangle over several devices while holding Shift.



1. ***Edit*** → ***Select all*** selects all five devices.

As soon as devices are selected, the buttons for selection actions appear in the toolbar and the selection bar appears above the selection.

Aligning devices

The align buttons are in the toolbar as soon as at least one device is selected. All results snap to the grid when ***Snap to grid*** is on.

BUTTON (TOOLTIP)	WITH ONE DEVICE	WITH SEVERAL DEVICES
Left align / ***Align to left viewport edge***	At the left edge of the visible area	Left edges flush
Centre horizontally	In the middle of the visible area	On a common vertical centre axis
Right align	At the right edge of the area	Right edges flush
Top align	At the top edge of the area	Top edges flush
Centre vertically	In the middle of the area	On a common horizontal centre axis
Bottom align	At the bottom edge of the area	Bottom edges flush
Distribute horizontally	–	From three devices: equal gaps
Distribute vertically	–	From three devices: equal gaps

1. With one device selected, ***Align to left viewport edge*** aligns it to the edge of the visible area.



1. Select Camera 2, Vision mixer and Multiviewer and click ***Left align***.



1. ***Distribute horizontally*** evens out the gaps.



Aligning can be undone with ***Edit*** → ***Undo***.

Saving a device group

The button ***Save N selected devices as a group*** stores the selection with its cables as a template. The group then appears in the library under ***Groups*** and can be dragged onto the plan.

1. Select several devices and click the button with the three rectangles. The field ***Group name…*** appears in the toolbar.

1. Enter a name and click the green tick (***Save group***). The group appears in the library under ***Groups***.



1. If the name already exists, the app asks ***A template named "…" already exists. Overwrite?*** With ***Overwrite*** you replace the template.

Arranging the selection in the rack builder

The button ***Arrange the N selected devices in the 2D rack builder*** opens the rack builder with the selection (the device context menu has the same as ***Arrange in rack builder***). If the selection already contains a rack, the button is missing; if exactly one rack is selected, the button ***Edit this rack in the 2D***

rack builder opens the builder for that rack instead. The builder itself is described in the chapter Rack Builder.



Several cables between two devices

When exactly two devices are selected, the toolbar shows the button ***Connect cables*** (tooltip: ***Create several cables between the two selected devices at once***). Without a selection, ***Tools*** → ***Connect multiple cables...*** opens the same dialog with two lists for source and target.

1. Select two devices, for example Camera 2 and Vision mixer.
1. Click ***Connect cables***. The dialog ***Connect multiple cables*** explains: it creates N cables at once, source port i → target port i; occupied target ports are skipped.



FIELD	MEANING
Source* → *Device*, *Side	Device and side (***Outputs*** or ***Inputs***) the cables start from.
Start Outputs (1..n)	Number of the first source port.
Target* → *Device*, *Side	Device and side (***Inputs*** or ***Outputs***) where they end.
Start Inputs (1..n)	Number of the first target port.
Cable count	How many cables are created.
Cable type	The cable type of all new cables; the colour comes from the type.
Length per cable (m)	Length of all new cables.
Preview (x/y cables)	Lists the pairs. If the count exceeds the free ports, it says ***Count exceeds available ports — extras are skipped.***

1. Set ***Start Inputs*** and ***Cable count***. The preview shows which pairs are created.



1. Click ***Create N cables***. A message states how many cables were created and how many were skipped (***target port occupied or invalid***).



Cables by voice

The button ***Voice*** (tooltip: ***Create cables from a spoken or typed sentence***) opens the dialog ***Cable by voice***. A sentence of the form "<source> to <target>" is read against the names of the devices, their rooms and ports in the plan. There is no language model and no network connection. Separate several cables with a full stop.

1. Click ***Voice***. The input field is active; with the microphone button you dictate if speech recognition is available, otherwise you type or use system dictation (macOS: press Fn twice, Windows: Win+H).

1. Enter a sentence, for example "SDI 1 from Camera 1 to Vision mixer In 3".

1. Click ***Preview*** or press Enter. For each sentence the preview shows source device and port, target device and port. Every choice can be changed. The button at the bottom gives the number of ready cables (***Connect N cables***).



1. Several sentences appear one below the other. A sentence without a match shows ***No match - pick a device***; as long as nothing is chosen there, it does not count. If several devices fit, the preview asks ***Which one? (n match)***. If a named device exists only in the library, the preview offers ***Add from library: name***; it is created in the plan when connecting. If a target port is occupied, the preview asks ***This input already has cable .... Replace it?***. If the signal families do not fit, a note says a converter is probably needed and a converter can be inserted.



1. ***Connect N cables*** creates the cables in one step. One undo takes all of them back.



Keyboard shortcuts on the canvas

KEY	EFFECT
Click, Shift/Ctrl/Cmd + click	Select, add to the selection
Arrow keys	Move selected devices by one grid cell
Shift + arrow keys	Move by four grid cells
Ctrl/Cmd + C, Ctrl/Cmd + V	Copy and paste selected devices
Ctrl/Cmd + D	Duplicate the selection
Ctrl/Cmd + Plus (or =)	Create a new device at the mouse position; a dialog asks for the name. The device gets the category ***Other*** and no ports.
Delete or Backspace	Delete the selection (devices and cables together in one step)
Esc	Cancel a cable being drawn
Ctrl/Cmd + F	Device search

The keys have no effect while the cursor is in a text field.

1. Ctrl/Cmd + Plus asks for the name of the new device.



Drawing cables

Cables are created by dragging from one port to another.

1. Press the port dot of an output (for example SDI Out of Camera 2) and drag it onto a free input (for example In 3 on the Vision mixer).



1. On release the dialog ***New cable*** opens. At the top are ***From:*** and ***To:***. The list ***Cable*** shows all cable types; ✓ marks types that fit both connectors, ✕ those that do not. ★ ***Custom cable…*** creates a custom type. Further fields are ***Signal standard***, ***Name***, ***Length (m)***, ***Colour*** and ***Notes***; a green note confirms that the type fits the connectors (for example ***SDI 3G (1080p50/60) fits BNC ↔ BNC.***).



1. Choose a type and click ***Create***. The cable appears with label and length.



Special cases when dragging:

- An **occupied input** is not silently overwritten. After ***Create*** the app reports ***Port already in use*** and names the existing cable. ***Replace*** removes the existing cable and creates the new connection, ***Cancel*** discards the new connection and everything stays as it is.



- Releasing **on empty area** gives an open end: the app creates a device "Open ..." there with a port ***Open End*** of the same connector type and opens the dialog ***New cable*** for it.



- Releasing **on the body of another device** creates a matching new port there and connects it. This also allows cabling a device that has only a name so far.



- **Two clicks instead of dragging:** a click on a port starts the cable; clicks on empty area set bends, a click on a port finishes it. The banner says ***Draw cable: tap the canvas for a bend, tap a port to finish. Undo bend*** takes back the last bend, ***Cancel*** discards the cable; Esc also cancels. An input can only be connected to an output, not to another input. While the cable is pending, the right side shows ***Quick suggestions (connector type)***: up to eight library devices with a matching port, those most often connected in the project first. A click on a suggestion places the device at the mouse position and finishes the cable at the first matching port.



The defaults for ***Cable routing*** and ***Arrow at cable end*** from Defaults apply to every new cable.

Editing cables

A click on a cable selects it; the inspector shows its properties, a double click opens the edit dialog. Handles appear on the selected cable.

1. Click a cable.



1. Drag a segment to move the route.

1. Drag a corner to relocate the bend.



1. A right click on the cable opens the cable menu.



ENTRY	EFFECT
Change label…	Asks for the label of the cable.
Add annotation…	Attaches an annotation to the cable.
Accept into plan (mobile suggestion) / ***Remove mobile check***	Only for cables suggested or ticked off from the phone.
Measure signal	Opens the scopes for the stream the device sends at the start of the cable. Greyed out when the source device has no stream the app can open (RTSP, RTMP, SRT, HLS, MJPEG; Properties → Streams).
Add waypoint here	Inserts a waypoint at the click point.
Remove nearest waypoint	Removes the waypoint closest to the click.
Clear all waypoints (n)	Removes all waypoints of the cable.
Auto-reroute	Calculates the route again.
Routing: Orthogonal / ***Direct*** / ***Curved***	Sets the shape of this cable.
Cable jumps for this cable	Overrides the global setting; ***Remove override (follow global)*** takes that back.
Arrow at end, ***Arrow at start***	Shows or hides the arrow.
Bidirectional	Turns arrows at both ends on or off.
Create off-page connection…	See Off-page connectors.
Delete cable	Asks ***Delete cable "…"?*** and removes it after confirmation.

1. A double click on a cable opens the dialog for editing the cable; its fields are described in the chapter Inspector.



Off-page connectors

An off-page connection replaces the continuous line of a cable at each end with a small connector symbol. This keeps plans readable in which two devices are far apart. All off-page cables with the same net name form a net.

1. Right click the cable, ***Create off-page connection…***. The app asks ***Net / signal name for the off-page connection:***; the cable name is prefilled.

1. With ***OK*** the cable becomes an off-page connection. Each connector symbol names the counterpart (***device · port***); an arrow shows the signal direction. A click on the arrow jumps to the nearest counterpart.
2. The net name appears when you point at the symbol; the entry ***Show off-page names*** in the ***View*** menu shows it permanently.
3. A right click on a symbol opens the net info: number of endpoints, a jump list and ***Resolve off-page (show line)***, which restores the line.

Frames

A frame is a coloured rectangle that groups devices into a place or room. The button ***Frame*** in the toolbar creates a new frame ("New location") in the middle of the visible area. If devices are selected, the button has the tooltip ***Frame around the N selected devices*** and draws the frame around them.

1. Click ***Frame*** without a selection.



1. A double click on the frame asks ***Rename location:***.

1. A click on the frame shows the frame properties in the inspector (name, width, depth, area, floor, colour, riser, room number, address, notes); they are described in the chapter Inspector.

1. Change the size with the handles of the selected frame.

1. Drag the frame by its title. Devices whose centre lies inside the frame move with it.



1. The lock at the frame title blocks moving and resizing; the settings stay reachable.

1. A right click on the frame opens the menu with ***Lock position*** (or ***Unlock position***) and ***Delete frame***.



1. ***Delete frame*** asks ***Delete frame "..."?*** — only the frame disappears, the devices stay.

1. Select several devices and click ***Frame*** to draw a frame around them.



Rooms, floors and the 3D building view

Every frame is a room. Frames can be assigned to floors; floors determine visibility in the plan and stacking in the 3D view. The buttons ***Rooms*** and ***3D*** are under ***More*** as soon as the plan contains at least one frame.

1. Create frames (here Studio, Control room, Machine room).

1. Select a frame. In the inspector, the entry ***Add floor…*** in the ***Floor*** selection opens the prompt ***Name of the new floor (e.g. "3rd floor")***.



1. The floor is then in the ***Floor*** field.

1. In the inspector, the section ***Floors (n)*** shows the floors from bottom to top with their floor level in metres; the arrows change the order, the bin removes a floor, ***Add floor…*** adds another.



1. ***Riser / vertical cable route*** marks a frame that runs through all floors in the 3D view; cables between floors then run through it instead of as a straight line.

1. ***More*** → ***Rooms*** opens a list grouped by floor (topmost first). Each floor and each room has a tick; rooms without a floor are under ***Without floor***.



1. Remove the tick of a room: its devices and cables disappear from the plan. The button then reads ***Rooms (n hidden)***.

1. The tick of a floor hides all rooms of that floor.

1. ***Show all*** shows everything again. Several rooms can be hidden at the same time.

1. ***More*** → ***3D*** opens ***Building 3D***: the rooms stacked by floor, with the connections in between.



1. Under ***Show*** you switch between ***Room connections*** and ***Single cables***.



1. ***Labels*** shows or hides the names. ***Storey height (m)*** applies only to floors without an entered height; the view points out that this is an assumption.

Devices can be dragged in the 3D view. Floor boxes appear as a flat plate in the floor, other devices as cubes. Dragging beside a device rotates the view, the mouse wheel zooms.

Layers

The layer chips show and hide the cables of a layer. Only the cables are filtered, the devices stay. A coloured dot marks the signal type; the tooltip gives the number of cables (for example ***Video — 4 cables · visible (click to hide)***).

1. The toolbar shows ***Video***, ***Audio***, ***Control***, ***Network***, ***Power*** and ***Other***.



1. Click ***Video***: the video cables disappear.



1. ***More*** → ***Layers*** ⋯ opens the management menu: ***Create custom layer...*** and ***Show all layers again***.



1. ***Create custom layer...*** asks for the name (for example "intercom"). The new layer appears as a chip with a diamond symbol.

1. A right click (on a phone a long press) on the chip of a custom layer asks ***Remove custom layer "..."?***.

Signal path

The signal path highlights the whole chain a cable is part of and dims the rest.

1. Select a cable.

1. Click ***Show signal path*** in the inspector.



1. The toolbar shows the chip ***Signal path: n cables, m devices***. A click on it or Esc ends the view.

Operating modes: schematic, circuit, test pattern

Schematic and live

The button ***Schematic*** under ***More*** shows where the plan gets its picture from: ***Schematic*** means it is the planned path without a connection to an installation; ***Live*** means the observed state of a switcher or router is shown (with its age in seconds). If the connection drops, it says ***· connection lost*** and the view falls back to the planned path. A click on the chip does not change the mode but turns the motion of the display on or off; if the operating system has motion turned off, the view stays still.

Circuit

Circuit calculates electrical circuits: which luminaires are lit, which switch positions apply, which lines are live. The result is calculated, not measured; the switch positions are not part of the plan. Only devices that carry a circuit type in their properties are taken into account; it is never guessed from the category. If no device with a type is in the plan, the chip shows ***· nothing declared***.

1. Switch ***Circuit*** on. The chip gives the lit luminaires out of all luminaires (for example "1/1").

1. ***Reset switches*** puts all switches back to their default; the plan does not change. ***Suggestions*** explains why the circuit does not do what it should and which wire would change that; every suggestion brings its truth table, nothing is entered without a click.

Test pattern

Test pattern is an expectation, not a video image: after choosing a source, the plan shows at every arrival point which image should be there. The app does not see what actually arrives.

1. Open ***More*** and choose a source under ***Test pattern*** (the list contains every device with an output, first ***none***).

1. The plan shows the test pattern at the source and at every arrival point, labelled ***Expected per plan***. The toolbar shows the chip ***Test pattern*** with the source, the number of arrival points and the counters ***· n open***, ***· n swapped***, ***· n unchecked***.



1. At each arrival point you record what you saw on site: ***correct***, ***different image…*** (then the name on it, and ***record***), ***no image*** or ***no monitor***. The finding is then shown in colour at the arrival point (correct, still open, swapped or another deviation) and feeds into the counters of the toolbar.



1. ***Save...*** offers three files: ***Test pattern image (SVG)*** for a media player, the switcher stills store or a laptop (the app feeds nothing in), ***Check sheet (CSV)*** as a walk-around list, also with paths the plan cannot follow to the end, and ***Sign-off sheet (CSV)*** with what was seen, including the time.

1. ***Switch path...*** appears when a router lies on a path of the source. The dialog sets the crosspoints of the plan on the live installation.

Under ***Where should the image go?*** you choose the target; the dialog shows the path (for example Camera 1 → Videohub 12x12 → Control room monitor) and the commands sent. If no control protocol is declared for the device (Properties → Control), nothing is sent. ***Switched by*** records a name. ***switch now*** is only possible if the plan contains commands, nothing is in the way (for example a missing control protocol) and the tick ***I have read which outputs will be switched, and I am switching the live installation.*** is set.

The choice ***none*** ends the test pattern.

Locking

More → ***Lock*** protects against accidental moves. The menu has three switches:

SWITCH	EFFECT
Frames	No frame moves
Devices	No device moves
Cables	No waypoint editing (the handles on the cable disappear)

The button shows the number of active switches (for example ***Lock 1/3***).

1. Open ***Lock***.



1. Switch ***Devices*** on. The devices can no longer be dragged.



1. With ***Cables*** locked, a selected cable shows no handles.



Individual devices and frames can also be fixed with ***Lock position*** in the context menu.

Finalising the plan

More → ***Finalise*** locks the whole plan: no moves, no new connections, no deletions. The entry then reads ***Finalised***.

1. Click ***Finalise***. The app asks ***Finalise plan?*** and explains that the canvas will be locked and that the lock can be lifted at any time.



1. After ***Finalise***, the banner ***Plan is finalized — changes are locked.*** appears above the plan with the button ***Release for editing***.



1. ***Release for editing*** asks ***Re-open the plan for editing?***; ***Release*** lifts the lock. The entry under ***More*** asks ***Re-enable plan editing?*** (***Re-enable***).

A viewer file (`.cpviewer`) is permanently read-only; the entry then reads ***Viewer*** and cannot be operated.

Annotations

Annotations are notes on the plan, free or attached to a device or cable. Two entries under ***More*** belong to them: ***Badges*** shows or hides the markers of the annotations on the plan (the data stays), ***Annotations*** opens the panel.

1. Open ***Annotations***. The panel shows the filters ***all***, ***open***, ***built***, ***resolved*** at the top and the button ***+ New annotation***.



1. Click ***+ New annotation*** and write the text.

1. ***Add*** asks for your name the first time; it is attached to all annotations you create.

1. The annotation is then in the list.



1. Each annotation has a status (***open***, ***built***, ***resolved***); the filters show only the annotations of one status.

1. The button for placing at the canvas centre puts the marker in the middle of the plan; drag the handle of an annotation onto a device to attach it there.



1. A click on the marker on the plan shows the annotation.

1. ***Badges*** hides the markers.

1. Deleting asks ***Delete annotation?***.

A right click on a device or cable also offers ***Add annotation…***: after asking for the text (and the first time for your name) the annotation is attached to the device or cable. In viewer mode the entry ***Annotations*** invites reviewers to leave notes (tooltip: ***Annotations — leave reviewer notes***).

Floor plan

More → ***Floor plan*** (also in the ***View*** menu) puts an image or a PDF under the plan. It serves as a scale for cable lengths and as a spatial template.

1. Open ***Floor plan***. The panel offers ***Load floor plan image or PDF…***, ***Import venue from MultiCam / Light Planner…*** and the note that an image or PDF can also be dropped here or onto the canvas.



1. Load an image (PNG, JPG, WebP, GIF, BMP or AVIF up to 40 MB). It lies under the devices. The app says ***Floor plan loaded. Set the scale next — until then lengths use "metres per 100 px".***



1. ***Opacity*** controls how strongly the image shows through.

1. ***Lock position (clicks go through to the devices)*** makes the image insensitive to clicks.

You set the **scale** in two ways.

1. ***Two points*** (for plans seen from above, CAD export, scan): enter the known distance in metres and click ***Two points***. The app says ***Click both ends of a distance of N m.***

1. After the second click the panel says ***Scale from N m reference: … cm per canvas pixel.***



1. ***Four corners*** (for photos, signs and isometric drawings): enter width × depth of a rectangular floor area in metres and click the four corners in turn: top left, top right, bottom right, bottom left. If the points do not form a rectangle, the app says so.



1. Afterwards the panel says ***Perspective scale from a W × D m area.***

1. ***Recalculate cable lengths*** determines the lengths along the drawn routes (***n cable lengths recalculated along their drawn routes.***).

1. ***Replace image...*** asks ***Replace the floor plan?*** — the scale calibration is lost and has to be set again.

1. A file that is not an image is rejected by the app: ***This file is not a floor plan image. Use PNG, JPG, WebP, GIF, BMP or AVIF.***

PDF. A PDF is loaded as an image of the page. If it has several pages, the panel shows ***PDF page*** with the page number and ***of n***; another page replaces the plan in the same place with the same opacity.

1. Load a PDF.

1. Choose another page.



1. ***Crop...*** opens a preview in the panel with the note ***Drag a rectangle over the part of the plan you want to keep.*** Draw the rectangle and click ***Crop plan***; ***Cancel*** discards it.



1. The plan now shows only the chosen part.



One plan per floor. As soon as the plan has floors, the panel shows the selection ***Floor*** at the top with ***All floors*** and the floor names; each floor has its own floor plan. For cable lengths the scale of the plan applies to all floors (***Cable lengths use the scale of the plan for all floors.***).

Venue exchange. ***Import venue from MultiCam / Light Planner…*** reads a venue file of the sister apps including floor plan and scale. The panel reports error cases: ***This is not a venue exchange file (MultiCam / Light Planner).***, ***The venue file carries no floor plan image.***, ***The venue file carries a floor plan without real dimensions. Export venue for MultiCam / Light Planner*** writes the plan back; the exchange carries one scale per plan, so the button is disabled after a four-corner calibration.

1. ***Remove floor plan*** takes the image away again.

Plan symbols

More → ***Symbols*** (also in the ***View*** menu) opens the panel ***Symbols*** with plan symbols that are not devices: sockets, detectors, loudspeakers, network outlets and the like.

1. Open ***Symbols***. At the top are the categories ***Electrical***, ***Intrusion alarm***, ***Fire alarm***, ***Voice alarm / PA***, ***IT / network***, ***Automation***, ***AV*** and ***Custom***; below are the search field ***Search symbols…*** and the symbols of the category.



1. Each category contains fixed symbols, for example under ***Electrical*** socket outlet, socket outlet with protective contact, switch, push button, luminaire, distribution board, fuse, residual current device, energy meter, earth, motor, transformer, junction box and CEE socket; under ***AV*** camera, monitor, projector, projection screen, stage box, rack, floor box and cable ramp.



1. A click on a symbol (tooltip ***Place on the canvas***) puts it on the plan.



1. A selected symbol has the fields ***Label***, ***Size***, ***Rotation*** (0°, 90°, 180°, 270°), ***Lock position*** and ***Delete symbol***.



1. ***Import symbol (SVG, PNG, JPG, WebP)…*** stores your own symbols under ***Custom***. SVG may be at most 200 KB, raster images at most 512 KB. An unused custom symbol can be removed from the library again with the **×** on its tile.

1. With an AI provider set up, ***Generate symbol*** creates a symbol from a description and stores it under ***Custom***. The app points out that the result must be checked: it is a model's drawing, not a standard symbol.

1. ***Symbol list as CSV (n)*** exports the placed symbols with category, count and labels.



Device search

Ctrl/Cmd + F or ***View*** → ***Find device*** opens the search bar ***Find device...*** above the plan. It can be moved, collapsed to a pill and closed (***Close search***); Ctrl/Cmd + F and the ***View*** menu bring it back.

1. The search sits as a pill above the plan.



1. Ctrl/Cmd + F expands it.

1. Type a term. The list shows matches with the field in which it was found. Searched are name, short name, IP, MAC, VLAN, asset no., internal no., serial number, label code, switch port, category, subtitle and note.



1. A click on a match centres the plan on the device and closes the search. Without matches it says ***No matches***.



Zoom and navigation

At the bottom left are the controls for zooming in, zooming out, fit view and the button for locking the interaction. At the bottom right the overview map shows the whole plan; a click on it or dragging jumps to the place. The mouse wheel zooms between 10 % and 400 %; dragging on empty area moves the plan. The ***View*** menu offers ***Fit to view***, ***Zoom 100 %***, ***Zoom in***, ***Zoom out*** and ***Fullscreen***.



1. ***Zoom in*** zooms in.

1. ***Fit to view*** shows all devices.



1. The lock button locks the interaction: the plan can then neither be moved nor zoomed.

1. ***View*** → ***Zoom 100 %*** resets the scale.

Context menus

Device (right click on a device):

ENTRY	EFFECT
Open rack editor	Only for a rack: opens the rack builder for it.
Add annotation...	Asks (the first time) for your name and for the text and attaches the annotation to the device.
Device datasheet...	Opens the datasheet (one A4 page) for the device or the selection.
Scopes... / ***Compare scopes***	Only in the desktop app and when the devices have streams the app can open.
Arrange in rack builder / ***Arrange N devices in rack builder***	Opens the rack builder with the device or the selection.
Lock position / ***Unlock position***	Keeps the device in its place.
Delete device	Asks ***Delete device "..."?*** — the device and all connected cables are deleted.



Empty area: a right click offers ***New device here ...***. It opens ***Create your own device*** with name, category, port groups and the buttons ***Save to library***, ***Place in project only*** and ***Save + place***; the dialog is described in the chapter Create your own device.

Cable and **frame:** see Editing cables and Frames.

Selection bar at the device

Above a selection a small bar with quick actions appears.

SELECTION	BUTTONS
One device	***Duplicate***, ***Frame around selection***, ***Device datasheet (A4 PDF / print)***, ***Delete***
Two devices	additionally the six align buttons
Three and more devices	additionally ***Distribute horizontally*** and ***Distribute vertically***

For devices with readable streams, ***Compare scopes (one parade per source)*** is added.





Still image under the device

For a device that delivers a stream or a still image, the canvas shows a tile under the device. It is switched on in the inspector under ***Streams*** (***Show a still image under the device on the canvas***, with a ***Still image address for the preview***). The tile does not start by itself: ***Start preview · name*** fetches a still image, then every 10 seconds while the tile is visible. For a live stream the tile plays it until ***Stop live*** is chosen. The tile names the reason when no image arrives, for example ***No preview: the address is not in the local network.***, ***No preview: ffmpeg was not found …*** or ***No preview: the device cannot be reached.*** Still images are fetched by the desktop app only.



Adapters and converters in the cable

When a cable is created, the app checks whether the connectors fit together. The dialog ***New cable*** then names the reason and what belongs in between:

- same gender at both ends: a gender changer,
- connectors that do not mate: an adapter,
- different signal families: a converter, a device with power and a bandwidth limit that you choose yourself.

After creating the cable, the inspector of the cable offers ***Insert***; it puts the adapter into the run as a device of its own (***Insert it into this run — one undo step removes it again***). An adapter belongs in the plan as a device, otherwise it is neither in the signal path nor on the pick list.


New cable
From: Line Out (Jack 6.35 mm TS)
To: Line In 2 (Jack 3.5 mm TRS)
Cable
★ Custom Cable...
No matching cable type in the catalog. Please deliberately choose a connector/standard below or create a new cable type — otherwise only a generic custom cable is created.
Custom Cable Definition
Connector Type
Jack 6.35 mm TS
Signal Standard
Generic
Recommended Max Length (m)
optional
Save as cable type...
Name
Custom Cable
Length (m)
1
Colour
Notes
Benutzerdefiniertes Kabel ohne Katalog-Preset.
This needs a piece in between. Create the cable, then insert it with one click in the cable properties.
Cancel
Create

4. Library

The library is the column to the left of the plan. It holds the templates the plan is built from: devices (local, from the shared device library and from Rentman), cable types, device groups and racks. Templates are put on the canvas with a click or by dragging; the properties of an entry appear in the Inspector.



The library column

The head of the column has the arrow ***Hide library*** on the left and the ***Window*** menu next to it. Below are the four tabs ***Equipment***, ***Cables***, ***Groups*** and ***Racks***; for groups and racks a number shows how many entries there are.

1. The arrow at the top left hides the column and gives the width to the plan.



1. A button ***Show library*** appears at the edge; it brings the column back.

1. The ***Window*** menu offers ***Undock (floating)*** and ***Open in its own window***.
   The button can also be dragged.



1. Undocked, the library floats above the plan; ***Dock*** (back to the side column) puts it back in its place.



1. You change the width of the column by dragging its divider to the plan (***Resize column***).



Equipment

The ***Equipment*** tab has three sub-tabs for the source of the templates: ***Local*** (own and imported templates plus the built-in catalogue), ***Shared*** (the shared device library, read-only) and ***Rentman*** (only when the Rentman module is on).

Local

The sub-tab ***Local*** shows the templates by category. Each category is a collapsible strip with the number of entries; a click opens or closes it.



Each entry shows the name and below it the category with the number of inputs and outputs. The **L** before the name marks a local device (not from Rentman). A click selects the entry and shows its template in the Inspector; a double click or dragging onto the canvas places the device. When you point at an entry, four buttons appear:

BUTTON	EFFECT
Star (***Mark as favorite*** / ***Remove favorite***)	Highlights the entry with a star.
Eye (***Hide*** / ***Show again***)	Hides the entry from the list; with ***Show hidden*** in the filter menu it reappears dimmed.
Arrow down (***Export***)	Saves the entry as a file (`.cpdevice`) in the Downloads folder.
Red × (***Remove from library***)	Asks "Remove … from the library?" and deletes the template after ***OK***.


Window
Library
Equipment
Cables
Groups 3
Racks 1
Local
Shared
Rentman
Search... Ctrl+F
Audio 22
Allen & Heath Avan...
Audio · 16 in / 14 out
Allen & Heath dLive...
Audio · 36 in / 17 out
Allen & Heath DX168
Audio · 18 in / 8 out
Allen & Heath SQ-5
Audio · 19 in / 14 out
Behringer S16
Audio · 18 in / 11 out
Behringer S32
Audio · 34 in / 21 out
Behringer Wing
Audio · 24 in / 17 out
Behringer X32
Audio · 42 in / 26 out
Behringer X32 Com...
Audio · 20 in / 12 out


Window
Library
Equipment
Cables
Groups 3
Racks 1
Local
Shared
Rentman
Search...
Ctrl+F
Audio
22
Remove favorite
Allen & Heath Av...
Audio · 16 in / 14 out
Allen & Heath dLive...
Audio · 36 in / 17 out
Allen & Heath DX168
Audio · 18 in / 8 out
Allen & Heath SQ-5
Audio · 19 in / 14 out
Behringer S16
Audio · 18 in / 11 out
Behringer S32
Audio · 34 in / 21 out
Behringer Wing
Audio · 24 in / 17 out
Behringer X32
Audio · 42 in / 26 out
Behringer X32 Com...
Audio · 20 in / 12 out



Searching

The search field above the list filters in real time by name and category. It carries the hint ***Ctrl+F***: while the sub-tab ***Local*** is open, Ctrl+F puts the cursor in this field. The × in the field clears the search term.



If the search finds nothing, it says ***No devices found*** with ***Clear search***.



Filter menu

The funnel symbol opens the filter menu.



ENTRY	EFFECT
Collapse all categories / ***Expand all categories***	Closes or opens all categories at once.
Sorting → ***Manual (drag & drop)***	The categories stand in the order you drag them into.
Sorting → ***Alphabetical A*** → ***Z*** / ***Z*** → ***A***	Sorts the categories by name.
Show hidden (n)	Shows the hidden entries dimmed; the number says how many there are.
Show empty categories	Also shows categories without entries.
Only own material	Shows only devices that match the own inventory (by model). The entry is greyed out as long as the inventory contains nothing matching.


Window
Library
Equipment
Cables
Groups 3
Racks 1
Local
Shared
Rentman
Search...
Ctrl+F
Audio
Collapse all categories
Sorting
Manual (drag & drop)
Alphabetical A → Z
Alphabetical Z → A
Show hidden (1)
Show empty categories
Only own material
Behringer S16
Audio · 18 in / 11 out
Behringer S32
Audio · 34 in / 21 out
Behringer Wing
Audio · 24 in / 17 out
Behringer X32
Audio · 42 in / 26 out
Behringer X32 Com...
Audio · 20 in / 12 out


Window
Library
Equipment
Cables
Groups 3
Racks 1
Local
Shared
Rentman
Search...
Ctrl+F
Expand all categories
Sorting
Manual (drag & drop)
Alphabetical A → Z
Alphabetical Z → A
Show hidden
Show empty categories
Only own material
Audio
Cameras
LED Processing
Lenses
Lighting
Microphones
Monitors 39
Networking 60
Patch panels 8
Tripods 49
Video 24
Control 3


Window
Library
Equipment
Cables
Groups 3
Racks 1
Local
Shared
Rentman
Search... Ctrl+F
Expand all categories
Sorting
Manual (drag & drop)
Alphabetical A → Z
Alphabetical Z → A
Show hidden
Show empty categories
Only own material
Wireless
Video Router
Video Mixer
Video Converter
Video
Tripods
Sync/Reference 4
Power distribution 6
Patch panels 8
Networking 60
Monitors 39
Microphones 184



Categories

Categories order the templates. A pencil appears when you point at the category strip.

1. The pencil opens ***Rename category***. The window has two fields, ***English*** and ***German***; when the interface language is switched, the respective name appears. An empty field is allowed, the display then falls back to the other language.



1. With the grip to the left of the name you drag a category to another place (with the sorting ***Manual***).



1. Entries can be dragged onto another category; an empty category says ***Drag a device here to move it***.

1. New categories are created with the **+** menu (see below).



The + menu

The **+** button next to the search field (tooltip: ***Create new device or category***) opens a menu with five entries.



ENTRY	EFFECT
New device...	Opens the dialog Create your own device.
New category...	Shows a field ***Category name...*** in the list; ***OK*** creates the category, × cancels.
Import file...	Reads a `.cpdevice` or `.cpgroup` file (see below).
Submit templates...	Opens the dialog Submit templates.
Open library folder...	Opens the folder of the library in the file manager.

1. ***New category...*** shows the name field above the list.



1. After ***OK*** the category is in the list and can be named in both languages with the pencil.



Create your own device

New device... opens the dialog ***Create your own device***. It is a single continuous form without tabs. A right click on empty area of the plan (***New device here ...***) and the key combination Ctrl/Cmd + Plus on the plan lead to the same form or to a name dialog respectively.



FIELD	MEANING
Name	Name of the device. While you type, the form lists matching devices of the library (name, category, number of inputs and outputs) with ***Use as template***.
Category	Choice from the existing categories; ***+ New category...*** creates another one. The default is ***Other***.
19" rack device → Is a rack device	Marks the device as a rack device; the field ***U*** for the height then appears.
Recognise ports from a photo	Appears as soon as an AI provider is set up; otherwise the note says to enter one under ***Settings → Integrations → AI***, with the button ***Open settings***.
Guess the ports from the device name	The buttons ***Fill in*** (fills the port groups from the source chosen in the settings) and ***Datasheet...*** (reads the port groups from a PDF, HTML or text file). The source is named next to it: ***from a web search — no API key needed*** or ***from the AI model — needs an API key***. ***Add API key (AI)*** opens a field for the key; it is stored locally only.
Port groups	The connectors in groups. ***+ Input group*** and ***+ Output group*** add a row.

A port group has four entries: the direction (***Input*** or ***Output***), the count, the connector type and the name (label prefix). When saving, individual ports are created from them. A group without a count produces no ports; the message ***No ports yet — that is fine.*** says that ports can also be added later: a cable dropped onto the device adds one.

1. Type a name. Matching devices of the library appear below the field.



1. ***Use as template*** takes over category and port groups of the entry; the name gets the suffix ***(copy)***. The form says ***Fields taken from "...". Adjust what differs.***



1. With the tick at ***Is a rack device*** the field ***U*** appears.



1. ***+ Output group*** adds another row; the red × removes a group.



Four buttons are at the bottom:

BUTTON	EFFECT
Cancel	Closes the dialog without saving.
Save to library	Stores the template in the local library (for re-use); the device does not go onto the plan.
Place in project only	Puts the device into this project without creating a template. Meant for loan gear, placeholders and one-offs; nothing is uploaded.
Save + place	Both.

With photo recognition the section ***Recognise ports from a photo*** appears: ***Choose photos*** or ***Take photo*** (photos of the connector side can also be dropped or pasted; they are sent to the chosen provider for recognition), ***Recognise***, ***Remove photo*** and the tick ***Keep the photos on the device when placing it***. The suggestions stand as a table (***Include***, ***Direction***, ***Count***, ***Connector***, ***Label***, if needed ***Read as: …***); unsure rows are unticked and marked ***unsure***. If the app recognises the model, it names the catalogue device with datasheet ports (***In the catalogue with datasheet ports: …***) and offers ***Place catalogue device***. ***Apply N port group(s) to the form*** enters the chosen rows into the port groups.

Import file

Import file… reads only `.cpdevice` and `.cpgroup` files (the format ***Export*** writes entries in).

1. After choosing the file, the app says ***Device imported: "…" was added to the library.***

1. If the name exists, it asks ***A device named "…" already exists. Overwrite?*** — ***Cancel*** or ***Overwrite***.



1. Any other file is rejected by the app: ***File not recognised: This file is not a valid .cpdevice or .cpgroup export.***



An imported group appears in the ***Groups*** tab (see there).

Submit templates

Submit templates… checks your own templates and sends them to the device library or saves them as a submission file. The dialog states at the top how many of the templates can be submitted (***3 of 3 templates can be submitted.***) and points out that the device library lists manufacturer and model separately: the split suggested from the template name is to be checked. Per template there are a tick, the fields for manufacturer and model, the datasheet link and notes, for example ***Power draw not stated.***

The **datasheet link is mandatory**: a template without a link cannot be submitted. To send to the device library you must be signed in (***Sign in…***); a submission file can also be saved without an account. The buttons at the bottom are ***Close***, ***Save submission file*** and ***Send N to device library***.



Changing, placing and removing entries

1. Find the entry.

1. The button ***Remove from library*** (red ×) asks for confirmation.



1. A double click on an entry puts the device on the plan; a click shows the template in the Inspector.



1. Drag an entry onto the plan to place it at the drop position.



Shared

The sub-tab ***Shared*** shows the shared device library (devices.zumpelars.de), read-only. Signing in is needed to fetch or update the devices (***Sign in...***); devices already fetched stay usable. ***Update*** fetches the current state. The line ***N devices stored locally*** states how many devices are on this computer; they are ordered by category. Each entry carries the name, the status (***verified***, ***confirmed***, ***unconfirmed*** or ***disputed***), the number of confirmations and the link ***Page*** to the detail page. The status is set by the device library, not by the planner.





Sign in... opens ***Settings*** → ***Device library*** with the server and the account.



Rentman in the library

The sub-tab ***Rentman*** belongs to the Rentman module. Without a linked project it says ***No Rentman project linked.*** with the button ***Link Rentman project…***; below, the views ***Imported***, ***Catalog*** and ***Reconcile*** are selectable.



1. ***Link Rentman project…*** opens ***Import from Rentman***, where the projects are loaded and one is chosen.



1. With a linked project the tab shows ***Currently linked Rentman project*** at the top with the counters ***n imported***, ***n without Rentman ID*** and ***n removed***, plus the buttons ***Refresh from Rentman / import new items*** and, if needed, ***Rebuild N missing library entries*** (reconstructs the templates from the data of the plan).



1. The view ***Imported*** lists the imported devices by project (the active one carries the badge ***AKTIV***) and category. With ***Collapse all*** / ***Expand all*** and the search field ***Search Rentman devices...*** you keep the overview.



1. The view ***Catalog*** shows, after ***Load catalog***, all equipment created in your Rentman account, organised by the Rentman folders, with the Rentman ID. ***+ Project*** asks ***Add "..." to Rentman?*** and points out that this changes the Rentman project and is not automatically reversible.





1. The view ***Reconcile*** (***Reconcile canvas*** ↔ ***Rentman***) states how many devices of the plan are not tracked: first those ***No longer in Rentman*** (***removed***), then the devices without a Rentman ID (***no Rentman ID***).



A Rentman device for which a local device of the same name exists can be linked with its ports (button ***Link*** on the entry).

Cables

The tab ***Cables*** (***Cable library***) lists the cable types, grouped by connector type (for example ***Audio / XLR***, ***SDI***, ***Ethernet***, ***Fiber***). Behind each group is the number of types. At the top the line ***N installed*** states how many cables are in the plan, how many custom cable types there are and which SDI recommendation applies.



1. A click on a group opens it. Each type shows colour, name, connector with maximum length and signal standards.



1. Custom types carry the badge ***Custom***, adjusted built-in types the badge ***Adjusted***.



1. The pencil opens ***Edit cable type***. The form has the fields ***Name***, ***Connector type*** (with **+** for a new connector type), ***Cable colour***, ***Also compatible with (optional)***, ***Signal standards*** (with ***+ Standard*** for a new standard), ***Max. length (m) — optional*** and ***Note (optional)***. ***Save*** is only possible when a name and at least one standard are set. For a built-in type the change is saved as a local adjustment (***Adjusted***); the button with the arrow (***Remove override***) asks ***Reset override for "…"?*** and restores the original values with ***Reset***.



1. The red × on a custom type asks ***Delete cable type "..."?*** — installed cables are not affected (if a cable refers to the type, it keeps connector and standard but loses the link to the template).



1. The groups can be moved by the grip in front of the name.



You create new custom cable types under ***Settings*** → ***Cable types***.

Groups

The tab ***Groups*** (***Device groups: Multiple devices + cables as a template***) shows saved device groups. A card names the name, the number of devices and cables, the height in RU and the device names. A group is created on the canvas: select several devices and click the button ***Save N selected devices as a group*** in the toolbar (see Saving a device group).



1. When you point at a card, ***Rename*** (pencil), ***Export*** (arrow down) and ***Remove group from library*** (red ×) appear.

1. A click on the card places the group on the canvas; when dragged, it lands at the drop position.



1. ***Rename*** asks ***New template name:***. If the name exists, the app asks for another one.

1. ***Export*** saves the group as a `.cpgroup` file in the Downloads folder; ***Import file…*** in the **+** menu of the ***Equipment*** tab reads it again. If the name is already taken, the app asks about overwriting.

1. The red **×** asks ***Delete group "…"?***.



1. The cards can be re-ordered by the grip in front of the name.



Without groups it says ***No groups saved yet.***



Racks

The tab ***Racks*** (***2D Rack Builder: Rack slots in RU, saved as a placeable group***) shows saved rack layouts as cards with the number of devices, RU and cables and the device names. At the top are the buttons ***For the warehouse*** and ***+ New rack***.

1. A click on the card places the rack as a black box on the canvas; when dragged, it lands at the drop position. When you point at it, ***Edit*** (pencil, opens the rack builder), ***Export*** and the red × (***Remove rack from library***, asks ***Delete rack "..."?***) appear.



1. ***For the warehouse*** saves what sits in each rack as a file for the Inventory Planner, which checks it against the rack case. Afterwards the app says how many racks were handed over and how many devices sit outside their rack and were left out. Without racks it says ***No rack layout to hand over yet.***



1. Without saved racks it says ***No rack layout saved yet.***



Rack Builder

+ New rack opens the 2D rack builder with an empty rack; the pencil on a card opens it with that rack. On the left the builder has the library of devices (***Patch panel***, ***Rack shelf***, search, ***Include non-rack devices***), in the middle the rack layout (***2D*** or ***3D***; ***Front***, ***Rear***, ***Both***, ***Side***) and on the right the live preview as a black box on the canvas. At the top are ***Rack name***, ***Height (HE)*** and ***Depth (mm)***, at the bottom ***Wire internally***, ***Cancel*** and ***Save***. Devices come with ***+ Into rack*** or by dragging into a slot; ***Conflicts*** names what does not fit. The saved rack is a placeable group.


New rack
New
2D rack builder · Add devices from the library, drag for U position, internal cabling Esc close
Export
Rack name *
New rack
Height (HE)
42
Depth (mm)
800
Library
33 / 1859
+ Patch panel
+ Rack shelf
Search device...
Include non-rack devices
Crestron Avia DSP-1283
Audio
1 HE · 20 In · 8 Out
+ Into rack
Camera 2
Cameras
1 HE · 0 In · 1 Out
Crestron CP3
Control
1 HE · 4 In · 9 Out
Clear-Com CS-702
Intercom
1 HE · 4 In · 8 Out
Clear-Com MS-702
Intercom
1 HE · 5 In · 8 Out
Clear-Com SB-704
Intercom
1 HE · 6 In · 16 Out
Rack layout
2D
3D
100%
Drag & Drop
Rack is empty
Add devices from the library on the left (button "+ Rack").
Tip: "Include non-rack devices" enable when the desired device is missing.
Front
Rear
Both
Side
Show connector symbols
U1
U2
U3
U4
U5
U6
U7
U8
U9
U10
U11
U12
U13
U14
U15
U16
U17
U18
U19
U20
Live-Preview
No devices in rack — preview appears once the first device is assigned.
Double-click a device in the rack → opens the properties popup (height, start RU, panel images, remove).
Devices: 0
U occupied: 0 / 42
Saved
Wire internally
Cancel
Save rack


Example rack: small OB van
Editing
2D rack builder · Add devices from the library, drag for U position, internal cabling Esc close
Export
Rack name *
Example rack: small OB van
Height (HE)
12
Depth (mm)
800
Library
33 / 1859
+ Patch panel
+ Rack shelf
Search device...
Include non-rack devices
Crestron Avia DSP-1283
Audio
1 HE · 20 In · 8 Out
+ Into rack
Camera 2
Cameras
1 HE · 0 In · 1 Out
Crestron CP3
Control
1 HE · 4 In · 9 Out
Clear-Com CS-702
Intercom
1 HE · 4 In · 8 Out
Clear-Com MS-702
Intercom
1 HE · 5 In · 8 Out
Clear-Com SB-704
Intercom
1 HE · 6 In · 16 Out
Rack layout
2D
3D
100%
Drag & Drop
Front
Rear
Both
Side
Show connector symbols
U1
Patch panel 16x BNC
8 In · 8 Out
U2
U3
Vision mixer
U4
4 In · 2 Out
U5
U6
Multiviewer
1 In · 0 Out
U7
U8
U9
Live-Preview
Black box on canvas
4 devices · 3 internal cables
Example rack: small OB van
Patch panel 16x BNC · 8 In · 8 Out
Vision mixer · 2 In · 1 Out
Multiviewer · 0 In · 0 Out
IEC strip 8-way · 1 In · 8 Out
Devices: 4
U occupied: 5 / 12
3 cables
Saved
Wire internally
Cancel
Save

5. Inspector

The inspector is the right-hand side panel. It shows the properties of the selection: a device, a cable, a frame or a library template. The header names the selection, for example ***Device: Camera 1***, ***Cable: CAM 1*** → ***mixer*** or ***Frame: Control room***.

Nothing selected



With nothing selected the inspector shows:

- ***Nothing selected*** with the hint to pick a device, cable, frame or library template.
- ***Photos of the project***: photos that belong to the whole plan rather than to one device. ***Add photo…*** opens the file picker. Each photo shows its size and source (***from the planner*** or ***from the phone***) and has a ***Note*** field.
- ***Quick orientation*** with four hints: drop devices from the library on the canvas, connect ports to create cables, select multiple devices and save them as a group from the canvas, Rentman actions live in the Equipment tab under Rentman.



The ***Window*** button at the top offers ***Undock (floating)*** and ***Open in its own window***; the arrow next to it collapses the inspector. Both are described in Arranging the side panels.

Device properties

Clicking a device on the canvas shows its properties.



In viewer mode and in a finalised plan the fields are locked; the inspector says so at the top. A finalised plan becomes editable again via ***Re-enable editing*** in the canvas banner. Filtering, expanding and collapsing still work.

Fixed at the top, in this order: name, short name, subtitle, ***Inputs & outputs*** and ***Note***. The collapsible sections follow below. Which sections appear depends on category, device and enabled modules.

Filtering, expanding and collapsing sections

- The ***Filter sections ...*** field hides every section whose title, subtitle or identifier does not contain the search text. Matching sections expand. The × clears the field.
- ***Collapse all*** collapses every section, ***Expand all*** expands them.


Device: Camera 1
Properties
Window
dmx
Collapse all
Expand all
Name
Camera 1
Short name KAM1
Subtitle (optional, optional, e.g. "PGM monitor")
Bühne links
Note (optional)
Beispielnotiz: Stativ steht hinter dem Vorhang.
Not tracked in Rentman plan
Category
Cameras
Specs — Cameras
Lifecycle / maintenance
Optics (MultiCam plan)
Pan 0°
Tilt 0°
Preset Shot Saved
1 Wide pan 0°, tilt -5°, 10 mm, focus 8 m 2026-10-21
2 Presenter pan -12°, tilt -8°, 45 mm, focus 6 m 2026-10-21
Set in the MultiCam planner; the next camera import updates it.
Controllable functions
DMX
no DMX
This device is addressed via DMX



Reordering sections

Sections with the ⠿ handle can be dragged to another position. The order applies to all devices and is remembered. Name, short name, subtitle, ***Inputs & outputs*** and ***Note*** are fixed and have no handle.

Name, short name, subtitle

FIELD	EFFECT
Name	name of the device in the plan
Short name	short form for port and endpoint labels; without your own entry it is derived from the name (***auto***). The pencil opens the field; ***auto*** restores the derived short name
Subtitle	optional line under the name on the node, e.g. “PGM Monitor”



Inputs & outputs

The section has two lists, ***Inputs*** and ***Outputs***. The header counts them, e.g. ***0 In · 1 Out***.

1. ***+ Port*** creates a port in the list.

1. Enter number and name and choose connector type and signal standard.



1. Further fields per port:

FIELD	VALUES
Content / function	free text, e.g. “PGM”
Direction	Direction (auto), Input only, Output only, Bidirectional (e.g. network)
Side	Side (auto), Left, Right
Gender	Gender (–), ♂ Male / plug, ♀ Female / socket
Group	— None —, existing groups, ***+ New group…***

1. For SDI ports, ***SDI capabilities (port-specific)*** expands: ***Max single-link*** overrides the device value for this port; ***Quad-link set*** and ***Dual-link set*** combine ports into a set (***+ New set…***). A new set reports how many ports are already assigned to it.

A group combines ports that belong together. Its kind is stereo (L/R), M/S, sum (A/B), bridged (+/-), Powerlock set (L1/L2/L3/N/PE) or other; each port picks its role in the group, for stereo L or R.

Fibre ports additionally show ***Breakout*** (DUO (2), QUAD (4)) with one row per fibre (TX (sending), RX (receiving), not stated, ***Add fibre***) and the SFP module with connector (LC, SC, ST, FC, E2000, MPO-MTP, opticalCON, LEMO) and fibre class (OM1–OM5, OS1, OS2).

An entry at the end of the connector type list creates a new connector type; the app asks for its name. The × deletes a port.

The ≡ handle in front of ***Inputs*** and ***Outputs*** swaps the two lists; ***Flip ports (inputs on right, outputs on left)*** puts the inputs on the right side of the node.

Note

Free field for anything that has no field of its own, such as web interface, firmware or location.

Rentman notice and category

With the Rentman module enabled and the device missing from the linked Rentman plan, the inspector shows ***Not tracked in Rentman plan***. Below it, ***Category*** picks the kind of device; ***+ New category…*** creates your own. The section ***Specs — <category>*** shows the fields of that kind, for monitors panel type, HDR, brightness, frame rate and colour space.



Optional fields



FIELD	EFFECT
Verify as correct	confirms with your name that the ports are correct; the number of confirmations is shown next to it
Rental price / day	price with currency
Manufacturer link	address of the datasheet; ***Open*** opens it
Price / rental (€)	value for the quote export
Reference image	image, e.g. of the port layout
Icon	glyph or emoji on the node, at most 2 characters; empty means automatic



Photos

Add photo... attaches a photo to the device. If the device has a device type from the library, the app asks ***Also use for the device type?***. With ***Also for the device type*** the photo shows on every device of this type in the plan and is stored only once; ***Only this device*** attaches it here only. The section then shows two lists: ***This device*** and ***Device type*** with the number of devices of that type.



Display & flags



FIELD	EFFECT
Compact display	node shows only icon and name, ports as dots
Device colour	colour of the node; ***Reset*** resets it
Packed / pack status	marks the device as packed: ✓ on the canvas and a column in the device BOM
Converter (patch list follows pass-through cable)	the patch list skips the device and shows the next real target
Patch panel (through-path follows the position)	input and output at the same position count as connected through
Distribution amp (1→N)	one input is split to several outputs of the same source
Timecode	—, Source, Sink
Tally	—, Source, Sink
Embedding	—, Embedder, De-embedder

Signal source (role)

A role is the editorial name of a source, e.g. “Camera 1”. It survives a device swap. ***Role*** picks an existing role or ***Create new role from device name…***. A role has an editorial name, a number and a TSL UMD address; ***Rename*** and ***Discard*** change the name, ***Delete role*** releases all bindings.



Network & access



FIELD	CONTENTS
IP Address, Subnet mask, Gateway, VLAN ID, MAC address	network data of the first interface
Serial number, Asset tag, Internal number	identifiers of the device
Unit from stock	the specific unit standing in this place
Username, Password	login of the device
Role of the first interface	Media primary, Media secondary, Control, Management, not stated
Additional network interfaces	***Add*** creates further interfaces, each with role, switch, PTP profile (ST 2059-2, AES67, IEEE 1588 default) and PTP role (Grandmaster, Boundary clock, Slave)

Username and password are stored in the project file. The app removes them on export and when sharing.



Streams

Streams this device sends or receives. User name, password or passphrase in an address are taken out and kept in this computer's keychain, never in the plan.

1. ***Add stream*** creates an entry.
2. Choose protocol (RTSP, SRT, RTMP, NDI, NDI-HX, HLS, MJPEG, WebRTC, WHIP, WHEP, RTP, ST 2110, Dante, AES67, Other) and direction (***Sends***, ***Receives***, ***Sends and receives***), then label, address, preview address, port, codec and format.



1. Options:

ELEMENT	EFFECT
Show a still image under the device on the canvas	shows the preview image on the node
Live view	plays the stream while it is open
Scopes	shows waveform and vectorscope of the stream live; ***Large scopes*** shows waveform, vectorscope, parade and histogram in one large panel
Show live waveform under the device on the canvas	shows the waveform on the node

The desktop app plays RTSP, RTMP, SRT, HLS and MJPEG (needs ffmpeg), the browser HLS, MJPEG and WebRTC (WHEP). The address must be on the local network; at most four streams run at the same time. When it cannot play, the view names the reason.

Lifecycle / maintenance

Appears when the Fixed installation or Rental module is enabled.



FIELD	VALUES
Status	— no status —, Planned, Installed, Tested, Operational, Fault, Retired
Warranty until	date
Maintenance interval (days)	number
Ownership (Rental only)	— n/a —, owned, rented, sub-hire
Purchase date, Storage location, Supplier (Rental only)	date or text
Service history	entries with date, kind (Installation, Inspection, Repair, Replacement, Note), text and author; ***Add*** creates one



Optics (MultiCam plan)

For cameras from a MultiCam plan this section shows, read-only: lens, focal range, set focal length, extender, horizontal field of view, lens and body mount, height, pan, tilt and a table of presets. The values are set by the MultiCam planner; the next camera import updates them.

Controllable functions

For cameras the section lists, per control function (pan and tilt, zoom, focus, iris, gain, shutter, ND filter, white balance, colour temperature, red and blue gain, detail, recall and store preset), whether the model supports it. ***not on record*** means nobody has checked it.

Controlled via

For devices whose control interfaces the app knows (for example cameras with VISCA or AW protocol, HyperDeck, KUMO), this section shows, read-only, per interface: protocol, transport (serial, SDI or IP), connector, baud, format, pinout, flow control, multidrop, network port and, for a network bridge, mode, port and packets. Details not found in the manufacturer documentation are marked ***Not in manufacturer documentation***. ***Source*** links to the documentation.

Power consumption

Fields voltage (V), current (A) and power (W). When voltage and current are set, the app computes the power (P = U × I).



Circuit (mains)

Role in the circuit defines what the device counts as in the mains diagram: none, Feed, On/off switch, Two-way switch, Intermediate switch, Dimmer, Luminaire, Junction / box, Power distro, Push button, Contactor, Relay, Emergency stop, RCD, Circuit breaker. Each connector is then assigned to a terminal of that role. The terminal belongs to the connector, not to its position in the list.



Adapter

This device is an adapter opens the fields:

FIELD	VALUES
Side facing the source, Side facing the sink	connector types
Direction	one direction only, both directions, not declared
Power	passive, active with own supply, active powered by the source, not declared
Passes at most	highest signal standard
Requires at the source	capability the source device must list under ***Can***
Note	text

Can lists the capabilities a device declares. Empty means “not declared”, not “cannot”.



DMX

This device is addressed via DMX opens manufacturer, model, the list of modes, and universe and address. ***+ Mode*** creates a mode with name, channel count and source (Manual, GDTF file, Console patch, Read off the device, Estimate). With a mode chosen, the header shows mode, channel count and address. ***Keep this address*** protects the address from automatic assignment.



House connection

Load building file… reads an `.avfacility` file from the building tool. ***House outlet*** then picks an outlet or feed of the building; the app shows fuse, continuous rating and whether the outlet is switched or dimmed. ***Control address*** links an address of the building, such as KNX or DALI.



Format profile (sink)

For this device it is declared which formats it accepts opens the profile. ***Source (required)*** says where the statement comes from; without a source the app discards the profile on the next load. ***+ Format*** adds a row: format, bit depth (8, 10, 12 bit), colour format (RGB, YCbCr 4:4:4, 4:2:2, 4:2:0) and dynamic range (SDR, HDR10, HLG, Dolby Vision). Without a profile the plan says “not declared”.



Dimensions

Width, height and depth in mm. The header shows the dimensions.



Operating modes

An operating mode is a port layout of its own.

1. ***+ New mode (editor)*** opens ***New operating mode*** with name, description, power and weight in this mode and separate input and output lists (***+ Port***). ***Adopt current device layout*** copies the device's ports. ***Create mode*** saves.



1. ***+ Save from current layout*** creates a mode from the current ports; the app asks for a name.
2. Per mode, ***Editor*** opens the dialog and ***Capture ports*** sets the mode's layout on the device. Deleting a mode keeps the ports on the device.



Library

Save as new default template overwrites, after confirmation, this device's template in the library. ***Save as new device in library*** asks for a name and creates a new template.

Catalogue & source

Links the device to a model in the built-in catalogue; datasheet link, stock matching and BOM use it. ***Choose manually*** opens a list of all catalogue models.



Replace device

Choose another device... opens a list of the library with category filter and search. After the choice the app shows how many cabled connections exist and how many inputs and outputs it maps. ***Replace*** swaps the device and keeps the cabling.



Print / documentation

BUTTON	EFFECT
Device datasheet (A4)…	opens this device's datasheet
Print patch sheet (A4 PDF)	prints the A4 patch sheet
Print patch sheet (A3 PDF)	prints the A3 patch sheet

The device datasheet is one A4 page. It is divided into photos, general, technical data, category data, operation and tables; each field has a check box. ***Filled ones***, ***All*** and ***None*** set the check boxes; ***Print*** and ***Save PDF*** output the sheet.



Switching (signal path)

On devices with inputs and outputs, such as mixers and routers, this section defines per output which input sits on it. The header counts the planned outputs.

Control protocol decides where the switching goes:

PROTOCOL	EXTRA FIELDS
none — nothing will be sent	none
Blackmagic Videohub	target; switch ***ATEM input names follow this Videohub's routing***
Blackmagic ATEM	target; numbers on the device per input and output (program, preview, aux)
Bitfocus Companion	Companion IP, port, ***Fetch connections***, page, row, column and two variables for output and input
Documented text protocol	command line from the device manual, line start, line end, counting start, numbers, level, acknowledgement, port and templates such as Quartz / Evertz; a preview shows the line sent

Target is the system (the device on the network) or the test bench (emulator).



With ***ATEM input names follow this Videohub's routing*** switched on for a Videohub, the section lists each hub output that ends at an ATEM input via

cables. ***Start following*** keeps the connection to the hub open; on every switch the ATEM input takes the name of the new hub source (long name up to 20 characters, short name 4 characters). Only names are written. Desktop app only.

Rack / 19" settings

Is a 19" rack device opens height in RU, ***View*** (Front only, Rear only, Front + rear), ***Import front graphic + crop***, ***Import rear graphic + crop*** and a 2D preview with the ports.



Display

For monitors: resolution and diagonal in inches.

Several devices selected

The inspector always edits one device. Actions for several selected devices, such as saving them as a group or aligning them, are on the canvas.

Cable properties

Clicking a cable shows its properties.



FIELD	EFFECT
Set cable type / standard	opens the choice of cable type and standard
Photos	photos of this cable
Name	label; ***from source*** → ***destination*** builds it from source and destination
Length (m)	length of the cable
Colour	colour on the canvas
Layer	Video, Audio, Control, Network, Power, Other; works with the layer filter in the toolbar
Multicore / snake	name of the multicore the cable belongs to
Tie-line / permanent link	marks a permanent connection
Off-page connection (arrow connector)	draws two arrow connectors with a ***Net / signal name*** instead of the line
Show signal path	highlights the signal path on the canvas
House run	assigns the cable to a run of the building
Notes	text
Delete cable	removes the cable



Show signal path

Show signal path highlights all cables and devices of the signal path on the canvas and dims the rest. The toolbar shows the number of cables and devices; the × there ends the highlight.



Fixed install / lifecycle

FIELD	VALUES
Status	— no status —, Planned, Installed, Tested, Operational, Fault, Retired
Pathway / route	text
Jacket/fire rating	text
Term. A, Term. B	termination at both ends
Fibre A, Fibre B	for fibre, the strand used at each end
Measurement/test result	— not tested —, PASS, FAIL; plus ***Margin dB***, ***Standard/limit*** and ***Report file***; ***Clear*** empties the result



Conductors (power)

Belongs to connection assigns the cable to a connection from ***Tools*** → ***Conductors and colour standards***. ***+ Conductor*** adds a conductor: role (L1, L2, L3, N, PE, spare), colour (empty means from the standard) and reason for a deviation.



Connection

Shows source and destination. ***From device***, ***Port***, ***To device*** and ***Port*** change the ends; ports in use carry ***in use***, and the app warns when a port is already taken.



Cable appearance

FIELD	VALUES
Routing	Ortho, Line, Curve
Stroke width	line width in px, slider
Label position	Start, Center, End; clicking the active position hides the label; the slider fine-tunes it along the cable
Endpoint labels	Auto (follows ***Settings*** → ***Editing***), Show, Hide
Dashed, Arrow ◄, Arrow ►	dashed line and arrows
Bidirectional cable ⇌	arrows on both ends



Wireless connection

Wireless connection (no cable) turns the cable into a wireless link. ***Max. reach (m)*** replaces the length; frequency and channel are added.



Adapter suggestion

When the connectors at both ends do not mate, or have the same gender, the cable shows a notice and matching adapters or converters from the library. ***Insert*** puts the adapter into the run; one undo step removes it again.

Frame properties

Clicking a frame shows its properties.



FIELD	EFFECT
Name	name of the room
Width (m), Depth (m)	size; the area below
Floor	floor of the room; ***Add floor...*** creates one
Colour	colour of the frame
Riser / vertical cable route	marks the frame as a vertical route between floors
Room number, Address, Notes	text
Floors	list of floors bottom to top with floor level in metres; the 3D view stacks rooms by it. ***Take floors from the building statement*** reads them from a building file



BUTTON	EFFECT
Export BOM	opens the room's BOM with devices, internal cables and external connections; ***Combine cables***, ***Embed plan*** and ***Export PDF***
Delete frame only	deletes the frame, the devices stay
Delete frame + contents	deletes, after confirmation, the frame with all its devices and their cables


Bill of materials — Regie
Devices: 3 Internal cables: 2 External connections: 2
Group cables
Embed plan
Devices
Pack Name Category S/N IP Specs
Vision mixer Mixer
Multiviewer Monitors
Control room monitor Monitors
Internal cables
Qty Type Length (m)
2× BNC 6
External connections
Qty Type Length (m)
1× BNC 18
1× BNC 25

6. File and Import

The ***File*** menu has four parts. At the top are creating, opening and saving a project. Below them come the imports (***Import yEd / GraphML***, ***Import MultiCam cameras***, ***Import equipment from CSV***, ***Rentman import***, ***NetBox import***) and the exchange of whole projects (***.avplan***, ***.avsourcemap***). Next come the outputs ***Patch list…***, ***Fixed install: docs & handover…***, ***Stage plot***, ***Export & Print…***, the cloud, the viewer file and the Rentman entries. The chapter ***Export & Print*** describes these outputs. ***Rentman import…*** and ***NetBox import…*** appear in the menu only when the integration is switched on under ***Settings*** → ***Integrations***. ***View linked venue plan…*** appears only when the project contains a linked venue plan.



New project

File → ***New project*** (`Ctrl+N`) opens the ***New project*** form. It needs a project name; without one ***Create project*** stays disabled. If the current plan contains devices, cables or locations, a notice at the top says that a new project discards the current one and unsaved changes are lost. With an empty plan the notice is absent.



Besides the name, the form asks for ***Contractor (company)***, ***Client***, ***Planner / author***, ***Project / job no.***, ***Event/rental start***, ***Event/rental end***, ***Description***, ***Company logo*** and ***Client logo***. These entries appear in the title block at the bottom right of the PDF export. You can change them later with ***Edit project metadata*** in the header bar.



Create project replaces the current plan with an empty one that carries these entries. With an empty plan the form shows no warning.



New from template

File → ***New from template...*** opens the ***New from template*** dialog. It loads a copy of the chosen template as a new project.



Under ***Bundled templates*** there are five show setups. Each card gives the number of devices, cables and locations.

TEMPLATE	CONTENT
OB van	OB van with stage and FOH, separate location frames
TV-Studio	Studio with control room and studio floor
Live stage	Stage, FOH and monitor world for live events
Konferenz / Corporate	Hall and control room for conferences and corporate events
Houses of Worship	Sanctuary/stage and tech gallery for church services

Under ***My templates*** are the templates you saved yourself. They live in the local storage of this app on this computer, not in the project file.

Loading a template

1. Click ***Use***. If the current plan has content, ***Discard current project?*** asks first. ***Load template*** confirms.



1. Enter the name of the new project. The template name is pre-filled.



1. ***Template loaded*** reports the new project. It is unsaved and has no file path yet.



If a venue template brings answers for a different venue than the current project carries, ***Answers from a different venue*** asks before the name. ***Load anyway*** continues.

Saving the current project as a template

Save current project as template asks for the template name; the project name is pre-filled.

If the project carries venue-bound entries, that is answers from the venue's IT or the address, ***Bind this template to the venue?*** asks. ***Neutral (shape only)*** leaves them out. ***For this venue*** takes them along and records which venue they apply to. Without venue-bound entries the question is skipped.



Saved as template confirms.



The template then appears under ***My templates***. A venue template shows ***Venue template*** with the venue and the number of answers; one made from the as-built shows ***Basis***. The bin icon on the card deletes the template after a confirmation.





As-built as template

As-built as template takes not the current plan but the state committed as "as built". The button is always active; its hint names the difference. The dialog first asks for the template name.

If no as-built is committed, ***No as-built committed*** refuses: commit an as-built revision first, otherwise the template would be the plan from before load-in under another name. The chapter ***Tools: Build*** describes revisions. With a committed as-built the dialog reports ***Template … created from the as-built …***.

Open

File → ***Open…*** (`Ctrl+O`) opens the operating system's file dialog. It shows files with the extensions `.cableplan`, `.json` and `.cpviewer`. The chosen file replaces the current plan in the window.

The app checks the file before loading it. It rejects valid JSON that contains no equipment and cable list. ***This file is not an LZ Cable Planner project*** reports this; the open plan stays unchanged.

A `.cpviewer` file, or a project with the mode ***viewer***, opens as a review file. First ***Viewer file — enter name*** asks for your name. It is attached to every annotation you create in this session.



Without a name the app does not load the file. ***Name missing*** says that without a name no annotations can be made. The chapter ***Export & Print*** describes how to create viewer files and bring annotations back.



If the opened project is named ***Untitled Project*** or has no name, the app takes the file name as the project name.

Save and Save as

File → ***Save*** (`Ctrl+S`) writes the project to its file. If the project has no file path yet, the ***Save as*** dialog opens first. The app appends `.cableplan` unless you give `.cableplan` or `.json`.

File → ***Save as…*** (`Ctrl+Shift+S`) writes the project under a new name or path. The new project is then the active one; the earlier file stays unchanged. The file name becomes the new project name.

Every write is atomic. The app writes a temporary file first, renames the previous file to `<name>.cableplan.bak` and then puts the temporary file in its place. After the second save the `.bak` file with the previous state therefore sits next to the project file. An interruption in the middle of writing destroys neither the old nor the new file.

Autosave and status bar

Independently of saving to a file, the app continuously backs up the open plan in the program's local storage. After a change it waits briefly before writing; the default is 400 ms. The interval is under ***Settings*** → ***Advanced*** in the field ***Autosave interval (ms)***. At the next start the app loads this backup again if it is valid.



Local storage holds only about 5 MB. If the plan gets larger, the storage refuses the backup. The status bar at the bottom then shows ***No recovery copy***. Hovering over it gives the size of the plan. Nothing is missing from the plan itself; save to a file. As soon as a backup succeeds again, the indicator disappears.



The `.cableplan` file format

A `.cableplan` file is a JSON document. The app writes it with two-space indentation. The top-level fields are `metadata` (name, description, timestamps, defaults, `projectId`), `equipment` , `cables` , `locations` , `canvasState` , `floors` , `revisions` , `changelog` , `sourceIdentities` , `tallyPositions` , `patternChecks` , `hubSwitches` , `cableStock` , `ledPanelTypes` , `ledWalls` , `fotos` and further ones for standards, report

templates, address layers and delivery destinations. New fields get a default value on load, including in older files. Photos are stored in the file; with many photos it grows accordingly.

Passwords and keys of external services (Rentman, NetBox, device library, stream keys) are not in the file but in the operating system's keychain.

Import yEd / GraphML

File → Import yEd / GraphML… reads a diagram from yEd or another GraphML file. Nodes become devices, connector cells become ports and edges become cables. The dialog first shows a preview; nothing enters the plan until you start the import.



Pick file… opens the file dialog. The parser needs about 250 ms per MB. Afterwards the dialog header shows the file name, the number of nodes and edges and the counters ***Devices***, ***Cables***, ***Skipped*** and ***Edges without target***. ***Devices: 3/3*** means three of three devices are selected for import. ***Another file*** returns to the file choice.



The ***yEd preview*** tab shows the drawing as read. The mouse wheel zooms, dragging pans. The ***Devices*** tab lists the detected devices.



COLUMN	MEANING
Checkbox	import the device or leave it out
Name	name from the diagram; editable in the field
Category	detected category; editable in the field
IP	the IP address found in the diagram
In/Out	number of detected inputs and outputs
Status	detection confidence: ***HIGH*** when a name and at least one port are detected, ***MED*** when the name is detected but no port, ***LOW*** when no name could be determined

A deselected device is greyed out. The import does not take its cables.



Name and category can be changed before the import.



The ***Cables*** tab shows ***Source***, ***Target***, ***Type***, ***Standard*** and ***Length*** for every edge. The app derives the type from the label. If a length is missing, the import sets 1 m. The import takes the bend points of the lines from yEd as waypoints of the cables.


Import yEd / GraphML
File beispiel.graphml 2.8 KB • 11 nodes • 3 edges
Another file
Devices: 2/3 Cables: 2/2 Skipped: 1 Edges without target: 1
Target: Canvas Library Mode: Append to project Replace GraphML import
Filter: name / IP / category / cable type
yEd preview Devices (3) Cables (2) Skipped (2)
Source Target Type Standard Length
Kamera 1 Bildmischer BNC – 25 m
Bildmischer Monitor Regie HDMI – 5 m
Cancel
2 devices & 2 cables onto canvas



The field ***Filter: name / IP / category / cable type*** at the top right hides rows that do not match.



The ***Skipped*** tab names what is not imported. ***Nodes skipped*** lists nodes such as legends and decorative shapes, with the reason. ***Edges with unresolved ports*** lists edges whose ends could not be assigned to a connector.



Target and mode

Target decides where the import writes.

- ***Canvas*** places the devices with their cables in the plan.
- ***Library*** stores the devices only as reusable templates in the local library. Cables and canvas placement are left out.



With ***Canvas*** the ***Mode*** also applies. ***Append to project*** adds the devices and cables to the plan. ***Replace GraphML import*** replaces only devices that an earlier GraphML import created; devices you added by hand stay untouched.



The button at the bottom right names what will happen, for example ***3 devices & 2 cables onto canvas*** or ***2 devices into library***. The import onto the canvas is a single step for ***Undo***. Afterwards the app selects the first new device and shows the area with the imported devices.



When importing into the library, ***Added to the library*** reports how many devices were created and which names already existed. The import never overwrites existing templates.



On a second run with the same file, the import creates nothing and names the existing ones.



If you click the background outside the dialog, ***Discard import?*** asks: anything not yet applied here will be lost. ***Keep editing*** returns, ***Discard*** closes. The cross at the top right closes the dialog without a question.



A file that is not valid XML shows ***Import failed*** with the file name and the parser's message.



Import MultiCam cameras

File → ***Import MultiCam cameras…*** opens the file dialog directly; there is no dialog of its own. It reads the camera list (`camera-list`, version 1 to 3) that the MultiCam planner exports. Each entry becomes a device of the category ***Kameras***.

If the model clearly matches a catalog entry, the camera inherits its connectors. If it does not match clearly, the camera stays without ports and counts as "ports unknown". The app does not invent connectors; the plan check then asks for the datasheet values.

A message gives the result: ***MultiCam cameras: 2 new, 0 updated, 0 unchanged.***



A further import is a reconciliation, not an append. The app recognises cameras by their origin in the MultiCam plan. From the list it takes the name, the optics and, from version 3, the PTZ presets. Position, ports and cables stay as you set them. Cameras that are no longer in the MultiCam plan are marked and not deleted, because cables may hang on them. If the model has changed, ports and cables are kept; you swap the body via ***Choose another device…*** in the properties.



A file that is not a valid camera list reports ***Camera import failed — not a valid MultiCam camera list.***



Import equipment from CSV

File → ***Import equipment from CSV...*** creates device templates in the local library. Only templates are created; nothing is placed on the canvas.

You paste the CSV text into the field or choose a file with ***Choose CSV file...***. The first row holds the column headings. The separator is a semicolon or a comma, whichever occurs more often in the header row. The app reads quotation marks and a BOM at the start of the file.



The app assigns the headings to a field. The whole text is compared in lower case, not a fragment.

FIELD	RECOGNISED HEADINGS
Name	`name`, `gerät`, `geraet`, `device`, `bezeichnung`, `artikel`
Category	`kategorie`, `category`, `typ`, `type`, `gruppe`
Power (W)	`watt`, `watts`, `leistung`, `power`, `w`
Weight (kg)	`gewicht`, `weight`, `kg`
Serial number	`seriennummer`, `serial`, `s/n`, `sn`
Asset tag	`asset-tag`, `asset tag`, `assettag`, `asset_tag`, `inventarnummer`, `inventar-nr`, `inventar-nr.`
Internal number	`interne nummer`, `interne nr`, `interne nr.`, `internal number`, `internal no`, `internal no.`, `hausnummer`
IP	`ip`, `ip-adresse`, `ipaddress`, `ip address`, `ip adresse`
Rack units	`he`, `rackunits`, `ru`, `höheneinheiten`, `hoeheneinheiten`
Subtitle	`untertitel`, `subtitle`, `hersteller`, `manufacturer`, `marke`, `brand`

A device with rack units counts as a rack device. If the category is missing, the app sets ***Imported***. If the name column is missing, the first column counts as the name.

The box ***What happens to the rest*** lays open what does not arrive as a field:

- Columns without an assignment go into the device's notes, as lines of the form `Heading: value`. Empty cells are dropped.
- A second column on the same field loses the assignment: the first wins, the second becomes a note.
- Rows without a name are skipped; the box names their row numbers.
- Names that already exist in the library stay unchanged. This also applies to names that occur twice in the file: only the first row counts.

The button ***Import 2*** gives the number of new templates. Afterwards ***CSV imported*** reports how many devices were created, how many names already existed and how many rows without a name were skipped.





If you repeat the import with the same names, the templates stay unchanged and the dialog lists the existing names.



The file can also come through ***Choose CSV file...***; the content lands in the same field.

Rentman import

File → ***Rentman import...*** loads the devices of a Rentman project into the library. The import creates templates but places nothing on the canvas.

Setting up. Under ***Settings*** → ***Integrations*** switch on ***Enable Rentman integration***. On the card ***Rentman API*** enter the API token and save it. It is stored in the operating system's keychain.

Choosing a project. ***Load projects*** fetches the projects of the account. The list shows number, name, period and status; ***Sort:*** orders by number or date, the search field filters by name, number or status.

A click on a project loads its equipment. The header shows the project; ***change*** returns to the list, ***Reload & sync*** fetches the quantities again.



The box ***Plan vs. reservation*** compares the plan with the Rentman reservation: devices that are only in the plan, only reserved, or whose quantity differs. It does not count lines without device character (comments, set contents, cancelled). ***CSV*** saves the comparison.

Selection. The list shows the devices grouped by category. Next to each row are the quantity in the Rentman project and the ***Link...*** choice, which connects a Rentman device to an existing local device. Badges show what the app knows about the device:

BADGE	MEANING
⊕ ***catalog***	match in the built-in catalog; the import creates the template from it
linked	already connected to a local template by Rentman ID; a repeated import changes only category and project link, the ports stay
in library	local template with the same name but no Rentman ID; the import then asks

Select all and ***Deselect all*** set all ticks. Combinations appear as ***Physical combi***, ***Virtual combi*** or ***Set***. A physical combination is one stock unit and is taken over as one device. ***+ as rack*** takes it over as a rack, ***+ main device only*** leaves out the accessories. ***Expand all sets*** shows the contents.





Cable quantities. The block ***Cable quantities from Rentman*** sums up the cable lines by type and length. It can be opened. For each type there are a tick, the length, an editable quantity and the number of Rentman entries.



Adopt cable quantities stores the chosen types with their quantities as the cable plan in the project and links the project to the Rentman project. This also works without a device import. The message reads ***2 cable type(s) adopted as plan.*** With ***Send cables to Rentman…*** in the File menu these quantities can later go back; the chapter ***Export & Print*** describes that.



Adopting. ***Add to library (n)*** gives the number of chosen devices.



Next, ***Category mapping before import*** opens. You assign each device a local category. The app recognises and remembers matching categories; you create missing ones with ***+ New***. ***Back*** keeps the selection.



Next without a complete mapping reports ***Category missing***.

If devices already exist under the same name, a conflict dialog appears per device. The default is ***Keep local version (recommended)***, so your own port assignments are kept. Further actions are ***Link to another local device***, ***Overwrite with Rentman version***, ***Merge ports*** and ***Skip (do not import)***.

Set all: applies ***Keep local***, ***Take Rentman*** or ***Skip*** to all rows. The message at the end says how many devices were added to the library.

NetBox import

File → NetBox import… reads a site or a rack from NetBox and creates devices, ports and connections as a cable plan.

Setting up. Under ***Settings → Integrations*** switch on ***Enable NetBox integration***. On the card ***NetBox API*** enter the ***Instance URL*** and the ***API token***. The token is stored in the keychain. ***Test connection*** checks the connection. Without a URL the dialog shows ***Please configure the instance URL and an API token first under Settings → Integrations → NetBox.*** The button ***Build preview*** stays disabled.



Choosing. Under ***Site*** you choose the site, optionally under ***Rack (optional)*** a single rack. The number in brackets is the number of devices. The icon next to the site reloads the lists. The default ***— import the whole site —*** takes all racks.







Under ***Options*** there are three switches:

- ***Only import cabled ports*** leaves out unused ports. Recommended: a 48-port switch would otherwise bring 48 unused ports.
- ***Import connections*** creates the cables.
- ***Create a frame per rack*** creates a frame in the plan for each rack.





Preview. ***Build preview*** loads the data and computes the reconciliation. Four counters are at the top: ***New devices***, ***New connections***, ***New ports on existing devices*** and ***Unchanged***. Below, a line gives the numbers from NetBox. ***skipped objects*** can be expanded and names each object with the reason; in the example one cable end lies outside the imported area. ***Devices that will be created*** lists name, type and port count.





Back returns to the choice, ***Add to project*** writes.

Reconciliation instead of appending. The reconciliation only ever adds: existing devices and cables stay with all their adjustments. The project remembers the site. The next time you open the dialog it shows ***This project is linked to site "...". Last reconciliation: ...***.



In the example one device has been added in NetBox. The second preview shows only this device as new; the five devices from the first run are under ***Unchanged***.



Exporting and importing a whole project (`.avplan`)

File → ***Export whole project (.avplan)…*** writes the project in the exchange format `.avplan`. The file is JSON with the fields `kind` (***avplan***), `formatVersion`, `app`, `appVersion`, `exportedAt`, `venue` and `domains`. The Cable Planner enters its part under `domains.cabling`. It keeps the parts of other planners (cameras, lighting, venue) unchanged. The file name is `<project name>.avplan`; the app replaces characters other than letters, digits, `_` and `-` with `_`. The file is written as a download of the program window.

If devices carry a user name or password, ***Include credentials?*** asks: the `.avplan` goes to other trades. ***Without credentials*** removes them; re-importing into this planner then loses them. ***Include*** keeps them, ***Cancel*** aborts the export. The question is skipped when no device carries credentials.



File → Import whole project (.avplan)... loads an `.avplan` or `.json` file and replaces the current plan. If the file knows sections that this app does not, for example from a newer version, ***This file contains unknown sections*** asks for each section. The choices are ***Carry through (unchanged, preserved on export)***, ***Take over as*** into a free known section, and ***Discard***. ***Carry all through*** is the cautious default; if you close the dialog without choosing, it applies as well.





If the file contains the camera list of the MultiCam plan, ***This file contains the cameras of the MultiCam plan. Apply them to the signal plan?*** asks. The text below gives the reconciliation result as in the MultiCam import. It asks because a camera you deleted on purpose would otherwise come back on every opening.

A file without a valid `.avplan` format reports ***Import failed — not a valid .avplan file.***



Identity map (`.avsourcemap`)

The identity map is a small, flat format for runtime programs such as a tally computer or a UMD sender. It should not have to read the whole project to learn that "Kamera 1" sits on switcher input 3. The file carries `kind` ***av-source-map***, `formatVersion`, `app`, `appVersion`, `exportedAt`, the sources (`sources`) and the open points (`unresolved`). Every value names its origin: ***planned*** (from the planning), ***commanded*** (sent to a device) or ***confirmed*** (reported back by the device). The Cable Planner writes only ***planned***.

File → ***Export identity map (.avsourcemap)…*** writes `<project name>.avsourcemap` as a download in the same way. Two notices appear after writing when they apply. ***Map written — with one limitation*** names roles with more than one device: the file carries the target label only once per role. ***Map written — without a switcher input*** names roles that reach a router without the crosspoint to the switcher being planned; for them the file holds no input number.

File → ***Import identity map (.avsourcemap)…*** reads a map and reconciles it with the sources of the plan. A report ***Identity map imported*** lists the result:

LINE	MEANING
Newly created	sources the plan did not know yet
Filled in	fields that were empty in the plan
Not applied	fields where plan and file carry different values; the plan keeps its value
Discarded	values the app rejects, with the reason (for example a UMD address outside the range 0 to 126)
No field for this in this app	entries that stay only in the file
Nothing to do	the map says what the plan already says





A file that is not an identity map reports ***Import failed*** with the reason.



View linked venue plan

If a project comes from an `.avplan` that carries room, camera or lighting data of another planner, the menu contains ***View linked venue plan…***. The dialog ***Linked venue plan (view only)*** names the room, the number of walls, persons and stage elements, and the cameras and fixtures. It changes nothing.



7. Export & Print

Everything that leaves the plan as a sheet, list or file is in the ***File*** menu. The entries at a glance:

ENTRY	RESULT
Patch list…	every cable as a row; CSV, Excel, labels, channel lists
Fixed install: docs & handover…	lists and documents for installer and operator, QR labels
Stage plot (SVG)… and ***Stage plot, light (SVG)…***	the stage top view as a one-page sheet
Export & Print…	the export centre with seven sections
Cloud & share link…	a copy with revisions and read links
Export as viewer file…	review file for reviewers
Import annotations from viewer file…	bring the reviewers' annotations back
Compare plan revisions…	differences between two states
Documents handed out…	register of the sheets handed out
Attach plan to Rentman…, ***Send cables to Rentman…***	the way back to Rentman



The command palette (`Ctrl+K`) finds entries such as ***Patch list…*** by name.

File names. Files the app downloads are named `YYYYMMDD_<project name>_NNN.<extension>`, with the sheet name after it for lists, for example `20260519_Demo-Show_007_patchliste.csv`. `NNN` counts up per day. Characters a file system does not accept are replaced by `_`.

Stamp. The lists of the fixed install, the sheets of the document packet and the raster PDF of the plan carry a stamp with the state of the plan. It lets you check later whether a sheet handed out still matches the plan; the register ***Documents handed out*** uses it for that.

Patch list

File → ***Patch list…*** shows every cable as its own row, sorted for the order of patching.



The columns are ***No.***, ***From device***, ***Port***, ***To device***, ***Port***, ***Type***, ***Length (m)*** and ***Colour***. A click on a heading sorts. If a port has a content label such as ***PGM***, it is the main line and the port name sits below it. The connector gender (♂/♀) is shown at the port where it is set. If a cable leads into a device marked as a converter that has only one onward cable, the row shows the end device with ***via*** and the converter; the onward cable then does not appear a second time. The ***Fibre*** column appears only if the plan contains a split socket (breakout).

The search field filters by device, port, type, colour and note.



If the plan has cables with a layer, the choice ***All layers*** appears next to it.





To the right of the filter is the number of cables shown and of all cables, for example ***12 / 12***. If no row matches, it says ***No cables match the filter.***



Outputs. The footer offers four outputs. All of them take the rows currently filtered.

- ***Export CSV*** writes the table with a semicolon as separator and a UTF-8 BOM for Excel. It has 13 columns: ***No.***, ***From device***, ***From port***, ***To device***, ***To port***, ***Type***, ***Length (m)***, ***Layer***, ***Multicore***, ***Fibre***, ***Colour***, ***Cable name*** and ***Notes***; the port columns carry the content label in brackets and the connector gender.
- ***Export XLSX*** writes the same 13 columns as an Excel file with a bold header row.
- ***Labels + QR (PDF)*** prints an A4 sheet with two columns and nine rows. Each cable gets two labels, one per end, with number, type, cable name, route,

length, colour strip and a QR code. The QR code carries the cable number or name and the route; both ends share it.

- ***Label CSV*** writes one row per cable end for label printers. You choose the format next to it: ***Generic (CSV)***, ***Brother P-touch (TXT)*** or ***Dymo (CSV)***. The texts are ASCII-safe, the connector gender is written as ***(M)*** or ***(F)***.

20261022_Beispieldaten_ Konzert und Regie_016_etiketten.pdf (Seite 1 von 2)

20261022_Beispieldaten_ Konzert und Regie_017_etiketten-generic.csv

Label1	Label2	Length	Color
V-03	Vision mixer PGM Out -> Control room monitor SDI In	6 m	#ef4444
V-03	Control room monitor SDI In -> Vision mixer PGM Out	6 m	#ef4444
V-04	Vision mixer Multiview Out -> Multiviewer SDI In	6 m	#22c55e
V-04	Multiviewer SDI In -> Vision mixer Multiview Out	6 m	#22c55e
A-03	Bass DI Out -> Stagebox A 3	10 m	#f59e0b
A-03	Stagebox A 3 -> Bass DI Out	10 m	#f59e0b
A-04	Snare Out -> Stagebox A 3	10 m	#f59e0b
A-04	Stagebox A 3 -> Snare Out	10 m	#f59e0b

20261022_Beispieldaten_ Konzert und Regie_018_etiketten-brother.txt

Label1	Label2	Length	Color
V-03	Vision mixer PGM Out -> Control room monitor SDI In	6 m	#ef4444
V-03	Control room monitor SDI In -> Vision mixer PGM Out	6 m	#ef4444
V-04	Vision mixer Multiview Out -> Multiviewer SDI In	6 m	#22c55e
V-04	Multiviewer SDI In -> Vision mixer Multiview Out	6 m	#22c55e
A-03	Bass DI Out -> Stagebox A 3	10 m	#f59e0b
A-03	Stagebox A 3 -> Bass DI Out	10 m	#f59e0b
A-04	Snare Out -> Stagebox A 3	10 m	#f59e0b
A-04	Stagebox A 3 -> Snare Out	10 m	#f59e0b

20261022_Beispieldaten_ Konzert und Regie_019_etiketten-dymo.csv

Label1	Label2	Length	Color
V-03	Vision mixer PGM Out -> Control room monitor SDI In	6 m	#ef4444
V-03	Control room monitor SDI In -> Vision mixer PGM Out	6 m	#ef4444
V-04	Vision mixer Multiview Out -> Multiviewer SDI In	6 m	#22c55e
V-04	Multiviewer SDI In -> Vision mixer Multiview Out	6 m	#22c55e
A-03	Bass DI Out -> Stagebox A 3	10 m	#f59e0b
A-03	Stagebox A 3 -> Bass DI Out	10 m	#f59e0b
A-04	Snare Out -> Stagebox A 3	10 m	#f59e0b
A-04	Stagebox A 3 -> Snare Out	10 m	#f59e0b

20261022_Beispieldaten_ Konzert und Regie_014_patchliste.csv

No.	From device	From port	To device	To port	Type	Length (m)	Layer	Multicore	Fibre	Colour	Cable name	Notes
V-03	Vision mixer	PGM Out	Control room monitor	SDI In	BNC	6	video			#ef4444	PGM → control room monitor	
V-04	Vision mixer	Multiview Out	Multiviewer	SDI In	BNC	6	video			#22c55e	Multiview → Multiviewer	
A-03	Bass DI	Out	Stagebox A	3	XLR	10	audio			#f59e0b	Bass DI → Stagebox	
A-04	Snare	Out	Stagebox A	3	XLR	10	audio			#f59e0b	Snare → Stagebox	
A-05	4	Out	Stagebox A		XLR	10	audio			#f59e0b	Kanal 4 → Stagebox	
V-01	Camera 1	SDI Out	Vision mixer	In 1	BNC	12	video			#3b82f6	CAM 1 → mixer	
A-01	Lead vocal	Out	Stagebox A	1	XLR	15	audio			#f59e0b	Lead vocal → Stagebox	
A-02	Kick	Out	Stagebox A	2	XLR	15	audio			#f59e0b	Kick → Stagebox	

20261022_Beispieldaten_ Konzert und Regie_015_patchliste.xlsx

20261022_Beispieldaten_ Konzert und Regie_015_patchliste.xlsx — 23134 Bytes

Labelling of patch panels (strips and labels) is described in the chapter ***Tools: Plan***, under the analyses.

Channel list. If the plan contains audio channels, the footer shows the choice ***View of the channel list*** and the button ***Channel list***. One channel list, five views, each as CSV:

VIEW	FOR WHOM
Band (rider)	the band's rider
Venue (patch)	patch at the house input
Stage (position)	layout on stage
Console (names)	channel names for the console
Monitor paths	paths to the monitors; only if the plan has any
Venue / band (who owns what)	puts both halves side by side: the stagebox input belongs to the house, the microphone to the band

The monitor view shows paths, not the mix; the plan does not know that.

20261022_Beispieldaten_ Konzert und Regie_020_kanalliste-band.csv

Ch	Name	Abnahme	Anschluss an der Quelle
1	Microphones	Microphones	Out
2	Lead vocal	SM58	Out
3	Kick	Beta 52	Out
4	Bass DI	DI box	Out
5	Snare	SM57	Out
6	FOH console	Mixer	Aux 1
7	FOH console	Mixer	Aux 2
# Spaltenlexikon — was die Spalten oben bedeuten			

20261022_Beispieldaten_ Konzert und Regie_021_kanalliste-venue.csv

Port	Name	Ziel	Stecker	Länge (m)
Ch 1 (kein Port)	Microphones	Stagebox A	XLR	10
1	Lead vocal	Stagebox A	XLR	15
2	Kick	Stagebox A	XLR	15
3	Bass DI	Stagebox A	XLR	10
3	Snare	Stagebox A	XLR	10
In	FOH console	Wedge 1	XLR	20
In	FOH console	Wedge 2	XLR	20
# Spaltenlexikon — was die Spalten oben bedeuten				

20261022_Beispieldaten_ Konzert und Regie_022_kanalliste-stage.csv

Ch	Name	X	Y
1	Microphones	77	1122
2	Lead vocal	77	561
3	Kick	77	704
4	Bass DI	77	836
5	Snare	77	979
6	FOH console	825	704
7	FOH console	825	704
# Spaltenlexikon — was die Spalten oben bedeuten			

20261022_Beispieldaten_ Konzert und Regie_023_kanalliste-console.csv

Ch	Name	Gekürzt
1	Microphones	
2	Lead vocal	
3	Kick	
4	Bass DI	
5	Snare	
6	FOH console	
7	FOH console	
# Spaltenlexikon — was die Spalten oben bedeuten		

20261022_Beispieldaten_ Konzert und Regie_024_kanalliste-monitor.csv

Pult	Ausgang	Ziel	Eingang
FOH console	Aux 1	Wedge 1	In
FOH console	Aux 2	Wedge 2	In
# Spaltenlexikon — was die Spalten oben bedeuten			
Pult	Das Mischpult, auf das sich der Kanal bezieht.		
Ausgang	Der Ausgang, auf den etwas geht — je nach Blatt der Pult-Ausgang eines Kanals oder der Router-Ausgang eines Kreuzpunkts. Auf dem Umbau-Zettel steht die Nummer, wie sie am Gerät aufgedruckt ist (ab 1), nicht die interne ab 0.		
Ziel	Wohin es geht. Bei der Ausspielung das Ausspielziel (Plattform-Adresse), sonst das empfangende Gerät oder der empfangende Kanal.		
Eingang	Der physische Eingang am Gerät oder Mischer.		

20261022_Beispieldaten_ Konzert und Regie_025_kanalliste-owner.csv

Port (Haus)	Name (Band)	Abnahme (Band)	Stecker (Band)	Ch (bandintern)
Ch 1 (kein Port)	Microphones	Microphones	XLR	1
1	Lead vocal	SM58	XLR	2
2	Kick	Beta 52	XLR	3
3	Bass DI	DI box	XLR	4
3	Snare	SM57	XLR	5
In	FOH console	Mixer	XLR	6
In	FOH console	Mixer	XLR	7
# Spaltenlexikon — was die Spalten oben bedeuten				

Above the table the dialog reports three oddities in the channels before a sheet is printed: a channel without a house port, a number that appears as a name, and two channels on the same socket.

Console scene file. ***Read scene file*** reads the file a mixing console writes (X32, M32, WING; extensions `.scn`, `.txt`, `.snap`, `.shw`). The app only reads and writes nothing back to the console. Afterwards ***Console scene file*** appears above the table with the format and the number of channels, and the number of unreadable lines if there are any. ***Match to the plan*** matches the channels to the plan ***by name*** or ***by channel number (only if it holds)***.


Patch list
Channel without a house port — 1 channel(s) have no house port. The sheet for the house technician shows the internal number there with the note "kein Port" — the only number that means anything outside is missing and is not invented. (Ch 1)
Number instead of a name — 1 channel(s) have only a number as their source. A number in place of a name says nothing on the desk, in the multitrack or on the label — exactly the state in which Dante Controller shows green ticks and still nobody knows which channel is meant. (Ch 1)
Two channels on the same port — 2 channels sit on "Stagebox A 3". An input takes one signal; one of them is left over when patching, and which one is only decided in the hall. (Ch 4, 5)
Console scene file X32 / M32 · 5 channels
by name
Channels
Match
Search (device, port, type, colour, note ...)
All layers
12 / 12
No. From device Port To device Port Type Length (m) Colour
V–03 Vision mixer PGM Out Control room monitor SDI In BNC 6
V–04 Vision mixer Multiview Out Multiviewer SDI In BNC 6
A–03 Bass DI Out Stagebox A 3 XLR 10
A–04 Snare Out Stagebox A 3 XLR 10
A–05 4 Out Stagebox A XLR 10
V–01 Camera 1 SDI Out Vision mixer In 1 BNC 12
A–01 Lead vocal Out Stagebox A 1 XLR 15
A–02 Kick Out Stagebox A 2 XLR 15
V–02 Camera 2 SDI Out Vision mixer In 2 BNC 18
A–06 FOH console Aux 1 Wedge 1 In XLR 20
A–07 FOH console Aux 2 Wedge 2 In XLR 20
N–01 Stagebox A Network FOH console Stagebox In RJ45 40
Each cable as its own row, sorted for patching order on set. more
Export CSV
Export XLSX
Labels + QR (PDF)
Dymo (CSV)
Venue / band (who owns
Channel list
Read scene file


Patch list
Channel without a house port — 1 channel(s) have no house port. The sheet for the house technician shows the internal number there with the note "kein Port" — the only number that means anything outside is missing and is not invented. (Ch 1)
Number instead of a name — 1 channel(s) have only a number as their source. A number in place of a name says nothing on the desk, in the multitrack or on the label — exactly the state in which Dante Controller shows green ticks and still nobody knows which channel is meant. (Ch 1)
Two channels on the same port — 2 channels sit on "Stagebox A 3". An input takes one signal; one of them is left over when patching, and which one is only decided in the hall. (Ch 4, 5)
Console scene file X32 / M32 · 5 channels
by name
by channel number (only if it holds)
Channels
Match
Search (device, port, type, colour, note ...)
All layers
12 / 12
No. From device Port To device Port Type Length (m) Colour
V–03 Vision mixer PGM Out Control room monitor SDI In BNC 6
V–04 Vision mixer Multiview Out Multiviewer SDI In BNC 6
A–03 Bass DI Out Stagebox A 3 XLR 10
A–04 Snare Out Stagebox A 3 XLR 10
A–05 4 Out Stagebox A XLR 10
V–01 Camera 1 SDI Out Vision mixer In 1 BNC 12
A–01 Lead vocal Out Stagebox A 1 XLR 15
A–02 Kick Out Stagebox A 2 XLR 15
V–02 Camera 2 SDI Out Vision mixer In 2 BNC 18
A–06 FOH console Aux 1 Wedge 1 In XLR 20
A–07 FOH console Aux 2 Wedge 2 In XLR 20
N–01 Stagebox A Network FOH console Stagebox In RJ45 40
Each cable as its own row, sorted for patching order on set. more
Export CSV
Export XLSX
Labels + QR (PDF)
Dymo (CSV)
Venue / band (who owns
Channel list
Read scene file



Three buttons write CSV: ***Channels*** (the channels read), ***Match*** and, from the second reading on, ***Changes***. The first import stays the reference state; every further one is compared against it. That turns the rehearsal into the list of changes that otherwise exists only in someone's head. If nothing changes, it says ***Nothing changed in the channel names between the two states.***

20261022_Beispieldaten_ Konzert und Regie_026_pult-kanaele.csv

Ch	Name	Farbe	Stumm
1	Lead vocal	RD	nicht angegeben
2	Kick	YE	nicht angegeben
3	Bass DI	GN	nicht angegeben
4	Snare	YE	nicht angegeben
5	unbeschriftet	keine Farbe	nicht angegeben
# Spaltenlexikon — was die Spalten oben bedeuten			
Ch	Die Kanalnummer am Pult.		
Name	Der Name, unter dem der Datensatz im Plan geführt wird.		

20261022_Beispieldaten_ Konzert und Regie_027_pult-zuordnung.csv

Ch (Pult)	Name (Pult)	Ch (Plan)	Quelle (Plan)
1	Lead vocal	1	4
2	Kick	2	Lead vocal
3	Bass DI	3	Kick
4	Snare	4	Bass DI
5	unbeschriftet	5	Snare
# Spaltenlexikon — was die Spalten oben bedeuten			
Ch (Pult)	Die Kanalnummer, die in der Szenendatei des Pults steht.		
Name (Pult)	Der Name, den jemand am Pult eingetippt hat.		



20261022_Beispieldaten_ Konzert und Regie_028_pult-aenderungen.csv

Ch	Was	Vorher	Nachher
1	umbenannt	Lead vocal	Lead Vox
3	Farbe geändert	GN	BL
4	Beschriftung entfernt	Snare	unbeschriftet
5	neu beschriftet	unbeschriftet	Gitarre
# Spaltenlexikon — was die Spalten oben bedeuten			
Ch	Die Kanalnummer am Pult.		
Was	Worum es in dieser Zeile geht.		
Vorher	Der Stand VOR der Änderung: beim Vergleich zweier Importe der erste Stand, auf dem Umbenennungs-Blatt der Text, den das Zielsystem heute speichert, auf dem Umbau-Zettel der Eingang, der jetzt auf diesem Ausgang liegt.		

Fixed install: docs & handover

File → ***Fixed install: docs & handover...*** collects the documents an installer and an operator need. The dialog has no tabs, but sections from top to bottom.



Basis of this handover. The box at the very top says whether the handover carries the built state (***as-built***) or the quote state (***As planned (no as-built)***), and names the findings, such as ***No as-built recorded*** or ***No venue named***; without a venue the file cannot be assigned to the venue next year, and the answers of the venue IT apply nowhere. The reason is given alongside: next year the same event will be planned from this file. If it carries the plan from before load-in, every on-site change gets rediscovered. Commit an as-built revision for that; the chapter ***Tools: Build*** describes revisions.

Editor. The field ***Editor (author for changelog & service)*** holds the name that appears in log and service entries. It applies to the whole app.



Recipient and reserve. ***Recipient of this sheet (department or person)*** is free text, not a required field. The entry appears in the register ***Documents handed out***; without one it says ***Recipient not named*** there. ***Reserve markup for BOM (%)*** (0 to 100, default 10) is added to the quantities of the cable BOM.


Fixed install — docs & handover
Basis of this handover As planned (no as-built)
Next year the same event will be planned from this file. more
No as-built recorded — Nothing has been frozen as "as built". Whoever opens this file next year plans from the state before the build — that is, from the quote, and every on-site change gets found a second time.
No venue named — The plan names no venue. Without it this file cannot be matched to the venue next year, and the answers of the house IT apply nowhere (needs 85, 91).
Editor (author for changelog & service)
Lars Z.
Lists & handover documents
Recipient of this sheet (department or person)
Kamera
Reserve markup for BOM (%) 10
All lists as one PDF
All lists as one Excel workbook
Pull/run list
Per cable: from→to, length, pathway, status (CSV)
PDF
Excel
Termination list
Per cable end: device, port, connector (CSV)
PDF
Excel
Cable schedule (register)
Master register of all cables (CSV)
PDF
Excel
Cable BOM + reserve
Aggregated by type/length incl. reserve markup (CSV)
PDF
Excel
Asset register
Devices: asset tag, location, serial, warranty, service (CSV)
PDF
Excel
Handover document
Operator overview: scope, status, BOM, assets (Markdown)
Acceptance record
Scope, test results, defects and open items from the plan, result boxes and signature block (HTML, print to PDF)
Defects and open items
Faults, failed tests, open field reports, items still planned (CSV)
PDF
Excel
Maintenance schedule
Next due date per device from its interval and the last service or the handover date (CSV)
Configuration settings
Per device and interface: address, mask, gateway, VLAN, switch port, patch panels in between, web interface (CSV)



Lists and documents. Each card under ***Lists & handover documents*** produces a file with the stamp of the plan. A click on the title writes the file in its basic format. A CSV carries a column glossary at the end and a stamp line with project, time and the identifier of the state.

CARD	FORMAT	CONTENT
Pull/run list	CSV	per cable: from→to, length, pathway, status
Termination list	CSV	per cable end: device, port, connector
Cable schedule (register)	CSV	master register of all cables
Cable BOM + reserve	CSV	by type and length, with reserve markup
Asset register	CSV	devices: asset tag, location, serial, warranty, service
Handover document	Markdown	operator overview: scope, status, BOM, assets
Acceptance record	HTML, printable as PDF	scope, test results, defects and open items from the plan, result boxes and signature block
Defects and open items	CSV	faults, failed tests, open field reports, items still planned
Maintenance schedule	CSV	next due date per device from its interval and the last service or the handover date
Configuration settings	CSV	per device and interface: address, mask, gateway, VLAN, switch port, patch panels in between, web interface
Device cards	HTML, printable as PDF	one card per device: location, identity, network, switcher input, cables, service history
Operator overview	HTML, printable as PDF	which source lies on which switcher input, where the outputs go, contacts, web interfaces
Camera positions	HTML, printable as PDF	per camera: location, height, aim, optics, switcher input and the PTZ presets from the camera plan
Attachment index	CSV	every attachment with kind, target, stored file and SHA-256, plus cables whose test result has no report
Signal paths	CSV	every chain from source to target with floor and room at each station
Route plan per floor	HTML, printable as PDF	top view per floor: rooms, riser, the connections between them, and the crossings list
Crossings (fire protection)	CSV	every room boundary, riser entry and floor slab a cable passes, with jacket rating and pathway
House run occupancy	CSV	per core of every house run: which cable uses it, which are free; only if the plan knows house runs

The dialog shows no preview of the files; the following captures show a selection.

20261022_Beispieldaten_ Konzert und Regie_036_pull-liste.csv

Label-ID	Kabel-Nr.	Name	Von Etage	Von Raum	Von Gerät	Von Port	Nach Etage	Nach Raum	Nach Gerät	Nach Port	Typ	Länge (m)	Adern	Faser	Bündel	Ebene	Trasse/Pfad	Mantel/Brandklasse
V-01	V-01	CAM 1 → mixer			Camera 1	SDI Out			Vision mixer	In 1	BNC	12				video		
V-02	V-02	CAM 2 → mixer			Camera 2	SDI Out			Vision mixer	In 2	BNC	18				video		
V-03	V-03	PGM → control room monitor			Vision mixer	PGM Out			Control room monitor	SDI In	BNC	6				video		
V-04	V-04	Multiview → Multiviewer			Vision mixer	Multiview Out			Multiviewer	SDI In	BNC	6				video		
A-01	A-01	Lead vocal → Stagebox			Lead vocal	Out			Stagebox A	1	XLR	15				audio		
A-02	A-02	Kick → Stagebox			Kick	Out			Stagebox A	2	XLR	15				audio		
A-03	A-03	Bass DI → Stagebox			Bass DI	Out			Stagebox A	3	XLR	10				audio		
A-04	A-04	Snare → Stagebox			Snare	Out			Stagebox A	3	XLR	10				audio		

20261022_Beispieldaten_ Konzert und Regie_039_kabel-bom.csv

Typ	Länge (m)	Menge	Menge inkl. 15% Reserve	Gesamtlänge (m)	Festverbindung	Stückelung	Kupplungen	Fehlbestand
BNC	6	2	3	12		1 × 10 m	0	
BNC	12	1	2	12		1 × 50 m	0	
BNC	18	1	2	18		1 × 50 m	0	
RJ45	40	1	2	40				
XLR	10	3	4	30		1 × 15 m	0	
XLR	15	2	3	30		1 × 15 m	0	
XLR	20	2	3	40		2 × 15 m	2	
# Spaltenlexikon — was die Spalten oben bedeuten								

20261022_Beispieldaten_ Konzert und Regie_041_uebergabe.md

```
# Übergabe-Dokumentation – Beispieldaten: Konzert und Regie

Erstellt: 22.10.2026

## 1 · Projekt / Anlage

- **Anlage:** Beispieldaten: Konzert und Regie
- **Standort:** –
- **Kunde:** –
- **Errichter:** –
- **Projekt-Nr.:** –
- **Übergabe-Datum:** –
- **Wartender Dienstleister:** –
- **Notfall-/Servicekontakt:** –
- **Aktuelle Revision:** –

## 2 · Umfang (Überblick)

- Geräte: **14**
- Kabel/Verbindungen: **12**
- Gesamt-Kabellänge: **182.0 m**
- Räume/Bereiche: **0**

## 3 · Commissioning / Status

- ohne Status: 12
- Kabel getestet: **0** (davon PASS: **0**)

## 4 · Kabel-Stückliste (mit 10% Reserve)

| Typ | Länge (m) | Menge | inkl. Reserve |
|---|---|---|---|
| BNC | 6 | 2 | 3 |
| BNC | 12 | 1 | 2 |
```

20261022_Beispieldaten_ Konzert und Regie_042_abnahmeprotokoll.html

Beispieldaten: Konzert und Regie — Acceptance record

1 · Installation

Installation	Beispieldaten: Konzert und Regie
Address	—
Client	—
Contractor	—
Project no.	—
Handover date	—
Maintaining service provider	—
Emergency contact	—

2 · Scope and tests

Item	Value
Devices	14
Cables	12
Cables with a test result	0 (pass 0, fail 0)
Without status	26

A cable without a status or without a test result is counted here, not listed as a defect: the plan does not know whether the work is missing or only its entry.

3 · Defects and open items

Taken from the plan: devices and cables marked as fault or still planned, failed cable tests, and field reports that were neither applied nor rejected. Points found during the walk-through go into the empty rows.

The plan records no defect. That does not mean there is none.

No.	Kind	Concerns	Description	Reported	By	Deadline	Done
1							
2							
3							
4							

4 · Result

☐ Accepted without defects

☐ Accepted with the defects listed under 3, to be remedied by the deadlines stated

20261022_Beispieldaten_ Konzert und Regie_050_signalwege.csv

Kette	Quelle	Von (Etage · Raum)	Ziel	Nach (Etage · Raum)	Zwischenstationen	Hausstrecken	Ende	Weg
K1	4 · Out		Stagebox A · box-x					4 · Out —[A-05]→ Stagebox A · box-x
K2	Bass DI · Out		Stagebox A · 3					Bass DI · Out —[A-03]→ Stagebox A · 3
K3	Camera 1 · SDI Out		Vision mixer · In 1					Camera 1 · SDI Out —[V-01]→ Vision mixer · In 1
K4	Camera 2 · SDI Out		Vision mixer · In 2					Camera 2 · SDI Out —[V-02]→ Vision mixer · In 2
K5	FOH console · Aux 1		Wedge 1 · In					FOH console · Aux 1 —[A-06]→ Wedge 1 · In
K6	FOH console · Aux 2		Wedge 2 · In					FOH console · Aux 2 —[A-07]→ Wedge 2 · In
K7	Kick · Out		Stagebox A · 2					Kick · Out —[A-02]→ Stagebox A · 2
K8	Lead vocal · Out		Stagebox A · 1					Lead vocal · Out —[A-01]→ Stagebox A · 1

PDF and Excel. The cards that are tables (pull list, termination list, cable schedule, cable BOM, asset register, defects and open items, maintenance schedule, configuration settings, attachment index, signal paths, crossings and house runs) carry the buttons ***PDF*** and ***Excel*** under the title. They write the same table in a designed form instead of CSV; the CSV remains the backup. The PDF is A4 landscape, repeats the table header on every page, carries bookmarks as well as stamp and page number and is set in Public Sans. The Excel file has one sheet per table with a frozen header row and an autofilter. ***All lists as one PDF*** and ***All lists as one Excel workbook*** combine all of these cards. The PDF then gets a cover page with a linked table of contents.

20261022_Beispieldaten_ Konzert und Regie_053_kabel-bom.pdf (Seite 1 von 1)



BEISPIELDATEN: KONZERT UND REGIE

Cable BOM + reserve

Beispieldaten: Konzert und Regie · 22.10.2026 12:39 · #2b1b95c6

Typ	Länge (m)	Menge	Menge inkl. 15% Reserve	Gesamtlänge (m)	Festverbindung	Stückelung	Kupplungen	Fehlbestand
BNC	6	2	3	12		1 × 10 m	0	
BNC	12	1	2	12		1 × 50 m	0	
BNC	18	1	2	18		1 × 50 m	0	
RJ45	40	1	2	40				
XLR	10	3	4	30		1 × 15 m	0	
XLR	15	2	3	30		1 × 15 m	0	
XLR	20	2	3	40		2 × 15 m	2	

Lars Zumpe Medienproduktion

Page 1 of 1

20261022_Beispieldaten_ Konzert und Regie_054_kabel-bom.xlsx (Blätter: Cable BOM + reserve)

Cable BOM + reserve								
Beispieldaten: Konzert und Regie · 22.10.2026 12:39 · #2b1b95c6								
Typ	Länge (m)	Menge	Menge inkl. 15% Reserve	Gesamtlänge (m)	Festverbindung	Stückelung	Kupplungen	Fehlbestand
BNC	6	2	3	12		1 × 10 m	0	
BNC	12	1	2	12		1 × 50 m	0	
BNC	18	1	2	18		1 × 50 m	0	
RJ45	40	1	2	40				
XLR	10	3	4	30		1 × 15 m	0	

20261022_Beispieldaten_ Konzert und Regie_055_uebergabe.pdf (Seite 1 von 12)

CONTENTS

Beispieldaten: Konzert und Regie

Pull/run list 2
Termination list 3
Cable schedule (register) 4
Cable BOM + reserve 5
Asset register 6
Defects and open items 7
Maintenance schedule 8
Configuration settings 9
Attachment index 10
Signal paths 11
Crossings (fire protection) 12

20261022_Beispieldaten_ Konzert und Regie_056_uebergabe.pdf (Seite 3 von 12)

BEISPIELDATEN: KONZERT UND REGIE

Termination list

Beispieldaten: Konzert und Regie · 22.10.2026 12:39 · #f24a849e

Label-ID	Ende	Gerät	Port	Steckverbinder	Geschlecht	Terminierung
V-01	A	Camera 1	SDI Out	BNC		
V-01	B	Vision mixer	In 1	BNC		
V-02	A	Camera 2	SDI Out	BNC		
V-02	B	Vision mixer	In 2	BNC		
V-03	A	Vision mixer	PGM Out	BNC		
V-03	B	Control room monitor	SDI In	BNC		
V-04	A	Vision mixer	Multiview Out	BNC		
V-04	B	Multiviewer	SDI In	BNC		
A-01	A	Lead vocal	Out	XLR		
A-01	B	Stagebox A	1	XLR		
A-02	A	Kick	Out	XLR		
A-02	B	Stagebox A	2	XLR		
A-03	A	Bass DI	Out	XLR		
A-03	B	Stagebox A	3	XLR		
A-04	A	Snare	Out	XLR		
A-04	B	Stagebox A	3	XLR		
A-05	A	4	Out	XLR		
A-05	B	Stagebox A	box-x	XLR		
N-01	A	Stagebox A	Network	RJ45		
N-01	B	FOH console	Stagebox In	RJ45		
A-06	A	FOH console	Aux 1	XLR		
A-06	B	Wedge 1	In	XLR		
A-07	A	FOH console	Aux 2	XLR		
A-07	B	Wedge 2	In	XLR		

Lars Zumpe Medienproduktion Page 3 of 12

20261022_Beispieldaten_ Konzert und Regie_057_uebergabe.xlsx (Blätter: Pull run list, Termination list, Cable schedule (register), Cable BOM + reserve, Asset register, Defects and open items, Maintenance schedule, Configuration settings, Attachment index, Signal paths, Crossings (fire protection))

Pull/run list																		
Beispieldaten: Konzert und Regie · 22.10.2026 12:39 · #8b21a3eb																		
Label-ID	Kabel-Nr.	Name	Von Etage	Von Raum	Von Gerät	Von Port	Nach Etage	Nach Raum	Nach Gerät	Nach Port	Typ	Länge (m)	Adern	Faser	Bündel	Ebene	Trasse/Pfad	Mantel/Brandklasse
V-01	V-01	CAM 1 → mixer			Camera 1	SDI Out			Vision mixer	In 1	BNC	12				video		
V-02	V-02	CAM 2 → mixer			Camera 2	SDI Out			Vision mixer	In 2	BNC	18				video		
V-03	V-03	PGM → control room monitor			Vision mixer	PGM Out			Control room monitor	SDI In	BNC	6				video		
V-04	V-04	Multiview → Multiviewer			Vision mixer	Multiview Out			Multiviewer	SDI In	BNC	6				video		
A-01	A-01	Lead vocal → Stagebox			Lead vocal	Out			Stagebox A	1	XLR	15				audio		

QR/asset IDs and labels. The section ***QR/asset IDs & labels*** assigns short, stable IDs and prints labels that tie the physical label to the record.



- ***Assign QR/asset IDs*** gives cables and devices without an ID one. The message gives the number; if everything already has an ID, it says ***All elements already have an ID.***
- ***QR labels (PDF)*** prints an A4 sheet with three columns, one label per cable and per device. On a cable the QR code carries the ID. On a device it leads to the device's page in the device library if it is known there, otherwise to the stored manufacturer or datasheet URL, otherwise it carries plain text with name, manufacturer, model and asset tag, which any phone reads without a network. The label names manufacturer and model even without a link. Scanning in the app finds the record in all three cases.
- ***Cable labels "source → destination" (AVIXA F501.01)*** names cables after their route. If a cable already has a name, it stays unless ***overwrite existing names*** is ticked. The message gives the number of labels; if nothing changed, it says so.


Fixed install — docs & handover
Device cards
One card per device: location, identity, network, switcher input, cables, service history (HTML, print to PDF)
Operator overview
Which source lies on which switcher input, where the outputs go, contacts, web interfaces (HTML, print to PDF)
Camera positions
Per camera: location, height, aim, optics, switcher input and the PTZ presets from the camera plan (HTML, print to PDF)
Attachment index
Every attachment with kind, target, stored file and SHA-256, plus cables whose test result has no report (CSV)
PDF
Excel
Signal paths
Every chain from source to target with floor and room at each station (CSV)
PDF
Excel
Route plan per floor
Top view per floor: rooms, riser, the connections between them, and the crossings list (HTML, print to PDF)
Crossings (fire protection)
Every room boundary, riser entry and floor slab a cable passes, with jacket rating and pathway (CSV)
PDF
Excel
QR/asset IDs & labels
Assigns short, stable IDs to cables/devices without one and prints QR labels linking the physical label to the record.
Assign QR/asset IDs
QR labels (PDF)
Cable labels "source → destination" (AVIXA F501.01)
overwrite existing names
Assigned 12 cable IDs, 14 device IDs.
Attachments (0)
Test reports, manufacturer documents, configuration backups. more
Test report
Whole installation
Attach files...
Field feedback (2)
Device
Wedge 2 steht 1 m weiter links
Wedge 2 · Jana (Bühne) · 22.10.26, 12:34
Cable
Länge 15 m → 20 m
Lead vocal → Stagebox · Jana (Bühne) · 22.10.26, 12:34

20261022_Beispieldaten_ Konzert und Regie_058_qr-etiketten.pdf (Seite 1 von 1)




Fixed install — docs & handover
Device cards
One card per device: location, identity, network, switcher input, cables, service history (HTML, print to PDF)
Operator overview
Which source lies on which switcher input, where the outputs go, contacts, web interfaces (HTML, print to PDF)
Camera positions
Per camera: location, height, aim, optics, switcher input and the PTZ presets from the camera plan (HTML, print to PDF)
Attachment index
Every attachment with kind, target, stored file and SHA-256, plus cables whose test result has no report (CSV)
PDF
Excel
Signal paths
Every chain from source to target with floor and room at each station (CSV)
PDF
Excel
Route plan per floor
Top view per floor: rooms, riser, the connections between them, and the crossings list (HTML, print to PDF)
Crossings (fire protection)
Every room boundary, riser entry and floor slab a cable passes, with jacket rating and pathway (CSV)
PDF
Excel
QR/asset IDs & labels
Assigns short, stable IDs to cables/devices without one and prints QR labels linking the physical label to the record.
Assign QR/asset IDs
QR labels (PDF)
Cable labels "source → destination" (AVIXA F501.01)
overwrite existing names
No labels changed (all named — enable "overwrite" if needed).
Attachments (0)
Test reports, manufacturer documents, configuration backups. more
Test report
Whole installation
Attach files...
Field feedback (2)
Device
Wedge 2 steht 1 m weiter links
Wedge 2 · Jana (Bühne) · 22.10.26, 12:34
Cable
Länge 15 m → 20 m
Lead vocal → Stagebox · Jana (Bühne) · 22.10.26, 12:34



Attachments. The section ***Attachments*** manages files attached to the plan and feeds the ***Attachment index***. Choose the ***Kind*** (***Test report***, ***Manufacturer document***, ***Configuration backup***, ***Other***) and what the file belongs to (***Whole installation***, ***Cables***, ***Devices***) and click ***Attach files...***. This exists only in the desktop app. The files live in a folder beside the project; a project not yet saved has none. The app does not accept files over 100 MB. An entry shows the file in its folder (***Show in folder***) or is removed, the file staying in the folder. The section names cables that have a test result but no report.



Field feedback. If the phone view reports corrections from the field, they arrive as open entries in the section ***Field feedback***, newest first. Each entry names the cable, the device or the note. ***Apply (merges + logs)*** brings the change into the plan and enters it in the changelog, ***Discard*** deletes the entry.


Fixed install — docs & handover
Device cards
One card per device: location, identity, network, switcher input, cables, service history (HTML, print to PDF)
Operator overview
Which source lies on which switcher input, where the outputs go, contacts, web interfaces (HTML, print to PDF)
Camera positions
Per camera: location, height, aim, optics, switcher input and the PTZ presets from the camera plan (HTML, print to PDF)
Attachment index
Every attachment with kind, target, stored file and SHA-256, plus cables whose test result has no report (CSV)
PDF
Excel
Signal paths
Every chain from source to target with floor and room at each station (CSV)
PDF
Excel
Route plan per floor
Top view per floor: rooms, riser, the connections between them, and the crossings list (HTML, print to PDF)
Crossings (fire protection)
Every room boundary, riser entry and floor slab a cable passes, with jacket rating and pathway (CSV)
PDF
Excel
QR/asset IDs & labels
Assigns short, stable IDs to cables/devices without one and prints QR labels linking the physical label to the record.
Assign QR/asset IDs
QR labels (PDF)
Cable labels "source → destination" (AVIXA F501.01)
overwrite existing names
Created 12 cable labels from source→destination.
Attachments (0)
Test reports, manufacturer documents, configuration backups. more
Test report
Whole installation
Attach files...
Field feedback (2)
Device
Wedge 2 steht 1 m weiter links
Wedge 2 · Jana (Bühne) · 22.10.26, 12:34
Cable
Länge 15 m → 20 m
Lead vocal → Stagebox · Jana (Bühne) · 22.10.26, 12:34


Fixed install — docs & handover
Device cards
One card per device: location, identity, network, switcher input, cables, service history (HTML, print to PDF)
Operator overview
Which source lies on which switcher input, where the outputs go, contacts, web interfaces (HTML, print to PDF)
Camera positions
Per camera: location, height, aim, optics, switcher input and the PTZ presets from the camera plan (HTML, print to PDF)
Attachment index
Every attachment with kind, target, stored file and SHA-256, plus cables whose test result has no report (CSV)
PDF
Excel
Signal paths
Every chain from source to target with floor and room at each station (CSV)
PDF
Excel
Route plan per floor
Top view per floor: rooms, riser, the connections between them, and the crossings list (HTML, print to PDF)
Crossings (fire protection)
Every room boundary, riser entry and floor slab a cable passes, with jacket rating and pathway (CSV)
PDF
Excel
QR/asset IDs & labels
Assigns short, stable IDs to cables/devices without one and prints QR labels linking the physical label to the record.
Assign QR/asset IDs
QR labels (PDF)
Cable labels "source → destination" (AVIXA F501.01)
overwrite existing names
Created 12 cable labels from source→destination.
Attachments (0)
Test reports, manufacturer documents, configuration backups. more
Test report
Whole installation
Attach files...
Field feedback (1)
Cable
Länge 15 m → 20 m
Lead vocal → Stagebox · Jana (Bühne) · 22.10.26, 12:34
Changelog (3)
Clear



Changelog. The last section lists the latest 30 entries: who, what, when. ***Clear*** deletes them. Without entries it says that status and service changes are logged here.


Fixed install — docs & handover
Basis of this handover As planned (no as-built)
Next year the same event will be planned from this file. more
No as-built recorded — Nothing has been frozen as "as built". Whoever opens this file next year plans from the state before the build — that is, from the quote, and every on-site change gets found a second time.
No venue named — The plan names no venue. Without it this file cannot be matched to the venue next year, and the answers of the house IT apply nowhere (needs 85, 91).
Editor (author for changelog & service)
Lars Z.
Lists & handover documents
Recipient of this sheet (department or person)
Kamera
Reserve markup for BOM (%) 15
All lists as one PDF
All lists as one Excel workbook
Pull/run list
Per cable: from→to, length, pathway, status (CSV)
PDF
Excel
Termination list
Per cable end: device, port, connector (CSV)
PDF
Excel
Cable schedule (register)
Master register of all cables (CSV)
PDF
Excel
Cable BOM + reserve
Aggregated by type/length incl. reserve markup (CSV)
PDF
Excel
Asset register
Devices: asset tag, location, serial, warranty, service (CSV)
PDF
Excel
Handover document
Operator overview: scope, status, BOM, assets (Markdown)
Acceptance record
Scope, test results, defects and open items from the plan, result boxes and signature block (HTML, print to PDF)
Defects and open items
Faults, failed tests, open field reports, items still planned (CSV)
PDF
Excel
Maintenance schedule
Next due date per device from its interval and the last service or the handover date (CSV)
Configuration settings
Per device and interface: address, mask, gateway, VLAN, switch port, patch panels in between, web interface (CSV)



Stage plot

File → ***Stage plot (SVG)...*** writes the stage top view as an SVG on one sheet. ***Stage plot, light (SVG)...*** writes the same graphic with a white background and dark text, for print and email. The entry without the addition follows the canvas theme.

The sheet contains drawing and legend from the same objects. The number on a device is the channel number of the channel list, the same as in the patch list. Devices that are not a channel, such as stagebox, console or wedge, carry no number; they are destination, not source. The legend carries the input list. If the plan has no audio cables, the sheet shows all devices without numbers and says so in its subtitle.



Export & Print

File → ***Export & Print…*** opens the export centre. On the left you choose one of seven sections: ***Plan***, ***Patch sheets***, ***Cable BOM***, ***Device BOM***, ***Racks & groups***, ***Tally map*** and ***Document packet***. Each section has a line at the top that says what it does. After an output the dialog closes.





Plan as a file

Plan outputs the canvas as a file. Five formats are available.

FORMAT	PROPERTY
PDF	printable; the title block is only in raster mode (see below)
PNG	transparent possible, sharp
JPEG	smaller, good for email
SVG	scalable, for web and further processing
DXF	CAD/plotter: devices, cables and text on layers

For PDF these settings are added:

- ***PDF theme***: ***Dark theme (like canvas)*** or ***Light theme (recommended for print)***.
- ***Monochrome-safe (layer spelled out, one line colour)*** writes the layer in plain text on every cable and gives all lines the same colour. On a black-and-white printer video and audio are otherwise hard to tell apart.
- ***Render mode***: ***Raster (classic)*** is a JPEG snapshot of the canvas, reliable, but text blurs at high zoom. It carries the title block with the project data and the stamp. ***Vector*** uses Chromium's print path: text stays selectable and sharp at any zoom, the file stays small. It has no title block; revision, state fingerprint and QR code are only in the raster PDF.
- ***Page size*** exists only for the vector PDF: ***Auto — A0 landscape (compatible with all viewers)***, ***A4 Landscape*** to ***A0 Landscape***, ***A0+ Plotter*** and ***Original — full canvas size for plotter***. Edge and Preview sometimes display pages above A0 as white; Acrobat and plotter software print them. The canvas is scaled vectorially to the page, text stays sharp.
- ***Layers (included in PDF)***: the chips Video, Audio, Control, Network, Power and Other toggle a layer for canvas and PDF. For a PDF with video only, switch the others off, export and switch them on again.


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Plan
Close
Download the canvas plan as a PDF or print it directly. PDF with title block, ready to print. Also PNG/JPEG for email/Slack.
Format
PDF
Vector with title block, printable
PNG
Transparent possible, sharp
JPEG
Smaller, good for email
SVG
Scalable, for web / further processing
DXF
CAD/plotter — devices, cables & text on layers
PDF theme
Dark theme (like canvas)
Light theme (recommended for print)
Monochrome-safe (layer spelled out, one line colour)
Render mode
Raster (classic)
JPEG snapshot. Reliable, but text blurs at high zoom in the PDF.
Vector
Chromium printToPDF. Text stays selectable & sharp at any zoom. Smaller file size. No title block — revision, state fingerprint and QR code are in the raster PDF only.
Layers (included in PDF)
Video
Audio
Control
Network
Power
Other
Layers ···
Click a chip to toggle that layer for canvas AND PDF.
Saved as Example: small studio setup
Print
Download as PDF


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Plan
Close
Download the canvas plan as a PDF or print it directly. PDF with title block, ready to print. Also PNG/JPEG for email/Slack.
Format
PDF
Vector with title block, printable
PNG
Transparent possible, sharp
JPEG
Smaller, good for email
SVG
Scalable, for web / further processing
DXF
CAD/plotter — devices, cables & text on layers
PDF theme
Dark theme (like canvas)
Light theme (recommended for print)
Monochrome-safe (layer spelled out, one line colour)
Render mode
Raster (classic)
JPEG snapshot. Reliable, but text blurs at high zoom in the PDF.
Vector
Chromium printToPDF. Text stays selectable & sharp at any zoom. Smaller file size. No title block — revision, state fingerprint and QR code are in the raster PDF only.
Layers (included in PDF)
Video
Audio
Control
Network
Power
Other
Layers ···
Click a chip to toggle that layer for canvas AND PDF.
Saved as Example: small studio setup
Print
Download as PDF


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Plan
Close
Download the canvas plan as a PDF or print it directly. PDF with title block, ready to print. Also PNG/JPEG for email/Slack.
Format
PDF
Vector with title block, printable
PNG
Transparent possible, sharp
JPEG
Smaller, good for email
SVG
Scalable, for web / further processing
DXF
CAD/plotter — devices, cables & text on layers
PDF theme
Dark theme (like canvas)
Light theme (recommended for print)
Monochrome-safe (layer spelled out, one line colour)
Render mode
Raster (classic)
JPEG snapshot. Reliable, but text blurs at high zoom in the PDF.
Vector
Chromium printToPDF. Text stays selectable & sharp at any zoom. Smaller file size. No title block — revision, state fingerprint and QR code are in the raster PDF only.
Layers (included in PDF)
Video
Audio
Control
Network
Power
Other
Layers ···
Click a chip to toggle that layer for canvas AND PDF.
Saved as Example: small studio setup
Print
Download as PDF


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Plan
Close
Download the canvas plan as a PDF or print it directly. PDF with title block, ready to print. Also PNG/JPEG for email/Slack.
Format
PDF
Vector with title block, printable
PNG
Transparent possible, sharp
JPEG
Smaller, good for email
SVG
Scalable, for web / further processing
DXF
CAD/plotter — devices, cables & text on layers
PDF theme
Dark theme (like canvas)
Light theme (recommended for print)
Monochrome-safe (layer spelled out, one line colour)
Render mode
Raster (classic)
JPEG snapshot. Reliable, but text blurs at high zoom in the PDF.
Vector
Chromium printToPDF. Text stays selectable & sharp at any zoom. Smaller file size. No title block — revision, state fingerprint and QR code are in the raster PDF only.
Page size
Auto — A0 landscape (compatible with all viewers)
Canvas is scaled vectorially to the page size. Text stays sharp.
Layers (included in PDF)
Video
Audio
Control
Network
Power
Other
Layers ···
Click a chip to toggle that layer for canvas AND PDF.
Saved as Example: small studio setup
Print
Download as PDF


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Plan
Close
Download the canvas plan as a PDF or print it directly. PDF with title block, ready to print. Also PNG/JPEG for email/Slack.
Format
PDF
Vector with title block, printable
PNG
Transparent possible, sharp
JPEG
Smaller, good for email
SVG
Scalable, for web / further processing
DXF
CAD/plotter — devices, cables & text on layers
PDF theme
Dark theme (like canvas)
Light theme (recommended for print)
Monochrome-safe (layer spelled out, one line colour)
Render mode
Raster (classic)
JPEG snapshot. Reliable, but text blurs at high zoom in the PDF.
Vector
Chromium printToPDF. Text stays selectable & sharp at any zoom. Smaller file size. No title block — revision, state fingerprint and QR code are in the raster PDF only.
Page size
Auto — A0 landscape (compatible with all viewers)
A4 Landscape (297×210 mm)
A3 Landscape (420×297 mm)
A2 Landscape (594×420 mm)
A1 Landscape (841×594 mm)
A0 Landscape (1189×841 mm)
A0+ Plotter (1682×1189 mm)
Original — full canvas size for plotter
Canvas is scaled vectorially to the page size. Text stays sharp.
Layers (included in PDF)
Video
Audio
Control
Network
Power
Other
Layers ···
Print
Download as PDF


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Plan
Close
Download the canvas plan as a PDF or print it directly. PDF with title block, ready to print. Also PNG/JPEG for email/Slack.
Format
PDF
Vector with title block, printable
PNG
Transparent possible, sharp
JPEG
Smaller, good for email
SVG
Scalable, for web / further processing
DXF
CAD/plotter — devices, cables & text on layers
PDF theme
Dark theme (like canvas)
Light theme (recommended for print)
Monochrome-safe (layer spelled out, one line colour)
Render mode
Raster (classic)
JPEG snapshot. Reliable, but text blurs at high zoom in the PDF.
Vector
Chromium printToPDF. Text stays selectable & sharp at any zoom. Smaller file size. No title block — revision, state fingerprint and QR code are in the raster PDF only.
Layers (included in PDF)
Video
Audio
Control
Network
Power
Other
Layers ···
Click a chip to toggle that layer for canvas AND PDF.
Saved as Example: small studio setup
Print
Download as PDF



At the bottom the dialog shows the name under which the file is saved. ***Download as PDF*** writes the file. ***Print*** opens the plan PDF in the system's print dialog and applies to PDF only; for PNG, JPEG, SVG and DXF the button is disabled.


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Plan
Close
Download the canvas plan as a PDF or print it directly. PDF with title block, ready to print. Also PNG/JPEG for email/Slack.
Format
PDF
Vector with title block, printable
PNG
Transparent possible, sharp
JPEG
Smaller, good for email
SVG
Scalable, for web / further processing
DXF
CAD/plotter — devices, cables & text on layers
Saved as Example: small studio setup
Print
Download as JPEG


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Plan
Close
Download the canvas plan as a PDF or print it directly. PDF with title block, ready to print. Also PNG/JPEG for email/Slack.
Format
PDF
Vector with title block, printable
PNG
Transparent possible, sharp
JPEG
Smaller, good for email
SVG
Scalable, for web / further processing
DXF
CAD/plotter — devices, cables & text on layers
Saved as Example: small studio setup
Print
Download as SVG



The results, shown here as a preview of the file written:



20261022_Example_ small studio setup_002.jpg



20261022_Example_ small studio setup_003.svg



20261022_Example_ small studio setup_004.dxf

```
0
SECTION
2
ENTITIES
0
LWPOLYLINE
8
EQUIPMENT
62
7
90
4
70
1
10
77.000
20
-77.000
10
330.000
20
-77.000
10
330.000
20
-154.000
10
77.000
20
-154.000
0
TEXT
8
LABELS
```

20261022_Example_ small studio setup_005.pdf (Seite 1 von 1)







Every PDF output of the plan, printing included, makes an entry in the register ***Documents handed out***. PNG, JPEG, SVG and DXF do not.

Patch sheets

Patch sheets creates a port assignment list per device, meant to be stuck on the device.



At the top is the compact patch list: one line per cable, sorted by source device, for the technician in the field. ***Open patch list...*** jumps into the ***Patch list*** dialog. Below it you choose devices: a tick per device, ***Select all***, ***Deselect all*** and a filter by name or category.


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Patch sheets
Close
One port assignment list per device, ideal for sticking on the device. Pick devices, then single PDF, combined PDF or print directly. Paper size is asked after the click. Alternatively: compact patch list (one line per cable, sorted by source device) for the technician in the field.
Open patch list... One line per cable, sorted by source device
— or create one patch sheet per device:
Devices (0 / 2)
Select all
Camera
Camera 1
Cameras
Camera 2
Cameras
Datasheets (0)...
Individual PDF (0)
Combined PDF (0)
Print


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Patch sheets
Close
One port assignment list per device, ideal for sticking on the device. Pick devices, then single PDF, combined PDF or print directly. Paper size is asked after the click. Alternatively: compact patch list (one line per cable, sorted by source device) for the technician in the field.
Open patch list... One line per cable, sorted by source device
— or create one patch sheet per device:
Devices (2 / 2)
Deselect all
Camera
Camera 1
Cameras
Camera 2
Cameras
Datasheets (2)...
Individual PDF (2)
Combined PDF (2)
Print


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Patch sheets
Close
One port assignment list per device, ideal for sticking on the device. Pick devices, then single PDF, combined PDF or print directly. Paper size is asked after the click. Alternatively: compact patch list (one line per cable, sorted by source device) for the technician in the field.
Open patch list... One line per cable, sorted by source device
— or create one patch sheet per device:
Devices (0 / 2)
Select all
Camera
Camera 1
Cameras
Camera 2
Cameras
Datasheets (0)...
Individual PDF (0)
Combined PDF (0)
Print



With devices selected, three buttons offer the output: ***Individual PDF (n)*** one PDF per device, ***Combined PDF (n)*** one PDF with one device per page, and ***Print*** the combined PDF in the print dialog. After the click a bar asks, for example ***Individual PDFs — Pick paper format:***, with ***A4***, ***A3*** and ***Cancel***.


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Patch sheets
Close
One port assignment list per device, ideal for sticking on the device. Pick devices, then single PDF, combined PDF or print directly. Paper size is asked after the click. Alternatively: compact patch list (one line per cable, sorted by source device) for the technician in the field.
Open patch list... One line per cable, sorted by source device
— or create one patch sheet per device:
Devices (2 / 5)
Select all
Filter...
Camera 1 Cameras
Camera 2 Cameras
Vision mixer Mixer
Multiviewer Monitors
Control room monitor Monitors
Individual PDFs — Pick paper format:
A4
A3
Cancel


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Patch sheets
Close
One port assignment list per device, ideal for sticking on the device. Pick devices, then single PDF, combined PDF or print directly. Paper size is asked after the click. Alternatively: compact patch list (one line per cable, sorted by source device) for the technician in the field.
Open patch list... One line per cable, sorted by source device
— or create one patch sheet per device:
Devices (2 / 5)
Select all
Filter...
Camera 1 Cameras
Camera 2 Cameras
Vision mixer Mixer
Multiviewer Monitors
Control room monitor Monitors
Datasheets (2)...
Individual PDF (2)
Combined PDF (2)
Print


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Patch sheets
Close
One port assignment list per device, ideal for sticking on the device. Pick devices, then single PDF, combined PDF or print directly. Paper size is asked after the click. Alternatively: compact patch list (one line per cable, sorted by source device) for the technician in the field.
Open patch list... One line per cable, sorted by source device
— or create one patch sheet per device:
Devices (2 / 5)
Select all
Filter...
Camera 1 Cameras
Camera 2 Cameras
Vision mixer Mixer
Multiviewer Monitors
Control room monitor Monitors
Batch PDF — Pick paper format:
A4
A3
Cancel


20261022_cable-planner-patch-sammlung_007.pdf (Seite 1 von 2)

Camera 1

Cameras 22.10.2026, 12:35:41

INPUTS (0)

OUTPUTS (1)

> SDI Out [BNC]
-> CAM 1 -> mixer (BNC · 12 m)
an Vision mixer - In 1 [BNC]

LZ Cable Planner - Camera 1 - 0 In / 1 Out - automatisch erzeugte Patch-Liste


20261022_Camera 1_008_patch.pdf (Seite 1 von 1)
Camera 1
Cameras
22.10.2026, 12:35:47
INPUTS (0)
OUTPUTS (1)
> SDI Out [BNC]
-> CAM 1 -> mixer (BNC - 12 m)
on Vision mixer - In 1 [BNC]



Datasheets (n)… opens the device datasheet: photos and chosen properties, one A4 page per device. The properties are arranged in groups (***General***, ***Technical data***, ***Category data***, ***Operation***, ***Tables***). The properties filled on at least one device are preselected. ***Filled ones***, ***All*** and ***None*** change the selection. A ticked but empty property prints as a dash. ***Print*** opens the print dialog, ***Save PDF*** writes the file.


Device datasheet — Camera 1
One A4 page for this device. more
General
Short name —
Type (as entered) —
Asset tag A-02f8cb62
Firmware —
Notes —
Category Cameras
Location —
Serial no. —
Manufacturer page —
Technical data
Dimensions (W × H × D) —
Weight —
Voltage —
Phases —
Screen size —
Rack units —
Power consumption —
Current —
Resolution —
Category data
Sensor size —
Connection —
Dynamic range —
Genlock input —
Lens mount —
Base ISO —
Max. frame rate —
Operation
Status —
Supplier —
Warranty until —
Web interface —
Ownership —
Purchase date —
Maintenance interval —
Switcher input —
Tables
Ports 1
Streams —
Service history —
Network —
Connections 1
Filled ones
All
None
Print


Device datasheet — Camera 1
One A4 page for this device. more
General
Short name —
Type (as entered) —
Asset tag A-02f8cb62
Firmware —
Notes —
Category Cameras
Location —
Serial no. —
Manufacturer page —
Technical data
Dimensions (W × H × D) —
Weight —
Voltage —
Phases —
Screen size —
Rack units —
Power consumption —
Current —
Resolution —
Category data
Sensor size —
Connection —
Dynamic range —
Genlock input —
Lens mount —
Base ISO —
Max. frame rate —
Operation
Status —
Supplier —
Warranty until —
Web interface —
Ownership —
Purchase date —
Maintenance interval —
Switcher input —
Tables
Ports 1
Streams —
Service history —
Network —
Connections 1
Filled ones
All
None
Print


Device datasheet — Camera 1
One A4 page for this device. more
General
Short name —
Type (as entered) —
Asset tag A-02f8cb62
Firmware —
Notes —
Category Cameras
Location —
Serial no. —
Manufacturer page —
Technical data
Dimensions (W × H × D) —
Weight —
Voltage —
Phases —
Screen size —
Rack units —
Power consumption —
Current —
Resolution —
Category data
Sensor size —
Connection —
Dynamic range —
Genlock input —
Lens mount —
Base ISO —
Max. frame rate —
Operation
Status —
Supplier —
Warranty until —
Web interface —
Ownership —
Purchase date —
Maintenance interval —
Switcher input —
Tables
Ports 1
Streams —
Service history —
Network —
Connections 1
Filled ones
All
None
Print


Device datasheet — Camera 1
One A4 page for this device. more
General
Short name —
Type (as entered) —
Asset tag A-02f8cb62
Firmware —
Notes —
Category Cameras
Location —
Serial no. —
Manufacturer page —
Technical data
Dimensions (W × H × D) —
Weight —
Voltage —
Phases —
Screen size —
Rack units —
Power consumption —
Current —
Resolution —
Category data
Sensor size —
Connection —
Dynamic range —
Genlock input —
Lens mount —
Base ISO —
Max. frame rate —
Operation
Status —
Supplier —
Warranty until —
Web interface —
Ownership —
Purchase date —
Maintenance interval —
Switcher input —
Tables
Ports 1
Streams —
Service history —
Network —
Connections 1
Filled ones
All
None
Print


Camera 1 - datasheet.pdf (Seite 1 von 1)

Camera 1

General

Category Cameras
Asset tag A-02f8cb62

Ports

Port	Direction	Connector	Signal
SDI Out	Out	BNC	BNC

Connections

Port	Cable	Other end	Behind the panels
SDI Out	CAM 1 → mixer	Vision mixer · In 1	

Example: small studio setup · 22.10.2026 12:36 · #30be8d07

Cable BOM

Cable BOM is the bill of materials of all cables, combined by type and length.



The table gives per row ***Type***, ***Length (m)***, ***Installed***, ***Total (m)***, the Rentman planning (***Rentman planned***, editable) and the ***Difference***. The column ***Pieces*** is added as soon as stock lengths are stored. The difference shows whether more or less is installed than planned. Below are the sum per discipline and the number of connectors by type.



A changed planning stays a draft. ***Save Rentman plan*** adopts it into the project, ***Discard*** takes it back. The planned quantities come from the Rentman import; the chapter ***File and Import*** describes it.



Download as CSV writes the table as CSV in UTF-8 with a BOM for Excel,
Download as PDF as PDF, ***Print*** opens it in the print dialog.

20261022_Example_ small studio setup_009_kabel-bom.csv

Type	Rentman name	Length (m)	Installed	Total (m)	Rentman planned	Difference	Pieces	Couplers	Stock short
BNC		6	2	12	0	+2			
BNC		12	1	12	0	+1			
BNC		18	1	18	0	+1			
Total			4	42				0	


20261022_Example_ small studio setup_010_kabel-bom.pdf (Seite 1 von 1)

Cable BOM

22.10.2025, 12:36:16

Example: small studio setup

Type	Length (m)	Installed	Rentman	Difference
BNC	6	2	0	+2
BNC	12	1	0	+1
BNC	18	1	0	+1

If stock lengths are stored in the project (***Settings*** → ***Project***, section ***Available stock lengths***), the BOM splits a run into pieces in stock. The column ***Pieces*** names the parts, plus the couplers per run and the excess length. If the stock does not suffice, ***Stock short*** appears with the shortfall; CSV and PDF carry the columns ***Pieces***, ***Couplers*** and ***Stock short***.


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Cable BOM
Close
Bill of materials for all cables in the project (type + length combined). Editable Rentman planning alongside. Export as CSV or PDF.
Installed cables: 12
Type
Length (m)
Installed
Total (m)
Rentman planned
Diff
Pieces
BNC (PGM → control room monitor)
6
2
12
0
+2
1 × 10 m
BNC (CAM 1 → mixer)
12
1
12
0
+1
1 × 50 m
BNC (CAM 2 → mixer)
18
1
18
0
+1
1 × 50 m
RJ45 (Stagebox → FOH)
40
1
40
0
+1
—
XLR (Bass DI → Stagebox)
10
3
30
0
+3
1 × 15 m
XLR (Lead vocal → Stagebox)
15
2
30
0
+2
1 × 15 m
XLR (Aux 1 → Wedge 1)
20
2
40
0
+2
2 × 15 m
Couplers per run: 1 · excess 10 m
Total
12
182 m
By discipline: Audio: 7× 100 m Video: 4× 42 m Network: 1× 40 m
Connectors (ends): XLR ×14 BNC ×8 RJ45 ×2
Rentman plan is saved with the project.
Save Rentman plan
Download as CSV
Download as PDF
Print


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Cable BOM
Close
Bill of materials for all cables in the project (type + length combined). Editable Rentman planning alongside. Export as CSV or PDF.
Installed cables: 12
1 cable type(s) missing
Type
Length (m)
Installed
Total (m)
Rentman planned
Diff
Pieces
BNC (PGM → control room monitor)
6
2
12
3
−1
1 × 10 m
BNC (CAM 1 → mixer)
12
1
12
0
+1
1 × 50 m
BNC (CAM 2 → mixer)
18
1
18
0
+1
1 × 50 m
RJ45 (Stagebox → FOH)
40
1
40
0
+1
—
XLR (Bass DI → Stagebox)
10
3
30
0
+3
1 × 15 m
XLR (Lead vocal → Stagebox)
15
2
30
0
+2
1 × 15 m
XLR (Aux 1 → Wedge 1)
20
2
40
0
+2
2 × 15 m
Couplers per run: 1 · excess 10 m
Total
12
182 m
By discipline: Audio: 7× 100 m Video: 4× 42 m Network: 1× 40 m
Connectors (ends): XLR ×14 BNC ×8 RJ45 ×2
Unsaved changes to the Rentman plan.
Discard
Save Rentman plan
Download as CSV
Download as PDF
Print



20261022_Beispieldaten_ Konzert und Regie_034_kabel-bom.csv

Type	Rentman name	Length (m)	Installed	Total (m)	Rentman planned	Difference	Pieces	Couplers	Stock short
BNC		6	2	12	3	-1	1 x 10 m	0	
BNC		12	1	12	0	+1	1 x 50 m	0	
BNC		18	1	18	0	+1	1 x 50 m	0	
RJ45		40	1	40	0	+1			
XLR		10	3	30	0	+3	1 x 15 m	0	
XLR		15	2	30	0	+2	1 x 15 m	0	
XLR		20	2	40	0	+2	2 x 15 m	2	
Total			12	182				2	

20261022_Beispieldaten_ Konzert und Regie_035_kabel-bom.pdf (Seite 1 von 1)

Cable BOM

22.10.2025, 12:38:38

Beispieldaten: Konzert und Regie

Type	Length (m)	Installed	Rentman	Difference
BNC S: 1 x 10 m	6	2	3	-1
BNC S: 1 x 50 m	12	1	0	+1
BNC S: 1 x 50 m	18	1	0	+1
RJ45	40	1	0	+1
XLR S: 1 x 15 m	10	3	0	+3
XLR S: 1 x 15 m	15	2	0	+2
XLR S: 2 x 15 m - 2x	20	2	0	+2



Device BOM

Device BOM counts the devices the plan needs by model and checks them against stock. Three states stay separate: ***covered*** (via catalogue identity), ***proposals*** (name match, awaiting confirmation) and ***not in stock***. The rows give ***Qty***, ***Model***, ***Coverage***, ***Stock*** and ***Location***. ***Assign type…*** assigns a type to a device without a catalogue type, ***Confirm*** adopts a proposal. ***Device BOM as CSV*** writes the list; ***Pick list (CSV)*** contains only safely covered items, sorted by storage location, for packing.



20261022_Example_ small studio setup_011_geraete-bom.csv

Menge	Modell	Kategorie	Deckung	Bestand	Verfügbar	Auf offener Ausgabe	Fehlmenge	Nicht einsatzbereit	Hinweis
1	BNC 12 m		nicht im Lager						Stammt (auch) aus: Kabelplan.
1	BNC 18 m		nicht im Lager						Stammt (auch) aus: Kabelplan.
2	BNC 6 m		nicht im Lager						Stammt (auch) aus: Kabelplan.
1	Camera 1	Cameras	nicht im Lager						Ohne Katalog-Typ — Modellname ist der Gerätename.
1	Camera 2	Cameras	nicht im Lager						Ohne Katalog-Typ — Modellname ist der Gerätename.
1	Control room monitor	Monitors	nicht im Lager						Ohne Katalog-Typ — Modellname ist der Gerätename.
1	Multiviewer	Monitors	nicht im Lager						Ohne Katalog-Typ — Modellname ist der Gerätename.
1	Vision mixer	Mixer	nicht im Lager						Ohne Katalog-Typ — Modellname ist der Gerätename.



Racks & groups

Racks & groups outputs saved racks and groups individually as PDF: one patch page per contained device with the internal wiring. A filter searches racks and groups; the card shows ***Rack · n U*** or ***Group*** and the number of devices. ***Format*** chooses the paper, ***PDF*** writes, ***Print*** opens the print dialog. Without saved racks or groups it says how to create them: select devices on the canvas and use ***Save as rack*** or ***Save group***.


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Racks & groups
Close
Export or print saved racks and groups individually as PDF: one patch page per contained device with internal wiring.
Filter racks/groups...
Format
A4
Example rack: small OB van
Rack · 12 U · 4 devices
PDF
Print


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Racks & groups
Close
Export or print saved racks and groups individually as PDF: one patch page per contained device with internal wiring.
Filter racks/groups...
Format
A4
A3
Example rack: small OB van
Rack · 12 U · 4 devices
PDF
Print


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Racks & groups
Close
Export or print saved racks and groups individually as PDF: one patch page per contained device with internal wiring.
zzz
Format
A4
No saved racks or groups yet. Select devices on the canvas and use "Save as rack" / "Save group".

20261022_Example rack_ small OB van_012_rack.pdf (Seite 1 von 4)



Patch panel 16x BNC

Patch panels 22.10.2026, 12:36:37

INPUTS (8)

> Rear 1 [BNC]
-- frei --

> Rear 2 [BNC]
-- frei --

> Rear 3 [BNC]
-- frei --

> Rear 4 [BNC]
-- frei --

> Rear 5 [BNC]
-- frei --

> Rear 6 [BNC]
-- frei --

> Rear 7 [BNC]
-- frei --

> Rear 8 [BNC]
-- frei --

OUTPUTS (8)

> Front 1 [BNC]
-> Patch 1 -> mixer In 1 (BNC - 1 m)
an Vision mixer - In 1 [BNC]

> Front 2 [BNC]
-> Patch 2 -> mixer In 2 (BNC - 1 m)
an Vision mixer - In 2 [BNC]

> Front 3 [BNC]
-- frei --

> Front 4 [BNC]
-- frei --

> Front 5 [BNC]
-- frei --

> Front 6 [BNC]
-- frei --

> Front 7 [BNC]
-- frei --

> Front 8 [BNC]
-- frei --

LZ Cable Planner - Patch panel 16x BNC - 8 In / 8 Out - automatisch erzeugte Patch-Liste


racks-druck.pdf (Seite 1 von 4)

Patch panel 16x BNC

Patch panels 22.10.2026, 12:36:41

INPUTS (8)

> Rear 1 [BNC]
-- frei --

> Rear 2 [BNC]
-- frei --

> Rear 3 [BNC]
-- frei --

> Rear 4 [BNC]
-- frei --

> Rear 5 [BNC]
-- frei --

> Rear 6 [BNC]
-- frei --

> Rear 7 [BNC]
-- frei --

> Rear 8 [BNC]
-- frei --

OUTPUTS (8)

> Front 1 [BNC]
-> Patch 1 -> mixer In 1 (BNC - 1 m)
an Vision mixer - In 1 [BNC]

> Front 2 [BNC]
-> Patch 2 -> mixer In 2 (BNC - 1 m)
an Vision mixer - In 2 [BNC]

> Front 3 [BNC]
-- frei --

> Front 4 [BNC]
-- frei --

> Front 5 [BNC]
-- frei --

> Front 6 [BNC]
-- frei --

> Front 7 [BNC]
-- frei --

> Front 8 [BNC]
-- frei --

LZ Cable Planner - Patch panel 16x BNC - 8 In / 8 Out - automatisch erzeugte Patch-Liste

Tally map

Tally map shows the chain role, device, switcher input and UMD address, derived from the plan and checked. The table has the columns ***No.***, ***Role***, ***Device(s)***, ***Switcher***, ***Input*** and ***UMD***. The lamp itself, that is which GPIO pin of which box, belongs to the hardware and is deliberately not included.


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Tally map
Close
The chain role → device → switcher input → UMD address, derived from the plan and checked. As CSV for proofreading, as JSON for the tally-pi configuration. The lamp itself (which GPIO pin of which box) belongs to the hardware and is deliberately not included.
No signal-source roles in the plan yet. A role is assigned on the device under "Signal source (role)" in the properties — it carries name, number and UMD address, and outlives the device swap.
Tally map as CSV
tally-pi devices (JSON)



The box ***Validation: n errors, m notes*** names what is wrong with the map, for example a role without a switcher input, a role without a device or a device without a UMD address. ***Tally map as CSV*** writes the table for proofreading. ***tally-pi devices (JSON)*** writes the part of `tally.json` that the plan owns: id, name, input. ATEM address and GPIO pins stay with the box. Next to the JSON file the app writes a provenance file (`.herkunft.txt`) with checksum and state.

20261022_Beispieldaten_ Konzert und Regie_030_tally.csv

Nr.	Rolle	Gerät(e)	Mischer	Eingang	UMD-Adresse
1	Kamera 1	Camera 1			1
2	Kamera 2	Camera 2			2
3	Kamera 3				

20261022_Beispieldaten_ Konzert und Regie_031_tally-devices.json.herkunft.txt

Herkunft dieser Gerätekonfiguration
==================================
Datei: 20261022_Beispieldaten_ Konzert und Regie_031_tally-devices.json
Für: tally-pi
Inhalt: Geräteliste für die Tally-Karte
Prüfsumme: #0a082d7e
Aus dem Plan

Projekt: Beispieldaten: Konzert und Regie

If the plan has devices with a multiviewer, the box ***Multiviewer layout (who is in which window)*** shows a button per device that writes the window layout as CSV: multiviewer, window, position, size, source (ATEM) and role. The names come from the same roles as tally and UMD, not from a second, hand-kept list. Below are findings, for example a window whose source has no role in the plan.

20261022_Beispieldaten_ Konzert und Regie_032_mv-Vision-mixer.csv

Multiviewer	Fenster	Position	Größe	Quelle (ATEM)	Rolle
Vision mixer · MV 1	0	oben links	groß	1	keine Rolle im Plan
Vision mixer · MV 1	1	oben rechts	groß	2	keine Rolle im Plan
Vision mixer · MV 1	30	unten links, Zelle 1	klein	nicht belegt	nicht belegt
Vision mixer · MV 1	31	unten links, Zelle 2	klein	nicht belegt	nicht belegt
Vision mixer · MV 1	32	unten links, Zelle 3	klein	nicht belegt	nicht belegt
Vision mixer · MV 1	33	unten links, Zelle 4	klein	nicht belegt	nicht belegt
Vision mixer · MV 1	40	unten rechts, Zelle 1	klein	nicht belegt	nicht belegt
Vision mixer · MV 1	41	unten rechts, Zelle 2	klein	nicht belegt	nicht belegt

The box ***Pre-show check: path, lamp, and what was seen*** records what the plan cannot derive. For each position you choose the ***Path*** of the tally, enter the ***Address*** and the ***Lamp*** and note what ***Program*** and ***Preview*** showed. The button ***seen*** writes the observation with a timestamp into the column ***Last***. Below it says how many positions are checked, and the findings, for example a missing tally path. ***Pre-show list*** writes the check as CSV.




Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Tally map
Close
The chain role → device → switcher input → UMD address, derived from the plan and checked. As CSV for proofreading, as JSON for the tally-pi configuration. The lamp itself (which GPIO pin of which box) belongs to the hardware and is deliberately not included.
No. Role Device(s) Switcher Input UMD
1 Kamera 1 Camera 1 — — 1
2 Kamera 2 Camera 2 — — 2
Multiviewer layout (who is in which window)
Vision mixer
The names come from the same roles as tally and UMD — not from a second, hand-kept list. more
MV 1: window oben links shows source 1, for which the plan knows no role.
MV 1: window oben rechts shows source 2, for which the plan knows no role.
MV 1: window unten links, Zelle 1 has no source.
MV 1: window unten links, Zelle 2 has no source.
MV 1: window unten links, Zelle 3 has no source.
MV 1: window unten links, Zelle 4 has no source.
Pre-show check: path, lamp, and what was seen
Pre-show list
The plan never claims a tally works — it records what someone saw, and when. more
Position Path Address Lamp Program Preview Last
Kamera 1 not set IP / pin / sou camera head red not checked not checked seen
Kamera 2 not set IP / pin / sou camera head not checked not checked not checked seen
Kamera 3 not set IP / pin / sou camera head not checked not checked not checked seen
No tally path is set for "Kamera 1".
No tally path is set for "Kamera 2".
No tally path is set for "Kamera 3".
0 of 3 positions checked.
Validation: 0 errors, 4 notes
Role "Kamera 1" reaches no switcher input — without an input there is no tally signal.
Role "Kamera 2" reaches no switcher input — without an input there is no tally signal.
Role "Kamera 3" is bound to no device — there is nothing whose tally would be switched.
Role "Kamera 3" has no UMD address — the display stays blank.
Tally map as CSV
tally-pi devices (JSON)



20261022_Beispieldaten_ Konzert und Regie_033_tally-vorshow.csv

Position	Weg	Adresse	Lampe	Programm	Vorschau	Geprüft am	Urteil
Kamera 1	not set	keine Adresse hinterlegt	keine Lampe benannt	not checked	not checked	not checked	not checked
Kamera 2	not set	keine Adresse hinterlegt	keine Lampe benannt	not checked	not checked	not checked	not checked
Kamera 3	not set	keine Adresse hinterlegt	keine Lampe benannt	not checked	not checked	not checked	not checked

If the direct route and the address of the Pi are entered in the settings, a block ***Straight to the Pi*** appears below. ***Read the Pi*** fetches the list from the Pi and shows the difference (***n stay, m are added***) and which roles disappear from the Pi, including their GPIO assignment. Only then is ***Send to the Pi*** available. Without these settings the block is absent; the file remains the default route.

Document packet

Document packet puts several sheets together into one printable stack, for the binder that travels to the event. One page per sheet, the column header repeats on every following page. Every sheet carries its stamp, so a stack of stamped sheets can be held against the plan tomorrow.



The sheets offered are those that carry a stamp, for example ***Pull list***, ***Termination list***, ***Cable schedule***, ***Asset register***, ***Network sheet***, ***Spectrum plan***, ***Delivery***, ***Tally map***, ***Handover to post***, ***Faceplates***, ***Signal paths***, ***House run occupancy***, ***Crossings (fire protection)***, ***Defects and open items***, ***Maintenance schedule***, ***Configuration settings*** and ***Attachment index***. Initially the pull list and the cable schedule are selected.



Paper chooses A4, Letter or A3. ***Colour*** chooses ***colour*** or ***black and white***; in black and white the name of a group stays, even where colour mode shows a colour swatch. ***Print column glossary*** appends a glossary of the columns. If a sheet has columns the glossary does not explain, the app reports it as a finding, because the stack goes to someone who does not know the columns. ***Print packet*** opens the print dialog.


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Document packet
Close
Several sheets as ONE printable stack: one page per sheet, column header repeated on every following page, paper size and colour mode selectable. For the binder that travels to the show. Every sheet carries its stamp, so a stack of stamped sheets can be checked against the plan tomorrow.
Pull list
Asset register
Delivery
Faceplates
Crossings (fire protection)
Configuration settings
Termination list
Network sheet
Tally map
Signal paths
Defects and open items
Attachment index
Cable schedule
Spectrum plan
Handover to post
House run occupancy
Maintenance schedule
Paper
A4
Letter
A3
Colour
colour
Print column glossary
Print packet


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Document packet
Close
Several sheets as ONE printable stack: one page per sheet, column header repeated on every following page, paper size and colour mode selectable. For the binder that travels to the show. Every sheet carries its stamp, so a stack of stamped sheets can be checked against the plan tomorrow.
Pull list
Asset register
Delivery
Faceplates
Crossings (fire protection)
Configuration settings
Termination list
Network sheet
Tally map
Signal paths
Defects and open items
Attachment index
Cable schedule
Spectrum plan
Handover to post
House run occupancy
Maintenance schedule
Paper
A4
Colour
colour
black and white
Print column glossary
Print packet


Export & print
Plan
Patch sheets
Cable BOM
Device BOM
Racks & groups
Tally map
Document packet
Document packet
Close
Several sheets as ONE printable stack: one page per sheet, column header repeated on every following page, paper size and colour mode selectable. For the binder that travels to the show. Every sheet carries its stamp, so a stack of stamped sheets can be checked against the plan tomorrow.
Pull list
Asset register
Delivery
Faceplates
Crossings (fire protection)
Configuration settings
Termination list
Network sheet
Tally map
Signal paths
Defects and open items
Attachment index
Cable schedule
Spectrum plan
Handover to post
House run occupancy
Maintenance schedule
Paper
A4
Colour
colour
Print column glossary
Print packet

Unterlagen-Stapel (Druckvorschau)

Pull list

Label-ID	Kabel-Nr.	Name	Von Etage	Von Raum	Von Gerät	Von Port	Nach Etage	Nach Raum	Nach Gerät	Nach Port	Typ	Länge (m)	Adern	Faser	Bündel	Ebene
C-e7b1b11a		CAM 1 → mixer			Camera 1	SDI Out			Vision mixer	In 1	BNC	12				video
C-9c09b70c		CAM 2 → mixer			Camera 2	SDI Out			Vision mixer	In 2	BNC	18				video
C-42be26fc		PGM → control room monitor			Vision mixer	PGM Out			Control room monitor	SDI In	BNC	6				video
C-a9a08269		Multiview → Multiviewer			Vision mixer	Multiview Out			Multiviewer	SDI In	BNC	6				video

Label-ID	Die Kennung auf dem Etikett: die Kabelnummer, sonst die QR-Kennung, sonst eine Kurzform der internen Id.
Kabel-Nr.	Die Kabelnummer aus dem Nummernschema des Plans.
Name	Der Name, unter dem der Datensatz im Plan geführt wird.
Von Etage	Etage des Rahmens, in dem das Quellgerät liegt. Leer heißt: der Rahmen hat keine Etage oder das Gerät liegt in keinem Rahmen — nicht „Erdgeschoss“.
Von Raum	Der Rahmen (Raum, Bereich), in dem das Quellgerät auf dem Plan liegt. Leer heißt: in keinem Rahmen.
Von Gerät	Das Gerät am A-Ende des Kabels.
Von Port	Der Anschluss am A-Ende, mit Inhaltsnamen, wo einer vergeben ist.
Nach Etage	Etage des Rahmens, in dem das Zielgerät liegt. Leer heißt: der Rahmen hat keine Etage oder das Gerät liegt in keinem Rahmen.
Nach Raum	Der Rahmen (Raum, Bereich), in dem das Zielgerät auf dem Plan liegt. Leer heißt: in keinem Rahmen.
Nach Gerät	Das Gerät am B-Ende des Kabels.
Nach Port	Der Anschluss am B-Ende, mit Inhaltsnamen, wo einer vergeben ist.
Typ	Je nach Blatt: in Kabellisten und Stückliste der Kabeltyp (etwa BNC, RJ45, XLR); im Plan-Vergleich, welche Sorte Objekt sich geändert hat (Kabel, Gerät, Raum).
Länge (m)	Die Länge in Metern.
Adern	Welche Leiter die Leitung führt, mit Farbe laut Farbnorm — etwa „L1 (braun)“. Leer, wo nichts angegeben ist.
Faser	Welche Faser der Buchse das Kabel je Ende belegt, mit Rolle, wo angegeben: „2 TX → 2 RX“. Leer, wo keine Buchse aufgeteilt ist.
Bündel	Zu welchem Anschluss die Leitung gehört. Leer, wenn zu keinem.
Ebene	Je nach Blatt: in den Kabellisten die Kabelebene (etwa Video, Audio, Netz, Strom), nach der der Plan Kabel ein- und ausblendet; im Spektrum-Plan, aus welcher Schicht der Bereich stammt — „stehend“ ist der Plan, der am Wagen hängt, „Haus“ die Überlagerung vor Ort, und die Haus-Ebene gewinnt.
Trasse/Pfad	Die Trasse, der Kanal oder das Rohr, in dem das Kabel läuft — wie am Kabel eingetragen. In der Durchgangsliste alle Trassen der Kabel, die den Übergang passieren.
Mantel/Brandklasse	Die Mantel- oder Brandklasse des Kabels (etwa LSZH, CPR B2ca). In der Durchgangsliste je Klasse gezählt; „ohne Angabe“ sind die Kabel, bei denen sie fehlt.
Term. A	Die Terminierung am A-Ende (etwa T568B, LC).
Term. B	Die Terminierung am B-Ende (etwa T568B, LC).
Status	Der Zustand der Zeile.
Test	Das Mess-Ergebnis des Kabels: PASS oder FAIL, mit der Reserve in dB, wo gemessen.
Notizen	Die freie Notiz am Kabel.

Example: small studio setup · 22.10.2026 12:36 · #be9b7a23

Termination list

Cloud & share link

File → ***Cloud & share link...*** is optional. Your file stays the master copy; the server keeps a copy with revisions, encrypted at rest. Credentials are removed before upload. The cloud uses the device library account.

Without signing in, the dialog shows ***Cloud projects use your device library account.*** and the button ***Sign in under Settings*** → ***Device library...***, which opens the settings.



Once signed in, the dialog has three sections. These sections are not captured because they need an account; they are described from the program.

- ***This project. Put this project in the cloud*** creates the first revision. Afterwards the dialog gives revision and time: ***Changes are saved to the cloud automatically. Save to cloud now*** saves at once, ***Stop syncing*** cuts the link, ***Delete from cloud*** removes the project with all revisions and share links; the local file stays. Under ***Revisions*** every revision appears with time and device. ***Restore*** makes an older one the newest revision; nothing is lost. If another device saved in the meantime, the app merges both changes and says so.
- ***Share link.*** A link lets anyone read the plan in the browser, without an account; credentials are not included. The dialog warns that the plan leaves

the computer. ***Always show the newest revision*** keeps the link current, otherwise it shows the revision that was newest when it was created. ***Expires*** chooses ***never*** or ***after 7***, ***30*** or ***90 days***. ***Create link and copy*** creates the link and copies it. The list of links gives the number of openings and the expiry for each; ***Copy*** copies again, ***Revoke*** makes the link invalid.

- ***Your cloud projects.*** Every other project of the account with ***Open*** and ***Download .cableplan***. The list has no delete button; only the linked project can be deleted.

Viewer file

File → ***Export as viewer file…*** writes a `.cpviewer` file for reviewers and helpers. The content equals the project file, with the mode forced to ***viewer***; device credentials are removed because the file goes to outsiders. Existing annotations stay, so the owner can pre-mark tasks for freelancers. Afterwards ***Viewer file saved*** names the path.

Whoever opens the file enters their name on first opening (chapter ***File and Import***); every annotation carries it.



Import annotations

File → ***Import annotations from viewer file…*** reads the annotations from a `.cpviewer` or `.json` file and merges them into the plan. The ID of an annotation is compared: new ones are added, ones changed by the reviewer (status, text) are updated. ***Annotations imported*** names both: ***n new annotation(s) imported.*** and ***n updated from reviewer changes.***

Reading the same file a second time adds nothing.

Compare plan revisions

File → ***Compare plan revisions…*** holds the open plan against an earlier state. The chosen state is the old one, the open plan the new one (***The open***

plan counts as the newer revision. Nothing is loaded or overwritten.): the question is what has changed since the earlier state.



The earlier state comes from one of two sources.

- ***Choose comparison file...*** reads a plan file. It is only read, not loaded, and does not enter the list of recently opened projects. A file without an equipment and cable list reports that it contains no readable plan.
- ***or committed revision:*** chooses a revision of the project. That needs no second file.



Afterwards the dialog names the earlier state (***Earlier revision: file*** or ***Earlier revision: revision***) and both stamps (***Revision of the chosen file***, ***Revision of the open plan***), plus a summary line with the counts: substantive changes, presentation-only changes, other areas, and the sheets superseded or impossible to judge. Two blocks follow. ***Documents*** says for each kind of sheet whether the comparison has superseded it: ***superseded***, ***cannot tell*** (with the reason) or ***unchanged***. ***Differences*** lists devices and cables as ***new***, ***gone*** or ***changed***. ***Other project areas (not itemised)*** names areas that have changed without being listed individually. ***Export as CSV*** writes the differences.


Compare plan revisions
Choose comparison file...
or committed revision:
— choose —
Probe 1
Earlier revision: file /tmp/plaene/en/beispieldaten-frueher.cableplan
Revision of the chosen file
#a78d8e5d
Revision of the open plan
#30c4162f
41 inhaltlich, 58 nur Darstellung, 20 weitere Bereiche · 10 überholt, 7 nicht beurteilbar
Documents
superseded Acceptance report
superseded Asset register
superseded Cable schedule
superseded Plan
superseded Pull list
superseded Signal paths
superseded Device fact sheet
superseded Tally pre-show list
superseded Termination list
superseded Handover document
cannot tell Multiviewer layout — There is one multiviewer layout per switcher, and the window count is a device setting that is not in the plan.
cannot tell Handover basis — The state depends on the revision list (as-built). The revision comparison builds snapshots without that list — a state from it would report every sheet as superseded although nothing changed.
cannot tell Cable bill of materials — The content depends on the reserve margin the user sets at export; that percentage is not in the stamp.
cannot tell Client summary — Every row names its basis (plan, as-built, reported), and that depends on the revision list. The revision comparison builds snapshots without that list — a state from it would report every sheet as superseded.
cannot tell Bill of materials — The content depends on the warehouse stock, which lives across projects and is not in the plan — the same list gives a different result tomorrow.
cannot tell Switch port map — There is one port map per switch; same reason as for the Videohub labels.
cannot tell Videohub labels — There is one label file per Videohub; the register keeps one state per identifier. A shared state would be wrong for the second device.
unchanged Run of show
unchanged Attachment index
unchanged Delivery
unchanged Delivery path
unchanged Fallback plan (safety net)
unchanged Operating quick reference
unchanged Network sheet (crew)
unchanged Penetrations (fire safety)
unchanged Event details
unchanged House tie-line allocation
unchanged Camera position sheet
unchanged Configuration targets
unchanged Costs: plan vs. actual
unchanged Defect list
unchanged Multicast address plan
The open plan counts as the newer revision. Nothing is loaded or overwritten.
Export as CSV
Close



20261022_Beispieldaten_ Konzert und Regie_059_plan-vergleich.csv

Art	Typ	Bezeichnung	Feld	Klasse	Vorher	Nachher
Stand	vorher	a78d8e5d				
Stand	nachher	30c4162f				
neu	Kabel	A-07				
geändert	Kabel	A-01	name	inhaltlich	Lead vocal → Stagebox	LV Out → S 1
geändert	Kabel	A-01	qrId	inhaltlich	-	C-0005
geändert	Kabel	A-01	waypoints	Darstellung	-	Liste (2)
geändert	Kabel	A-02	name	inhaltlich	Kick → Stagebox	K Out → S 2
geändert	Kabel	A-02	qrId	inhaltlich	-	C-0006

Documents handed out

File → Documents handed out… is the register of the sheets the app has output: the lists of the fixed install and every PDF output of the plan. Only sheets whose state can be computed are entered; an entry without a state could never say whether it still holds. The register lies beside the app, not in the project: it records what was output on this computer and does not travel with the plan.

Without outputs a note says ***Nothing has been handed out for this project yet — or the exports came from another machine.***

With outputs, a summary line gives how many entries belong to this project and how many of them are superseded. The table groups by recipient (from the field ***Recipient of this sheet***; without one it says ***Recipient not named***) and shows for each entry ***Document***, ***Handed out***, ***Revision on the sheet***, ***Still valid?*** and ***What changed since***. The status is ***current***, ***superseded — hand out again*** or ***cannot tell***; for superseded sheets the last column explains what has changed. ***Refresh*** reads the register again, ***Clear register*** deletes the entries after a confirmation. Older entries fall out of the register; a note says so, and a second one names entries of other projects.



Way back to Rentman

Attach plan to Rentman… attaches the current plan as a PDF, with stamp, to the linked Rentman project. The file name carries the project name and the time; beforehand a confirmation asks about the target project. ***Send cables to Rentman…*** opens a dialog that sets ***Built***, ***Planned*** and ***Already sent*** side by side per cable type and length, lets you choose the Rentman mapping and sends the difference as an addition; fewer built than last sent must be corrected in Rentman by hand. Both entries are greyed out as long as no Rentman project is linked (***no project linked***). The link is created in the Rentman import, see ***File and Import***. Neither path is captured because they need a Rentman account.

8. Tools: Plan

The ***Tools*** menu has five groups: ***Calculate***, ***Check***, ***Plan***, ***Create & manage*** and ***Device configuration***. This chapter describes the calculators, the checks and the tools for capturing and planning on site. The other entries of the groups ***Plan*** and ***Create & manage*** are in the chapter "Tools". Every dialog opens from ***Tools*** and closes with the × or Esc.



The menu entries and their hint lines:

GROUP	ENTRY	HINT LINE
Calculate	***Calculate recording storage...***	–
	Projection & display...	–
Check	***Analyses (weight/network/redundancy)...***	Weight, network, redundancy, cable runs
	Plan check...	Finds gaps and contradictions in the plan
	Plan vs. found...	Compares the plan with what is on site
Plan	***Survey (capture existing)...***	Capture existing equipment on site: name, room, assumed connection, photo
	Drum micing...	Place and name microphones on the kit
	Wireless / vocals...	Frequencies, transmitters, receivers in the spectrum
	Rundown and camera assignments...	Read in segments, assign a shot per camera position
	Delivery (streaming destinations)...	Where it goes out, with which parameters

Calculate

Recording storage calculator

Tools → ***Calculate recording storage...*** calculates the storage a recording needs: codec bitrate × duration × channels. The values are guide figures

without file system overhead.



FIELD	MEANING
Codec / bitrate preset	A preset with resolution, frame rate and bitrate in its name, for example ***ProRes 422 HQ (1080p25) — 220 Mbps***. The list holds ProRes 422 HQ, 422, 422 LT and 4444 (1080p25), ProRes 422 and 422 HQ (2160p25), DNxHD 220, 145 and 36 (proxy), H.264 1080p (high), H.265 2160p (high), XDCAM HD422 50, AVC-Intra 100 and ***Custom (own bitrate)***.
Custom bitrate (Mbps)	Appears with ***Custom***.
Hours, ***Minutes***, ***Channels***	Duration and number of recorded channels.

The result shows ***Effective bitrate***, ***Duration***, ***Per channel***, the total for all channels and the ***Write rate*** with a rating (for example ***uncritical*** or ***single HDD borderline***).

1. Pick another preset, here ***ProRes 422 HQ (2160p25)***.



1. With ***Custom (own bitrate)*** you enter the bitrate yourself.



1. Enter duration and channels.



1. The block ***Array sizing*** works out the drives: ***Redundancy*** (***None (JBOD)***, ***RAID 5 (+1)***, ***RAID 6 (+2)***, ***Mirror (×2)***), ***Slack (%)*** and ***Drive (TB)***. The result shows ***Usable need incl. headroom*** and ***Drives needed***.



1. ***Formula*** unfolds the calculation rule.



Projection & display

Tools → ***Projection & display…*** works out image size, throw distance and viewing distances, and the resolution of an LED wall. Two tabs: ***Projection & display*** and ***LED wall***.

Tab Projection & display

A second selection chooses the kind: ***Projector*** or ***Display / LED***.

FIELD	MEANING
Diagonal (")	Image diagonal in inches.
Aspect ratio	***16:9 (HD/UHD)***, ***16:10 (WUXGA)***, ***4:3 (XGA)***, ***21:9 (UltraWide)***, ***2.39:1 (CinemaScope)*** or ***1:1***.
Bottom edge above floor (m)	Height of the image's bottom edge.
Throw ratio	Projector only: ratio of throw distance to image width.
Lens shift vertical / ***horizontal*** (%)	Projector only.
Available depth (m)	Projector only: room depth for checking the distance.

Below, ***2D plan*** and ***3D view*** select the preview. The 2D plan shows a side view with projector, image area and the viewing distances (***First row***, ***Optimal***, ***Last row***) and a front view with dimensions. The result fields:

RESULT	MEANING
Image area (W × H)	Width and height of the image.
Top edge above floor	Height of the image's top edge.
Throw distance (lens → image)	Throw ratio × image width (projector only).
Lens height above floor, ***Lens offset from screen centre***	Position of the lens (projector only).
Max. image width in room	Largest image width at the available depth (projector only).
Min. viewing distance (THX 36°)	Smallest distance by THX.
Optimal viewing distance (SMPTE 30°)	Distance by SMPTE.
Max. viewing distance (6 × image height)	Largest distance.

If the projector does not fit the available depth or the lens ends up below the floor, the dialog says so.

1. Enter diagonal, throw ratio and available depth. The preview and results follow at once.



1. ***3D view*** shows the room with projector, image and seat positions in three dimensions.



1. ***Display / LED*** hides the projector fields; diagonal, aspect ratio and bottom edge remain.

Tab LED wall

The tab works out the resolution of an LED wall from ***Pixel pitch*** (mm), ***Width*** (m) and ***Height*** (m): ***Resolution*** in pixels and ***Total pixels*** with megapixels. The rule of thumb: the minimum viewing distance in metres is roughly the pixel pitch in millimetres; with 2.6 mm that is from about 2.6 m.



Check

Analyses

Tools → ***Analyses (weight/network/redundancy)…*** opens a dialog with 14 tabs in two rows: ***Was ansteht***, ***Kunden-Übersicht***, ***Kosten: Plan gegen Ist***, ***Crew: Stunden & Auslagen***, ***Namensregel***, ***Dante-Patch***, ***Gewicht & Wärme***, ***Netzwerk***, ***Redundanz***, ***RF / Funk***, ***Kabelwege***, ***Signalwege***, ***Anschlussliste*** and ***Blatt prüfen***. The tab labels appear in German in every interface language; the contents of the tabs are translated. The examples show a project in which a lot is deliberately unfinished.



Was ansteht

Was ansteht says what is due and edits nothing. The page gathers findings from the other analyses by urgency: ***Due***, ***State*** (for example ***today*** or ***no date***), ***Source*** (for example receipts, costs, crew) and ***What***. Without findings it reads ***Nothing open — there is nothing to report on this state.***



Kunden-Übersicht

The ***Kunden-Übersicht*** is a table of key figures (***Range***, ***Metric***, ***Value***, ***Share***, ***Basis***) for devices, cables and other areas of the plan, with ***Export CSV***. A selection decides whether it shows the plan as planned or as built.



Area	Metric	Value	Share	Basis
Geräte	Geräte gesamt	24	24 von 24 (100 %)	from the plan
Geräte	Cameras	3	3 von 24 (13 %)	from the plan
Geräte	Captured	3	3 von 24 (13 %)	from the plan
Geräte	Networking	3	3 von 24 (13 %)	from the plan
Geräte	Audio	2	2 von 24 (8 %)	from the plan
Geräte	IT/Server	2	2 von 24 (8 %)	from the plan
Geräte	Lighting	2	2 von 24 (8 %)	from the plan
Geräte	Adapters	1	1 von 24 (4 %)	from the plan
Geräte	Converters	1	1 von 24 (4 %)	from the plan
Geräte	Distribution	1	1 von 24 (4 %)	from the plan
Geräte	Mixer	1	1 von 24 (4 %)	from the plan
Geräte	Monitors	1	1 von 24 (4 %)	from the plan
Geräte	Other	1	1 von 24 (4 %)	from the plan
Geräte	Patch panels	1	1 von 24 (4 %)	from the plan
Geräte	Power	1	1 von 24 (4 %)	from the plan
Geräte	Recorder	1	1 von 24 (4 %)	from the plan
Kabel	Kabel gesamt	31	31 von 31 (100 %)	from the plan
Kabel	Länge gesamt (m)	2993	Summe	from the plan
Kabel	davon Länge geschätzt	1	1 von 31 (3 %)	from the plan
Kabel	BNC	8	8 von 31 (26 %)	from the plan
Kabel	Ethernet	6	6 von 31 (19 %)	from the plan
Kabel	IEC 230V	5	5 von 31 (16 %)	from the plan
Kabel	Fiber	4	4 von 31 (13 %)	from the plan
Kabel	HDMI	3	3 von 31 (10 %)	from the plan
Kabel	XLR	2	2 von 31 (6 %)	from the plan
Kabel	DMX	1	1 von 31 (3 %)	from the plan
Kabel	PowerCON	1	1 von 31 (3 %)	from the plan
Kabel	USB	1	1 von 31 (3 %)	from the plan
Ausspielung	Ziele gesamt	2	2 von 2 (100 %)	from the plan
Ausspielung	custom	1	1 von 2 (50 %)	from the plan
Ausspielung	youtube	1	1 von 2 (50 %)	from the plan
Ausspielung	davon Ausweichwege	0	0 von 2 (0 %)	from the plan
Aufbau	Gesteckte Kabel	nicht gemeldet	nicht gemeldet	not reported
Aufbau	Bestätigte Ports	nicht gemeldet	nicht gemeldet	not reported

Kosten: Plan gegen Ist

The tab compares estimate and actual value per cost line. Each row has a reference device (***— no anchor —*** or a device), ***Estimate***, the actual value and its origin (***Where it comes from***). The total row shows the project estimate (calculated), the lines without estimate or actual value and the deviation in percent. If it exceeds the set tolerance, the tab says so. An actual value without a stated origin is reported as well.



Crew: Stunden & Auslagen

The tab works out hours, rates and expenses for a period (***from*** … ***to***) and produces the sheet for the accounts (***Sheet as CSV***). A line at the top sums up: ***Hours***, ***Labour***, ***Billable expenses***, ***own expenses*** and ***to the client***. The sections:

SECTION	CONTENT
People	Name and company / freelance; add a person.
Surcharge bands	Band name, start, end, surcharge in percent, ***Sundays only***; add a band.
Rates	Per person an activity with hourly rate, optionally a flat fee, hours from and surcharge; add a rate.
Shifts	Date, person and activity, start, end and booking state (for example ***confirmed***); the row shows hours, amount and overtime. Add a shift.
Expenses	Date, kind (travel, accommodation, per diem, material, other), job, amount, receipt, ***goes to the client***; add an expense. A receipt text (till-slip mail, PDF text) can be pasted; the app reads date, amount, issuer, currency and tax rate and ***Create expense from receipt*** creates an expense.
Receipt coverage per cost line	How much of the actual values the receipts cover. The documented sum is not written into the actual value.
Approvals	Paste a message; time and sender are read as far as they are in the text. ***Record approval***.
Handover to the accounts (net)	The items per person and the call-out flat fees.

The tab reports overtime without an approval as a hint.




Analyses
Was ansteht
Kunden-Übersicht
Kosten: Plan gegen Ist
Crew: Stunden & Auslagen
Namensregel
Dante-Patch
Gewicht & Wärme
Netzwerk
Redundanz
RF / Funk
Kabelwege
Signalwege
Anschlussliste
Blatt prüfen
Stunden, Sätze und Auslagen dieses Jobs — und das Blatt, das sie in die Buchhaltung trägt. more
from 21.10.2026 to 21.10.2026 Sheet as CSV
Hours: 0:00 h Labour: 0.00 Billable expenses: 0.00 own expenses: 0.00 to the client: 0.00
People
Max Beispiel Freelance
Name
Company / freelance
+ Person
Surcharge bands
Nacht 20:00–06:00 · +25 %
Band name, e.g. Night
20:00
06:00
25
Sundays only
+ Band
Rates
Max Beispiel
Activity
Hourly rate
+ Rate
Shifts
Expenses
The receipt hangs on the line, not on the project: only that way is it visible which slip belongs to which amount. more
21.10.2026
Travel
— Job —
Amount
Receipt
goes to the client
+ Expense
Paste receipt text (till-slip mail, PDF text, typed)
— Job —
Create expense from receipt
Receipt coverage per cost line
The documented sum is not written into the actual. more
Kameras
documented: 0.00 of which with a file: 0.00 Actual: 5600.00
documented: 0.00 of which with a file: 0.00 Actual: not set
Approvals
Paste the message — time and sender are read from the text, as far as they are in it. more
[09/09/26, 20:14] Max Mustermann: yes, do the overtime
— general —
+ Record approval


Analyses
Was ansteht
Kunden-Übersicht
Kosten: Plan gegen Ist
Crew: Stunden & Auslagen
Namensregel
Dante-Patch
Gewicht & Wärme
Netzwerk
Redundanz
RF / Funk
Kabelwege
Signalwege
Anschlussliste
Blatt prüfen
Stunden, Sätze und Auslagen dieses Jobs — und das Blatt, das sie in die Buchhaltung trägt. more
from 21.10.2026 to 21.10.2026 Sheet as CSV
Hours: 15:00 h Labour: 1100.00 Billable expenses: 0.00 own expenses: 0.00 to the client: 1100.00
Overtime without approval — Max Beispiel has 7.0 h of overtime on 2026-10-21 — the plan holds no approval for it.
People
Max Beispiel Freelance
Name
Company / freelance
+ Person
Surcharge bands
Nacht 20:00–06:00 · +25 %
Band name, e.g. Night
20:00
06:00
25
Sundays only
+ Band
Rates
Max Beispiel
Kamera
60
50
8
25
Nacht
Max Beispiel
Activity
Hourly rate
+ Rate
Shifts
21.10.2026
Max Beispiel · Kamera
08:00
23:00
worked
15:00 h 1050.00 + 50.00 · 7:00 h overtime
+ Shift
Expenses
The receipt hangs on the line, not on the project: only that way is it visible which slip belongs to which amount. more
21.10.2026
Travel
— Job —
Amount
Receipt
goes to the client
+ Expense
Paste receipt text (till-slip mail, PDF text, typed)
— Job —
Create expense from receipt
Receipt coverage per cost line
The documented sum is not written into the actual. more
Kameras
documented: 0.00 of which with a file: 0.00 Actual: 5600.00
documented: 0.00 of which with a file: 0.00 Actual: not set
Approvals


Analyses
Max Beispiel
Freelance
Name
Company / freelance
+ Person
Surcharge bands
Nacht
20:00–06:00 · +25 %
Band name, e.g. Night
20:00
06:00
25
Sundays only
+ Band
Rates
Max Beispiel
Kamera
60
50
8
25
Nacht
Max Beispiel
Activity
Hourly rate
+ Rate
Shifts
21.10.2026
Max Beispiel · Kamera
08:00
23:00
worked
15:00 h 1050.00 + 50.00 · 7:00 h overtime
+ Shift
Expenses
The receipt hangs on the line, not on the project: only that way is it visible which slip belongs to which amount. more
2026-10-21 Travel
42.50 B-17
Attach receipt
— no cost line —
own cost
21.10.2026
Travel
— Job —
Amount
Receipt
goes to the client
+ Expense
Paste receipt text (till-slip mail, PDF text, typed)
12.09.2026
Gaffa 3 Rollen 17,85
Summe EUR 21,24
MwSt 19 %
Date: 2026-09-12 (from the receipt text) Amount: 21.24 (from the receipt text) Merchant: Baumarkt Nord GmbH (from the receipt text)
Currency: EUR (from the receipt text) Tax rate: 19 % (from the receipt text)
— Job —
Create expense from receipt
Receipt coverage per cost line
The documented sum is not written into the actual. more
Kameras
documented: 0.00 of which with a file: 0.00 Actual: 5600.00
documented: 0.00 of which with a file: 0.00 Actual: not set
1 expenses point at no cost line and show up in no comparison.
Approvals
Paste the message — time and sender are read from the text, as far as they are in it. more
[09/09/26, 20:14] Max Mustermann: yes, do the overtime
— general —
+ Record approval
Handover to the accounts (net)



Namensregel

The tab forms device names from a rule instead of from a feeling. A row with separator, case (***as generated***, ***UPPER***, ***lower***) and category (***— all categories —*** or one) controls the naming; the table shows ***Old name***, ***New name*** and the character count. ***Apply (n)*** renames the devices, ***Export CSV*** writes the table.

Below, ***Recording names*** produces the file name of every recording from the plan: ***Take***, ***Separator*** and a ***Sheet for the deck (CSV)***. The table lists per role the recorder, the channel and the file name. If a role reaches no recorder, no recording is made; a hint beside it says so.


Analyses
Was ansteht
Kunden-Übersicht
Kosten: Plan gegen Ist
Crew: Stunden & Auslagen
Namensregel
Dante-Patch
Gewicht & Wärme
Netzwerk
Redundanz
RF / Funk
Kabelwege
Signalwege
Anschlussliste
Blatt prüfen
Names from a rule instead of from a feeling. more
as generated
— all categories —
Apply (24)
Export CSV
Old name New name Characters
Kamera 1 Cameras-01 10
Kamera 2 Cameras-02 10
Bildmischer Mixer-03 8
PTZ-Kamera Cameras-04 10
Konverter Converters-05 13
Regiemonitor Monitors-06 11
Switch 1 Networking-07 13
Patchfeld Patch panels-08 15
Streaming-PC IT/Server-09 12
Stagebox Audio-10 8
Tonmischer Audio-11 8
LWL-Sender Networking-12 13
LWL-Empfänger Networking-13 13
Lichtpult Lighting-14 11
Scheinwerfer Lighting-15 11
Stromverteiler Power-16 8
Verteilverstärker Distribution-17 15
Laptop IT/Server-18 12
Adapter USB-C auf DisplayPort Adapters-19 11
Unbekanntes Gerät Other-20 8
Vermuteter Recorder Recorder-21 11
Projektor Decke vorne Captured-22 11
Lautsprecher links Captured-23 11
Beamer Saal hinten Captured-24 11
Recording names
The filename of every recording, built from the plan instead of deck by deck on each config page. more
Take
Separator _
Sheet for the deck (CSV)
Role Recorder Channel Filename
Kamera 1 no recorder in the plan Planungsprobe_Kamera 1 This role reaches no recorder: no recording is made The name contains a character a storage medium rejects ( )
Kamera no recorder in the Planungsprobe_Kamera 2 This role reaches no recorder: no recording is made The name contains a


Analyses
Was ansteht
Kunden-Übersicht
Kosten: Plan gegen Ist
Crew: Stunden & Auslagen
Namensregel
Dante-Patch
Gewicht & Wärme
Netzwerk
Redundanz
RF / Funk
Kabelwege
Signalwege
Anschlussliste
Blatt prüfen
Names from a rule instead of from a feeling. more
_
UPPER
Audio
Apply (2)
Export CSV
Old name New name Characters
Stagebox AUDIO_01 8
Tonmischer AUDIO_02 8
Recording names
The filename of every recording, built from the plan instead of deck by deck on each config page. more
Take
Separator _
Sheet for the deck (CSV)
Role Recorder Channel Filename
Kamera 1 no recorder in the plan Planungsprobe_Kamera 1 This role reaches no recorder: no recording is made The name contains a character a storage medium rejects ( )
Kamera 2 no recorder in the plan Planungsprobe_Kamera 2 This role reaches no recorder: no recording is made The name contains a character a storage medium rejects ( )



Dante-Patch

Read matrix reads the subscription matrix of a Dante network and shows the number of receive channels; ***Export CSV*** writes it as a sheet. When a second matrix is read, ***Changes*** shows the comparison.



Gewicht & Wärme

The tab shows weight (kg), power (W), heat load (BTU/h) and value (€) per category from the device properties, with a total row. A line says how many devices have no weight stated. ***Heaviest devices (rigging/transport)*** lists the heaviest devices; ***Export CSV*** writes the table. The button ***Calculate power consumption...*** opens the Power calculator.



Power calculator

The calculator adds up the power ratings of the devices (devices without a value do not count). ***Connection type*** (for example ***CEE 32 A (3-phase, red)***) and ***Safety margin (%)*** determine the sizing. The result shows the devices counted, the total consumption plus margin in W and kW, the current, the generator size and the heat in BTU/h and kW; ***Fits on*** names the connections that suffice. ***Phase distribution*** shows the load per phase and the neutral current; ***Devices*** → ***Phase*** assigns devices to a fixed phase or leaves them on ***Auto*** (the balancer distributes, sorted by power). ***EU colour code (DIN VDE 0293-308)*** names the conductor colours. ***Export CSV*** and ***PDF report*** write the result. Further sections: ***UPS / battery backup*** (apparent power, power factor, battery data, load, recommended UPS, estimated backup time), ***Voltage drop (feeder)*** (cable length, cross-section, load current, voltage drop in percent rated ≤ 3 %, > 3 %, > 5 %) and ***Top consumers***.



Netzwerk

The ***Netzwerk*** tab gives an IP/VLAN overview of all network-capable devices with a duplicate-IP check. At the top are ***Calculate bandwidth*** (see below) and the findings: ***Duplicate IP addresses*** and ***Check Dante/AES67 names (≤31 chars, a–z/0–9/-)*** with a suggestion for a valid name. Below follow the table ***Device***, ***IP***, ***Mgmt VLAN***, ***VLANs*** and the sections:

SECTION	CONTENT
Segments (VLAN, purpose, timing, way in)	One segment per VLAN with name, ***Purpose*** (media primary, media secondary, control, management, not stated), ***PTP domain*** and ***Way in***. Adopting VLANs from the plan creates the segments; ***Segments*** exports, ***Who sits where*** lists the devices per segment. A VLAN number alone does not say whether Dante may go there; the tab therefore reports segments without a name.
Streams	Sent and received streams of the devices (protocol, address, format); ***CSV***.
Patch panel labels	Strips and labels for patch panels: ***Template: automatic*** (or a template), ***Print strips***, ***Generic (CSV)*** (format selectable) and ***Label-printer file***. If a patch panel is in no rack, the tab says so.
Address ranges (standing plan + venue overlay)	A standing layer and the ***venue layer***; the venue layer replaces a standing range with the same key. ***Ranges*** exports.
Subnets	The subnets of the plan with their devices.
Address plan	How many network devices are addressed; hints on missing or duplicate addresses.
Switch port map	Per switch the ports with device, interface, address and kind of connection; ***CSV*** and ***Labels***.
Request to the venue IT	The wishes towards the venue network (VLANs, address ranges, network ports, media bandwidth, multicast standards, PoE, IGMP querier, PTP, DHCP, QoS / DSCP). For each point the answer can be recorded: ***granted***, ***with a condition*** (with a field ***condition or workaround, in plain words***), ***refused*** or ***no answer yet***. ***CSV***.
Timing (PTP)	The PTP domains and the question which device sets the clock.
Which box fills which slot	Devices with a network identity but without a named unit.
Multicast address plan	***Pool (CIDR)*** and ***UDP port***; assigning gives the streams addresses.


Analyses
Was ansteht
Kunden-Übersicht
Kosten: Plan gegen Ist
Crew: Stunden & Auslagen
Namensregel
Dante-Patch
Gewicht & Wärme
Netzwerk
Redundanz
RF / Funk
Kabelwege
Signalwege
Anschlussliste
Blatt prüfen
IP/VLAN overview of all network-capable devices with duplicate-IP detection.
Calculate bandwidth…
Duplicate IP addresses
10.0.1.20: Bildmischer, PTZ-Kamera
Check Dante/AES67 names (≤31 chars, a–z/0–9/-)
Switch 1: invalid characters (only a–z, 0–9, -) → Switch-1
Device IP Mgmt VLAN VLANs
Bildmischer 10.0.1.20 10 10
PTZ-Kamera 10.0.1.20
Switch 1 10.0.1.2
Streaming-PC 10.0.1.30
Devices per VLAN: VLAN 10 (2)
Segments (VLAN, purpose, timing, way in)
+ Adopt 4 VLAN(s) from the plan
Segments
Who sits where
A VLAN number alone tells nobody whether Dante may go there. more
VLAN Segment Purpose PTP domain Way in Interfaces
10 not recorded 1
20 not recorded 1
30 not recorded 1
31 not recorded 1
VLAN 10 carries 1 interface(s) but has no name — a number alone tells nobody whether Dante may go there.
VLAN 20 carries 1 interface(s) but has no name — a number alone tells nobody whether Dante may go there.
VLAN 30 carries 1 interface(s) but has no name — a number alone tells nobody whether Dante may go there.
VLAN 31 carries 1 interface(s) but has no name — a number alone tells nobody whether Dante may go there.
Streams (2)
CSV
Streaming-PC Sends SRT Programm srt://10.0.1.30:9000 H.264 1080p50
Streaming-PC Receives RTSP PTZ rtsp://10.0.1.20/1
Patch panel labels
1 panels · 1 labelled ports
Template: automatic
Print strips
Generic (CSV)
Label-printer file
Patchfeld: patch panel is not placed in a rack.


Analyses
Segments (VLAN, purpose, timing, way in)
Segments
Who sits where
A VLAN number alone tells nobody whether Dante may go there. more
VLAN Segment Purpose PTP domain Way in Interfaces
10 Dante Prim not specified reachable only from inside 1
20 Dante Prim not specified reachable only from inside 1
30 Dante Prim not specified reachable only from inside 1
31 Dante Prim not specified reachable only from inside 1
VLAN 10 carries 1 interface(s) but has no name — a number alone tells nobody whether Dante may go there.
VLAN 20 carries 1 interface(s) but has no name — a number alone tells nobody whether Dante may go there.
VLAN 30 carries 1 interface(s) but has no name — a number alone tells nobody whether Dante may go there.
VLAN 31 carries 1 interface(s) but has no name — a number alone tells nobody whether Dante may go there.
Streams (2)
CSV
Streaming-PC Sends SRT Programm srt://10.0.1.30:9000 H.264 1080p50
Streaming-PC Receives RTSP PTZ rtsp://10.0.1.20/1
Patch panel labels
1 panels · 1 labelled ports
Template: automatic
Print strips
Generic (CSV)
Label-printer file
Patchfeld: patch panel is not placed in a rack.
Address ranges (standing plan + venue overlay)
+ standing layer
venue layer
Ranges
The venue layer replaces a standing range carrying the same key and leaves all others in force. more
No layer created yet.
Subnets (1)
10.0.1.0/24 4 devices Bildmischer, PTZ-Kamera, Switch 1, Streaming-PC
Address plan 7 of 9 networked devices addressed
Bildmischer 10.0.1.20 · VLAN 10 Address used twice: PTZ-Kamera · Gateway outside the subnet LAN (Eth-1G)
PTZ-Kamera 10.0.1.20 Address used twice: Bildmischer LAN (Eth-1G)
Patchfeld No address Ein 1 (Ethernet/RJ45)
AUDIO_01 No address Dante (Dante)
Switch port map
1 switches
Switch 1
6 of 8 occupied
CSV
Descriptions
Port 1 PTZ-Kamera LAN 10.0.1.20 cable via Patchfeld
Port 2 Streaming-PC NET1 10.0.1.31 VLAN 20 interface
Port 3 Bildmischer LAN 10.0.1.20 cable
Port 4 Kamera 1 2110 A cable


Analyses
Subnets (1)
10.0.1.0/24 4 devices Bildmischer, PTZ-Kamera, Switch 1, Streaming-PC
Address plan 7 of 9 networked devices addressed
Bildmischer 10.0.1.20 · VLAN 10 Address used twice: PTZ-Kamera · Gateway outside the subnet LAN (Eth-1G)
PTZ-Kamera 10.0.1.20 Address used twice: Bildmischer LAN (Eth-1G)
Patchfeld No address Ein 1 (Ethernet/RJ45)
AUDIO_01 No address Dante (Dante)
Switch port map
1 switches
Switch 1
6 of 8 occupied
CSV
Descriptions
Port 1 PTZ-Kamera LAN 10.0.1.20 cable via Patchfeld
Port 2 Streaming-PC NET 1 10.0.1.31 VLAN 20 interface
Port 3 Bildmischer LAN 10.0.1.20 cable
Port 4 Kamera 1 2110 A cable
Port 5 AUDIO_01 Dante cable
Port 6 free
Port 7 Kamera 1 2110 A cable
Port 8 free
Request to the venue IT
CSV
The design literature prescribes the content and a joint test session, but no document. more
The plan carries both: Dante (audio vendors' field advice: turn IGMP snooping off) and ST2110-20 (does not work without multicast management). On a shared network those two pieces of advice are mutually exclusive — that belongs before the build, not into the night.
VLANs
10, 20, 30, 31
granted with a condition refused no answer yet
Address ranges
10.0.1.0/24, 10.1.1.0/24, 10.1.2.0/24
granted with a condition refused no answer yet
Network ports
7
granted with a condition refused no answer yet
Media bandwidth
3049 Mbit/s
Summe der Medien-Standards im Plan; Link-Kapazität zählt bewusst nicht mit. Planungsrichtwert für eine Konferenz mit drei Streams: mindestens 100 Mbit/s dedizierter Upload, getrennt vom Besuchernetz (trivisionstudios.com)
granted with a condition refused no answer yet
Multicast standards
Dante, ST2110-20
Shure, „Dante networks and IGMP snooping"; Arista, Multicast Addressing (ST 2110)
granted with a condition refused no answer yet
PoE
20 W
granted with a condition refused no answer yet
IGMP querier
Wer im Haus ist IGMP-Querier, und ist es genau einer? Der Plan kann das nicht wissen. Die Praxis nennt beide Fehler: „only one IGMP querier should be turned on", und „turning on IGMP snooping on certain


Analyses
Request to the venue IT
CSV
The design literature prescribes the content and a joint test session, but no document. more
The plan carries both: Dante (audio vendors' field advice: turn IGMP snooping off) and ST2110-20 (does not work without multicast management). On a shared network those two pieces of advice are mutually exclusive — that belongs before the build, not into the night.
VLANs
10, 20, 30, 31
granted with a condition refused no answer yet
Address ranges
10.0.1.0/24, 10.1.1.0/24, 10.1.2.0/24
granted with a condition refused no answer yet
Network ports
7
granted with a condition refused no answer yet
Media bandwidth
3049 Mbit/s
Summe der Medien-Standards im Plan; Link-Kapazität zählt bewusst nicht mit. Planungsrichtwert für eine Konferenz mit drei Streams: mindestens 100 Mbit/s dedizierter Upload, getrennt vom Besuchernetz (trivisionstudios.com)
granted with a condition refused no answer yet
Multicast standards
Dante, ST2110-20
Shure, „Dante networks and IGMP snooping"; Arista, Multicast Addressing (ST 2110)
granted with a condition refused no answer yet
PoE
20 W
granted with a condition refused no answer yet
IGMP querier
Wer im Haus ist IGMP-Querier, und ist es genau einer? Der Plan kann das nicht wissen. Die Praxis nennt beide Fehler: „only one IGMP querier should be turned on", und „turning on IGMP snooping on certain switches can disable 100 % of the Dante multicast traffic".
Blue Room, Dante switch performance; ControlBooth 47261
granted with a condition refused no answer yet
ptp
Lassen die Haus-Switches PTP (IEEE 1588) durch, oder sind sie Boundary Clock? Welche Domäne ist im Haus schon belegt? ST 2059-2 steht per Vorgabe auf Domäne 127, AES67 in der Praxis auf 0 — kollidiert eine davon mit dem Haus, läuft der Aufbau auf dem falschen Medientakt an, ohne einen Fehler zu melden.
SMPTE ST 2059-2; AES67 Media Profile
granted with a condition refused no answer yet
DHCP
Gibt es DHCP in diesen VLANs, und in welchem Bereich? Der Plan arbeitet mit festen Adressen; ein zweiter, unbekannter DHCP-Dienst im selben Netz ist ein benannter Ausfallgrund. Audinates Feldrat für AV-Switches lautet ausdrücklich: kein DHCP anbieten.
Blue Room, Dante switch performance
granted with a condition refused no answer yet
QoS / DSCP
Welche QoS-/DSCP-Behandlung ist im Haus gesetzt, und bleibt sie über alle beteiligten Switches gleich? Die Design-Literatur schreibt QoS als Inhalt vor, nennt aber keine Werte; und uneinheitliche Switches sind selbst die Gefahr: „If the network uses different types of switches, the configurations may not behave as intended even if set correctly".
Crestron, AV-over-IP Network Design; Ruckus; ControlBooth 47261
granted with a condition refused no answer yet


Analyses
Request to the venue IT
CSV
The design literature prescribes the content and a joint test session, but no document. more
The plan carries both: Dante (audio vendors' field advice: turn IGMP snooping off) and ST2110-20 (does not work without multicast management). On a shared network those two pieces of advice are mutually exclusive — that belongs before the build, not into the night.
VLANs
10, 20, 30, 31
granted with a condition refused no answer yet condition or workaround, in plain words
Address ranges
10.0.1.0/24, 10.1.1.0/24, 10.1.2.0/24
granted with a condition refused no answer yet condition or workaround, in plain words
Network ports
7
granted with a condition refused no answer yet
Media bandwidth
3049 Mbit/s
Summe der Medien-Standards im Plan; Link-Kapazität zählt bewusst nicht mit. Planungsrichtwert für eine Konferenz mit drei Streams: mindestens 100 Mbit/s dedizierter Upload, getrennt vom Besuchernetz (trivisionstudios.com)
granted with a condition refused no answer yet
Multicast standards
Dante, ST2110-20
Shure, „Dante networks and IGMP snooping"; Arista, Multicast Addressing (ST 2110)
granted with a condition refused no answer yet
PoE
20 W
granted with a condition refused no answer yet
IGMP querier
Wer im Haus ist IGMP-Querier, und ist es genau einer? Der Plan kann das nicht wissen. Die Praxis nennt beide Fehler: „only one IGMP querier should be turned on", und „turning on IGMP snooping on certain switches can disable 100 % of the Dante multicast traffic".
Blue Room, Dante switch performance; ControlBooth 47261
granted with a condition refused no answer yet
ptp
Lassen die Haus-Switches PTP (IEEE 1588) durch, oder sind sie Boundary Clock? Welche Domäne ist im Haus schon belegt? ST 2059-2 steht per Vorgabe auf Domäne 127, AES67 in der Praxis auf 0 — kollidiert eine davon mit dem Haus, läuft der Aufbau auf dem falschen Medientakt an, ohne einen Fehler zu melden.
SMPTE ST 2059-2; AES67 Media Profile
granted with a condition refused no answer yet
DHCP
Gibt es DHCP in diesen VLANs, und in welchem Bereich? Der Plan arbeitet mit festen Adressen; ein zweiter, unbekannter DHCP-Dienst im selben Netz ist ein benannter Ausfallgrund. Audinates Feldrat für AV-Switches lautet ausdrücklich: kein DHCP anbieten.
Blue Room, Dante switch performance
granted with a condition refused no answer yet
QoS / DSCP
Welche QoS-/DSCP-Behandlung ist im Haus gesetzt, und bleibt sie über alle beteiligten Switches gleich? Die Design-Literatur schreibt QoS als Inhalt vor, nennt aber keine Werte; und uneinheitliche Switches sind selbst die Gefahr: „If the network uses different types of switches, the configurations may not behave as intended even if set correctly".
Crestron, AV-over-IP Network Design; Ruckus; ControlBooth 47261
granted with a condition refused no answer yet



Calculate bandwidth

Calculate bandwidth works out the gross data rate of a video stream before compression and names the smallest SDI tier that carries it (pixels × lines × fps × bits per pixel). If it exceeds 12G-SDI, the dialog says it is possible only over IP transport (ST 2110, NDI, JPEG-XS …). Unfoldable lists name the SDI tiers and the IP/digital signal standards. The section ***Project network budget*** adds up the gross bandwidths of all cables with an IP media signal (NDI, Dante/AES67, ST 2110); Ethernet cables do not count as load, their capacity is shown separately below.



Redundanz

The table ***Device*** / ***Finding*** names per device what is missing in redundancy, for example ***only one power connection (no PSU redundancy)***, ***no power connection in the plan*** or ***ST 2110 without 2110-7 redundancy (only one network path)***. ***Export CSV*** writes it.



RF / Funk

RF / Funk calculates everything in the plan that transmits — the wireless mic rig and the radio links — in one calculation. The tab names the number of transmitters in the plan, transmitters without a frequency (they are in no calculation) and lists ***Possible RF conflicts*** (for example the same WLAN channel) and ***Frequency findings across the whole spectrum*** (carrier spacing and intermodulation of 2nd and 3rd order).

Below are ***Free frequencies in band*** (band selectable), the ***Frequency bands (Sennheiser / Shure / …)*** as a table with manufacturer, series, band, MHz range and notes (for example restricted in the EU), and the ***Spectrum scan from the analyser***: ***Read scan*** reads a CSV with measurement points, ***occupied from (dBm)*** sets the threshold, ***Sync*** checks the carriers against the scan. Carriers outside the measured range are listed separately; "not measured" does not mean "free".


Analyses
Was ansteht
Kunden-Übersicht
Kosten: Plan gegen Ist
Crew: Stunden & Auslagen
Namensregel
Dante-Patch
Gewicht & Wärme
Netzwerk
Redundanz
RF / Funk
Kabelwege
Signalwege
Anschlussliste
Blatt prüfen
Everything that transmits in the plan — wireless mic rig AND radio links, in one calculation. more
5 transmitters in the plan: 1 from the wireless mic rig, 4 as radio links. 1 without a frequency — they are in NO calculation: Channel 2
Possible RF conflicts
• WLAN Kamera 1 ↔ WLAN Kamera 2: same channel 36
Frequency findings across the whole spectrum (16)
• Channel 1 (Funkmikrofon-Rig) ↔ Funk Kamera 1 (UHF) (Funkstrecke: Kamera 1 → Bildmischer) — Channel 1 (606.4) ↔ Funk Kamera 1 (UHF) (606.4): Abstand 0 MHz < 0.4 MHz
• Channel 1 (Funkmikrofon-Rig) ↔ Funk Kamera 2 (UHF) (Funkstrecke: Kamera 2 → Bildmischer) — Channel 1 (606.4) ↔ Funk Kamera 2 (UHF) (606.6): Abstand 0.2 MHz < 0.4 MHz
• Funk Kamera 1 (UHF) (Funkstrecke: Kamera 1 → Bildmischer) ↔ Funk Kamera 2 (UHF) (Funkstrecke: Kamera 2 → Bildmischer) — Funk Kamera 1 (UHF) (606.4) ↔ Funk Kamera 2 (UHF) (606.6): Abstand 0.2 MHz < 0.4 MHz
• WLAN Kamera 1 (Funkstrecke: Kamera 1 → Bildmischer) ↔ WLAN Kamera 2 (Funkstrecke: Kamera 2 → Bildmischer) — WLAN Kamera 1 (5180) ↔ WLAN Kamera 2 (5180): Abstand 0 MHz < 0.4 MHz
• Channel 1 (Funkmikrofon-Rig) ↔ Funk Kamera 1 (UHF) (Funkstrecke: Kamera 1 → Bildmischer) ↔ Funk Kamera 2 (UHF) (Funkstrecke: Kamera 2 → Bildmischer) — 2·Channel 1 − Funk Kamera 1 (UHF) = 606.4 MHz trifft Funk Kamera 2 (UHF) (606.6)
• Channel 1 (Funkmikrofon-Rig) ↔ Funk Kamera 2 (UHF) (Funkstrecke: Kamera 2 → Bildmischer) ↔ Funk Kamera 1 (UHF) (Funkstrecke: Kamera 1 → Bildmischer) — 2·Channel 1 − Funk Kamera 2 (UHF) = 606.2 MHz trifft Funk Kamera 1 (UHF) (606.4)
• Funk Kamera 1 (UHF) (Funkstrecke: Kamera 1 → Bildmischer) ↔ Funk Kamera 2 (UHF) (Funkstrecke: Kamera 2 → Bildmischer) ↔ Channel 1 (Funkmikrofon-Rig) — 2·Funk Kamera 1 (UHF) − Funk Kamera 2 (UHF) = 606.2 MHz trifft Channel 1 (606.4)
• Channel 1 (Funkmikrofon-Rig) ↔ WLAN Kamera 1 (Funkstrecke: Kamera 1 → Bildmischer) ↔ Funk Kamera 1 (UHF) (Funkstrecke: Kamera 1 → Bildmischer) ↔ WLAN Kamera 2 (Funkstrecke: Kamera 2 → Bildmischer) — Channel 1 + WLAN Kamera 1 − Funk Kamera 1 (UHF) = 5180 MHz trifft WLAN Kamera 2 (5180)
• Channel 1 (Funkmikrofon-Rig) ↔ WLAN Kamera 1 (Funkstrecke: Kamera 1 → Bildmischer) ↔ Funk Kamera 2 (UHF) (Funkstrecke: Kamera 2 → Bildmischer) ↔ WLAN Kamera 2 (Funkstrecke: Kamera 2 → Bildmischer) — Channel 1 + WLAN Kamera 1 − Funk Kamera 2 (UHF) = 5179.8 MHz trifft WLAN Kamera 2 (5180)
• Channel 1 (Funkmikrofon-Rig) ↔ WLAN Kamera 1 (Funkstrecke: Kamera 1 → Bildmischer) ↔ WLAN Kamera 2 (Funkstrecke: Kamera 2 → Bildmischer) ↔ Funk Kamera 1 (UHF) (Funkstrecke: Kamera 1 → Bildmischer) — Channel 1 + WLAN Kamera 1 − WLAN Kamera 2 = 606.4 MHz trifft Funk Kamera 1 (UHF) (606.4)
• Channel 1 (Funkmikrofon-Rig) ↔ WLAN Kamera 2 (Funkstrecke: Kamera 2 → Bildmischer) ↔ Funk Kamera 1 (UHF) (Funkstrecke: Kamera 1 → Bildmischer) ↔ WLAN Kamera 1 (Funkstrecke: Kamera 1 → Bildmischer) — Channel 1 + WLAN Kamera 2 − Funk Kamera 1 (UHF) = 5180 MHz trifft WLAN Kamera 1 (5180)
• Channel 1 (Funkmikrofon-Rig) ↔ WLAN Kamera 2 (Funkstrecke: Kamera 2 → Bildmischer) ↔ Funk Kamera 2 (UHF) (Funkstrecke: Kamera 2 → Bildmischer) ↔ WLAN Kamera 1 (Funkstrecke: Kamera 1 → Bildmischer) — Channel 1 + WLAN Kamera 2 − Funk Kamera 2 (UHF) = 5179.8 MHz trifft WLAN Kamera 1 (5180)
• Funk Kamera 1 (UHF) (Funkstrecke: Kamera 1 → Bildmischer) ↔ WLAN Kamera 1 (Funkstrecke: Kamera 1 → Bildmischer) ↔ Funk Kamera 2 (UHF) (Funkstrecke: Kamera 2 → Bildmischer) ↔ WLAN Kamera 2 (Funkstrecke: Kamera 2 → Bildmischer) — Funk Kamera 1 (UHF) + WLAN Kamera 1 − Funk Kamera 2 (UHF) = 5179.8 MHz trifft WLAN Kamera 2 (5180)
• Funk Kamera 1 (UHF) (Funkstrecke: Kamera 1 → Bildmischer) ↔ WLAN Kamera 1 (Funkstrecke: Kamera 1 → Bildmischer) ↔ WLAN Kamera 2 (Funkstrecke: Kamera 2 → Bildmischer) ↔ Channel 1 (Funkmikrofon-Rig) — Funk Kamera 1 (UHF) + WLAN Kamera 1 − WLAN Kamera 2 = 606.4 MHz trifft Channel 1 (606.4)
• Funk Kamera 1 (UHF) (Funkstrecke: Kamera 1 → Bildmischer) ↔ WLAN Kamera 2 (Funkstrecke: Kamera 2 → Bildmischer) ↔ Funk Kamera 2 (UHF) (Funkstrecke: Kamera 2 → Bildmischer) ↔ WLAN Kamera 1 (Funkstrecke: Kamera 1 → Bildmischer) — Funk Kamera 1 (UHF) + WLAN Kamera 2 − Funk Kamera 2 (UHF) = 5179.8 MHz trifft WLAN Kamera 1 (5180)
• Funk Kamera 2 (UHF) (Funkstrecke: Kamera 2 → Bildmischer) ↔ WLAN Kamera 1 (Funkstrecke: Kamera 1 → Bildmischer) ↔ WLAN Kamera 2 (Funkstrecke: Kamera 2 → Bildmischer) ↔ Channel 1 (Funkmikrofon-Rig) — Funk Kamera 2 (UHF) + WLAN Kamera 1 − WLAN Kamera 2 = 606.6 MHz trifft Channel 1 (606.4)
Free frequencies in band
Sennheiser A1 (470–516)



Manufacturer	Series	Band	MHz	Note
Sennheiser	ew G3/G4	A1	470–516	
Sennheiser	ew G3/G4	A	516–558	
Sennheiser	ew G3/G4	AS	520–558	
Sennheiser	ew G4	G	566–608	
Sennheiser	ew G3/G4	GB	606–648	
Sennheiser	ew G3/G4	B	626–668	
Sennheiser	ew G3/G4	C	734–776	EU eingeschränkt
Sennheiser	ew G3/G4	D	780–822	EU nicht mehr zulässig
Sennheiser	ew G3	E	823–865	nur 823–832 / 863–865 lizenzfrei (EU)
Sennheiser	ew G4	1G8	1785–1800	1,8 GHz
Sennheiser	EW-D	Q1–6	470.2–526	
Sennheiser	EW-D	R1–6	520–576	
Sennheiser	EW-D	R4–9	552–607.8	
Sennheiser	EW-D	S1–7	606.2–662	
Sennheiser	EW-D	S4–7	630–662	
Sennheiser	EW-D	S7–10	662–693.8	
Sennheiser	EW-D	U1/5	823.2–864.8	nur 823,2–831,8 / 863,2–864,8
Sennheiser	EW-D	V3–4	925.2–937.3	
Sennheiser	EW-D	Y1–3	1785.2–1799.8	
Sennheiser	EW-DX	Q1–9	470.2–550	
Sennheiser	EW-DX	R1–9	520–607.8	
Sennheiser	EW-DX	S1–10	606.2–693.8	
Sennheiser	EW-DX	S2–10	614.2–693.8	
Sennheiser	EW-DX	S4–10	630–693.8	
Sennheiser	EW-DX	U1/5	823.2–864.8	nur 823,2–831,8 / 863,2–864,8
Sennheiser	EW-DX	V3–4	925.2–951.8	nur 925,2–937,3 / 941,7–951,8
Sennheiser	EW-DX	W5–6	1240–1260	
Sennheiser	EW-DX	Y1–3	1785.2–1799.8	
Sennheiser	Digital 6000	A1–A4	470–558	
Sennheiser	Digital 6000	A5–A8	550–638	
Sennheiser	Digital 6000	B1–B4	630–718	
Shure	ULX-D	G50	470–534	
Shure	ULX-D	G51	470–534	
Shure	ULX-D	G52	479–534	
Shure	ULX-D	G53	470–510	
Shure	ULX-D	G56	470–636	nur ULXD1/2/4D/4Q
Shure	ULX-D	G57	470–608	nur ULXD1/2/4D/4Q
Shure	ULX-D	G62	510–530	
Shure	ULX-D	H50	534–598	
Shure	ULX-D	H51	534–598	
Shure	ULX-D	J50	572–636	
Shure	ULX-D	J51	572–636	
Shure	ULX-D	K51	606–670	
Shure	ULX-D	L50	632–696	

Kabelwege

The tab reports cables whose length is doubtful: estimated lengths carry their origin. It names cables whose estimated length has changed since the estimate and cables beyond the range of their type, each with the services running in the run. ***CSV*** writes the list.



Signalwege

The tab lists the multi-stage paths: source, port, cable number, intermediate device (converter, patch panel) and ***End device reached***.



Anschlussliste

The connection list shows every network connection with device, interface, IP, VLAN, path and the switch port reached, with the source (***Cables***, ***Interface***, ***Cable + interface***). Connections whose path ends at a device other than a switch are listed under ***Without a reached switch***. ***Only open ones*** shows just the unresolved ones; ***CSV*** exports.



Blatt prüfen

Blatt prüfen takes a printed sheet in hand: type the eight-character state from its foot, or read the whole document code; ***Check*** says whether the sheet matches the current plan, cannot be read or belongs to another project.



Plan check dialog

Tools → ***Plan check…*** finds gaps and contradictions in the plan. The check runs continuously against the current plan, not only on saving. At the top are the counts of findings by severity (errors, warnings, infos) and the total. Each row names the kind (for example ***Duplicate cable number***, ***Duplicate IP***, ***House outlet***, ***Fibre breakout***) and the finding. Clicking a row selects the affected object in the plan. In the status bar at the bottom, three coloured counters show the same state.



Plan vs. found

Tools → ***Plan vs. found…*** compares the plan with what is on site: what came off the truck, under which names and with which addresses — against what the plan says. ***Load file*** reads a CSV file of the finds. Each row shows the result (***matches***, ***address differs***, ***not found***, ***not in the plan***, ***not unique — no match made***), the device found with its address and how it was matched (by IP or by name). A line at the top counts the results. The button ***As-built***

writes the as-built sheet (as planned / as built); the line "n of m entries verified" says how many entries have been checked. ***CSV*** exports the comparison.





Plan

Survey

Tools → ***Survey (capture existing)...*** is for the walk through the room: write down what you see. The fields: ***Device*** (required), ***Room*** (stays for the next entry), ***Connected to (assumed)*** and ***Note***. ***Capture (Enter)*** creates the entry; if a device of the same name is already in the plan, the app says so.

Two lists: ***From the phone (n)*** shows entries a phone has reported (on the phone set "Contribute" and choose "Report" → "New device"; phone access must be on beforehand). A tick adopts the entry, × discards it. ***Captured, not worked out yet (n)*** gathers the captured entries; ***Done*** takes an entry off the list. On an entry, ***Photos*** with ***Add photo...*** attaches a photo.


Survey: capture what is there
Walk through the room and write down what you see. more
Device *
e.g. Projector ceiling front
Room
stays for the next entry
Connected to (assumed)
e.g. lectern, HDMI at the back?
Note
what it is for, what is odd
Capture (Enter)
From the phone: Phone access → set "Contribute" → on the phone "Report" → "New device". more
From the phone (1)
Beamer Saal hinten
Saal · HDMI zur Wand? · Deckenhalterung
Anna (Telefon)
Captured, not worked out yet (0)
Nothing open.


Survey: capture what is there
Walk through the room and write down what you see. more
Device *
e.g. Projector ceiling front
Room
Saal
Connected to (assumed)
e.g. lectern, HDMI at the back?
Note
what it is for, what is odd
Capture (Enter)
"Projektor Decke vorne" is in the plan.
From the phone: Phone access → set "Contribute" → on the phone "Report" → "New device". more
From the phone (1)
Beamer Saal hinten
Saal · HDMI zur Wand? · Deckenhalterung
Anna (Telefon)
Captured, not worked out yet (1)
Projektor Decke vorne
Room: Saal
Connected to (assumed): Pult, HDMI hinten?
Lüfter laut, Halterung locker
› Photos
Done


Survey: capture what is there
Walk through the room and write down what you see. more
Device *
e.g. Projector ceiling front
Room
Saal
Connected to (assumed)
e.g. lectern, HDMI at the back?
Note
what it is for, what is odd
Capture (Enter)
"Lautsprecher links" is in the plan.
From the phone: Phone access → set "Contribute" → on the phone "Report" → "New device". more
From the phone (1)
Beamer Saal hinten
Saal · HDMI zur Wand? · Deckenhalterung
Anna (Telefon)
Captured, not worked out yet (2)
Projektor Decke vorne
Room: Saal
Connected to (assumed): Pult, HDMI hinten?
Lüfter laut, Halterung locker
Done
Photos
No photos yet. A photo answers questions no field has.
Add photo...
Lautsprecher links
Room: Saal
Done
Photos



Drum micing

Tools → ***Drum micing…*** places and names the microphones on the drum kit. On the left is the kit as a top view with the zones ***Kick***, ***SN Top***, ***SN Bot***, ***HiHat***, ***Tom 1***, ***Tom 2***, ***Floor Tom***, ***Ride***, ***OH L***, ***OH R***, ***Room L*** and ***Room R***. At the top, the ***Technique*** presets set a starting point: ***Minimal (Kick + Overheads)***, ***Glyn Johns (4 Mics)***, ***Recorderman (Kick, Snare, 2 OH)*** and ***Full Close***; ***Remove all mics*** empties the kit.



1. A preset places the microphones of the technique (here ***Glyn Johns***).



1. Clicking a zone shows its microphones on the right. Adding a mic puts one in, ***— pick microphone —*** assigns it a model (dynamic, condenser and ribbon microphones of common makers), the bin removes it.



1. On the right are also ***Subsnake*** (the stage box size: 8, 12, 16, 24 or 32 in), ***Patch list*** and ***Labels*** (output of the channel list and of the labels) and

Channel list & requirements with the number of channels, of 48 V channels and of channels without a microphone. The material list names microphones, XLR cables, stands and rim clamps and can be copied to the clipboard.



1. ***Edit kit*** opens the kit editor: move, rename and delete zones in the picture and add new zones (kick, snare, tom, hi-hat, ride, crash, overhead, room). ***Kit done*** ends editing.



1. ***Full Close*** places all drums, overheads and room microphones: twelve channels.



If the plan lacks mic inputs for the kit, the Plan check reports it.

Wireless / vocals

Tools → ***Wireless / vocals…*** plans wireless microphones and checks their frequencies. The header has the channel add button, the number of channels, the number of RF conflicts, the selection ***— country —*** (Germany, Austria, Switzerland, Netherlands, France, USA) with the button ***Frequency table***, ***CSV*** and ***Print / PDF***. Each channel has a row with:

COLUMN	MEANING
Channel	Name of the channel.
Transmitter (body)	Handheld or bodypack transmitter (for example Shure AD2, ULXD2, QLXD2, Sennheiser SKM 6000, SK 6000).
Capsule / headset	The capsules compatible with the transmitter; a tick shows that the combination fits.
Band	The frequency band of the device; the selection can be narrowed by country.
Frequency (MHz)	The carrier frequency.
Bandwidth (kHz)	The occupied bandwidth.

The box ***RF coordination — conflicts*** lists what does not fit: ***spacing*** (carriers too close, spacing smaller than the bandwidth) and ***IMD3·3*** or ***IMD3·2*** (third-order intermodulation with three or two transmitters). Carrier spacing and intermodulation are checked. The plan is included: radio links from the plan, such as camera wireless or WLAN, appear too.


Wireless / vocals
+ Channel
0 channels
6 RF conflicts
— country —
Frequency table
CSV
Print / PDF
No channels yet. Add a channel and assign body + capsule/headset.
RF coordination — conflicts
spacing Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) (606.4) ↔ Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) (606.6): Abstand 0.2 MHz < 0.4 MHz
spacing WLAN Kamera 1 (Kamera 1 → Bildmischer) (5180) ↔ WLAN Kamera 2 (Kamera 2 → Bildmischer) (5180): Abstand 0 MHz < 0.4 MHz
IMD3·3 Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) + WLAN Kamera 1 (Kamera 1 → Bildmischer) − Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) = 5179.8 MHz trifft WLAN Kamera 2 (Kamera 2 → Bildmischer) (5180)
IMD3·3 Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) + WLAN Kamera 1 (Kamera 1 → Bildmischer) − WLAN Kamera 2 (Kamera 2 → Bildmischer) = 606.4 MHz trifft Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) (606.6)
IMD3·3 Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) + WLAN Kamera 2 (Kamera 2 → Bildmischer) − Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) = 5179.8 MHz trifft WLAN Kamera 1 (Kamera 1 → Bildmischer) (5180)
IMD3·3 Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) + WLAN Kamera 1 (Kamera 1 → Bildmischer) − WLAN Kamera 2 (Kamera 2 → Bildmischer) = 606.6 MHz trifft Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) (606.4)
Checked: carrier spacing + 3rd-order intermodulation (2-and 3-transmitter). more
Mic plot — who wears which channel
— no session —
+ Session
Carry over from previous
Session sheet
No session yet. The channel plan above belongs to the production; who wears which channel changes per performance — that is what this section is for.


Wireless / vocals
+ Channel
1 channels
6 RF conflicts
— country —
Frequency table
CSV
Print / PDF
Channel
Transmitter (body)
Capsule / headset
Band
Frequency (MHz)
Bandwid (kHz)
Channel 1
— pick body —
— pick compatible —
—
z.B. 502.375
200
RF coordination — conflicts
spacing Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) (606.4) ↔ Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) (606.6): Abstand 0.2 MHz < 0.4 MHz
spacing WLAN Kamera 1 (Kamera 1 → Bildmischer) (5180) ↔ WLAN Kamera 2 (Kamera 2 → Bildmischer) (5180): Abstand 0 MHz < 0.4 MHz
IMD3·3 Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) + WLAN Kamera 1 (Kamera 1 → Bildmischer) − Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) = 5179.8 MHz trifft WLAN Kamera 2 (Kamera 2 → Bildmischer) (5180)
IMD3·3 Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) + WLAN Kamera 1 (Kamera 1 → Bildmischer) − WLAN Kamera 2 (Kamera 2 → Bildmischer) = 606.4 MHz trifft Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) (606.6)
IMD3·3 Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) + WLAN Kamera 2 (Kamera 2 → Bildmischer) − Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) = 5179.8 MHz trifft WLAN Kamera 1 (Kamera 1 → Bildmischer) (5180)
IMD3·3 Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) + WLAN Kamera 1 (Kamera 1 → Bildmischer) − WLAN Kamera 2 (Kamera 2 → Bildmischer) = 606.6 MHz trifft Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) (606.4)
Checked: carrier spacing + 3rd-order intermodulation (2-and 3-transmitter). more
Mic plot — who wears which channel
— no session —
+ Session
Carry over from previous
Session sheet
No session yet. The channel plan above belongs to the production; who wears which channel changes per performance — that is what this section is for.





Mic plot

The section ***Mic plot — who wears which channel*** records for each session who wears which link. The channel plan above belongs to the production;

who wears which link changes with each performance — that is what this section is for.

CONTROL	EFFECT
Session (selection) and add session	Picks or creates a session.
Take over from the previous one	Takes over the assignments of the previous session; they count as unconfirmed for today.
Session sheet	Exports the sheet of the session.
Add person	Adds a row with ***Person***, ***Role***, ***Channel***, ***Transmitter*** and ***Battery fitted***.

The app points out gaps: when the battery change was not recorded, and two people on the same channel.




Wireless / vocals
+ Channel
2 channels
16 RF conflicts
— country —
Frequency table
CSV
Print / PDF
Channel
Transmitter (body)
Capsule / headset
Band
Frequency (MHz)
Bandwid (kHz)
Channel 1
Shure AD2
Shure SM58 (Kapsel)
606.4
200
RF coordination — conflicts
spacing Channel 1 (606.4) ↔ Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) (606.4): Abstand 0 MHz < 0.4 MHz
spacing Channel 1 (606.4) ↔ Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) (606.6): Abstand 0.2 MHz < 0.4 MHz
spacing Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) (606.4) ↔ Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) (606.6): Abstand 0.2 MHz < 0.4 MHz
spacing WLAN Kamera 1 (Kamera 1 → Bildmischer) (5180) ↔ WLAN Kamera 2 (Kamera 2 → Bildmischer) (5180): Abstand 0 MHz < 0.4 MHz
IMD3·2 2·Channel 1 − Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) = 606.4 MHz trifft Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) (606.6)
IMD3·2 2·Channel 1 − Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) = 606.2 MHz trifft Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) (606.4)
IMD3·2 2·Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) − Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) = 606.2 MHz trifft Channel 1 (606.4)
IMD3·3 Channel 1 + WLAN Kamera 1 (Kamera 1 → Bildmischer) − Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) = 5180 MHz trifft WLAN Kamera 2 (Kamera 2 → Bildmischer) (5180)
IMD3·3 Channel 1 + WLAN Kamera 1 (Kamera 1 → Bildmischer) − Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) = 5179.8 MHz trifft WLAN Kamera 2 (Kamera 2 → Bildmischer) (5180)
IMD3·3 Channel 1 + WLAN Kamera 1 (Kamera 1 → Bildmischer) − WLAN Kamera 2 (Kamera 2 → Bildmischer) = 606.4 MHz trifft Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) (606.4)
IMD3·3 Channel 1 + WLAN Kamera 2 (Kamera 2 → Bildmischer) − Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) = 5180 MHz trifft WLAN Kamera 1 (Kamera 1 → Bildmischer) (5180)
IMD3·3 Channel 1 + WLAN Kamera 2 (Kamera 2 → Bildmischer) − Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) = 5179.8 MHz trifft WLAN Kamera 1 (Kamera 1 → Bildmischer) (5180)
IMD3·3 Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) + WLAN Kamera 1 (Kamera 1 → Bildmischer) − Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) = 5179.8 MHz trifft WLAN Kamera 2 (Kamera 2 → Bildmischer) (5180)
IMD3·3 Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) + WLAN Kamera 1 (Kamera 1 → Bildmischer) − WLAN Kamera 2 (Kamera 2 → Bildmischer) = 606.4 MHz trifft Channel 1 (606.4)
IMD3·3 Funk Kamera 1 (UHF) (Kamera 1 → Bildmischer) + WLAN Kamera 2 (Kamera 2 → Bildmischer) − Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) = 5179.8 MHz trifft WLAN Kamera 1 (Kamera 1 → Bildmischer) (5180)
IMD3·3 Funk Kamera 2 (UHF) (Kamera 2 → Bildmischer) + WLAN Kamera 1 (Kamera 1 → Bildmischer) − WLAN Kamera 2 (Kamera 2 → Bildmischer) = 606.6 MHz trifft Channel 1 (606.4)
Checked: carrier spacing + 3rd-order intermodulation (2- and 3-transmitter). more
Mic plot — who wears which channel
Session 1
+ Session
Carry over from previous
Session sheet
Two people on the same channel — Anna, ohne Namen are on "Channel 1". Two transmitters on the same frequency cancel each other out — you notice when someone speaks.
Battery change not recorded — For 1 link(s) it is not recorded when the battery was fitted. The card says "nicht festgehalten" — it claims no remaining runtime that nobody knows.
Person
Role
Channel
Transmitter
Battery fitted
Anna
Moderation
Channel 1 · 606.4 MHz
— not named —
23:48:05
ohne Namen
e.g. presenter
Channel 1 · 606.4 MHz
— not named —
now
+ Person



Rundown and camera assignments

Tools → ***Rundown and camera assignments…*** reads the editorial rundown and gives each camera position an assignment per segment. The rundown belongs to the editorial team and is only read here.

1. Enter the origin (for example "ablauf.xlsx, mail of 9 Sept.") and ***Version of the source*** (for example "v4").



1. Paste the rundown into the text field — per line number, title and note, separated by tab or semicolon — and click ***Read in***.

1. The result names the number of segments with origin and version. Lines that cannot be read are reported by the app and not taken over.



1. The table ***Who does what*** has a column per camera position for each segment. Enter the assignments (for example "Wide", "Close presenter"). The assignment hangs on the role, not on the device — if the spare camera steps in, it stays. The line below counts the assignments per camera.



1. When the rundown is read in again, the assignments of matching segments are kept.



Delivery

Tools → ***Delivery (streaming destinations)…*** records where the programme goes out, with which parameters and which path is the fallback path. At the top are ***CSV***, ***Run sheet*** and ***Delivery path***; the dialog is one long scrolling sheet. Without a destination it reads ***No delivery destination yet. Add one.*** with ***Add destination***.



The sheet has these sections:

SECTION	CONTENT
Independent archive recording	The question where the archive recording lives: ***— not answered yet —***, ***on this device*** (then with a device choice and a remark) or ***deliberately none***. Unanswered, it is an open question, not a warning about a device. ***Sheet*** exports the archive sheet.
Event details	Title, ***Visibility*** (***public***, ***unlisted***, ***private***; there is no default), start, time zone, thumbnail, tags, description. Below, deliberate deviations per destination (empty means "as on the project"; a deviation needs a reason).
Transmission record	What the broadcast did, as far as someone wrote it down: add an ***Entry*** (start, end, dropout, degradation, switchover, back to normal, change during the broadcast, observation) with time, destination and origin (***seen***, typed from a log, reported), a summary for the client (deliberately by hand) and ***Sheet***.
Fallback behaviour (safety net)	Which device runs the watchdog (***Watchdog runs on***), the statistics source and the scenes in the encoder (***Apply***); per destination ***Normal***, ***Low bitrate***, ***Offline*** and thresholds. ***Sheet*** and ***Skeleton*** write the documents.
Uplink (Mbit/s)	The available uplink; the line sets planned against usable kbit/s (after 40 % headroom).
Destinations	Per destination platform (***YouTube Live***, ***Twitch***, own destination), transport (***RTMP***, ***SRT***, ***HLS***), encoder (a device of the plan) and path (own path or a fallback path), the address, the ***Stream key*** (***Save key*** stores it in the keychain; it is not in the project), width, height, fps, video kbit/s, keyframe interval, audio, codec and for SRT mode and measured RTT with the recommended latency. For control of the encoder, give OSC address, Companion page and slot.

For each destination the app checks and reports, for example ***No stream key stored***, a bitrate above the platform limit, or ***No fallback path***.


Delivery
CSV
Run sheet
Delivery path
Where the show is sent, with which parameters, and which path is the fallback. more
Independent archive recording
— not answered yet —
Sheet
Archive question unanswered — Der Plan hat Ausspielziele, sagt aber nicht, wo die unabhängige Archiv-Aufzeichnung liegt. Das ist keine Warnung über ein Gerät, sondern eine offene Frage: entweder ein Gerät benennen oder ausdrücklich sagen, dass es bewusst keine gibt.
Event details
Sheet
Event title
— visibility not stated —
Start, e.g. 2026-09-12T19:00+02:00
Announced in, e.g. Europe/Berlin
Thumbnail — file name, not the image
Tags, comma separated
Description text for the platform forms
Deliberate deviations per destination — empty means "same as the project".
New destination
deviating title
why deviating?
Destinations set, details missing entirely — 1 delivery destination(s) are in the plan, but no event details. Title, start and visibility are then pieced together from e-mails on show day and retyped per platform.
No title for this destination — "New destination" has no title — neither on the project nor as an override.
Visibility not stated — The visibility of "New destination" is not stated. No default is set here on purpose: guessing "public" can put the dress rehearsal online.
Transmission record
As planned (no as-built)
+ Entry
Sheet
What the transmission did, as far as somebody wrote it down. more
Summary for the client — written by hand on purpose, not generated
No entry — the report would be empty — There is no entry in the transmission report. After the show the course is then reconstructed from OBS logs, a platform graph and memory — exactly the state this report is written against.
Fallback behaviour (safety net)
Sheet
Skeleton
The expensive failure is not the net that never fires — it is the net that fires for no reason and parks the show on a slate while the stream is fine. more
Watchdog runs on
— not stated —
Stats source, as the watchdog sees it
http://10.0.0.20/stat
Scenes in the encoder (0 on file)
Paste names, separated by comma or newline
Apply
+ Add destination
1 destinations, 3 findings


Delivery
CSV
Run sheet
Delivery path
Description text for the platform forms
Deliberate deviations per destination — empty means "same as the project".
New destination
YouTube Hauptkanal
why deviating?
Visibility not stated — The visibility of "New destination" is not stated. No default is set here on purpose: guessing "public" can put the dress rehearsal online.
Override without a reason — "New destination" deviates from the project value without a reason. Without one, nobody can later decide whether it was intended or a typo.
Transmission record
As planned (no as-built)
+ Entry
Sheet
What the transmission did, as far as somebody wrote it down. more
Summary for the client — written by hand on purpose, not generated
No entry — the report would be empty — There is no entry in the transmission report. After the show the course is then reconstructed from OBS logs, a platform graph and memory — exactly the state this report is written against.
Fallback behaviour (safety net)
Sheet
Skeleton
The expensive failure is not the net that never fires — it is the net that fires for no reason and parks the show on a slate while the stream is fine. more
Watchdog runs on
— not stated —
Stats source, as the watchdog sees it
http://10.0.0.20/stat
Scenes in the encoder (0 on file)
Paste names, separated by comma or newline
Apply
New destination
+ Protect
Uplink (Mbit/s)
50
6128 kbit/s planned, 30000 kbit/s usable
50 Mbit/s - 40 % Kopfraum = 30000 kbit/s · contentflow.live/wie-muss-ich-meinen-encoder-richtig-einstellen/
New destination
YouTube Live
SRT
— no encoder named —
— own path —
rtmp://a.rtmp.youtube.com/live2
Stream key
Save key
Width 1920
Height 1080
fps 25
Video kbit/s 6000
Keyframe s 2
Audio Hz 48000
Audio kbit/s 128
Video codec H.264
SRT mode caller
measured RTT (ms) 45
+ Add destination
1 destinations, 2 findings


Delivery
CSV
Run sheet
Delivery path
Description text for the platform forms
Deliberate deviations per destination — empty means "same as the project".
New destination
YouTube Hauptkanal
why deviating?
Visibility not stated — The visibility of "New destination" is not stated. No default is set here on purpose: guessing "public" can put the dress rehearsal online.
Override without a reason — "New destination" deviates from the project value without a reason. Without one, nobody can later decide whether it was intended or a typo.
Transmission record
As planned (no as-built)
+ Entry
Sheet
What the transmission did, as far as somebody wrote it down. more
Summary for the client — written by hand on purpose, not generated
No entry — the report would be empty — There is no entry in the transmission report. After the show the course is then reconstructed from OBS logs, a platform graph and memory — exactly the state this report is written against.
Fallback behaviour (safety net)
Sheet
Skeleton
The expensive failure is not the net that never fires — it is the net that fires for no reason and parks the show on a slate while the stream is fine. more
Watchdog runs on
Stats source, as the watchdog sees it
— not stated —
http://10.0.0.20/stat
Scenes in the encoder (0 on file)
Paste names, separated by comma or newline
Apply
New destination
+ Protect
Uplink (Mbit/s)
50
6128 kbit/s planned, 30000 kbit/s usable
50 Mbit/s - 40 % Kopfraum = 30000 kbit/s · contentflow.live/wie-muss-ich-meinen-encoder-richtig-einstellen/
New destination
YouTube Live
SRT
Streaming-PC
— own path —
rtmp://a.rtmp.youtube.com/live2
Stream key
Save key
Width 1920
Height 1080
fps 25
Video kbit/s 6000
Keyframe s 2
Audio Hz 48000
Audio kbit/s 128
Video codec H.264
SRT mode caller
measured RTT (ms) 45
+ Add destination
1 destinations, 2 findings


Delivery
CSV
Run sheet
Delivery path
Description text for the platform forms
Deliberate deviations per destination — empty means "same as the project".
New destination
YouTube Hauptkanal
why deviating?
Visibility not stated — The visibility of "New destination" is not stated. No default is set here on purpose: guessing "public" can put the dress rehearsal online.
Override without a reason — "New destination" deviates from the project value without a reason. Without one, nobody can later decide whether it was intended or a typo.
Transmission record
As planned (no as-built)
+ Entry
Sheet
What the transmission did, as far as somebody wrote it down. more
Summary for the client — written by hand on purpose, not generated
No entry — the report would be empty — There is no entry in the transmission report. After the show the course is then reconstructed from OBS logs, a platform graph and memory — exactly the state this report is written against.
Fallback behaviour (safety net)
Sheet
Skeleton
The expensive failure is not the net that never fires — it is the net that fires for no reason and parks the show on a slate while the stream is fine. more
Watchdog runs on
Stats source, as the watchdog sees it
— not stated —
http://10.0.0.20/stat
Scenes in the encoder (0 on file)
Paste names, separated by comma or newline
Apply
New destination
+ Protect
Uplink (Mbit/s)
50
15128 kbit/s planned, 30000 kbit/s usable
50 Mbit/s · 40 % Kopfraum = 30000 kbit/s · contentflow.live/wie-muss-ich-meinen-encoder-richtig-einstellen/
New destination
YouTube Live
SRT
Streaming-PC
— own path —
rtmp://a.rtmp.youtube.com/live2
Save key
Width
1920
Height
1080
fps
25
Video kbit/s
15000
Keyframe s
4
Audio Hz
48000
Audio kbit/s
128
Video codec
H.264
SRT mode
caller
measured RTT (ms)
45
+ Add destination
1 destinations, 3 findings


Delivery
CSV
Run sheet
Delivery path
Visibility not stated — The visibility of "New destination" is not stated. No default is set here on purpose: guessing "public" can put the dress rehearsal online.
Override without a reason — "New destination" deviates from the project value without a reason. Without one, nobody can later decide whether it was intended or a typo.
Transmission record
As planned (no as-built)
+ Entry
Sheet
What the transmission did, as far as somebody wrote it down. more
Summary for the client — written by hand on purpose, not generated
No entry — the report would be empty — There is no entry in the transmission report. After the show the course is then reconstructed from OBS logs, a platform graph and memory — exactly the state this report is written against.
Fallback behaviour (safety net)
Sheet
Skeleton
The expensive failure is not the net that never fires — it is the net that fires for no reason and parks the show on a slate while the stream is fine. more
Watchdog runs on
— not stated —
Stats source, as the watchdog sees it
http://10.0.0.20/stat
Scenes in the encoder (0 on file)
Paste names, separated by comma or newline
Apply
New destination
+ Protect
Uplink (Mbit/s)
50
15128 kbit/s planned, 30000 kbit/s usable
50 Mbit/s - 40 % Kopfraum = 30000 kbit/s · contentflow.live/wie-muss-ich-meinen-encoder-richtig-einstellen/
New destination
YouTube Live
SRT
Streaming-PC
— own path —
rtmp://a.rtmp.youtube.com/live2
Save key
Width 1920
Height 1080
fps 25
Video kbit/s 15000
Keyframe s 4
Audio Hz 48000
Audio kbit/s 128
Video codec H.264
SRT mode caller
measured RTT (ms) 45
from RTT: 180 ms — 4 x 45 ms RTT (Spanne 3-4x: 135-180 ms) (vajracast.com/srt-latency-tuning/ (3-4x RTT))
fixed practical value: 1500–2500 ms (Praxis-Leitfäden, fester Wert 1.500-2.500 ms; siehe medium.com/innovation-labs-blog/examining-srt-streaming-over-4g-networks-925e71c45cdf)
Die beiden belegten Lesarten liegen bei 45 ms RTT um Faktor 8.3 auseinander (180 ms gegen 1500 ms). Auf kurzen Strecken widersprechen sich die Quellen; die Entscheidung gehört dem Menschen, nicht diesem Rechner.
OSC address
/stream/haupt/start
Companion page
2
Companion bank
5
+ Add destination
1 destinations, 3 findings


Delivery
CSV
Run sheet
Delivery path
Event details
Sheet
Event title
— visibility not stated —
Start, e.g. 2026-09-12T19:00+02:00
Announced in, e.g. Europe/Berlin
Thumbnail — file name, not the image
Tags, comma separated
Description text for the platform forms
Deliberate deviations per destination — empty means "same as the project".
New destination
YouTube Hauptkanal
why deviating?
New destination
deviating title
why deviating?
Visibility not stated — The visibility of "New destination" is not stated. No default is set here on purpose: guessing "public" can put the dress rehearsal online.
No title for this destination — "New destination" has no title — neither on the project nor as an override.
Visibility not stated — The visibility of "New destination" is not stated. No default is set here on purpose: guessing "public" can put the dress rehearsal online.
Override without a reason — "New destination" deviates from the project value without a reason. Without one, nobody can later decide whether it was intended or a typo.
Transmission record
As planned (no as-built)
+ Entry
Sheet
What the transmission did, as far as somebody wrote it down. more
Summary for the client — written by hand on purpose, not generated
No entry — the report would be empty — There is no entry in the transmission report. After the show the course is then reconstructed from OBS logs, a platform graph and memory — exactly the state this report is written against.
Fallback behaviour (safety net)
Sheet
Skeleton
The expensive failure is not the net that never fires — it is the net that fires for no reason and parks the show on a slate while the stream is fine. more
Watchdog runs on
— not stated —
Stats source, as the watchdog sees it
http://10.0.0.20/stat
Scenes in the encoder (0 on file)
Paste names, separated by comma or newline
Apply
New destination
+ Protect
New destination
+ Protect
Uplink (Mbit/s)
10
21256 kbit/s planned, 6000 kbit/s usable
+ Add destination
2 destinations, 6 findings


Delivery
CSV
Run sheet
Delivery path
Where the show is sent, with which parameters, and which path is the fallback. more
Independent archive recording
on this device
— pick a device —
Note (medium, card swap ...)
Sheet
Named recorder missing from the plan — Das als Recorder benannte Gerät steht nicht mehr im Plan. Die Antwort auf die Archiv-Frage zeigt damit ins Leere.
Event details
Sheet
Event title
— visibility not stated —
Start, e.g. 2026-09-12T19:00+02:00
Announced in, e.g. Europe/Berlin
Thumbnail — file name, not the image
Tags, comma separated
Description text for the platform forms
Deliberate deviations per destination — empty means "same as the project".
New destination
YouTube Hauptkanal
why deviating?
New destination
deviating title
why deviating?
Visibility not stated — The visibility of "New destination" is not stated. No default is set here on purpose: guessing "public" can put the dress rehearsal online.
No title for this destination — "New destination" has no title — neither on the project nor as an override.
Visibility not stated — The visibility of "New destination" is not stated. No default is set here on purpose: guessing "public" can put the dress rehearsal online.
Override without a reason — "New destination" deviates from the project value without a reason. Without one, nobody can later decide whether it was intended or a typo.
Transmission record
As planned (no as-built)
+ Entry
Sheet
What the transmission did, as far as somebody wrote it down. more
Summary for the client — written by hand on purpose, not generated
No entry — the report would be empty — There is no entry in the transmission report. After the show the course is then reconstructed from OBS logs, a platform graph and memory — exactly the state this report is written against.
Fallback behaviour (safety net)
Sheet
Skeleton
The expensive failure is not the net that never fires — it is the net that fires for no reason and parks the show on a slate while the stream is fine. more
Watchdog runs on
— not stated —
Stats source, as the watchdog sees it
http://10.0.0.20/stat
Scenes in the encoder (0 on file)
+ Add destination
2 destinations, 6 findings


Delivery
CSV
Run sheet
Delivery path
Transmission record
As planned (no as-built)
+ Entry
Sheet
What the transmission did, as far as somebody wrote it down. more
2026-09-12T19:04+02:00
Observation
— whole transmission —
source not stated
by whom?
r da
Summary for the client — written by hand on purpose, not generated
No as-built: deviations cannot be derived — No as-built has been frozen. The report can say what was observed, but not what the delivery deviated from — there is no built state to compare against.
Time without a time zone — The time "" carries no time zone. It cannot be matched against an OBS log or a platform graph, and the order in the report is then that of the written strings, not of the points in time.
Source of the entry not named — For "Bild eingefroren, nach 20 s wieder da" it is not stated where the information comes from. A report that goes to the client is read like a measurement log — this planner measures nothing, and that must be on every line.
No summary for the client — The report carries no summary. It is deliberately not generated: deriving an assessment of the transmission from eight lines would be a statement that belongs to the person responsible for it.
Fallback behaviour (safety net)
Sheet
Skeleton
The expensive failure is not the net that never fires — it is the net that fires for no reason and parks the show on a slate while the stream is fine. more
Watchdog runs on
Stats source, as the watchdog sees it
— not stated —
http://10.0.0.20/stat
Scenes in the encoder (0 on file)
Paste names, separated by comma or newline
Apply
New destination
+ Protect
New destination
+ Protect
Uplink (Mbit/s)
10
21256 kbit/s planned, 6000 kbit/s usable
10 Mbit/s · 40 % Kopfraum = 6000 kbit/s · contentflow.live/wie-muss-ich-meinen-encoder-richtig-einstellen/
New destination
YouTube Live
SRT
Streaming-PC
— own path —
rtmp://a.rtmp.youtube.com/live2
Save key
Width 1920
Height 1080
fps 25
Video kbit/s 15000
Keyframe s 4
Audio Hz 48000
Audio kbit/s 128
Video codec H.264
SRT mode caller
measured RTT (ms) 45
from RTT: 180 ms — 4 x 45 ms RTT (Spanne 3-4x: 135-180 ms) (vairacast.com/srt-latency-tuning/ (3-4x RTT))
+ Add destination
2 destinations, 6 findings


Delivery
CSV
Run sheet
Delivery path
Fallback behaviour (safety net)
Sheet
Skeleton
The expensive failure is not the net that never fires — it is the net that fires for no reason and parks the show on a slate while the stream is fine. more
Watchdog runs on
— not stated —
Stats source, as the watchdog sees it
http://10.0.0.20/stat
Scenes in the encoder (0 on file)
Paste names, separated by comma or newline
Apply
New destination
Normal
Low bitrate
Offline
Low threshold
Offline threshold
New destination
+ Protect
Scene list missing — names cannot be checked — Rules are set, but no scene of the encoder is in the plan. The name check — the cheapest check of all — therefore does not run, and a result of "no objection" would be none.
Uplink (Mbit/s) 10
21256 kbit/s planned, 6000 kbit/s usable
10 Mbit/s - 40 % Kopfraum = 6000 kbit/s · contentflow.live/wie-muss-ich-meinen-encoder-richtig-einstellen/
New destination
YouTube Live
SRT
Streaming-PC
— own path —
rtmp://a.rtmp.youtube.com/live2
Save key
Width 1920
Height 1080
fps 25
Video kbit/s 15000
Keyframe s 4
Audio Hz 48000
Audio kbit/s 128
Video codec H.264
SRT mode caller
measured RTT (ms) 45
from RTT: 180 ms — 4 x 45 ms RTT (Spanne 3-4x: 135-180 ms) (vajracast.com/srt-latency-tuning/ (3-4x RTT))
fixed practical value: 1500–2500 ms (Praxis-Leitfäden, fester Wert 1.500-2.500 ms; siehe medium.com/innovation-labs-blog/examining-srt-streaming-over-4g-networks-925e71c45cdf)
Die beiden belegten Lesarten liegen bei 45 ms RTT um Faktor 8.3 auseinander (180 ms gegen 1500 ms). Auf kurzen Strecken widersprechen sich die Quellen; die Entscheidung gehört dem Menschen, nicht diesem Rechner.
OSC address
Companion page
Companion bank
/stream/haupt/start
2
5
Companion: der SCHALT-Weg läuft über die HTTP-API (ab Werk an), das ZURÜCKLESEN über die TCP-Steuerung (bei einer Neuinstallation ab Werk aus, Port 16759; eine hochgezogene Installation hat sie an, auf Port 51234). Vor Ort nachsehen, nicht annehmen.
⚠ No stream key stored
⚠ Bitrate 15000 kbit/s above the platform limit 12000 kbit/s
⚠ No fallback path
Streaming-PC → SRT → New destination
+ Add destination
2 destinations, 6 findings

9. Tools: Build

The ***Tools*** menu has five groups: ***Calculate***, ***Check***, ***Plan***, ***Create & manage*** and ***Device configuration***. This chapter describes the entries of the ***Plan*** group from ***LED wall…*** onwards, plus the groups ***Create & manage*** and ***Device configuration***. The calculators, the checks and the other entries of the ***Plan*** group are in the chapter Tools: Plan. Patch list, fixed install, stage plot and ***Export & Print…*** are in the ***File*** menu and in the chapter Export and Print.

The group ***Device configuration*** appears only when the plan contains a matching device: ***ATEM multiviewer layout…*** for an ATEM or a multiviewer, ***ATEM audio routing…*** and ***ATEM input labels…*** for an ATEM, ***Videohub routing / labels…*** for a Videohub and ***GreenGo intercom…*** for a GreenGo device. The same tools are in the Inspector in the section ***Tools for this device***. ***Inventory / stock…*** appears when the rental module is switched on.



LED wall

Tools → LED wall…

The ***LED wall*** dialog plans a wall of identical tiles. From the datasheet values of the panel type it calculates tile count, resolution, size, weight and power of the wall, checks whether the ports of the sending card can carry the pixels, calculates the crop of a standard source onto the wall and delivers the pixel map as a PNG. Panel types and walls belong to the project. A missing value appears as a sentence where the number would otherwise be: if a panel type carries no weight, the weight of the wall is unknown, not 0 kg.

1. Open ***Tools → LED wall…***. Without a panel type it says ***No panel type recorded.*** with the hint to take the figures off the datasheet; under ***Walls*** it says ***A wall needs a panel type first.***

1. ***Add panel type*** creates a type with the defaults ***New panel type***, 3.9 mm pitch, 128 × 128 pixels and 500 × 500 mm.



1. Enter the datasheet values. Each number is applied when you leave the field.



FIELD	MEANING
Name	Name of the type; it appears in the wall's selection.
Pitch (mm)	Pixel pitch.
Pixels across / ***Pixels down***	Resolution of one panel.
Width (mm) / ***Height (mm)***	Size of one panel.
Weight (kg)	Weight of one panel; empty means not stated.
Power, average (W) / ***Power, peak (W)***	Power draw of one panel on average and at peak; empty means not stated.
Datasheet (URL)	Link to the datasheet.

The × next to the first fields (***Remove***) deletes the panel type.

1. ***Add wall*** creates a wall ***New wall*** with the first panel type, 4 columns and 3 rows. With several walls, the buttons with the wall names choose which wall is shown below.



1. The wall has the fields ***Name***, ***Panel type*** (a choice among the types), ***Columns*** and ***Rows***. The totals below change as soon as you change ***Columns*** or ***Rows***.



1. Instead of counting the grid, enter the opening: ***Opening width (mm)*** and ***Opening height (mm)***. Next to the button it says what fits, for example ***6 × 3 tiles, 300 mm across and 200 mm up left over***. The result is rounded down: a tile that is only half inside the opening does not count. The remainder stays visible so that you can decide whether to hang the wall centred or change the opening.



1. ***Fit the grid*** applies columns and rows. The button is active only when both dimensions are greater than 0.



Wall totals

Six values appear under the fields: ***Panels***, ***Resolution*** (total pixels), ***Size (mm)***, ***Weight***, ***Power, average*** and ***Power, peak***. If the panel type lacks weight or power, this place says ***panel type carries no weight*** or ***panel type carries no power figure***. A hint reminds you to size the breaker on the peak, not on the average.



Source crop

The section ***Source crop*** calculates which part of a standard source the processor has to show so that it fills the wall without distortion and centred. ***Source width (px)*** and ***Source height (px)*** default to 1920 × 1080. The source is scaled so that it fills the whole wall; the axis that overhangs is cropped centrally. Four tiles give the values in source pixels: ***X***, ***Width***, ***Y*** and ***Height***. The axis that is not cropped carries the full source size, not 0. Below there is a sentence such as ***Cropped: top and bottom (Y). Scale 30 %, layer 1152 × 576.*** The axis is called ***none, same aspect ratio***, ***sides (X)*** or ***top and bottom (Y)***. If the wall has no resolution yet, it says ***The wall needs a resolution first.***

1. Enter the resolution of the source, here 3840 × 2160.

1. A click on a tile copies its value to the clipboard; the tile then shows ***· copied***.

Sending card

Ports on the sending card and ***Pixels per port*** describe the sending card. The dialog calculates only the number of ports, not which tile hangs on which port. The verdict appears next to the fields: ***2 of 4 ports carry it***, ***Not enough — 2 ports needed, 1 there*** or, as long as nothing is entered, ***Nothing recorded about the sending card — so nothing is claimed.***


LED wall
Name
Pitch (mm)
Pixels across
Pixels down
Sample panel 2.6
2.6
192
192
Width (mm)
Height (mm)
Weight (kg)
Power, average (W)
Power, peak (W)
500
500
7.5
90
180
Datasheet (URL)
https://example.com/datenblatt-beispiel.pdf
+ Add panel type
Walls
New wall
+ Add wall
Name
Panel type
Columns
Rows
New wall
Sample panel 2.6
6
3
Opening width (mm)
Opening height (mm)
3300
1700
Fit the grid
6 × 3 tiles, 300 mm across and 200 mm up left over
Panels
18
Resolution
1152 × 576
Size (mm)
3000 × 1500
Weight
135 kg
Power, average
1620 W
Power, peak
3240 W
Size the breaker on the peak, not the average. more
Source crop
Source width (px)
Source height (px)
3840
2160
X
0 · copied
Width
3840
Y
120
Height
1920
Cropped: top and bottom (Y). Scale 30 %, layer 1152 × 576.
Ports on the sending card
Pixels per port
4
650000
2 of 4 ports carry it
Pixel map as PNG



Building outlet

If the project contains a building record with outlets, the selection ***Fed from (building outlet)*** appears, defaulting to ***not stated***. The continuous power then joins the load at that outlet; the peak gets its own finding.

Pixel map

Pixel map as PNG saves an image that is as large as the wall has pixels. The tiles are numbered row by row from the top left. The button is disabled without panels. The file is named `<date>_<project name>_<no.>_pixelmap.png`.

Faceplate editor

Tools → Faceplate editor…

The faceplate editor places the connectors of a wall panel, a floor box, a stage box or a panel in millimetres and prints the label strip at 1:1. The connectors are the ports of the device, not a drawing of them: what you move is the same position the rack view reads.

1. Open ***Tools → Faceplate editor…***. If the chosen device has no size in millimetres, it says ***This device has no size in millimetres yet.*** Without width and height there is no plate, and ***Print 1:1*** is disabled.



1. Choose the ***Device***. The selection lists all devices of the plan.



1. Under ***Kind*** choose what the device is: ***Wall panel***, ***Floor box***, ***Stage box***, ***Rack panel*** or ***Other***. ***not a faceplate*** removes the setting. The ***Floor box*** is a floor outlet: it passes through like a wall panel and connects like a connection point; the 3D view of the building lays it flat on the floor.



1. Enter ***Width (mm)*** and ***Height (mm)*** of the plate. Both values apply to the device.



1. Every connector without a position appears in the table with the button ***place***; it puts the connector in the middle of the plate.

1. Drag the connectors to their positions with the mouse. The table shows the position in millimetres from the top left (***Position (mm)***).

1. For each connector enter the ***Cutout (mm)*** from the manufacturer's document; it appears as a dashed circle around the connector. The program does not guess the cutout. Without a cutout the connector is not checked against the others, and the findings say so.



1. ***Grid (mm)*** snaps dragged connectors to a grid; 0 or empty means free. ***Strip (mm)*** is the height of the strip holder; empty means no strip. ***Print 1:1*** prints the strip at original size.



The findings appear under the table: ***... sits outside the plate***, ***... overlap by ... mm*** (both red), ***... connectors have no position on the plate yet*** and ***... connectors carry no cutout size — they were NOT checked against each other.*** For a pass-through panel (patch panel) there is also the field ***On the plate*** with ***Inputs (n)*** and ***Outputs (n)***: only one side sits on the plate; position n in front is position n behind.



Report editor

Tools → Report editor...

The report editor defines how a list looks: columns, order, grouping, sorting and filters. The table in the dialog is the content of the CSV file and of the printed sheet, not a preview of them.

1. Open ***Tools → Report editor...***. At the top you choose the ***List***; it is ***Pull list*** when you open it. ***Group by*** and the counter (***4 of 4 rows · 24 columns***) are next to it, and the buttons ***CSV*** and ***Print*** are on the right.



There are 17 lists to choose from: ***Pull list***, ***Termination list***, ***Cable schedule***, ***Asset register***, ***Network sheet***, ***Spectrum plan***, ***Delivery***, ***Tally map***, ***Handover to post***, ***Faceplates***, ***Signal paths***, ***House run occupancy***, ***Crossings (fire protection)***, ***Defects and open items***, ***Maintenance schedule***, ***Configuration settings*** and ***Attachment index***.

1. Choose another list, here ***Cable schedule***. The form changes with the list; it belongs to the list.



1. The table ***Column | Order | Sort | Filter*** has one row per column. The checkbox before the name hides the column (the name appears struck through) or shows it again.



1. The arrows under ***Order*** move the column up (***Move up***) or down (***Move down***).



1. ***Sort*** advances with each click: ***ascending***, ***descending***, ***off***. Several columns sort in the order in which you switched them on; a hidden column sorts too.



1. Type a text into ***Filter*** (placeholder ***contains...***); only rows whose cell contains it remain. The counter gives the rows, here ***2 of 4 rows***.



1. ***Group by*** chooses a column; under the table the groups appear with their row count, for example ***BNC (2)***. Without a value in the group column it says ***not stated***.



1. Under ***Save as template*** enter a name, for example ***Pull list without room***.



1. ***with this project*** stores the template in the project file; it travels with it. ***for all projects*** stores it in the installation; it applies to the next project. The templates of the chosen list appear below as chips with the suffix ***project*** or ***global***. A click on the name loads the template; the wastebasket asks ***Delete report template?*** and removes only this saved view.



1. ***CSV*** saves the table as a CSV file with a semicolon as separator, named after project and list. ***Print*** opens the sheet for printing. Both output exactly the rows and columns that the table shows.



If a list is empty in the project it says ***This list has no rows in this project yet.***; if no row matches the filters it says ***No row matches the filters.***

Conductors and colour standards

Tools → Conductors and colour standards…

The dialog ***Conductors, colour standards, connections and fibre polarity*** has three tabs. No standard is built in: which colour assignment or polarity method applies to the installation is not something the program knows. A preset standard would look like a checked entry. You therefore enter the standard yourself, and every standard carries a source.

Tab Colour standards

1. Without an entry it says ***No colour standard entered yet.*** Without a standard the conductor colours stay unchecked; the plan check says so.



1. ***Enter colour standard*** creates a standard ***New colour standard***. The wastebasket deletes it after the question ***Delete colour standard?***; connections that had chosen it are then left without a standard.



1. Enter the ***Name of the standard*** and the ***Source (required)***, for example a regulation with edition and page, or "house standard, set by ...". Without a source the field is red and the standard is discarded on the next load. Then enter the colour for each conductor: ***L1***, ***L2***, ***L3***, ***N*** and ***PE***.



Tab Connections (bundles)

A connection is a link that is pulled one conductor at a time: five lines make up a 400 A connection, for example. Enter which conductors it must have; only then can the plan notice that the fourth line is missing. A connection is not the same as the multicore name of a cable: the multicore name counts cables in one jacket as one piece, the connection defines which conductors must be present.

1. The tab starts empty; ***Add connection*** creates a connection.



1. A connection has a name, the conductors ***L1***, ***L2***, ***L3***, ***N***, ***PE*** and ***free*** that it must have, the ***Colour standard for this connection*** (default ***none chosen***) and a ***Note (e.g. connector coding)***. The coding is in the manufacturer's

document; it is entered, not guessed. The wastebasket asks ***Delete connection?***; the lines remain and then belong to no connection.



Tab Fibre polarity

Here too no method is built in: TIA-568 knows the methods A, B and C, and they differ in where the fibres are crossed. Which one applies is in the installation document.

1. Without an entry the fibre direction stays unchecked.





1. Enter ***Name of the method*** and ***Source (required)***. ***This method crosses the fibres: TX at one end meets RX at the other.*** switches the crossing on. ***This method applies to this project.*** chooses the method for the project. Deleting asks ***Delete polarity method?***; if it was the chosen one, the fibre direction is unchecked again afterwards.



Received show-control messages

Tools → Received show-control messages…

The window keeps a transcript of incoming OSC messages. It is not a monitor of the installation: a line says that something arrived, not that anything is in order. An empty window therefore only means that nothing arrived here, not that nothing was sent.

1. At the top is the state of the listener: ***Listener: off***, ***Listener: listening — address:port*** or ***Listener: switched on, but not bound*** with the reason. In the last case nothing arrives, even if someone is sending.



1. Enter the ***Address to listen on*** and the ***Port*** (default 9000). There is deliberately no default for the address: one that listens on every interface would be a decision nobody made, even on the customer network. The setting belongs to the project. A loaded project file does not switch the listener on by itself.



1. ***Listen for this project*** switches the listener on.



1. Every message appears in the ***Transcript*** with address, time, sender and age, for example ***/cue/12/go at 06:29:01 from 127.0.0.1:57060 received (2 s ago)***, plus the size of the payload. The age keeps running so that an old line does not look like a current one.



1. ***Clear*** deletes the transcript.



Below the transcript is the section ***Read back Companion variable values***. It has no button that queries Companion: it names the command lines that you type into the TCP control of Companion, and takes the answers back through the field ***Paste the answers here*** with ***Take as a reading***. Every reading carries the time of reading. As long as no device in the plan is switched through Companion, it says ***No device in the plan is switched through Companion — there is no variable to read back.***

Connect multiple cables

Tools → Connect multiple cables...

The dialog creates several cables in one go: port ***i*** of the source goes to port ***i*** of the target. Occupied target ports are skipped. It also opens from the command palette (Ctrl+K) and from the button ***Connect cables*** in the toolbar of the canvas when exactly two devices are selected; the two devices are then preset as source and target.

1. Open ***Tools → Connect multiple cables...***. The dialog has the blocks ***Source*** and ***Target***, below them ***Cable count***, ***Cable type*** and ***Length per cable (m)***.



1. Under ***Source*** choose the ***Device***, the ***Side*** (***Outputs*** or ***Inputs***) and the start port (***Start Output (1..n)***).



1. Under ***Target*** choose device, side (***Inputs*** or ***Outputs***) and start port in the same way. The sides can be combined freely, even output to output, for example with a patch panel.



1. Enter the ***Cable count*** (1 to 256; default 8). The ***Preview*** shows the pairs, up to 12; if there are more, the number of the rest appears. If the ports are not enough, the dialog warns ***Count exceeds available ports — extras are skipped.***



1. Choose the ***Cable type*** from the catalogue including custom cable types, and the ***Length per cable (m)***. The cable name is made from the two port names, the colour from the cable type.



1. ***Create 8 cables*** creates the cables; the button names the number of pairs in the preview. If target ports have to be skipped, a message says how many cables were created and how many were skipped. The cables count as one step for undo. The status bar then shows the new cable count.

Create new rack

Tools → Create new rack…

The entry opens the 2D rack builder with an empty rack and switches the library to the tab ***Racks***. The builder assembles a rack from devices, shows it from the front, the rear, the side and in 3D, and saves it as a placeable group in the library. The cards on the tab ***Racks***, editing saved racks and placing them on the canvas are described in the chapter Library; how a rack looks on the canvas is in the chapter Canvas.

The draft of a new rack is saved continuously; the footer shows ***Autosave active*** while there are unsaved changes, otherwise ***Saved***.

1. Open ***Tools → Create new rack…***. The header says ***New rack*** with the badge ***New***, after the first change also ***Unsaved***. On the right are ***Export*** and ×.



1. Enter the ***Rack name*** (required), the ***Height (U)*** (1 to 60) and the ***Depth (mm)*** (200 to 1500; default 800; common values are 350, 450, 600, 800, 1000 and 1200).



1. On the left is the ***Library*** with the number of hits. The search field ***Search device...*** filters by name; × in the field clears the search. Each card shows name, category and ***n U · x In · y Out***.



1. ***+ Into rack*** puts the device in the first free place. A device can also be dragged from the library into the rack; the place where it drops determines the start U and, in the view ***Both***, the side. If the device is already in the rack, the button says ***+ Add more***, and a counter ***n×*** shows how often it stands there.



The small arrow on the button opens the mount type: ***Full-depth*** (front + rear, default), ***Front only*** (***Front-mount***) or ***Rear only*** (***Rear-mount***, for example for a patch panel).

1. More devices are added in the same way. The footer counts how full the rack is: ***Devices:*** and ***U occupied:***.



Views

Above the rack are the tabs ***2D*** and ***3D***. In the tab ***2D*** the buttons ***Front***, ***Rear***, ***Both*** and ***Side*** change the view; the zoom (**–**, percentage, **+**, ***Fit***) works only in 2D. ***Show connector symbols*** shows or hides the drawn connectors in 2D and 3D.

1. ***Rear*** shows the rear.



1. ***Both*** puts front and rear side by side.



1. ***Side*** shows the depth: each device is a strip from its front edge to its rear edge within the rack depth (***Front to rear: 800 mm***); the front and rear rails are marked.



1. ***3D*** shows the rack spatially: rotate with the left button, pan with the right, zoom with the wheel; ***Shift*** moves the view up, ***Space*** down. The selection ***View:*** chooses ***All*** (all devices, free ports and patch panels), ***Free ports*** (only devices with free ports and patch panels) or ***Released*** (patch panels and externally cablable devices). The 3D view is read-only; editing happens in 2D.



Special cases when filling a rack

– Patch panel. ***+ Patch panel*** opens ***Create patch panel***. The tab ***Basics*** has ***Name***, ***Height (U)***, ***Mount*** (***Full-depth (front)***, ***Front only***, ***Rear only***), ***Port count*** (12, 16, 24, 32 or 48, or your own value), the checkbox ***Adapter patch panel*** (front and rear carry different connectors, with an internal adapter cable) and the ***Connector type***. In the tab ***Per-port detail (n)*** label and connector can be overridden per port; empty means default. ***Create patch panel*** puts it in the rack.


Create patch panel
Basics
Per-port detail (24)
Name
Patch panel
Height (U)
1
Mount
Full-depth (front)
Port count
24
12
16
24
32
48
Adapter patch panel (front ≠ rear connector, with internal adapter cable)
Connector type (both sides)
BNC
Applies to all 24 ports. Adjust individually in the "Per-port detail" tab.
Cancel
Create patch panel


Create patch panel
Basics
Per-port detail (24)
Per port label and connector type are overridable. Leave empty for default.
Label Front
1 P1 BNC
2 P2 BNC
3 P3 BNC
4 P4 BNC
5 P5 BNC
6 P6 BNC
7 P7 BNC
8 P8 BNC
Cancel
Create patch panel


New rack
Main video rack
Save rack

– **Rack shelf.** ***+ Rack shelf*** opens ***Create rack shelf*** with ***Name***, ***Height (U)*** and ***Depth (mm)***. A shelf carries devices that are not 19 inch: put them on the same start U as the shelf, and in the view they stand on it.





– **Devices without a rack size.** With the checkbox ***Include non-rack devices*** the library also shows devices that are not marked as 19-inch devices; they carry the badge ***No-HE***.



When you add one, ***Add "..."*** asks for the type: ***As 19″ device*** (with ***U height***) or ***On a shelf*** (with ***Width (mm)***, ***Height (mm)*** and ***Depth (mm)***; quick choices 1/3, 1/2 and 2/3 rack width). ***Save dimensions to template permanently*** remembers the answer so that it is not asked again.





Properties of a device in the rack

A double-click on a device in the rack opens ***Properties · device name***. The window has ***Name***, ***Category***, ***Height (RU)***, ***Start RU*** (with the maximum), ***Depth (mm)***, ***Mount*** (***Full-depth***, ***Front only***, ***Rear only***), for half-width devices ***Half (front view)*** (***Left*** or ***Right***), ***3D model (STL, optional)***, the sections ***Depth position (Z)*** and ***Port side (front/rear)*** and ***Panel images (import + crop)***. At the bottom are ***Remove from rack*** (with a question) and ***Close***.



- ***Port side*** defines per port whether it sits at the front or the rear; ***all to rear***, ***mirror*** and ***all to front*** change all ports at once.
- ***Pick STL...*** takes a 3D model up to 5 MB; without a model the 3D view draws the device as a box with front and rear photo. ***Remove*** takes the model away again.
- The panel images can be imported, cropped (***Apply crop***), swapped (***Swap front/rear***) and removed.



Conflicts

If two devices overlap, the box ***Conflicts (n)*** appears above the rack with the cases, for example ***Luminex GigaCore 12 overlaps with Blackmagic Smart Videohub 12x12.*** The footer gives the number as well (***n Conflicts***). Other cases: a device that is not marked as a rack device, a start U smaller than 1 and a device that no longer fits into the rack from its start U. Conflicts do not block saving; the rack is saved anyway.


New rack
New
Unsaved
2D rack builder · Add devices from the library, drag for U position, internal cabling
Esc
close
Export
Rack name *
Main video rack
Height (HE)
12
Depth (mm)
800
Conflicts (1)
• Luminex GigaCore 12 overlaps with Blackmagic Smart Videohub 12x12.
Library
32 / 1856
+ Patch panel
+ Rack shelf
Search device...
Include non-rack devices
Crestron Avia DSP-1283
Audio
1 HE · 20 In · 8 Out
+ Into rack
AIDA PTZ4K-NDI-X30
1×
Cameras
1 HE · 0 In · 0 Out
+ Add more
Crestron CP3
Control
1 HE · 4 In · 9 Out
+ Into rack
Clear-Com CS-702
Intercom
1 HE · 4 In · 8 Out
+ Into rack
Clear-Com MS-702
Intercom
1 HE · 5 In · 8 Out
+ Into rack
Clear-Com SB-704
Intercom
1 HE · 6 In · 16 Out
+ Into rack
Sonnet xMac mini Server Thunderbolt 3 (XMAC-MS-A-TB3)
+ Into rack
Rack layout
2D
3D
100%
Drag & Drop
Front
Rear
Both
Side
Show connector symbols
Front
U1
Blackmagic Smart Videohub 12x12
14 In · 12 Out
U2
U3
Patch panel
24 In · 24 Out
U4
Rack-Shelf
0 In · 0 Out
U5
AIDA PTZ4K-NDI-X30
0 In · 0 Out
U6
U7
U8
U9
U10
U11
Live-Preview
Black box on canvas
5 devices · 0 internal cables
Main video rack
Luminex GigaCore 12 · 2 In · 15 Out
Blackmagic Smart Videohub 12x12 · 14 In · ...
Devices: 5
U occupied: 5 / 12
1 Conflicts
Autosave active
Wire internally
Cancel
Save rack


New rack
New
Unsaved
2D rack builder · Add devices from the library, drag for U position, internal cabling
Esc
close
Export
Rack name *
Main video rack
Height (HE)
12
Depth (mm)
800
Library
32 / 1856
+ Patch panel
+ Rack shelf
Search device...
Include non-rack devices
Crestron Avia DSP-1283
Audio
1 HE · 20 In · 8 Out
+ Into rack
AIDA PTZ4K-NDI-X30
Cameras
1 HE · 0 In · 0 Out
+ Add more
Crestron CP3
Control
1 HE · 4 In · 9 Out
+ Into rack
Clear-Com CS-702
Intercom
1 HE · 4 In · 8 Out
+ Into rack
Clear-Com MS-702
Intercom
1 HE · 5 In · 8 Out
+ Into rack
Clear-Com SB-704
Intercom
1 HE · 6 In · 16 Out
+ Into rack
Sonnet xMac mini Server Thunderbolt 3 (XMAC-MS-A-TB3)
IT/Server
+ Into rack
Rack layout
2D
3D
100%
Drag & Drop
Front
Rear
Both
Side
Show connector symbols
Front
U1
Luminex GigaCore 12
2 In · 15 Out
U2
Blackmagic Smart Videohub 12x12
14 In · 12 Out
U3
Patch panel
24 In · 24 Out
U4
Rack-Shelf
0 In · 0 Out
U5
AIDA PTZ4K-NDI-X30
0 In · 0 Out
U6
U7
U8
U9
U10
U11
U12
Live-Preview
Black box on canvas
5 devices · 0 internal cables
Main video rack
Luminex GigaCore 12 · 2 In · 15 Out
Blackmagic Smart Videohub 12x12 · 14 In · ...
Devices: 5
U occupied: 5 / 12
Autosave active
Wire internally
Cancel
Save rack



Export, wiring and saving

- ***Export*** in the header offers four ways: ***2D as PNG*** (the current view), ***3D from 4 perspectives*** (PNG: front, rear, iso, top; the tab ***3D*** must have been opened beforehand), ***3D as STL*** (the whole rack as binary STL for 3D printing and CAD) and ***Download .cpgroup*** (the complete rack with STL and photos for transfer to another computer).



- ***Wire internally*** in the footer opens ***Rack cabling: rack name***, a canvas view of the devices of the rack: drag lines from an output to an input; on the right the Inspector (***Properties (rack scope)***) shows the selected device or cable. ***Done*** returns to the builder. The button is active only when at least one device is in the rack. If there are internal cables, the footer gives their number (***n cables***).



- ***Save rack*** stores the rack as a new group in the library. It requires a name (***Please enter a rack name.***) and at least one device (***Please add at least one device to the rack.***). ***Cancel*** and × ask when there are unsaved changes (***Discard unsaved rack changes?***). When editing a saved rack the button is called ***Save***.



The field ***Live-Preview*** on the right shows the rack as ***Black box on canvas*** with ***n devices · m internal cables***: this is how it appears on the canvas.

Generate AI plan

Tools → Generate AI plan...

The dialog ***AI plan generation*** creates a draft from a description or completes the open plan from documents. Nothing is inserted without confirmation: a preview appears first. The request goes to the provider you chose under ***Settings → Integrations → AI***; the recordings in this chapter show invented answers, no request leaves the computer.

1. Without a stored key it says ***No AI API key set. Add a provider key under Settings → AI.*** at the top, and ***Generate*** is disabled.



1. **From a description.** Describe the installation under ***Describe the system in plain language***, for example one camera over SDI into a switcher and the programme output to a recorder.



1. ***Generate*** shows the preview: ***Preview: 3 devices, 2 cables*** with the list of the devices and their category, plus warnings, for example when a connection pointed to an unknown device. ***Insert into plan*** takes over devices and cables.



1. After inserting, the dialog closes; the status bar gives the new number of devices and cables.

1. **From documents.** ***Choose files*** or dropping files in the dashed field accepts block diagrams, IP lists, bills of materials and floor plans: PDF, Excel, CSV, images and `.cableplan`. The files appear with their size; **×** removes one again. All attachments together must not exceed 20 MB; otherwise it says ***Together … — more than one request can carry. Send the documents in several rounds.*** With documents the text field is called ***Note for the AI (optional)***.



1. ***Complete plan*** compares the documents with the open plan and delivers only what is missing: ***Preview: 1 new rooms, 1 new devices, 0 cables, 0 devices completed*** with the new rooms (+) and devices (•, with category and IP) and warnings. If the documents contain nothing new it says ***The documents add nothing the plan does not already contain.***



1. ***Insert into plan*** takes over the completion.

Revisions & snapshots

Tools → Revisions & snapshots...

A revision stores a complete state of the plan under a name. Restoring keeps the history. The latest revision appears in the title block of the outputs, for an as-built revision with the suffix ***(As-Built)***. You compare two states with ***File → Compare plan revisions...***, see Export and Print.

1. Open ***Tools → Revisions & snapshots...***. The section ***Commit current state*** has ***Label*** (for example "A" or "Rev 2"), ***Note: what changed?*** and the checkbox ***As-built***. As long as no revision exists it says ***No revisions committed yet.***



1. ***Commit*** creates the revision. Without a label it is called ***Rev n***.



1. With the checkbox ***As-built*** you mark the state as it was built; the list marks it with ***As-built***. The list is newest first, each row with label, note and time.



1. The arrow in the row (***Restore***) asks ***Restore this state?***: the current plan is replaced by the revision, the history stays.



1. The wastebasket (***Delete***) asks ***Delete revision?***; the revision is removed permanently.

Inventory / stock

Tools → Inventory / stock…

The entry appears when the rental module is switched on. The window manages your own equipment: items with quantity and price, storage locations and cases, individual serialised units, sets, the check-out of containers, QR labels and a report.



Above the tabs is the field ***Scan / type code (item, location, unit)…***. ***Resolve*** looks the code up; a hit reports ***Item: …***, ***Location: …*** or ***Unit: model · serial***, otherwise it says ***No match for "…".*** The camera button (***Scan with camera***) reads the code with the camera. The footer gives the stock figures (***n items · m units · k locations · s sets***) and offers ***Export*** and ***Import***: ***Export*** saves the inventory as a portable file (avplan-inventory) that other applications can read as well; ***Import*** reads such a file and asks ***REPLACE the existing stock? "Cancel" merges instead.*** with the buttons ***Replace*** and ***Merge***. If the file is not an inventory, it says ***Not a valid inventory file (avplan-inventory).***

Tab Items

An item is a model with a quantity. The list shows ***Model***, ***Quantity***, ***Location / case***, ***Code (QR/barcode)*** and ***Ownership***; the search field filters it. The pencil edits an item, the wastebasket deletes it after the question ***Delete***

item? When empty it says ***No inventory items yet. Add some or import them from the plan.***

1. ***Import from plan*** creates an item for every device of the plan that does not exist yet; existing ones are not duplicated. A message then gives the number of new items. If the plan has no devices it says ***No equipment in plan***.

1. ***+ Item*** opens the form ***New item***.



1. Fill in the fields.



FIELD	MEANING
Model (required)	Name of the item.
Manufacturer, ***Category***	Free text.
Quantity	Number of pieces.
Rent price/day (€)	Rent price per day; the report calculates with it.
Ownership	***Owned***, ***Rented*** or ***Sub-hire***. With the last two, ***Return by*** appears.
Location / case	Choice among the locations; cases are marked with a package symbol.
Supplier	Where the equipment comes from.
Country of origin	For example DE, JP, US; it goes into the carnet sheet.
Code (QR/barcode) and ***Code type***	The code a label carries; ***QR code*** or ***Barcode***.
Material type	***Rental*** or ***Consumable***.
Dimensions (W×H×D · weight)	Width, height and depth in mm and weight in kg.
Note	Free text.

1. ***Save*** creates the item.



Third-party equipment that has to go back is reported by a box above the list: ***Third-party gear: n item(s) to return*** with the rows ***qty× model → supplier · due back since date*** or ***· no return date***.

Tab Locations

Storage places and cases are nodes in a tree; every node is scannable and can be nested at will: case in case in transport case.

1. ***Locations (n)*** shows the nodes. ***+ Location*** opens the form ***New location*** with ***Name***, ***Type*** (***Depot***, ***Room***, ***Shelf***, ***Bin / box***, ***Case***, ***Transport case***), ***Parent*** (***— root —*** or another node), ***Code (QR/barcode)***, ***Code type*** and ***Dimensions (W×H×D · weight) — mainly for cases***.



1. The row of a node offers ***Stock-take at this location***, ***Add child node***, ***Edit*** and ***Delete***; ***Delete*** asks ***Delete location?*** — child nodes move up one level, the items lose their location. For a case, ***Print pack list*** and ***Copy pack list (recursive)*** are added; the copied list names everything in the case and its sub-cases.



1. The ***Stock-take at this location*** opens the field ***Scan a code — a location label switches the location*** under the node. Every scanned code is recorded as ***expected here***, ***in the wrong place*** or as unknown; the row names the model and, where it differs, the expected location. Without a scanner, the list ***Tick off without a scanner — expected here: n, still open: m*** is ticked off (***here***); it records the row as ***from the list***. ***CSV*** writes the sheet including the items not found, ***Adopt location (n)*** writes the location onto all objects that were in the wrong place.

Tab Units

Units are individual serialised copies of an item with their own serial number, code, condition and history. The buttons ***Insurance*** and ***Carnet*** at the top right produce the lists for the insurance and the carnet; they are disabled without units.

1. ***+ Unit*** opens the form ***New unit***. Without items it says ***Create items first, then you can serialize individual units.***



1. Enter ***Item model***, ***Serial number (manufacturer)***, ***House reference***, ***Code (QR/barcode)*** with ***Code type***, the ***Purchase price*** (with ***Currency*** and ***Bought on***), the ***Insured value*** (with ***Currency*** and ***Value as of***) and a ***Note***.



1. A saved unit shows the condition (***OK***, ***defective***, ***in repair***, ***retired***) with ***Change condition***, ***Change location***, ***Report a fault*** (with ***Fault description***; ***Record***) and the ***History*** of moves and repairs. The row counts open faults (***n open faults***); a fault is closed with ***resolved***.



Tab Sets

A set is a logical kit of items. Its availability results from the scarcest component (***n× buildable***).

1. ***+ Set*** opens the form ***New set*** with ***Set name*** and the list ***Components***: choose ***Pick item…*** and ***Add***. Without an entry it says ***No components yet.***



Tab Check-out

A container goes out as a whole; what lies in it follows through all levels.
Only cases and transport cases can be checked out.

1. Choose the container under ***— pick a container —***, enter ***To (person, truck, client)*** and optionally ***Show (optional)*** as well as ***Handed out on*** and ***Due back***. The preview names which positions go with it (***n positions go with it: …***); an empty container reports ***This container is empty — nothing would go out.***



1. ***Check out*** books the container out. Under ***Out (n)*** every container that has been checked out appears with recipient, number of positions and, if overdue, the mark ***overdue***. Per entry the buttons offer ***Move return date*** (***New return date***; it counts how often it was moved), ***Sheet*** (the handover sheet), the signature ***Sign out*** or ***Counter-sign return***, ***Damage (n)*** (***Record damage***), ***Check in*** and ***Delete record***. When checking in, the window checks the label codes of the contents (***Check***); the ***Return findings*** name what is missing and what came back in addition. A counter-signature is possible only when the container is back; an existing signature cannot be overwritten. ***CSV*** above the list saves the checked-out containers; a list ***Damage (n)*** names recorded damage and, where it accumulates, to whom the equipment went.

Tab Labels

Print QR labels — on A4 sheets (Avery/Zweckform) or continuous label printers. Only objects with a stored code. Choose the ***Source*** (***Items with code***, ***Locations / cases with code***, ***Units with code*** or ***Contents of a case (recursive)*** with the selection ***Case / container***), the ***Code type*** (***Per code type (auto)***, ***QR code*** or ***Barcode (Code128)***) and the ***Format*** (A4 sheets by Avery and Zweckform or continuous label printers). If the code does not fully fit on the label, the dialog names the formats it fits on. ***First label position (partially used sheet)*** skips labels already used. The counter gives ***n labels · p page(s)***; ***Print*** produces the sheet. If the source contains no objects with a code, it says ***No codes***.



Tab Reports

The report counts the inventory: ***Item positions***, ***Units (bulk)***, ***Serialized*** and ***Rental vol./day (€)***, plus the distribution ***By category***, ***By location (root)***, ***By ownership***, ***By material type*** and ***Units by condition***. If items lack a rent price it says ***n items without rental price — rental volume incomplete.***



Device configuration

The tools of this group are in the ***Tools*** menu and at the device itself; the audio router of an ATEM opens via the Inspector. When you select an ATEM, Videohub, GreenGo or multiviewer device on the canvas, the Inspector shows, below the ports and the note, a card with the name of the detected device (for example ***Blackmagic ATEM detected***) and the buttons of that device, and further down the section ***Tools for this device*** with the same entries as the menu.

All dialogs of this group work on the plan offline first. Connecting, reading and sending need a device on the network and the desktop app; without a connection the corresponding buttons are disabled. The recordings in this chapter show only the state without a connection; nothing is searched, connected or sent. Reading from the device never replaces the plan by itself: the state that was read appears next to the plan, with the number of differences, and only ***Adopt into the plan*** takes it over after a question; ***Discard reading*** leaves the plan as it is.

ATEM multiviewer layout

Tools → ***ATEM multiviewer layout...***, in the Inspector ***Configure multiviewer layout***

The dialog plans which source is in which window of the multiviewer outputs of an ATEM switcher.

1. The menu ***Tools*** → ***ATEM multiviewer layout…*** first opens the selection ***ATEM multiviewer — pick device***. If the plan contains no ATEM switcher it says ***No ATEM mixer in the plan. Add an ATEM from the library first — its multiviewer config will then be selectable here.*** From the Inspector of a switcher the dialog opens directly with that device.



1. If there is an ATEM, the selection shows it (***Which ATEM mixer multiviewer do you want to configure?***). A click on the name opens the editor.

1. The editor is called ***Multiviewer layout · device name***. At the top are the tabs ***MV 1***, ***MV 2*** … for the multiviewers of the device; **+** (***Add multiviewer***) and **−** (***Remove last multiviewer***) change their number (1 to 4). The layout shows four quadrants; each window carries the name of its source and the ID.



1. A click on a window opens the source selection. It has a search field (***Search…***), a field for any ID with ***Apply*** and the sources by group, each with name and ID. Without a connection it lists the inputs of the device and the usual internal sources (Black, Color Bars, Color 1 and 2, Media Player 1 and 2, Super Source, Program and Preview of ME 1 to 4, AUX 1 to 24); with a connection the sources of the switcher.





1. The small preview next to ***Layout*** switches each quadrant between one large window and four small ones (***1*** → ***4*** and ***4*** → ***1***). The ATEM layout is derived from it.



1. The row ***Model capabilities: device · n MVs · m layouts*** expands: it shows which layouts the model knows and lets you change this by hand if the detection by device name is wrong. The boxes switch layouts (***Default***, ***Program Top***, ***Program Bottom***, ***Program Left***, ***Program Right***, ***Top-Left***

Small, ***Top-Right Small***, ***Bottom-Left Small***, ***Bottom-Right Small***, ***Grid (16 small)***, ***Quad (4 big)***) on and off; ***MV count:*** (0 to 4) and ***Max windows:*** (0 to 32) set the numbers; ***Reset override*** returns to the detection. The setting is saved with the project.



1. The buttons at the bottom: ***As PNG*** saves the view of the current multiviewer as an image; ***Save draft*** writes the draft into the plan (the message ***Saved*** confirms); ***Load from ATEM*** reads the multiviewers of the connected switcher; ***Push to ATEM*** sends the draft. The last two are disabled without a connection; the status line then says ***ATEM not connected.***, with a connection ***ATEM connected — ready to push.*** A change is kept only if you pressed ***Save draft*** or ***Push to ATEM***.



ATEM audio routing

In the Inspector of an ATEM switcher: ***Configure audio router***

The dialog ***ATEM audio configuration — device name*** plans the audio assignment of an ATEM offline. It reads and writes the profile XML of the

ATEM software and changes only audio entries in it; all other sections of the profile are preserved.

1. Open the dialog via the Inspector of an ATEM switcher (***Configure audio router***).



   Without a configuration it shows ***ATEM audio routing*** with two ways: ***Load profile XML*** reads an ATEM profile; the editor recognises whether it contains a crosspoint matrix or a classic mixer. ***Matrix manual*** creates a new matrix with the ATEM default inputs and 8 output busses; sources, outputs and mappings can then be edited freely.

1. The matrix shows the sources on the left (rows) and the outputs at the top (columns). A click on a cell routes the source to the output; a second click removes the crosspoint. A routed cell is green; an output that is occupied otherwise carries a dot. Next to the name of a source it says on how many outputs it lies (***×n***). The line above the matrix gives ***n × m visible · k crosspoints***.



1. ***Filter sources…*** and ***Filter outputs…*** hide rows and columns by a part of the text.



1. ***Source picker*** and ***Output picker*** open a list with checkboxes: individual sources or outputs can be hidden, entire groups of same-named entries at once (***Show all***, ***Hide all***). The button says how many are hidden. This only changes the view.



1. ***Reset all routings*** asks ***Reset all routings to "No Audio"?*** and sets every output to ***No Audio***. If the matrix exceeds 12,000 visible crosspoints, the dialog asks whether to draw it anyway (***Render anyway***); with the pickers it can be made smaller.



1. The buttons at the top: ***Load XML*** and ***Save XML*** (the changed profile as a file, with a provenance sheet next to it), ***Read (offline)*** or ***Read from ATEM*** and ***Send (offline)*** or ***Send to ATEM***. Sending takes effect immediately on the switcher and is not stored as startup state; for that ***Save Startup State*** has to be triggered in the ATEM software. At the bottom ***Save in project*** writes the matrix into the plan and closes the dialog; ***Cancel*** discards it.

ATEM input labels

Tools → ***ATEM input labels…***, in the Inspector ***Connect ATEM / push setup***

The dialog ***ATEM live integration*** enters the names of the inputs: it connects to the switcher over UDP and writes the port names of the plan as long and short names.

1. The window starts with the ***ATEM IP address*** and the buttons ***Search*** (looks for ATEM switchers on the local network via mDNS) and ***Connect***. Below is the ***Event log (n)***.

1. After connecting, the dialog shows model and number of M/E and AUX and the table ***Input names (n)*** with ***ID***, ***Type***, ***Live (long / short)***, ***New long (max 20)*** and ***New short (4)***. The new names are preset from the port names of the plan, for inputs with the bound source (role). The long name has at most 20 characters, the short name 4. ***Send n changes*** writes only the changed rows. Media players, audio inputs (XLR, RJ45 talkback) and internal sources (Black, Bars, Color, SuperSource) are not overwritten; their rows are locked. The names go into the working memory of the switcher; to survive a restart, ***Save Startup State*** has to be triggered in the ATEM software. With an existing connection, ***MV Layout*** → leads to the multiviewer layout.

Videohub routing / labels

Tools → ***Videohub routing / labels…***, in the Inspector ***Configure Videohub · Labels + Routing***

The dialog ***Configure Videohub · Labels + Routing*** plans labels and crosspoints of a Blackmagic Videohub and outputs them as a file or directly to the hub.

1. Choose the ***Device on the canvas*** and the ***Videohub model***. The list names the models from ***Micro Videohub 16x16*** to ***Universal Videohub 288*** with their size; the last entry of the list (a custom size) asks for ***Inputs*** and ***Outputs***. If the device has more ports than the model, the dialog warns that surplus ports are truncated.





1. ***File export format*** chooses what the preview and the file contain: ***Full routing dump (Protocol 2.5)*** or ***Labels only (Input, n, name)***. It affects only the file; direct sending is independent of it. ***Friendly Name*** is the name of the hub in the dump; in the format ***Labels only*** it is ignored.

1. The ***Routing view*** shows the crosspoints. ***Matrix*** is the crosspoint matrix, ***List*** a list with a selection per output. A click on a crosspoint routes the output to that input. ***Swap Out·In*** swaps the axes; ***Cabling on*** or ***off*** shows after the names the device that hangs on the port (← ***device***), and ***Input label on/off*** adds the port name. Row and column sizes can be dragged as in Excel (***Reset layout***). If the matrix is too large for the matrix display, the dialog switches to the list by itself.





1. ***Smart routing*** suggests a routing from the cables in the plan: per output the input with the most similar device name, otherwise diagonal. ***Reset*** restores the diagonal (output n to input n).



1. ***Salvos (routing snapshots)***: ***+ Save current routing*** asks ***Salvo name (= save routing snapshot):*** and stores the state; a click on the name recalls it, **×** (***Delete salvo***) removes it. Salvos belong to the device and the model and are stored locally.





With two salvos the row ***Changeover from — pick a set — to — pick a set —*** appears. It calculates the difference of two salvos: ***n of m crosspoints change.*** (or ***No difference — nothing to re-patch for this changeover.***). ***Changeover sheet*** saves the changed crosspoints as CSV, ***Full set*** all crosspoints of the chosen salvo.

1. ***Send to Videohub (TCP)*** connects only when you press a button. The fields ***IP address*** and ***Port*** (default 9990) take the address; the arrow next to it names the recently used connections. ***Search*** looks for hubs via mDNS, ***Load status*** fetches labels, routing and locks from the hub. ***Send labels***, ***Send routing*** and ***Send labels + routing*** send only what is chosen. After reading, the dialog compares the routing of the hub with the plan (***Routing matches the plan.*** or ***n crosspoint(s) differ from the plan*** with ***adopt into the plan***); it counts locked outputs (***n outputs locked***). The ***Activity log*** names the latest send attempts.

1. At the bottom the ***Preview*** shows the content of the file. ***To clipboard*** copies it, ***Save as file*** writes the `.txt` file; next to the file a provenance sheet with the ending `.herkunft.txt` is created that names project, state and a checksum. In the format ***Labels only***, ***Import Labels.txt*** reads a labels file (for example from Videohub Setup) and writes the names onto the ports of the device; ***Labels PDF*** produces printable label strips in the Smart Control grid.



GreenGo intercom

Tools → GreenGo intercom…, in the Inspector ***Intercom planning / export .gg5***

The dialog ***GreenGo Intercom planning*** plans a Green-GO system: stations, talk groups and the assignment between them. It exports a `.gg5` file that is loaded into the Green-GO software. Under the title is the system name.

1. The tab ***Overview*** is empty as long as there are neither stations nor groups (***No stations or groups yet — switch to the "Stations" and "Groups" tabs.***). At the bottom are ***GreenGo devices on the canvas*** with the hint ***unassigned***.



1. In the tab ***Stations (n)***, ***+ Station*** creates a station (up to 12). Enter the name (placeholder ***Station name (e.g. control room)***) and assign a device on the canvas (***— Device —***).





1. In the tab ***Groups (n)***, ***+ Group*** creates a talk group (up to 9) and gives the number of members.



1. The ***Overview*** is the matrix of stations and groups: a click on a circle adds the station to the group or removes it; the row ***Members*** counts per group. For each station the column ***Device (canvas)*** chooses the device; ***— unassigned —*** means no device.



1. The tab ***System*** has ***System name***, ***Description***, ***Multicast address*** (default 239.1.160.1, must be unique on the network) and ***Sample rate*** (***32000 Hz (GreenGo default)*** or ***48000 Hz***).



1. The footer gives ***n stations · m groups*** and the number of devices on the canvas and offers: ***Import .gg5*** (reads a `.gg5` and links its stations to devices on the canvas), ***Import Excel matrix*** and ***Export Excel matrix*** (users and groups as an Excel matrix, also for printing), ***Import neutral*** and ***Export neutral*** (a vendor-neutral intercom file with stations, conferences and who talks or listens), ***Save in project*** and ***Export as .gg5***. Without at least one station or group no valid `.gg5` is produced (***Without at least one station or group there is no valid .gg5 — create one first.***). Outputting the file also writes a provenance sheet (`.herkunft.txt`).


GreenGo Intercom planning
Produktion
Overview
Stations (2)
Groups (1)
System
System name
Produktion
Description
optional
Multicast address
239.1.160.1
Default: 239.1.160.1 — must be unique on the network.
Sample rate
32000 Hz (GreenGo default)
2 stations · 1 groups · 1 devices on canvas
Import .gg5
Import Excel matrix
Import neutral
Export neutral
Export Excel matrix
Save in project
Export as .gg5

10. Settings

Opening the settings

The ***Settings*** button sits on the right of the header bar.

Other ways into the dialog:

- Command palette (***Ctrl+K***), entry ***Settings…***; the entry ***Switch modules on or off…*** opens the ***Modules*** tab directly.
- While the MCP server runs, the status bar shows an indicator for it; clicking it opens the ***MCP*** tab.
- During a live collaboration, the ***Live*** indicator in the status bar opens the ***Network sync*** tab.

The dialog lists the 15 tabs on the left and shows the selected tab on the right. It opens on the ***Project*** tab.



Two buttons sit at the top right: the arrow button pops the settings out into a separate window (for example on a second monitor), the cross closes the dialog. Clicking the dimmed background also closes it. Drag the header to move the dialog.

Almost every setting takes effect immediately. The exceptions are the project metadata in the ***Project*** tab (button ***Save***) and individual fields with their own ***Save*** button.

TAB	CONTENTS	APPLIES TO
Project	metadata, plan defaults, logos, cable numbering, length estimation, stock lengths, library export	the open project (library export: this computer)
Modules	show or hide feature areas	this computer
Appearance	language, theme, colours, canvas background	this computer
Editing	cable routing, grid, behaviour when connecting	this computer
Hotkeys	keyboard shortcuts	this computer
Integrations	Rentman, NetBox, Tally-Pi, fill-in source, AI providers, GreenGo presets	this computer
Device library	server, account, uploads and sync	this computer
MCP	local server through which Claude queries the plan	this computer
Configurations	library of device configuration files	this computer
Cable types	own and changed cable types	this computer
Master data	own connector types, signal standards, cable layers	this computer
Categories & fields	own categories and domain fields	this computer
Network sync	live collaboration and sync directory	this computer
Credentials	qualifications, insurance, safety briefings	this person
Advanced	autosave, category management, caches, data export	this computer

Project

Project metadata

The fields at the top are saved with the project file:

FIELD	CONTENTS
Project name	name of the project
Description	free text
Client	end customer
Contractor	executing company
Author	name of the planner
Project no.	e.g. 2026-042

Changes to these fields and to the logos are applied only by ***Save*** at the bottom of the tab; ***Reset*** restores the saved values. The dialog that opens when you click the project name in the header bar edits the same data.

Plan defaults

Technical defaults for this plan, by discipline. The three lists take effect immediately.



LIST	VALUES	EFFECT
Video format (SDI)	576i50 (PAL) up to 2160p59.94/60 plus DCI 4K p24 and p60, each with the SDI standard it needs (3G, 6G, 12G or quad 3G)	drives the default SDI cabling
Power / mains standard	Europe / IEC 230 V single-phase, Europe 400 V three-phase, UK 230 V (BS 1363), North America 120 V, 208 V three-phase and 240 V split-phase, Japan 100 V, Australia / NZ 230 V	voltage used by the power calculator (watts ↔ amps)
Lighting control (default)	DMX512 / RDM (5-pin XLR), Art-Net (Ethernet), sACN — ANSI E1.31 (Ethernet)	default lighting control

Plan signature (logos)

One logo each for ***Contractor*** and ***Client***. ***Choose...*** loads an image file, the cross next to it removes the logo. The logos are stored in the project file and appear in the PDF export and in the signature on the canvas.

Linked Rentman project

Shows name and ID of the linked Rentman project. If none is linked, a note says that the link is made in the ***Integrations*** tab.



Cable numbering

Automatic, collision-free cable IDs from a fixed scheme; they appear on the canvas, in the patch list and on the labels.



OPTION	EFFECT
Auto-assign a number to new cables	every new cable gets the next free number
Prefix	text before the number, default "C"
Separator	up to two characters between prefix and number, default "-"
Digits	number of digits (1 to 6)
Start number	first number assigned
Separate counter per layer (V/A/N/P ...)	counts each cable layer separately

Example shows the number the current scheme produces. ***Renumber all cables*** reassigns the numbers of all cables according to the scheme; the number of cables is shown in brackets. Without cables the button is disabled.

Estimate cable lengths

Estimates lengths from the distance between devices on the canvas: straight line × scale plus slack. The estimate overwrites existing lengths; wireless links are left alone.

OPTION	EFFECT
Metres per 100 px	scale of the canvas
Slack (%)	surcharge in percent, 0 to 200
Round up to whole metres	rounds every estimated length up

Estimate lengths now runs the estimate and reports how many lengths were changed.

Available stock lengths

This is where you record which cable lengths (drums) this production runs. The cable bill of materials splits every run into these lengths — fewest

couplers first, least excess second — and reports what the stock cannot cover.

1. Pick the cable type under ***Type for a new entry***. The list shows the types used in the plan.
2. ***Add length*** adds a row with 100 m.
3. Adjust ***Cable type***, ***Length (m)*** and ***In stock*** in the row. The cross removes the row.



Leave ***In stock*** empty when nobody has counted. Empty means "not counted", not zero: the bill of materials only warns about a shortfall somebody actually established.

Library Export / Import



Export library saves your own device templates, groups and categories as a JSON file; the counts are shown in brackets. ***Import library...*** reads such a file. Only new entries are created: a template whose name already exists stays unchanged. The report after the import names the created templates and group presets and the skipped names.

Modules

Modules show or hide whole feature areas. This only affects the visibility of menu entries, panels and dialogs; saved project data is always kept in full. Canvas, devices, cables, properties and export are always present and are not modules.



MODULE	CONTENTS
Festinstallation	lifecycle/service, asset register and QR labels, handover documentation, field feedback
Mobile-Companion	phone patch list, plug check, QR scan lookup, field reports
Rentman	import/export link to Rentman (catalogue and cable quantities)
Rental / Lager	stock, ownership and availability, rental calculation (under construction)
NetBox	import a site or rack from a NetBox instance as a cable plan and later add new devices and connections

Each module has a checkbox ***Module enabled***.

Appearance



SECTION	CONTROL	EFFECT
Language	***Deutsch*** / ***English***	interface language, takes effect immediately
Theme	***Auto*** / ***Light*** / ***Dark***	theme of the whole app including the canvas; ***Auto*** follows the system
Device card colors	per theme (***Light***, ***Dark***) colour fields for card body, header strip, border, main text, secondary text; ***Reset*** per theme	colours of the device nodes. A device colour set on a device still overrides the body value.
Default device color	colour field, ***Reset***	starting colour of newly added devices; empty: body colour of the theme



SECTION	CONTROL	EFFECT
Port label font size	slider, default 11 px, button to reset	font size of the input and output labels on the device nodes; larger is easier to read when zoomed out but makes devices wider
Port colours	***By direction (default)*** / ***By connector type***	colouring of the port handles
Cable colour	***Manual*** / ***By length*** / ***By discipline***	manual: colour per cable from the properties; by length: length colour coding; by discipline: the layer colours. The colour stored on the cable is kept in every mode.
Arrows on cables	***Show arrow at the target end (signal flow direction)***	default for newly drawn cables; changeable per cable in the properties
Connection warnings	***Connect any inputs and outputs without warning***	Normally the app asks for confirmation on a connector-type conflict. With this box ticked the connection is created without asking and marked as adapter/converter.



SECTION	CONTROL	EFFECT
Identifier on the device node	***Asset tag*** / ***Internal number*** / ***None***	which number of the unit is shown next to the category; shown only where one is entered
Canvas background	***Pattern***: ***Dots***, ***Lines***, ***Crosses***, ***No grid***; slider ***Opacity***	pattern and opacity of the canvas grid. The grid size is set in the ***Editing*** tab.



Custom background image: ***+ Upload image...*** loads an image as the canvas background, separately as ***Dark-mode image*** and ***Light-mode image***. Once an image is set, ***Replace...*** and ***Remove image*** take the place of the button. ***Scaling*** chooses between ***Cover*** (fills completely, crops), ***Contain*** (fully visible, with margin) and ***Tile*** (repeated). The grid pattern is drawn on top of the image.

Custom palette: ***Enable custom palette*** shows two colour fields: ***Background*** and ***Grid stroke*** of the canvas. They override the defaults of the light and dark themes, but only on the canvas; dialogs keep the theme.



Connector-type colors: one colour field per connector type. The colour is only visible when ***Port colours*** is set to ***By connector type***. An empty field means default; ***Reset all*** resets every connector colour.



Device colors per category: a default colour per device category for all devices of that category without their own colour. A colour set on the device wins. ***Reset all*** removes all category colours.

Editing



SECTION	CONTROL	EFFECT
Default cable routing	***Ortho*** / ***Linie*** / ***Kurve***	shape of new cables; changeable per cable. ***Apply to all existing cables*** sets the selected shape on every existing cable (their number in brackets).
Grid	***Snap equipment to grid***; ***Grid size in pixels (6-60)***	one grid for everything: devices snap to it, port rows sit on it, automatic routing searches on it
Inline selection toolbar	***Show inline toolbar on selection***	floating quick actions (align, duplicate, frame, delete) next to the selection on the canvas
Label travels with the cable	***Swap port labels on reconnect***	When re-plugging, the new port takes over the user-assigned name of the old port; the old one falls back to the name from the template. Off by default. Only affects ports with a user-assigned name.



SECTION	CONTROL	EFFECT
Cable type follows port connector	***Derive cable type from port connector***	When a port's connector changes (e.g. BNC → XLR), connected cables take the new type, also when re-plugging to a port with a different connector. Cables with a converter hint stay untouched. On by default.
Endpoint labels at cable ends	***Show endpoint labels***	small label at each cable end: at the source end "→ target device · target port", at the target end "← source device · source port". Off by default. Works together with "Hide all labels" and the label position of a cable.
Cable rendering	***Crossing bridges on orthogonal cables***; ***Automatically offset center lines when cables overlap***	bridges where orthogonal cables cross; automatic offset of overlapping centre lines

Hotkeys

The tab lists the assignable keyboard shortcuts with their current binding.
The action names are currently shown in German.



ACTION (AS SHOWN)	MEANING	DEFAULT
Rückgängig	undo	Ctrl+Z
Wiederherstellen	redo	Ctrl+Y
Projekt speichern	save project	Ctrl+S
Projekt speichern unter...	save project as	Ctrl+Shift+S
Neues Projekt	new project	Ctrl+N
Projekt öffnen	open project	Ctrl+O
Auswahl löschen	delete selection	Delete
Alles auswählen	select all	Ctrl+A
Auswahl aufheben	clear selection	Escape
Library ein-/ausblenden	show/hide library	Ctrl+B
Eigenschaften ein-/ausblenden	show/hide properties	Ctrl+I
Längen-Legende anzeigen	show length legend	L
Zu Patches springen	jump to patches	P
Pfeil-Anzeige umschalten	toggle arrows	A
Routing umschalten	toggle routing	R

To rebind a shortcut:

1. Click the field showing the key combination. It shows ***Press key...***.
2. Press the desired combination, e.g. Ctrl/Shift/Alt plus a letter or a function key. It is applied at once.



The cross next to the field clears the binding; an empty field disables the shortcut. Duplicate bindings are allowed; the first match wins. ***Reset to default*** restores all defaults.

Integrations

Rentman



- ***Enable Rentman integration*** shows or hides the library tab, menu entries and status badges for Rentman. When off, the app shows only local devices and cables.
- ***Rentman API***: field ***API token*** for the bearer token from your Rentman account. ***Save token*** stores it encrypted in the operating system keychain, never in the project file. ***Test connection*** checks it, ***Delete token*** removes it. Status and ***Token stored*** show the current state; the endpoint is https://api.rentman.net.
- ***Linked Rentman project***: ***Link to a Rentman project...*** links the open project to a Rentman project. A saved token is required.

NetBox



- ***Enable NetBox integration*** shows or hides the menu entry and import dialog for your own NetBox instance.
- ***Instance URL***: base URL of the NetBox instance, applied with ***Save***.
- ***API token***: token with read access. ***Save token*** stores it encrypted in the keychain; it never leaves the main process. ***Test connection*** and ***Delete token*** as for Rentman.
- ***Import site/rack…*** opens the import that takes over a site or rack as a cable plan. The app only reads (`/api/dcim/…`).

Tally-Pi (direct path)

Sends the tally map from the export dialog straight to the tally Pi instead of downloading a file. The file remains as the way that works without a network path. The Pi keeps its wiring; roles missing from the plan disappear there.

1. Switch on ***Allow the direct path to the tally-pi***.
2. Enter the address under ***Address of the Pi***.
3. ***Check the connection*** reports ***The Pi answers.*** or ***No answer.***



The Pi asks for no credential on this path: whoever can reach it can write to it. Use the direct path only on a network you trust.

Fill-in source and AI providers

Fill-in source (the "Fill in" button) decides where the ***Fill in*** button in the create dialog and in the Rentman assistant takes its port groups from:

SOURCE	PROPERTY
Web search	Wikipedia and DuckDuckGo, no API key. Source and text excerpt stay stored on the device.
AI model	the provider selected below; needs an API key and names itself as the origin, but no source

Both sources guess and replace no datasheet.



AI provider (AI port suggestions) lists Google Gemini, Anthropic Claude and OpenAI with the model each uses. The radio button makes a provider active. Each provider has its own key field with ***Show***/***Hide***, ***Save*** and delete; ***Create key*** ↗ opens the provider's page. Anthropic Claude also has the field ***Workspace ID (only if the API asks for it)***. These keys are stored locally in the app's storage.

GreenGo intercom presets



A library of reusable intercom configurations. ***Save current configuration as preset*** asks for a name and saves the project's GreenGo configuration with beltpack names, groups and routing; without a GreenGo configuration in the project the button is disabled. Each preset shows its number of users and groups; ***Load*** applies it to the project after confirmation, ***Delete*** removes it.

Device library

The device library is a shared server the planner syncs device templates with and submits its own templates to.



Server: leave empty to use the default server https://devices.zumpelars.de. ***Save*** applies a different address; ***Restore default*** goes back to the default. The line ***In use*** shows the active server. In the browser edition the sign-in is kept in the browser's storage, in the desktop app in the system keychain.

Account: the device library can only be used with an account. Accounts are created on the website, where you confirm your email address and accept the guidelines.

1. Enter ***Email or username*** and ***Password***, then ***Sign in***.
2. If two-factor sign-in is set up for the account, the field ***Two-factor code from your authenticator app*** appears; ***Confirm code*** completes the sign-in, ***Cancel*** aborts.

Create account and ***Forgot password*** open the website. When signed in, the section shows name and email address and the button ***Sign out***.

My devices: templates you created or changed are uploaded and go to moderation first.

- ***Upload my own devices automatically*** uploads at start and after every change to a template, while you are signed in.
- ***Sync now*** uploads what changed, then fetches updates. The button requires a sign-in.
- ***Own templates (n)*** expands the list of your own templates. Each shows its state, e.g. ***not uploaded yet***, ***changed since the last upload***, ***uploaded — waiting for moderation***, ***uploaded — live*** or ***blocked — fix the points below***. If manufacturer or model are missing, fields for them appear below; without both the template is not uploaded.



Sync: ***Update from device library*** fetches only what changed since the last sync (requires a sign-in). The devices appear read-only in the library under ***Shared*** and stay available offline. Below it are the number of devices stored locally and the time of the last sync. The report names new, updated and removed devices as well as entries skipped because they fail the template check of this app.

MCP

Through the MCP server Claude queries this plan: devices, ports, signal paths, cables and the result of the plan check. The server runs only in the desktop app, listens only on 127.0.0.1 and requires a pairing token.



1. ***Start server*** starts the server. The address appears next to it, e.g. ***Listening on http://127.0.0.1:4187/mcp***; ***Stop server*** stops it. While a client is asking, it says ***a client is asking***. If the configured port is busy, the server runs on a random port and the line says so.
2. The state is remembered: if the server was running when the app closed, it starts again on the next launch on the same port.
3. ***Port*** sets the port; it takes effect when the server is next started.



Claude may also change the plan: a separate switch, off by default. When on, Claude may place library and custom devices, connect and remove cables, set cable details and rack heights, save racks and rename devices. Every call is one undo step and leaves a line in the list ***What Claude changed***, which appears in the tab as soon as there are entries. Switching commands to devices (Videohub, ATEM) are never offered. The switch takes effect when the server is next started.

Pairing token: ***Show pairing token*** reveals the token, ***New token*** creates a new one. The token lives in the operating system credential store. A new token takes effect after the server is restarted, and every client has to be given the new one.



While the server runs, the tab shows three ready-made templates with address and token, each with ***Copy***:

TEMPLATE	PURPOSE
Add it to Claude Code	the command `claude mcp add --transport http cable-planner …`
JSON for .mcp.json or other clients	configuration block for other clients
Without restarting the client: call it with curl	a `curl` call that lists the tools



claude.ai and the Claude app cannot reach this computer. For them: put the project into the cloud (***File*** → ***Cloud & share link…***), then add a custom connector in claude.ai with the address shown (default: https://devices.zumpelars.de/mcp) and sign in with your device library account. This connector only reads cloud projects and never changes anything.

Configurations

A library of device configuration files (ATEM, Videohub, GreenGo), independent of the project.



1. ***Choose file...*** loads a file (XML, JSON, TXT, CSV or .gg5). The type is guessed from the file name.
2. The file appears in the ***Configuration library***, grouped by type.



Each entry has:

- a name field,
- the type list: ***ATEM Multiviewer Layout***, ***ATEM Audio-Routing***, ***Videohub Labels***, ***Videohub Routing***, ***GreenGo Intercom (.gg5)***, ***Sonstige*** (other),
- the device list, which assigns the configuration to a device on the canvas (***(unassigned)*** for none),
- the file name, a button ***Download original file*** and the cross to remove it (with confirmation).

The filter buttons above the list (***All*** and one per type, with counts) narrow the view. ***Export library as JSON*** saves the whole library to one file; ***Import JSON library...*** reads such a file and asks whether to replace or append to the existing library.

Cable types

Cable types are the presets the plan offers while drawing: connector, signal standards, colour and maximum length. They belong to the installation, not to a project.



- **Your own cable types:** ***+ New cable type*** opens the dialog ***New cable type***. Created types are available in every project on this computer and each have ***Edit*** and ***Delete***.
- **Changed built-in types:** a built-in type is never deleted, only overridden. ***Reset to the built-in default*** puts the shipped values back.

The cable library in the left sidebar can also edit a type in place.



FIELD	CONTENTS
Name	e.g. CAT6a patch 5m
Connector type	list of all connector types; **+** creates your own
Cable colour	colour field
Also compatible with (optional)	further connector types to click
Signal standards	standards to click; ***+ Standard*** creates your own
Max. length (m) – optional	maximum length
Note (optional)	free text

Create saves the type, ***Cancel*** discards it.

Master data

Your own connector types, signal standards and cable layers in one place. They appear in every picker next to the built-in ones and travel with the shared library (Network sync), so a team uses the same names.



Each of the three sections ***Connector types***, ***Signal standards*** and ***Cable layers*** works the same way:

1. Type the name into the input field (e.g. "SMPTE 2110-20" for signal standards).
2. ***Add*** creates the entry. A name that already exists is not accepted.



Own entries can be renamed (the app asks for the new name) and removed (after confirmation). Renaming an entry also renames it on all ports, cables and library templates that use it.

Built in (n) expands the shipped entries. Built in are 127 connector types, 64 signal standards and six cable layers: video, audio, control, network, power, other.



Categories & fields

This is where you create your own device categories and domain fields (e.g. a polar pattern). Own fields appear automatically in the device properties and in the bill of materials and export. Built-in fields are locked (***built-in***).



Choose or create a category: the ***Category*** list shows the fields of a category. A new category is created with ***New category (DE)***, optionally ***Name (EN)***, and ***Create category***.



Create a field:

1. ***Add field*** opens the form ***New field***.
2. Enter ***Label (DE)***, ***Label (EN)*** and ***Key***.
3. Choose the ***Type***: ***Text***, ***Number***, ***Select***, ***Yes/No*** or ***Polar pattern (diagram)***. For ***Select***, add at least one choice with ***Option***.
4. Optionally ***Unit*** and ***Placeholder***.
5. ***Create field*** saves, ***Cancel*** discards.



A key may occur only once per category. Own fields are deleted with the bin icon; a created field is not edited afterwards but deleted and created again. Categories are renamed in the ***Advanced*** tab.

Network sync

The tab holds two separate ways of working together: live collaboration and the shared sync directory.

Live collaboration (beta)

Several planners edit the same plan in real time. Changes are merged without a server, even after a brief disconnect.



FIELD	CONTENTS
Your display name	the name the others see
Mode	***This device (multiple windows)*** or ***Network (LAN/WAN, P2P)***
Room name	name of the shared room

In ***Network*** mode further fields appear:

FIELD	CONTENTS
Signaling server	empty: wss://relay.zumpelars.de; it only sees connection metadata, never the plan
Local only	no remote relay, nothing leaves the LAN
Room password (optional)	encrypts the room
STUN/TURN servers (optional)	one server per line: `URL user password`; only needed when the other side sits in a different network. The credentials stay on this computer and are not part of the invite link.

Without a room password the room is unencrypted: anyone who knows the room name and signaling server or finds the session on the LAN can read the entire project.



Sessions on the network: ***Search the network*** looks for running sessions on the local network (desktop app only). Sessions found have a ***Join*** button. Joining adopts the host's plan and, after confirmation, replaces your own.

Start session opens the session. The section then shows ***Connected — changes are shared live***, the participants in the room and the button ***Copy invite***, which puts an invite link on the clipboard. ***Leave*** ends your participation.



Sync directory

A shared directory (mapped FTP drive, network path or local folder) in which project, library and presets are exchanged as JSON files. This path requires the desktop app.

1. Enter the ***Sync directory***.
2. Enter ***User name (for lock display)***; the others see it while you hold the lock on the directory.
3. ***Save***. ***Reset*** restores the saved values.



With a directory set, the buttons ***Push*** and ***Pull*** appear in the header bar:

- ***Push*** writes `cable-planner.project.json`, `cable-planner.library.json` and `cable-planner.presets.json` to the directory.
- ***Pull*** loads these files into the current state. If the directory holds no sync files, the app says so.
- A lock file (`.cable-planner-sync.lock`) prevents simultaneous overwrites; it expires after two hours. If the directory is locked, the message names whoever holds the lock.

Shared library (workgroup): ***Sync library now*** syncs device templates, groups and categories with the file `cable-planner.library.json` in the sync directory. Matching is by name; local templates are never overwritten. The message names what was pulled and shared, and name conflicts where the local version was kept.



Credentials

Qualifications, insurance and safety briefings of the person using the app, each with an expiry date. They belong to the person, not to the plan, and never go into a project file.



Adding a credential:

1. ***Credential*** opens the form.
2. Choose the ***Kind***. The list currently shows the German names: Qualifikation (qualification), Versicherung (insurance), Unterweisung (safety briefing), Ausweis (ID card), Sonstiges (other).
3. Enter the ***Name*** (required), optionally ***Issued by***, ***Number***, ***Issued on***, ***Valid until*** and ***Scan file name***.
4. ***Save***.



Without ***Valid until***, a credential does not count as open-ended but as "no expiry stated"; the cover sheet says exactly that. Each entry shows its state, kind and expiry with the remaining days and has ***Edit*** and ***Delete***.

Advance warning: the number of ***days*** before expiry from which a warning is given. Below it are the credentials that expire within that window. With no figure, nothing is reported.

Cover sheet: saves a CSV file `nachweise-deckblatt.csv` with all credentials (kind, name, issuer, number, valid until, state, file) and summary lines for expired credentials, credentials without expiry and credentials without a named file. The column headings of this file are in German. Without credentials the button is disabled.


Settings
Project
Modules
Appearance
Editing
Hotkeys
Integrations
Device library
MCP
Configurations
Cable types
Master data
Categories & fields
Network sync
Credentials
Advanced
Credentials (qualifications, insurance)
Credentials
Qualifications, insurance and safety briefings held by this person, with expiry dates. They belong to you, not to the plan — they never go into a project file.
1 credentials
Cover sheet
+ Credential
gültig
Working-at-height certificate · Qualifikation · 2026-11-15 (in 25 days)
Edit
Advance warning
How many days before expiry to warn. With no figure, nothing is reported — a default would be an opinion about how long a renewal takes.
30
days
1 expire within that window: Working-at-height certificate

Advanced



Autosave: ***Autosave interval (ms)*** sets how often the project is saved automatically to local storage. Default 400 ms.

Category management: the table lists all library categories with their number of templates.

- ***Rename*** opens the dialog ***Rename category*** with one field each for ***English*** and ***German***. The matching name is shown for the current interface language; an empty field falls back to the other language. If the name changes, all assigned templates and placed devices move along. ***OK*** applies.
- ***+ New category*** creates a category with the same dialog.



Caches & local data: ***Clear Rentman template cache*** and ***Clear web search history*** clear the respective cache after confirmation; it is reloaded on demand, project data is not lost. ***Show welcome dialog on next start*** shows the welcome dialog again on the next start, after confirmation.

Data export: ***Export all localStorage data*** saves all data the app stores locally as a JSON file, for example to move it to another computer.


Settings
Project
Modules
Appearance
Editing
Hotkeys
Integrations
Device library
MCP
Configurations
Cable types
Master data
Categories & fields
Network sync
Credentials
Advanced
Advanced
Category management
Rename library categories or add new ones. When renaming, all assigned templates move along.
Category
Templates
Audio 22 Rename
Cables 0 Rename
Cameras 381 Rename
Control 3 Rename
Converter 27 Rename
+ New category
Caches & local data
Cache contents are reloaded on demand. Your data is safe — only performance caches are cleared.
Clear Rentman template cache
Clear web search history
Show welcome dialog on next start
Data export
Export LZ Cable Planner data stored locally as JSON — e.g. to migrate to another machine.
Export all localStorage data

11. Claude (MCP)

Claude can answer questions about the open plan — devices, ports, signal paths, cables and the plan check — search the device library and check the plan against a cable list (missing, extra, wrong port, wrong direction).

On this computer

1. ***Settings*** → ***MCP*** → switch on. The server listens on `127.0.0.1` only and uses a pairing token from the keychain.
2. Copy the command shown there, for example:

```
claude mcp add --transport http cable-planner http://127.0.0.1:<port>/mcp --header "Authorization: Bearer <token>"
```

1. Reading is the default. **Writing** is a second switch: Claude can then build a system — place library devices, create custom devices from port groups, draw cables one at a time or many per call, set rack heights and save devices as a rack with their internal cables — and remove cables, set cable details and rename devices. Ports are named exactly; the cable type is chosen as in the cable dialog. Input to input is refused, a reversed pair is flipped, an occupied input stays as it is unless Claude is told to replace it. Each call is one undo step and is listed under ***What Claude changed***.

From claude.ai, the phone or another machine

1. Put the project into the cloud (***File*** → ***Cloud & share link…***).
2. In claude.ai: ***Settings*** → ***Connectors*** → ***Add custom connector*** with `https://devices.zumpelars.de/mcp` and sign in with your device library account.
3. Read-only, over your own cloud projects. Disconnect under ***Account*** → ***Security*** → ***Connected apps*** on devices.zumpelars.de.

Switching commands for ATEM or Videohub are never offered.

12. Web edition and tablet

- Open **https://larszu.github.io/cable-planner/** and add it to the home screen; it runs full-screen with its own icon.
- Touch: pinch zooms the plan, two fingers pan, a **long press** opens the context menu.
- Not available in the browser (no socket, listening port or keychain): ATEM, Videohub, NetBox, LAN sync, phone access, MCP server, show control, switching, Tally-Pi, Rentman export, update check. ***Settings*** → ***Integrations*** lists them with the reason.

13. Data, safety and troubleshooting

- **Projects**: local JSON files. The app writes them atomically with a backup copy.
- **App data** (library, recent projects, settings) lives in the app-data folder `Cable Planner`.
- **Secrets** (API tokens, stream credentials, device library sign-in) live in the operating system's keychain. The web edition keeps the device library sign-in in the browser's storage.
- **"No recovery copy"** in the status bar: save the project to a file.
- **No still image preview**: install ffmpeg, and check the device is in the local network.
- **Device library unreachable**: the app keeps working with the devices from the last sync.

Questions and bug reports: GitHub Issues.

© 2026 Lars Zumpe Medienproduktion · free to use, proprietary licence

IM FOKUS.

Lars Zumpe
Lars Zumpe Medienproduktion · Turmstraße 37 · 51645 Gummersbach
+49 151 2070 3235
info@zumpelars.de
www.zumpelars.de

lars zumpe
MEDIENPRODUKTION

Free to use, proprietary licence.