CORVELL FRENCH-DOOR REFRIGERATOR — USE & CARE GUIDE AND WARRANTY
Models CF-3400 / CF-3400S

--- page 1 ---

IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before using this appliance. This refrigerator must be pro
perly installed and located in accordance with these instructions before it is u
sed. Do not allow children to climb, stand or hang on the doors or shelves. Neve
r clean refrigerator parts with flammable fluids. Keep fingers out of pinch-poin
t areas; clearances between the doors and cabinet are necessarily small. Unplug
the refrigerator before cleaning or making repairs. If the power cord is damaged
, it must be replaced by the manufacturer, its service agent or a similarly qual
ified person. Do not use an extension cord. Child entrapment and suffocation are
 not problems of the past: junked or abandoned refrigerators are still dangerous
. Before you throw away your old refrigerator, take off the doors and leave the
shelves in place.

Read all instructions before using this appliance. (See also the Quick Start car
d included in the literature pack.)

--- page 2 ---

INSTALLATION

Allow 1/2 inch of clearance on each side and at the top, and 1 inch behind the u
nit, for air circulation. Do not install where the temperature will fall below 5
5°F or rise above 110°F. The floor must be strong enough to support a fully load
ed refrigerator, about 700 pounds. Level the refrigerator side to side and front
 to back by turning the leveling legs. The front should be slightly higher than
the back so the doors close easily. Connect the water line using 1/4-inch copper
 or the supplied PEX tubing; do not use plastic tubing without a reinforced brai
d. Flush the water system by dispensing 3 gallons before first use. Discard the
first three batches of ice.

Allow 1/2 inch of clearance on each side and at the top, and 1 inch behind the u
nit, for air circulation. (See also the Quick Start card included in the literat
ure pack.)

--- page 3 ---

USING THE CONTROLS

The control panel is inside the fresh-food compartment at the top. Recommended s
ettings are 37°F for the fresh-food compartment and 0°F for the freezer. Allow 2
4 hours for temperatures to stabilize after any change. Turbo Cool lowers the fr
esh-food temperature quickly after a large grocery load and turns off automatica
lly after 6 hours. Vacation Mode raises the fresh-food setting to 55°F to save e
nergy; do not store perishable food while it is on. The Door Alarm sounds after
the door has been open 60 seconds; press and hold Alarm for 3 seconds to silence
 it permanently.

The control panel is inside the fresh-food compartment at the top. (See also the
 Quick Start card included in the literature pack.)

--- page 4 ---

THE ICE MAKER AND DISPENSER

The ice maker produces about 3.5 pounds of ice per day. It will not produce ice
until the freezer reaches 10°F. If the ice maker does not run, check that the fe

eler arm is in the down position and that the water supply valve is open. Do not use the dispenser to crush ice cream or frozen food. Hollow or small cubes usually mean low water pressure or a clogged filter; replace the filter first. To reset the ice maker, press and hold the test button for 3 seconds. Empty the ice bucket before long absences.

The ice maker produces about 3.5 pounds of ice per day. (See also the Quick Start card included in the literature pack.)

--- page 5 ---

STORAGE TIPS

Store meat and fish in the lower crisper set to Meat. Store vegetables in the upper crisper set to Produce. Butter keeps best in the covered dairy bin. Do not overload door bins; they are rated for 15 pounds each. Allow air to circulate around food. Hot food may be placed in the refrigerator after it has cooled for 30 minutes. Freezer: wrap food in moisture-proof material to avoid freezer burn. Do not refreeze thawed food.

Store meat and fish in the lower crisper set to Meat. (See also the Quick Start card included in the literature pack.)

--- page 6 ---

CLEANING

Clean the interior every few months with a solution of 2 tablespoons baking soda in 1 quart warm water. Do not use abrasive cleaners, bleach or cleaners containing ammonia on the fingerprint-resistant stainless finish; use a soft cloth and mild dish soap. Vacuum the condenser coils behind the toe grille once a year, more often with pets. The door gaskets can be cleaned with mild soap and warm water; dry thoroughly. Shelves are tempered glass; let them reach room temperature before washing in warm water.

Clean the interior every few months with a solution of 2 tablespoons baking soda in 1 quart warm water. (See also the Quick Start card included in the literature pack.)

--- page 7 ---

NORMAL SOUNDS

Your new refrigerator may make sounds your old one did not. A high-pitched whine or pulsating sound is the variable-speed compressor adjusting to cool efficiently. Clicking is the defrost timer or the water valve. Gurgling is refrigerant flowing. Popping is contraction and expansion of the inside walls. A buzzing sound may be heard when the water valve opens to fill the ice maker. Water dripping on the defrost heater can cause a sizzling sound. None of these sounds indicate a problem.

Your new refrigerator may make sounds your old one did not. (See also the Quick Start card included in the literature pack.)

--- page 8 ---

TROUBLESHOOTING

Refrigerator does not operate: check the plug, the household fuse or breaker, and whether the unit is in Showroom Mode (press Freezer and Fresh Food together for 5 seconds to exit). Temperature too warm: the doors may be opened too often, the door gaskets may not seal, or the coils may be dirty. Frost or ice crystals o

n frozen food: the door may have been left ajar. Water on the floor: the drain p
an may be cracked or the water line connection loose. Water has poor taste: repl
ace the filter. Dispenser slow: low household water pressure (below 40 psi) or a
 clogged filter. If the problem persists, call Corvell Service before scheduling
 any outside repair; unauthorized repairs may void the warranty.

Refrigerator does not operate: check the plug, the household fuse or breaker, an
d whether the unit is in Showroom Mode (press Freezer and Fresh Food together fo
r 5 seconds to exit). (See also the Quick Start card included in the literature
pack.)

--- page 9 ---

WATER FILTER

Use only genuine Corvell CWF-9 filters. Replace the filter every 6 months, or so
oner if
the filter indicator turns red or water flow decreases. To replace: turn the old
 filter a
quarter turn counter-clockwise, pull out, insert the new filter and turn clockwi
se until it
locks. Dispense 2 gallons to flush. Reset the indicator by holding Filter for 3
seconds.

--- page 10 ---

CORVELL LIMITED WARRANTY — MODEL CF-3400

Keep your sales receipt; proof of the original purchase date is needed for warra
nty service.

FIRST YEAR — From the date of original purchase, Corvell will repair or replace
any part
of the refrigerator that fails because of a defect in materials or workmanship,
and pay
all labor and in-home service.

SECOND THROUGH FIFTH YEAR — SEALED SYSTEM. For five (5) years from the date of o
riginal
purchase, Corvell will repair or replace, parts AND labor, any part of the seale
d
refrigerating system (the compressor, evaporator, condenser, dryer and connectin
g tubing)
that fails because of a defect in materials or workmanship.

SIXTH THROUGH TENTH YEAR — LINEAR INVERTER COMPRESSOR. For ten (10) years from t
he date of
original purchase, Corvell will provide a replacement compressor (PART ONLY) if
the
compressor fails because of a defect. In years 6 through 10 the owner pays labor
 and
in-home service.

NOT COVERED: water filters; light bulbs; service calls to teach you how to use t
he
product; damage from improper installation, accident, fire, flood or acts of God
; food
loss; commercial use.

Registration (detach and mail, or register online within 60 days of purchase):

  Model: CF-3400   Serial: CV34-26-0712-8841

Purchased: 2026-07-12 at Valley Appliance, Alder Creek OR
Owner: Anna Halvorsen Phone: 541-555-0123 Email: anna.halvorsen.test@example.com