




WORLD BICYCLE RELIEF™


Bicycle Maintenance Manual




Frame




Tire





Fork



Spoke




WORLD BICYCLE RELIEF®
Copyright © 2012, World Bicycle Relief
Rev. 15-02-12 - PAGE 1




Components


	Tire Lever
	Hacksaw Blade
	Cutting Tool
	Patching Glue




Remove tube



Hold underwater to locate hole




Cut patch from old tube



Scratch patch area with hacksaw blade
or sandpaper



Add patching glue to tube and patch




Press patch down hard on tube



WORLD BICYCLE RELIEF®
Copyright © 2012, World Bicycle Relief
Rev. 15-02-12 - PAGE 3




Tube Repair



	10mm spanner
	15mm spanner
	26mm spanner
	36mm spanner
	Lockring spanner
	Hammer
	Cotter Anvil


A		Frame
B		BB Spindle
C		BB Bearings (2)
D		Adjustable Cup
E		Lockring
F		Fixed Cup
G		Left Crank Arm


H		Right Crank Arm and Chainring
I		Cotter Pins (2)
J		Cotter Pin Washers (2)
K		Cotter Pin Nuts (2)
L		Left Pedal
M		Right Pedal




Bottom Bracket

A		Frame
B		Fork
C		Headset Bearing (2)
D		Upper Headset Race
E		Lamp Bracket
F		Headset Spacer
G		Lock Nut
H		Expander Bolt
I		Washer
J		Handlebars
K		Handlebar Grips (2)
L		Stem
M		Stem Bolt
N		Expander Wedge





A		Master Link
B		Master Link Side Plate
C		Retaining Clip
D		Chain




WORLD BICYCLE RELIEF®


Copyright © 2012, World Bicycle Relief
Rev. 15-02-12 - PAGE 6




A		Axe
B		Hub Shell
C		Bearing (2)
D		Cone
E		Locknut
F		Axe Washers (2)
G		Axe Nuts (2)
H		Fork




	15mm spanner
	17mm spanner
	15mm cone spanner



Front Hub



	10mm Spanner
	15mm Spanner
	17mm Spanner
	Screwdriver
	15mm cone spanner



A		Axle Nut (2)
B		Axle Washers (2)
C		Snap Ring
D		Cog
E		Right Dust Cover
F		Lock Nuts (2)
G		Bearing Shield
H		Cone
I		Small Bearing

J		Hub Driver
K		Large Bearings (2)
L		Hub Shell
M		Axle
N		Clutch Cone
O		Clutch Washer
P		Clutch Spring
Q		Spring Holder
R		Brake Shoes

S		Brake Cone
T		Left Dust Cover
U		Brake Arm
V		Washer
W		Bolt
X		Brake Arm Clip
Y		Nut




WORLD BICYCLE RELIEF®
Copyright © 2012, World Bicycle Relief
Rev. 15-02-12 - PAGE 8



KT Rear Hub




1




2


# of crossings	Hub holes
4x	10
3x	8
2x	6
1x	4



-or-




3








Truing



Rounding




Tighten




Loosen


Dishing



Rim Off Center



Correctly Dished



Rim Off Center



Wheel Alignment





WORLD BICYCLE RELIEF™

World Bicycle Relief
1333 N. Kingsbury, 4th Fl.
Chicago, IL 60642
tel: +1.312.664.3836
www.worldbicyclerelief.org