

Colemak-DH · Bilateral Home-Row Mods · Semantic F13–F24 Protocol · 42 Positions · 6-Thumb Layer Model

☐ Unused on this Layer

Esc	Q	W	F	P	B	J	L	U	Y	'	Bsp
MEDIA	A Cmd	R Alt	S Ctrl	T Shift	G	M	N RShift	E RCtrl	I RAlt	O RCmd	;
Shift Sticky	Z	X	C	D	V	K	H	,	.	/	RShift
	Esc MOUSE	Space NAV	Tab HOST	Enter SYM	Bsp NUM	Del FUN					

[illegible]

	F12	F7	F8	F9	PrtSc	Caps Lock				
	F11	F4	F5	F6	ScrLk		RShift	RCtrl	RAlt	RCmd
	F10	F1	F2	F3	Pause					
			Menu	Space	Tab					

[illegible][illegible]

The diagram shows a standard QWERTY keyboard layout with keys represented as a grid. The keys are arranged as follows:

- Row 1: [, 7, 8, 9,], [space], [space], [space], [space], **BOOT**
- Row 2: [space], ; , 4, 5, 6, =, [space], RShift, RCtrl, RAlt, RCmd, [space]
- Row 3: [space], ` , 1, 2, 3, \ , [space], [space], [space], [space], [space], [space]
- Row 4: [space], [space], [space], . 0 -, [space], [space], [space], [space], [space], [space]

The 'BOOT' key is highlighted in red, indicating it is the selected key for the exercise.

	Move→ WEB	Move→ DEV	Move→ COMMS	Move→ RUN	Move→ AUX		Resize	Service			Esc
	WEB	DEV	COMMS	RUN	AUX	Prev Win	Focus ←	Focus ↓	Focus ↑	Focus →	
	Launch	QTerm	Term	LANG			Move ←	Move ↓	Move ↑	Move →	
						Full	Prev WS	Float			

▽	1	2	3	4	5	6	7	8	9	0	▽
▽	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	▽
▽	,	-	=	[	]	▽	▽	▽	▽	▽	▽
						▽	▽	BASE			

								Redo	Paste	Copy	Cut	Undo	
	Cmd	Alt	Ctrl	Shift				Back	Pointer ←	Pointer ↓	Pointer ↑	Pointer →	Forward
									Scroll ←	Scroll ↓	Scroll ↑	Scroll →	
								Right click	Left click	Middle click			

[illegible][illegible]

LAYER ACCESS		SPECIAL MECHANICS		HARDWARE & PROTOCOL	
● MEDIA	Hold LM5	ADJUST	NAV + NUM conditional rule (L1+L4)	BOOTLOADER SHORTCUTS	
● MOUSE	Hold L-thumb Esc (LH2)	GAME	Entered via ADJUST RT3 (&to L_GAME)	Left side: NAV LT5 / ADJUST LT5	
● NAV	Hold L-thumb Space (LH1)	GAME_FN	Hold Esc (LT5) or Hold RH1 (&mo)	Right side: NUM RT5 / ADJUST RT5	
● HOST	Hold L-thumb Tab (LH0)	EXIT GAME		Peripheral Bootloader Caveat	
● SYM	Hold R-thumb Enter (RH0)	GAME_FN RH2 (&to L_BASE)		Right BOOT requires split link. Use physical reset button if unlinked.	
● NUM	Hold R-thumb Bsp (RH1)			HOST PROTOCOL (F13-F24)	
● FUN	Hold R-thumb Del (RH2)			HOST and edit semantic signals require the active macOS or Windows host bridge.	
● ADJUST	Hold NAV + NUM (Space+Bsp)				