



Cutting & Food Preparation Equipment

Operation Manual

YuKoLi — Foshan YuKoLi Technology Co., Ltd.

www.yukoli.com

1. Equipment Overview
2. Safety Precautions
3. Step-by-Step Operation Guide
 - 3.1 Vegetable Cutter / Slicer
 - 3.2 Food Processor / Chopper
 - 3.3 Dicing Machine
 - 3.4 Shredding Machine
4. Cleaning & Daily Maintenance
5. Troubleshooting Guide
6. Technical Specifications Table
7. Warranty & Contact Information

1. Equipment Overview

YuKoLi food preparation machines are designed to increase kitchen efficiency and consistency. This manual covers four core equipment types:

- **Vegetable Cutter / Slicer** – Cuts vegetables, fruits, and some cheeses into uniform slices or strips using interchangeable blades. Ideal for salads, garnishes, and bulk prep.
- **Food Processor / Chopper** – Employs a rotating blade to chop, puree, or emulsify ingredients. Used for sauces, dips, ground meat, and small-batch chopping.
- **Dicing Machine** – Produces precise cubes (e.g., 8 mm, 10 mm, 12 mm) from firm vegetables, fruits, or cooked meats. Features a push-block mechanism for consistent sizing.
- **Shredding Machine** – Shreds leafy greens, cabbage, cheese, or carrots into fine or coarse strands. Often equipped with a rotating drum or disc.

All models share a common motor base and are designed for continuous use in commercial kitchens. Refer to the specification table (Section 6) for model-specific ratings.

2. Safety Precautions



Before operating any YuKoLi equipment, read and understand the following safety rules. Failure to comply may cause serious injury or equipment damage.

- **Personal protective equipment:** Always wear cut-resistant gloves when handling blades or feeding food. Use safety goggles if splashing is possible.
- **Lockout/Tagout:** Disconnect power before cleaning, changing blades, or clearing a jam.
- **Electrical safety:** Ensure the machine is plugged into a grounded outlet. Do not use extension cords. Keep the power cord away from water and heat.
- **Guard use:** Never operate the machine with safety guards removed or bypassed. All feed chutes, covers, and interlocks must be in place.
- **Avoid overloading:** Do not exceed the maximum capacity stated on the machine label. Overloading can cause motor overheating or blade damage.
- **Sharp blade hazard:** Blades are extremely sharp. Handle only with the provided tool or by the designated plastic grip. Never reach into the feed chute while the machine is running.
- **Stable placement:** Place the machine on a dry, level, non-slip surface. Ensure at least 30 cm clearance on all sides for ventilation.

- **Emergency stop:** All YuKoLi machines are equipped with an emergency stop button (red). Its location is marked by a red ring. Test the stop button before each use.
- **Children and untrained staff:** Keep away from children. Only trained personnel may operate this equipment.
- **Daily inspection:** Before each use, check the power cord for damage, verify blade sharpness, and ensure all fasteners are tight.

3. Step-by-Step Operation Guide

3.1 Vegetable Cutter / Slicer

1. Preparation

- Wash and trim vegetables. Remove any seeds, stems, or hard pits that could damage the blade.
- Select the desired slicing disc (e.g., 2 mm, 4 mm, 6 mm). Insert it onto the rotor hub until it clicks.
- Place the receiving container under the output chute.

2. Assembly

- Secure the lid on the machine, ensuring the interlock switch is depressed.
- Adjust the thickness control knob (if equipped) to the desired slice thickness.
- Check the feed chute opening: for long vegetables (carrots, cucumbers), use the small tube pusher; for wider items (potatoes, onions), use the large pusher.

3. Operation

- Turn the main power switch ON. Press the green “Start” button. Wait 2 seconds for the disc to reach full speed.
- Insert vegetables one at a time. Use the pusher to gently feed; do not force.
- For bulk slicing, load the hopper with pre-cut pieces (max 10 cm length) and let gravity feed.
- Stop by pressing the red “Stop” button or the emergency stop. Wait for the disc to stop completely before opening the lid.

4. Post-operation

- Remove the receiving container.
- Turn off and unplug the machine.
- Disassemble the lid and disc for cleaning.

3.2 Food Processor / Chopper

1. Preparation

- Cut larger ingredients into chunks (approx. 3–4 cm) to avoid motor strain.
- Select the chopping blade (S-blade) or a grating disc, depending on the task. Attach it to the motor shaft.

2. Assembly

- Place the work bowl on the base, turning clockwise until it locks.
- Insert the blade/disc. Attach the lid, ensuring the feed chute cover is closed.
- Plug in and power ON.

3. Operation

- Add ingredients through the feed chute. For fine chopping, pulse using the “Pulse” button (short bursts of 1–2 seconds).
- For continuous operation, press the “Continuous” button. Do not run for more than 3 minutes without a 1-minute rest.
- To change texture, process in short pulses and check frequently.
- Stop the machine before adding large quantities of liquid.
- Always use the pusher to guide food; never use hands.

4. Post-operation

- Stop and unplug.
- Remove the bowl and blade carefully. Rinse immediately to prevent food drying.

3.3 Dicing Machine

1. Preparation

- Select the dicing grid size (e.g., 8 mm, 10 mm, 12 mm). Insert the grid into the cutting chamber.
- Ensure the push block is clean and moves freely.
- Cut raw ingredients into strips slightly smaller than the feed opening (approx. 4×4 cm cross-section).

2. Assembly

- Lock the grid with the retaining lever.
- Close the front cover until it clicks. The machine will not start if the cover is open.

- Position a collection tray beneath the output chute.

3. Operation

- Turn on the main power. Press "Start".
- Place a strip of ingredient into the feed chute. Push fully with the pusher block.
- Use the automatic push mechanism: once the pusher reaches the end, it retracts automatically. Feed the next strip.
- Do not push against the blade with excessive force – let the machine do the work.
- If a jam occurs, immediately press "Stop", disconnect power, and manually clear the grid.

4. Post-operation

- Stop and unplug.
- Remove the grid using the provided extraction tool (never bare hands).
- Wash all parts.

3.4 Shredding Machine

1. Preparation

- Select the shredding drum (fine or coarse). Insert the drum into the housing.
- Cut cabbage or leafy vegetables into halves or quarters (remove core). For carrots, trim ends.

2. Assembly

- Secure the drum by turning the locking knob clockwise.
- Attach the hopper and chute cover.
- Place a large bin under the output.

3. Operation

- Start the machine. Feed ingredients through the top hopper. Use the tamper to push down firmly but gradually.
- For even shredding, alternate pieces of different sizes.
- Do not feed frozen or overly soft produce; it will clog the drum.
- After finishing a batch, let the machine run for 10 seconds to clear remaining shreds.

4. Post-operation

- Stop and unplug.
- Remove the drum. Clean with a brush under running water.
- Dry all parts before storage.

4. Cleaning & Daily Maintenance



Proper cleaning prevents cross-contamination and extends equipment life. Perform these steps after each use.

Daily cleaning (all models):

1. **Disconnect power** and unplug.
2. **Disassemble** all removable parts: blades, discs, grids, bowls, pushers, feed chutes.
3. **Pre-rinse** parts under warm water (max 40°C) to remove food debris.
4. **Wash** in a sink with mild detergent and a soft brush. Do not use abrasive pads that can scratch surfaces.
5. **Sanitize** with a food-grade sanitizer (e.g., chlorine solution 50–100 ppm) according to local health regulations.
6. **Rinse** thoroughly with clean water.

- 7. **Dry** completely with a clean cloth or air-dry on a rack.
- 8. **Wipe down the motor base** with a damp cloth. Do not let water enter the motor housing.
- 9. **Reassemble** only when fully dry.

Weekly maintenance:

- Inspect blades for nicks or dullness. Replace as needed (contact YuKoLi for genuine parts).
- Lubricate moving parts (e.g., pusher rails, locking levers) with food-grade mineral oil.
- Check all screws and fasteners; tighten if loose.
- Test the emergency stop button.

Monthly maintenance:

- Clean the motor ventilation grilles with a vacuum to prevent dust buildup.
- Have a qualified technician check the carbon brushes (for models with universal motors).
- Verify the power cord insulation integrity.

5. Troubleshooting Guide

Problem	Possible Cause	Solution
Machine will not start	Power disconnected, emergency stop pressed, or interlock engaged	Check power cord and plug. Release emergency stop (pull/turn). Ensure interlock is disengaged.
Motor runs but no cutting	Blade slipping or not installed correctly.	Stop machine, unplug, and reinstall the blade/disc until it clicks.
Uneven slices/dices	Dull blade or clogged grid.	Replace blade. Clean grid with a brush. Ensure ingredients are evenly distributed.
Excessive vibration	Machine not level, or blade unbalanced.	Place on level surface. Check if blade is bent or improperly seated.
Food jams in feed chute	Overloading or ingredient too large.	Press stop. Remove power. Manually clear chute. Cut ingredients into smaller pieces.
Strange noise	Foreign object (stone, bone) or loose part.	Stop immediately. Inspect blade chamber. Remove debris. Check for loose components.
Motor overheats and stops	Continuous use beyond duty cycle.	Let machine cool for 15 minutes. Reset thermal overload (press reset button).
Leak from bowl (food processor)	Bowl cracks or lid seal worn.	Replace bowl or seal. Ensure lid is tightened.

If the problem persists, contact YuKoLi service (see Section 7).

6. Technical Specifications Table

Model Type	Model # (example)	Power (W)	Voltage	Max Capacity (kg/h)	Blade Speed (RPM)	Weight (kg)	Dimensions (L×W×H)
Vegetable Cutter	VC-300	300	220–240V / 50–60Hz	150	1400	12	40×30×35
Food Processor	FP-500	500	220–240V / 50–60Hz	200	1800	15	45×35×38
Dicing Machine	DM-400	400	220–240V / 50–60Hz	200	1200	18	50×40×45
Shredding Machine	SM-350	350	220–240V / 50–60Hz	180	1600	14	42×32×40

Note: Actual models may vary. Refer to the rating plate on your machine. All units are suitable for commercial kitchens with a standard single-phase supply.

7. Warranty & Contact Information

Warranty terms:

YuKoLi machines are warranted against defects in materials and workmanship for **12 months** from the date of purchase (parts and labor). The warranty does not cover damage caused by improper use, unauthorized modifications, normal wear of blades, or failure to follow cleaning instructions.

- To claim warranty, contact your local dealer or YuKoLi directly with the purchase receipt and machine serial number.
- Consumable items (blades, discs, grids, pushers) are covered only for initial manufacturing defects, not for wear.

Service and support:

- **Address:** Foshan YuKoLi Technology Co., Ltd., No. 88 Industrial Avenue, Shunde District, Foshan City, Guangdong Province, China.
- **Phone:** +86-757-XXXX-XXXX
- **Email:** support@yukoli.com
- **Website:** www.yukoli.com

For replacement parts, please quote the part number from the exploded diagram included in the packaging.

This manual is subject to revision. Always refer to the latest version on the YuKoLi website.

© 2025 Foshan YuKoLi Technology Co., Ltd. All rights reserved.