



Equipment Maintenance & Preventive Care Guide

YuKoLi — All Equipment Series

YuKoLi — Foshan YuKoLi Technology Co., Ltd.

www.yukoli.com

Product Lines Covered:

- Stir-fry machines (ESL DLB series – electric & gas)
- Drum stir-fry machines (G-Series)
- Stirring/braising cookers (XC/QXC)
- Top-stir machines (TBS/TBQ)
- Deep fryers, noodle cookers, steamers, soup pots

Tone: Professional, clear, practical

1. Daily Inspection Checklist



Pre-Shift Inspection (Before First Use)

Perform a visual and functional check of every machine before the cooking shift begins. This ensures safe operation and reduces the risk of unexpected downtime.

For all YuKoLi equipment:

- **Power and gas supply:** Confirm that electrical cords are intact, plugs are clean and dry, and gas hoses are free from cracks, kinks, or leaks. For gas models, use a soap-and-water solution on all connections and watch for bubbles. If a leak is detected, shut off the gas supply immediately and call a qualified technician.
- **Control panel and displays:** Turn on the unit and verify that all indicator lights, digital displays, and control knobs respond correctly. Listen for abnormal sounds from the control board or relays.
- **Safety devices:** Check emergency stop buttons (if equipped), temperature limit switches, and gas shut-off valves. Ensure they are accessible and functional.
- **Cooking vessel and agitator:** Inspect the interior of pots, drums, or fryer baskets for any leftover food residue, foreign objects, or damage. For stirring machines, manually rotate the agitator (if possible) to confirm free movement.
- **Lubrication points:** On machines with moving parts (e.g., stir arms, drum rollers), verify that grease nipples are clean and that grease reservoirs are not empty. A quick visual check of oil levels in gearboxes is recommended (see weekly tasks for detailed lubrication).
- **Exterior and ventilation:** Ensure that air intake and exhaust grilles are not blocked by debris, grease buildup, or nearby equipment. Clear any obstructions.

Specific checks by equipment type:

- **Stir-fry machines (ESL DLB series):** For electric models, check that the heating element connections are tight and free of carbon deposits. For gas models, inspect burner ports for blockages and ensure the flame is blue and stable.
- **Drum stir-fry machines (G-Series):** Confirm that the drum rotation mechanism engages smoothly and that the drive belt or chain has proper tension (no sagging or fraying).
- **Stirring/braising cookers (XC/QXC):** Verify that the tilting mechanism (manual or electric) operates without hesitation and that locking pins are secure.
- **Top-stir machines (TBS/TBQ):** Check that the stir paddle height adjustment locks firmly and that the paddle does not scrape the vessel bottom when empty.
- **Deep fryers, noodle cookers, steamers, soup pots:** For fryers, confirm that the oil level is within the marked range and that the filtration system (if present) is clean. For steamers, check water supply and drain lines for leaks. For soup pots, ensure the drain valve closes tightly.

Post-Shift Inspection (After Last Use)

After the cooking shift and before cleaning, perform a quick evaluation to catch issues that may have developed during operation.

- **Temperature recovery:** Note any unusual slowness in reaching set temperature. This could indicate a failing heating element, thermostat, or gas valve.
- **Unexpected noises or vibrations:** Record any grinding, squealing, or excessive shaking. These often point to worn bearings, loose fasteners, or misaligned agitators.
- **Oil and water condition:** For fryers, examine the oil for excessive darkening, foaming, or off-odors. For steamers and soup pots, check for scale buildup or discoloration in the water.
- **Leaks:** Inspect under the unit and around all connections for drips of oil, water, or gas (use the soap test again if gas is suspected).
- **Control panel behavior:** Note any error codes, flickering displays, or unresponsive buttons. Record the information for the maintenance log.

Document all findings in a daily logbook. Flag any issue that might affect the next day's operation.

2. Daily Cleaning Procedures

Cleaning must be performed after each day's use. Use only non-abrasive cleaners and soft cloths or sponges. Never spray water directly onto electrical components, control panels, or gas valves. Allow all surfaces to cool to safe handling temperature before cleaning.

Stir-fry Machines (ESL DLB Series – Electric & Gas)

1. **Remove the cooking vessel:** If the pan or wok is detachable, lift it out and place it in the wash sink. For fixed vessels, use a plastic scraper to remove food debris.
2. **Clean the vessel interior:** Wash with warm water and a mild detergent. For stubborn carbonized residues, use a paste of baking soda and water. Rinse thoroughly and dry with a clean cloth.
3. **Wipe the heating surface:** For electric models, use a damp cloth to remove oil splatter from the heating plate. Do not use abrasive pads. For gas models, clean burner heads with a soft brush and ensure all ports are open.
4. **Clean the agitator arm:** If the machine has a stir arm, detach it (if possible) and wash separately. Wipe the shaft and mounting bracket.
5. **Exterior and control panel:** Wipe down the outer body, including the control panel, with a damp cloth and mild cleaner. Dry immediately.
6. **Gas models only:** Check the gas hose for any signs of grease buildup and wipe clean. Ensure the hose does not touch hot surfaces.

Drum Stir-fry Machines (G-Series)

1. **Empty the drum:** Scrape out all product. If the drum is tilted, use the tilting mechanism to facilitate emptying.
2. **Flush the drum:** Use a hose with warm water to rinse away loose particles. For sticky residues, fill the drum with warm water and a degreasing agent, then run the drum at low speed for 1–2 minutes. Drain and repeat.
3. **Clean the drum interior:** Use a long-handled soft brush to scrub the inner surface. Pay attention to weld seams and corners where food may accumulate.
4. **Wipe the exterior:** Clean the frame, motor housing, and control box with a damp cloth. Avoid getting water near the motor or gearbox.
5. **Lubricate after cleaning:** Apply a light food-grade silicone spray to the drum support rollers and any exposed chain (if applicable). This prevents rust and ensures smooth rotation.

Stirring/Braising Cookers (XC/QXC)

1. **Lower the agitator:** If the stir paddle can be raised, lower it to the vessel bottom for cleaning.
2. **Remove the paddle:** Detach the paddle (or paddles) according to the model instructions. Wash in the sink with hot, soapy water.
3. **Clean the vessel:** Use a plastic scraper to remove residue. For the tilting vessel, tilt it fully to drain. Wash with a soft sponge and rinse.
4. **Clean the paddle shaft and seal:** Wipe the shaft with a cloth and check the shaft seal for any food buildup. If the seal is damaged, note it for replacement.
5. **Exterior and base:** Wipe down the entire unit, including the tilting mechanism and any hydraulic lines. For electric tilting models, avoid water contact with the motor.

Top-stir Machines (TBS/TBQ)

1. **Raise the stir paddle:** Lift the paddle to its highest position.
2. **Remove the paddle:** Unlock and slide the paddle off the shaft. Wash separately.
3. **Clean the vessel:** Wash the pot or pan by hand or in a dishwasher if permitted. Rinse and dry.
4. **Wipe the support arm and column:** Clean the vertical column and the arm that holds the paddle. Pay special attention to the locking mechanism and height adjustment track.
5. **Inspect the paddle lock:** Ensure the locking pin or clamp is free of grease and moves smoothly.

Deep Fryers

1. **Turn off and cool:** Allow oil to cool to at least 100°F (38°C). Never attempt to clean a hot fryer.
2. **Drain and filter oil:** If the fryer has a built-in filtration system, follow the manufacturer's procedure. Otherwise, drain oil through a fine mesh strainer into a clean container. Discard oil if it is dark, rancid, or foamy.
3. **Clean the fryer tank:** Fill with hot water and a commercial fryer cleaner. Boil for 10 minutes, then scrub with a non-abrasive brush. Drain and rinse thoroughly with clean water. Dry completely.
4. **Clean the heating elements:** For electric fryers, wipe elements with a damp cloth after they have cooled. Do not immerse.
5. **Wipe the exterior:** Clean the outer body, control panel, and basket hangers. For gas fryers, clean the burner area with a brush.

Noodle Cookers

1. **Drain the water:** Open the drain valve and let all water empty. Remove the basket and any inserts.
2. **Clean the basket and inserts:** Wash in the sink with hot, soapy water. Rinse and dry.
3. **Clean the tank:** Use a non-abrasive cleaner to remove starch buildup. For stubborn scale, use a commercial descaling solution (follow product instructions). Rinse thoroughly.
4. **Wipe the exterior:** Clean the body and control panel. Ensure the drain valve is clean and closes tightly.

Steamers

1. **Turn off and cool:** Allow the steamer to cool completely. Drain any remaining water from the reservoir.
2. **Remove and clean trays:** Wash steam trays or baskets in the sink. Rinse and dry.
3. **Clean the interior:** Wipe the cooking chamber with a damp cloth. For steamers with a built-in water reservoir, use a descaling agent every few days depending on water hardness. Rinse well.
4. **Check and clean the drain:** Remove any debris from the drain opening. Run clean water through to flush.
5. **Wipe the exterior:** Clean the door gasket with a damp cloth to prevent sticking. Dry the gasket and door edges.

Soup Pots (Stationary or Tilting)

1. **Drain and scrape:** Open the drain valve and remove all product. Scrape the interior with a plastic scraper.
2. **Wash the interior:** Use hot water and a mild detergent. For large pots, use a long-handled brush. Rinse and dry.
3. **Clean the drain valve:** Disassemble the valve (if possible) and clean all parts. Reassemble and ensure it closes without leaks.
4. **Exterior and jacket:** Wipe the outer body. For steam-jacketed pots, check that the safety relief valve is clean and unobstructed.

3. Weekly Maintenance Tasks

Perform these tasks once per week, typically at the end of a heavy-use day or on a designated maintenance day.

Lubrication

- **All stirring and rotating equipment:** Apply food-grade grease to all grease fittings (zerk fittings) on agitator shafts, drum support rollers, and tilting mechanisms. Use a manual grease gun. Wipe away excess grease.
- **Chains and sprockets:** On drum stir-fry machines and any equipment with exposed drive chains, apply a food-grade chain lubricant. Do not over-lubricate; wipe off drips.
- **Gas valve stems:** For gas models, lightly lubricate the valve stems with a high-temperature food-grade grease to ensure smooth operation.

Electrical and Gas Checks

- **Inspect all electrical cords:** Look for cuts, fraying, or exposed wires. Replace any damaged cords immediately.
- **Tighten connections:** For electric models, check the terminal block connections inside the control panel (only if qualified). For gas models, tighten any loose gas fittings (use a wrench, but do not overtighten).
- **Check gas burners:** Remove burner caps and clean the burner ports with a wire brush. Ensure the flame pattern is even. Adjust the air shutter if necessary (refer to the specific model manual).

Mechanical Adjustments

- **Check belt and chain tension:** On drum stir-fry machines and top-stir models with belt drives, press down on the belt midway between pulleys. Deflection should be about 1/2 inch (12 mm). Adjust as needed. For chains, ensure the slack is no more than 1 inch (25 mm) at the midpoint.
- **Verify agitator alignment:** For stirring/braising cookers and top-stir machines, run the agitator empty and watch for wobble or scraping. If the paddle contacts the vessel wall, adjust the mounting height or alignment per the service manual.
- **Test safety interlocks:** For steamers and fryers with lid interlocks, confirm that the unit will not operate when the lid is open (if applicable). For tilting machines, verify that the tilt lock engages securely.

Cleaning of Hidden Areas

- **Behind and underneath equipment:** Move the unit (if possible) and sweep or mop the floor. Remove any grease or debris that has accumulated.
- **Ventilation hood filters:** If the equipment is under a hood, clean or replace the hood filters weekly to ensure proper airflow.
- **Control panel vents:** Use compressed air or a soft brush to remove dust from the vents of the control panel. This prevents overheating of electronics.

4. Monthly & Quarterly Preventive Care



Monthly Tasks

- **Deep clean of all equipment:** Perform a more thorough cleaning than the daily routine. For fryers, boil out with a fryer cleaner. For steamers, descale the reservoir. For all equipment, remove any stubborn carbon deposits using a plastic scraper.
- **Inspect seals and gaskets:** Check door gaskets on steamers, lid gaskets on soup pots, and shaft seals on stirring machines. Look for cracks, hardening, or leaks. Replace if worn.
- **Tighten all fasteners:** Use a torque wrench (if specified) or a hand tool to check bolts on mounting brackets, agitator arms, and tilting mechanisms. Loose fasteners can cause misalignment and excessive wear.
- **Test temperature calibration:** For all cooking equipment with thermostats, compare the displayed temperature to a calibrated probe thermometer. If the difference exceeds $\pm 5^{\circ}\text{F}$ (3°C), recalibrate according to the service manual.
- **Check gas pressure:** For gas models, use a manometer to measure the gas pressure at the burner manifold. Adjust the pressure regulator if needed to match the specification on the data plate.

Quarterly Tasks (Every 3 Months)

- **Replace air filters:** For equipment with forced-air cooling (e.g., some electric stir-fry machines), replace the air intake filters.
- **Inspect and clean heat exchangers:** For gas-fired equipment, remove the heat exchanger covers and clean the flue passages with a wire brush. Soot buildup reduces efficiency and can cause unsafe carbon monoxide levels.
- **Check electrical components:** Use a multimeter to test the continuity of heating elements, contactors, and relays. Replace any components that show signs of corrosion or pitting.
- **Lubricate gearboxes:** For equipment with gearboxes (e.g., drum stir-fry machines), check the oil level and top off with the recommended oil. If the oil appears milky or contains metal particles, change it.
- **Inspect hydraulic systems:** For tilting cookers with hydraulic lifts, check hydraulic fluid level and inspect hoses for leaks. Replace any cracked or swollen hoses.

- **Verify safety relief valves:** For steam-jacketed pots and steamers, manually operate the safety relief valve to ensure it opens and closes freely. Do this when the equipment is cold.

5. Annual Servicing Schedule

Once per year, schedule a comprehensive service by a YuKoLi authorized technician or a qualified commercial kitchen equipment technician. The annual service includes tasks that require specialized tools or expertise.

Annual Service Tasks

- **Complete disassembly and cleaning:** The technician will disassemble major components (agitator shafts, burner assemblies, heating elements) for thorough cleaning and inspection.
- **Replace all seals and gaskets:** This includes door gaskets, shaft seals, drain valve seals, and any O-rings. Rubber and silicone parts harden over time and lose their sealing ability.
- **Replace wear items:** Belts, chains, sprockets, and bearings should be replaced annually, even if they appear functional. This prevents unexpected failures during peak usage.
- **Calibrate all controls:** Thermostats, pressure switches, and timers will be recalibrated to factory specifications.
- **Inspect gas train components:** For gas models, the technician will check the gas valve, regulator, and safety shut-off valve for proper operation and replace any worn parts.
- **Test electrical safety:** Grounding continuity, insulation resistance, and leakage current will be measured to ensure compliance with electrical safety standards.
- **Update software/firmware:** For models with digital controls, the technician will check for and install any available firmware updates.
- **Lubricate all moving parts:** All bearings, bushings, and slides will be greased with the correct food-grade lubricants.
- **Perform a final operational test:** The technician will run each machine through its full range of functions and verify that all parameters are within specification.

Record the date of annual service and any replacement parts used in the equipment’s maintenance log.

6. Spare Parts Replacement Guide

Keep a stock of commonly replaced parts to minimize downtime. The following table lists recommended spare parts and their typical replacement intervals.

Part	Equipment Applicability	Replacement Interval	Notes
Heating elements	Electric stir-fry machines, electric fryers	1–2 years	Replace when temperature recovery slows or element fails.
Burner nozzles/orifices	Gas stir-fry machines, gas fryers	2–3 years	Clogging or uneven flame indicates need for replacement.
Thermostats/sensors	All equipment with temperature control	1–2 years	Replace when calibration drifts beyond ±5°F.
Control boards	All electronic models	As needed	Keep one spare board per model in stock.
Agitator paddles	Stirring/braising cookers, top-stir machines	2–3 years	Replace when bent, worn, or showing cracks.
Drive belts	Drum stir-fry machines, some top-stir models	1 year	Check tension monthly; replace if frayed or stretched.
Chains	Drum stir-fry machines	1–2 years	Replace when slack exceeds 1 inch or links are stiff.
Bearings	All rotating shafts, drum support rollers	1–2 years	Replace if noisy or rough-turning.
Shaft seals	Stirring/braising cookers, top-stir machines	1 year	Leaks around the shaft indicate seal failure.
Gas hoses	All gas models	2 years	Replace earlier if cracks, brittleness, or leaks appear.
Door gaskets	Steamers, soup pots, fryers with lids	1–2 years	Replace when gasket no longer seals tightly.
Drain valves	Soup pots, noodle cookers, steamers	2–3 years	Replace if leaking or difficult to close.
Fryer baskets	Deep fryers	2–3 years	Replace when wires break or basket deforms.
Filtration pump (fryers)	Deep fryers with filtration	2–3 years	Replace if pump is noisy or does not prime.
Ignition electrodes	Gas models with electronic ignition	1–2 years	Clean quarterly; replace if spark is weak.

Ordering parts: Use only genuine YuKoLi replacement parts to ensure proper fit, safety, and warranty compliance. Contact your local YuKoLi distributor with the model number and serial number of your equipment.

7. Signs of Wear & When to Call Service

Even with diligent maintenance, some problems require professional attention. Recognize these warning signs and call a qualified service technician promptly.

Immediate Action Required (Shut Down Equipment)

- **Gas smell:** If you detect the odor of natural gas or propane, shut off the gas supply at the main valve immediately. Do not operate any electrical switches. Evacuate the area and call the gas company and a technician.
- **Electrical burning smell:** Turn off the unit at the circuit breaker. Do not use the equipment until a technician inspects it.
- **Visible sparks or arcing:** Shut off power immediately. This indicates a serious electrical fault.
- **Flame roll-out (gas burners):** If flames extend outside the burner chamber, shut off the gas and call a technician. This is a sign of blocked flues or improper gas pressure.

Signs That Require Service Within 24 Hours

- **Oil or water leaks:** A steady leak can cause slip hazards and damage flooring. For steam-jacketed pots, a leak in the jacket can lead to pressure loss.
- **Abnormal noise:** Grinding, screeching, or thumping from motors, agitators, or pumps indicates worn bearings, misaligned parts, or foreign objects.
- **Inconsistent temperature:** If the equipment repeatedly fails to reach set temperature or overshoots, the thermostat or heating element may be failing.

- **Error codes on display:** Refer to the user manual for error code meanings. Some codes indicate sensor failures or communication errors.
- **Agitator not moving:** If the stir paddle or drum does not rotate when activated, check for a tripped breaker, broken belt, or seized motor. If the motor hums but does not move, the capacitor or motor may be faulty.
- **Slow drainage:** For steamers, noodle cookers, and soup pots, slow drainage often points to a blocked drain line or a faulty drain valve.

Signs That Indicate Preventive Maintenance Is Overdue

- **Excessive grease or oil buildup on exterior:** This suggests that daily cleaning is insufficient or that the unit is leaking.
- **Rust or corrosion:** Rust on metal surfaces, especially near electrical connections or gas fittings, weakens the structure and creates safety hazards.
- **Pitted or burned electrical contacts:** If you see blackened or pitted contacts in relays or contactors during inspection, they need replacement.
- **Hardened or cracked gaskets:** Gaskets that have lost flexibility will not seal properly, leading to heat loss, steam leaks, or oil leaks.
- **Frequent tripping of circuit breakers:** This indicates an electrical fault (shorted element, failing motor) that requires professional diagnosis.

How to Call for Service

1. **Identify the equipment:** Note the model number and serial number (usually on a data plate on the back or side of the unit).
2. **Describe the problem:** Be specific. For example, "The drum stir-fry machine makes a grinding noise when rotating, and the drum speed seems slower than usual."
3. **Provide error codes:** If the display shows an error code, write it down.
4. **Tell the technician what has been done:** Mention any recent maintenance, cleaning, or repairs you have performed.
5. **Contact information:** Have your YuKoLi distributor's service department number ready. If under warranty, have the purchase date and invoice available.

Do not attempt to repair gas or electrical components yourself unless you are a certified technician. Improper repairs can void the warranty and create serious safety risks.

This guide is a general reference for YuKoLi commercial kitchen equipment. Always refer to the specific user manual provided with each machine for model-specific instructions, torque values, and lubricant specifications. For questions or service requests, contact your authorized YuKoLi dealer.

YuKoLi – Quality You Can Cook With