



Commercial Cooking Equipment

Operation Manual

YuKoLi — Foshan YuKoLi Technology Co., Ltd.

www.yukoli.com

1. Introduction & Equipment Overview

This manual covers the operation, cleaning, and basic troubleshooting of YuKoLi's most common commercial cooking equipment. Read all safety instructions before use. Keep this manual accessible to all operators.

Product categories covered:

Category	Models	Key Features
Intelligent Stir-Fry Machines	ESL (DLB series)	Touchscreen, voice menu, auto seasoning, 800 recipes
Drum/Tumbling Stir-Fry Machines	G-Series (G26–G80)	Rotary drum, electric/gas, tabletop or floor
Stirring & Braising Cookers	XC / QXC series	Planetary stirring, 80–120 L, voice menu, auto-dispensing
Top-Stir Fry Machines	TBS / TBQ / TQBQ series	Planetary stirring, non-stick flat pan, countertop
Deep Fryers	4 models	Electric/gas, temperature control, basket lifts
Noodle Cookers	6 models	Multiple compartments, rapid boil, auto fill
Steamers & Steam Cabinets	2 models	Pressureless steam, timer, auto water feed
Soup Pots & Pressure Cookers	4 models	Direct/steam heating, lid lock, pressure release

2. Safety Instructions



General Warnings

- Only trained personnel may operate this equipment.
- Do not modify electrical or gas connections. Use only original parts.
- Keep the unit at least 30 cm (12 in) from combustible materials.
- Never operate with damaged cords, gas hoses, or control panels.
- Turn off and unplug/disconnect gas supply before cleaning or servicing.
- Use personal protective equipment (heat-resistant gloves, apron) when handling hot surfaces, oil, or steam.
- Keep children and untrained persons away from the equipment.

Hot Surfaces & Liquids

- Exterior surfaces become hot during operation. Mark the unit with a warning sign if needed.
- Hot oil (deep fryers), boiling water (noodle cookers), and steam (steamers) can cause severe burns.
- Allow equipment to cool fully before cleaning.

Gas Models (if applicable)

- Ensure adequate ventilation. Install a gas shutoff valve nearby.
- Check gas connections for leaks annually (soap-and-water test).
- If you smell gas: shut off gas supply, extinguish all flames, ventilate area, and call service.

Electric Models

- Connect only to a grounded outlet with proper voltage and amperage (see specification plate).
- Do not spray water on electrical components during cleaning.

Emergency Stop

- Every unit has an emergency stop button (red) on the control panel. Press to immediately cut power or gas supply. Reset only after identifying and resolving the cause.

3. Operation Instructions by Category

3.1 Stir-Fry Machines (Intelligent, Drum, Braising, Top-Stir)

These machines include touchscreen controls, voice menu, and automatic seasoning dispensing. Operation is similar across series.

Before First Use

1. Remove all packaging and shipping locks.
2. Clean the cooking surface and all removable parts with warm soapy water.
3. Season the cooking surface (for non-stick pans) by rubbing a thin layer of cooking oil and heating to 150°C for 10 minutes. Wipe off excess.
4. For gas models: open gas valve and check for leaks with soapy water.

Standard Operating Steps

1. **Power on:** Plug in (electric) or open gas valve (gas). Press the main power button.
 2. **Select recipe** (Intelligent models only):
 - Touch the recipe icon on the screen.
 - Browse by category or use voice menu (say “beef stir-fry”).
 - Confirm – the machine will set time, temperature, and auto-dispensing sequence.
 3. **Manual operation** (all models):
 - Set temperature using knob or touch slider (80–280°C).
 - Set cooking time (up to 99 minutes, or continuous).
 - For drum models: adjust rotation speed (5–20 RPM).
 4. **Load ingredients:**
 - Add oil first (auto-dispenser will inject if programmed).
 - Add solid ingredients. Use the stirrer/tumbling action – do not overload beyond 80% of drum capacity.
 5. **Start cooking:** Press **Start** button.
 - The machine will stir continuously (drum rotates, planetary arm moves).
 - Intelligent models announce when to add seasoning or liquid.
 6. **End of cycle:**
 - Machine beeps and stops heating. The stirrer continues for 30 seconds to prevent sticking.
 - For drum models: open the lid/door and tip the drum using the handle or motorised tilt.
 - For top-stir: use the release lever to tip the pan.
 7. **Idle/Standby:** Press **Stop** – if no further use within 5 minutes, unit enters standby. Press **Power Off** to shut down completely.
- Voice Menu (Intelligent models)**
- To activate: say “Hey YuKoLi” (or push the microphone button).
 - Examples: “Set temperature 200,” “Add oil 50 ml,” “Start.”
 - Unit responds verbally. Adjust volume in settings.

3.2 Deep Fryers

Models: 4 variants – single/double basket, electric/gas, with or without filter.

Preparation

- Fill tank with cooking oil to the MAX line (use high smoke point oil, e.g., canola).
- For gas models: open gas valve. For electric: plug into dedicated outlet.

Operation

1. **Power on:** Press main switch.
2. **Set temperature** (adjustable 120–190°C). Use digital display or knob.
3. **Preheat:** Wait until the temperature indicator shows ready (usually 10–15 minutes).
4. **Load basket:** Fill basket with food – do not exceed 1.5 kg for single basket.
5. **Fry:** Lower basket slowly into oil. Set timer (0–30 minutes).
6. **Drain:** Lift basket and hang on support hook to drain excess oil.
7. **Shutdown:** Turn off power/gas. Allow oil to cool completely before filtering or draining.

Filter System (if equipped)

- After every use (or daily for heavy use), open drain valve and let oil flow through filter paper into clean container. Replace filter paper.

3.3 Noodle Cookers

Models: 6 models – 2 to 6 compartments, gas or electric, with auto water fill.

Setup

- Connect to water supply (3/4" hose, shutoff valve recommended).
- For gas models: ensure gas type matches burner orifice kit.

Operation

1. **Fill tanks:** Turn on water supply – auto fill stops at preset level.
2. **Heat:**
 - Electric: press power, set temperature to 100°C (boil).
 - Gas: turn gas knob to HIGH (ignition spark fires automatically – if not, light pilot manually with long lighter).
3. **Boil:** Wait for vigorous boil (approximately 8–12 minutes).
4. **Cook noodles:**
 - Place noodles in basket, lower into boiling water.
 - Stir gently. Cook time varies (typically 1–5 minutes).
 - Lift basket, shake to drain.

5. **Shutdown:** Turn all knobs to OFF. Close gas valve (gas) or unplug (electric).

6. **Drain water:** Open drain valve when tank is cool (< 60°C). Rinse tank.

Tip: Keep water level above MIN line to prevent burner damage. For electric models, never operate with empty tank.

3.4 Steamers & Steam Cabinets

Models: 2 models – countertop steamer (1–3 pans) and large steam cabinet (6–12 pans). Both pressureless.

Startup

1. Open water supply valve.
2. (Countertop) Fill reservoir to marked level – use filtered water to reduce scale.
3. (Cabinet) Auto fill – ensure drain line is open.
4. **Power on:** Press power button. Set timer (0–99 minutes) or continuous.
5. Wait for steam (3–6 minutes). Temperature stays at ~100°C.

Loading Food

- Use standard GN pans (20–40 mm deep). Do not exceed max pan depth (cabinet: 150 mm).
- Leave 5 cm gap between pans for steam circulation.

Operation

- Place pans on shelves. Close door securely – latch handle.
- Press **Start** – steam generator activates. Timer counts down.
- When timer ends, unit beeps. Open door carefully – hot steam escapes.
- Remove pans with heat-resistant gloves.

Shutdown

- Turn power off. Close water supply. For countertop units, drain reservoir after cooling.

3.5 Soup Pots & Pressure Cookers

Models: 4 models – direct heat (electric/gas) and steam-jacketed (30–150 L). Pressure cookers have lockable lid.

Before Cooking

- Check lid seal (pressure models) – must be clean and free of cuts.
- For steam-jacketed: ensure jacket is filled with coolant (antifreeze) – see specification plate.
- Fill pot to no more than 80% capacity (pressure models: 60% for foaming foods).

Operation (non-pressure)

1. Set temperature (50–200°C). For gas, adjust flame.
2. Stir occasionally using the planetary stirrer (if equipped) or manually.
3. When done, turn off heat. Serve or transfer to holding pot.

Operation (pressure models)

1. Close lid, rotate to lock, engage safety pin.
2. Set temperature to high. Wait for steam to escape from vent (5–10 seconds), then close vent valve.
3. Pressure rises (max 1.2 bar). Adjust heat to maintain steady pressure.
4. Cooking time starts from when pressure is reached.
5. After timer:
 - **Natural release:** Turn off heat, let pressure drop (10–30 minutes).
 - **Quick release:** Pull the vent handle carefully – stand back from steam.
6. Only open lid after pressure gauge reads 0 bar and safety pin drops.

Shutdown - Turn off power/gas. Clean pot and lid seal after each use.

4. Cleaning & Maintenance



Daily Cleaning (all equipment)

Surface	Method
Stainless steel exterior	Wipe with damp cloth and mild detergent. Rinse. Dry.
Cooking surfaces (non-stick, drum, braising pan)	While warm (but not hot), scrub with soft brush and water. For stuck food, use a plastic scraper.
Touchscreen	Wipe with dry microfiber cloth. Do not spray liquid directly.
Oil filters (fryer)	Remove, rinse with hot water. Replace filter paper.
Steam generators	Flush with vinegar solution (1:1 water/vinegar) weekly to descale.
Gas burners	Brush debris from burner ports.

Weekly Maintenance

- Check all gaskets and seals for wear (steamer, pressure cooker).
- Lubricate hinges and door latches with food-grade grease.
- Inspect electrical cords for fraying.

- For gas models: clean pilot assembly and check flame colour (blue = good, yellow = adjust air shutter).

Monthly

- Deep clean steam generator by disassembling and removing scale deposits.
- Test safety devices (pressure relief valve, overtemperature cutoff).
- Calibrate temperature sensors (contact technician).

Descaling (steamers and noodle cookers)

- Fill tank/compartments with descaling solution (follow manufacturer’s concentration).
- Heat to 80°C, hold for 20 minutes, drain.
- Rinse twice with fresh water.

5. Troubleshooting Table

Problem	Possible Cause	Solution
Unit does not power on	No power / circuit breaker tripped / gas valve closed	Check outlet/breaker; reset. Open gas valve.
Touchscreen unresponsive	Screen protector or moisture	Clean screen; reboot (press and hold power 10 s).
No heat / low heat	Thermostat failure / gas supply issue / burner clogged	Check set temperature. For gas, check supply and bleed air. Clean burner.
Food sticking to pan	Pan not seasoned / temperature too high / insufficient oil	Re-season pan; reduce heat; add oil first.
Excessive smoke (fryer)	Oil too hot / old oil	Lower temperature; replace oil.
Steamer not steaming	No water / scale in generator / steam valve closed	Fill water; descale; open valve.
Pressure cooker won't lock	Lid seal misaligned / debris	Clean seal; re-seat lid.
Oil auto-dispenser not working	Clogged nozzle / empty container	Clean nozzle with pin; refill seasoning container.
Error code “E01” or “E02” (intelligent models)	Sensor fault / overtemperature	Turn off. Wait 10 min. Restart. If persists, call service.
Gas burner flame yellow	Air shutter closed	Adjust air shutter (open slightly).

If the problem persists or involves electrical/gas components not listed, contact YuKoLi service at [\[service@yukoli.com\]](mailto:service@yukoli.com) or +86-757-xxxx-xxxx. Do not attempt internal repairs.

6. Specifications Summary

Equipment Type	Typical Power (Electric)	Gas Rating	Net Weight	Dimensions (W×D×H mm)	Key Notes
Intelligent Stir-Fry (DLB3005)	5 kW / 230V 1ph	–	45 kg	600×700×800	Tabletop, 300 mm drum
Intelligent Stir-Fry (DLB9004)	40 kW / 380V 3ph	30 kW	180 kg	1200×1300×1500	Floor, 900 mm drum
Drum G-Series (G40)	15 kW / 380V 3ph	12 kW	120 kg	900×1000×1200	40-inch drum, electric/gas
Stirring Braising (XC100)	12 kW / 380V 3ph	15 kW	200 kg	1100×1200×1400	100 L, planetary stirring
Top-Stir (TBS30)	5 kW / 230V 1ph	–	35 kg	500×600×350	Countertop, non-stick
Deep Fryer (DF2)	9 kW / 380V 3ph	8 kW	30 kg	800×700×900	Double basket, 25 L oil
Noodle Cooker (NC4)	12 kW / 380V 3ph	15 kW	60 kg	900×800×850	4 compartments, auto fill
Steamer Cabinet (SC12)	18 kW / 380V 3ph	–	150 kg	900×800×1800	12×GN1/1 pans, pressureless
Soup Pot (SP80)	12 kW / 380V 3ph	15 kW	100 kg	800×800×900	80 L, steam-jacketed
Pressure Cooker (PC50)	9 kW / 380V 3ph	12 kW	80 kg	700×700×900	50 L, 1.2 bar max

For exact specifications of your specific model, refer to the rating label on the unit. Electrical connection must comply with local codes.

End of Manual

© 2025 YuKoLi Technology Co., Ltd. All rights reserved. Reproduction without permission is prohibited.

For service, spare parts, or training, contact your local distributor or YuKoLi directly.