

Instructions Before Use


- 1) Bus Servo Control.exe is PC software of Bus servo controller.



- 2) Bus Servo Terminal is the parameter setting software of LX-224HV servo.



- 3) Before using the servo controller, please set the parameters and ID of the servo with the servo debug board (BusLinker). In general, you only need to set the ID.



- 4) The servo controller can be used to control the servos after the servo ID number being set.