

Scanner Floor Guide

The self-serve guide to every station on the
Legend of Toys production-floor scanner.

OPERATOR SUPERVISOR

Version	Updated	Application
1.0.0	2026-05-29	scanner.legendoftoys.com

Contents

GETTING STARTED

How the Scanner Works	5
Signing In	7
Device Setup	8

PRODUCTION

Assembly (INW)	10
QC Pass	11
QC Fail	12
Workshop	13
Packaging (PKG)	14

DISPATCH

PKG Out	16
Dispatch In	17
Allocate	18
Pack	19
Dispatch Out	20
Restock	21

STORE & RETURNS

Store Issue	23
Returns Intake	24
Repack (Channel Swap)	25

REPAIR, OUTSOURCED & UTILITIES

Repair	27
Outsourced Inward	28
Legacy Registration	29

Lookup 30

Attendance 31

PART 1

Getting Started

What the scanner is, how scans give feedback, signing in, and setting a device up for the shift.

How the Scanner Works

OPERATOR

SUPERVISOR

The Scanner is the handheld app that records the physical work on the production floor. At every station, an operator scans a barcode and the system updates instantly: a unit is inwarded, passed, packed, dispatched. This guide walks through every station. This first chapter covers the things that are true everywhere, so learn it once and the rest is easy.

WHAT IT'S FOR	RUNS ON	ONE DEVICE	WHERE
Recording floor work, scan by scan.	An Android device at each station.	One station, one line, per shift.	scanner.legendoftoys.com

Starting the camera

The camera does **not** start on its own. Every time the scan screen opens you will see a **Tap to start camera** button: tap it, then hold the barcode in the middle of the yellow frame. Holding the same code twice within two seconds does nothing (the scanner ignores rapid duplicates).

What a scan tells you

Every station gives the same three signals, so you always know what happened without reading the screen closely:

RESULT	WHAT YOU SEE AND HEAR
Success	Green flash, a rising triple beep, a short buzz, and a green tick line in the log. The scan worked.
Reject	Red flash, a falling buzz, and a full-screen red REJECT panel with the reason and "RESCAN THE CODE". It clears itself after a moment.
Pending / warning	Orange flash and an orange message: the scan was counted but something needs your attention (for example an over-pick, or a scan queued while offline).

▲ WORKING OFFLINE

If the device loses connection you will see an orange **OFFLINE** bar and a **queued** count. Many scans (Assembly, QC Fail, Outsourced Inward, Restock) are saved and sync automatically when the connection returns. But the stations that need live data: **QC Pass, Packaging, Pack, Store Issue, Repack, Workshop and the dispatch stations**, will reject with "OFFLINE" until you are back online.

The barcodes you will scan

CODE	LOOKS LIKE	USED AT
Unit (car) UPC	LOT-XXXXXXX	Assembly, QC, repair, restock.
Batch / dispatch label	LOT-XXXXXXX-E	Packing onwards (the -E is Ecom, -R Retail).
Box label	BOX-XXXXX	Dispatch Out, Repack In.
Bag QR	BAG-...	Store Issue picking.
Employee card	LOT-FACT-XXXX	Attendance, dispatch sign-in.

① EACH STATION EXPECTS ITS OWN CODE

A station only accepts the barcode it is meant for. Scanning a box label at a unit station (or the wrong-format code anywhere) gives a **WRONG BARCODE** reject. If you keep getting rejected, check you are at the right station for the label in your hand.

Signing In

OPERATOR

SUPERVISOR

When a device wakes for a shift it asks who is using it. Which sign-in you see depends on whether a supervisor has already set the device up for today.

WHAT IT'S FOR	WHO	RESETS	PIN
Identifying who is on the device.	OPERATOR SUPERVISOR	Setup expires at 1 AM each day.	Held by supervisors.

Operator Sign In

If the device is already set up for the shift, you see **Operator Sign In**. Tap **Select name manually**, enter the supervisor PIN when prompted, then tap your name from the list. You will see "Welcome, [your name]" and the device moves on to the station setup screen.

Supervisor Sign In

If the device is not set up, the setup has expired, or it could not reach the server, it shows **Supervisor Sign In** with a red banner explaining why (for example "Shift setup expired"). A supervisor enters the **Supervisor PIN**, taps **Confirm PIN**, then picks their name. This leads into Device Setup.

① WHY THE PIN MATTERS

The supervisor PIN protects who can set a device up and who can pick a name. A locked device at the start of a shift is normal and safe: it just means a supervisor needs to sign in and set the station before operators can scan.

Device Setup

SUPERVISOR **OPERATOR**

Device Setup binds one physical device to one station and one line for the shift. A supervisor normally does this after signing in with the PIN. Setup lasts until 1 AM, when the device locks and needs setting up again for the next shift.

WHAT IT'S FOR	WHO	EXPIRES	CHANGE LATER
Pointing a device at a station + line.	SUPERVISOR (+ OPERATOR for dispatch sign-in)	1 AM each day.	The ⚙ button returns here.

Setting up a device

- 1 Pick the station.** Tap one station (tap again to deselect). Stations are grouped: Production, Dispatch, Store, External Runs, Legacy and Utilities.
- 2 Pick the line.** Production stations ask for a line (L1 to L5); dispatch stations ask for D1 or D2; shared stations (Lookup, Attendance, PKG Out, Returns Intake) need no line.
- 3 Set the options.** Choose the camera (back or front), whether the torch comes on while scanning, and the beep volume.
- 4 Launch Scanner.** The device finds its station record and opens the scan screen.

Dispatch stations: operators sign in too

The four dispatch stations (Pack, Dispatch In, Allocate, Dispatch Out) add one step: after the supervisor sets the device up, **each operator scans their own QR ID card** at the start of their shift before they can scan units (or types their ID with "Type ID instead"). The **Change Op** button in the top bar hands the device to the next person without redoing the whole setup.

⚠ "NO ACTIVE DEVICE FOUND"

If setup says no active device exists for that station and line, that station/line has no registered device: pick the correct line, or ask an admin to register the device. Both the supervisor setup and the dispatch operator sign-in expire at 1 AM, so the first task each morning is to set the device up again.

PART 2

Production

The assembly-line stations: inward, quality check, workshop and packing.

Assembly (INW)

OPERATOR

Assembly (INW) is where a freshly built unit is brought into the system for the first time. It is the simplest station: one scan per unit.

STATION INW · lines L1 to L5.	YOU SCAN The unit's LOT UPC.	WHO OPERATOR	OFFLINE Queues and syncs later.
----------------------------------	---------------------------------	-----------------	------------------------------------

The flow

- 1 Read the hint. The camera shows "Scan LOT UPC".
- 2 Scan the unit's UPC (the LOT-XXXXXXX code). A green flash and tick confirm it is inwards.
- 3 Move to the next unit. The log shows your recent scans.

① TWO REJECTS YOU MIGHT SEE

WRONG BARCODE means the code was not a LOT-XXXXXXX UPC (you may have scanned a label or remote). **DUPLICATE** means the unit was already inwards. Both are harmless: rescan the right code or move on.

QC Pass

OPERATOR

QC Pass marks a unit as having passed quality control. For products that ship with a remote, it also verifies that the car and its remote are a genuine pair before letting them through.

STATION	YOU SCAN	WHO	OFFLINE
QC_PASS · lines L1 to L5.	Car first, then remote.	OPERATOR	Needs a live connection.

The flow

- 1 Scan the car’s LOT UPC first. The hint says “Scan LOT UPC (car first)”.
- 2 If the product has a remote, a green band appears: “Now scan remote control”. Scan the remote to confirm the pair. A single-piece product passes straight away.
- 3 See “Paired” and the green tick. The unit is QC-passed.

△ ALWAYS CAR FIRST, AND WATCH FOR PAIRING FAILED

Scan the car before the remote. If you scan a remote that does not belong to that car you get **PAIRING FAILED**: find the correct remote and scan again, or tap **Cancel** to abandon a half-finished pair and start over. This station needs a live connection, so it rejects with “OFFLINE” if the device is offline.

QC Fail

OPERATOR

QC Fail records a unit that did not pass, along with exactly which defects were found. The unit then goes to the workshop for repair.

STATION	YOU SCAN	WHO	OFFLINE
QC_FAIL · lines L1 to L5.	The unit's LOT UPC.	OPERATOR	Queues and syncs later.

The flow

- 1 Scan the unit's LOT UPC. An orange flash fires and the **Select Defects** list slides up.
- 2 Tap every defect that applies. Defects are grouped and tagged by severity (Critical, Major, Minor, Cosmetic), and the list only shows defects valid for that part (car or remote).
- 3 Tap Log Defects. The button stays disabled until at least one defect is ticked. A red flash and buzz confirm the fail was logged (failing is meant to feel like a negative signal).

ⓘ AT LEAST ONE DEFECT IS REQUIRED

You cannot log a fail with no defect selected. Recording the real defects is what feeds the quality reports and the workshop's repair list, so pick all that apply rather than the first one you see.

Workshop

OPERATOR

Workshop is where failed units are received for repair and later sent back out. You do not pick “in” or “out”: the scanner works out which one this is from the unit’s history.

STATION	YOU SCAN	WHO	IN OR OUT
WKS · lines L1 to L5.	The unit’s LOT UPC.	OPERATOR	Decided automatically.

Receiving a unit (first scan)

The first scan of a unit shows the **Workshop In** overlay with the product, its loop number, and the list of defects logged at QC. Tap **Unit Received**, **Scan Next** to take it in.

Sending a unit out (next scan)

Scanning the same unit again shows **Workshop Out** with the defects that were meant to be repaired, and asks for the outcome:

- **Repaired, send to QC** (green): the unit goes back for another quality check.
- **Cannot fix, scrap** (red): the unit is written off.

① THE TWO SCANS ARE THE TWO STEPS

There is no mode to set: the first scan takes a unit in, the next scan of that same unit sends it out. The overlay tells you which step you are on, so just follow the on-screen buttons.

Packaging (PKG)

OPERATOR

Packaging (PKG) is the final assembly-line step: confirm the car and remote are a pair, choose the sales channel, and print the dispatch label that the unit carries from here on.

STATION PKG · lines L1 to L5.	YOU SCAN Car first, then remote.	WHO OPERATOR	OFFLINE Needs a live connection.
----------------------------------	-------------------------------------	-----------------	-------------------------------------

The flow

- 1 Choose the channel first. Tap **Ecom** or **Retail** at the top. Your choice sticks until you change it, and it decides which label prints.
- 2 Scan the car UPC. For a unit with a remote, a purple band asks you to scan the remote next.
- 3 See “Pair Verified, Label Ready”. The overlay shows the batch label (LOT-XXXXXXX-E or -R), the channel, and that the print job is queued.
- 4 Tap **Next Unit** to continue (or **Reprint Label** if needed).

 SET THE CHANNEL BEFORE YOU SCAN

The channel toggle decides whether an Ecom or Retail label prints, so check it is right *before* scanning. While the “Label Ready” overlay is up, further scans are ignored: tap **Next Unit** to move on. As at QC Pass, scan the car before the remote, and use **Cancel** to abandon a half-finished pair.

PART 3

Dispatch

The dispatch-floor stations that move finished units out the door.

PKG Out

OPERATOR

PKG Out is the handover point as a packed unit leaves the line for dispatch. It tallies each unit by channel so you can see the session count building.

STATION	YOU SCAN	WHO	SHOWS
PKG_OUT · shared.	The batch label.	OPERATOR	The session tally.

The flow

Scan the batch label (LOT-XXXXXXX-E or -R). A large channel badge flashes **Ecom** or **Retail**, and the **Session Tally** at the top counts up by Ecom, Retail and Returns. Undamaged returns coming back through show as "Return" and count separately.

① SCAN THE RIGHT LABEL

PKG Out expects a batch label with its channel suffix. A unit UPC or any other code gives "WRONG BARCODE, expected LOT-XXXXXXX-E or -R". This is a dispatch-floor station, so the operator signs in with their QR card at the start of the shift.

Dispatch In

OPERATOR

Dispatch In (DTK) records units being handed over into the dispatch area, ready to be allocated and packed.

STATION DTK · lines D1 / D2.	YOU SCAN The batch label.	WHO OPERATOR	SIGN IN Scan your QR card per shift.
---------------------------------	------------------------------	-----------------	---

The flow

Scan a batch label (LOT-XXXXXXX-E or -R). A green **Handed Over** tick confirms the unit is now in dispatch. That is the whole station: one scan per unit.

① IF IT REJECTS

“Invalid label, scan a PKG batch label” means the code was not a batch label (you may have a plain unit UPC or a box label). As a dispatch station it needs a live connection and your shift QR sign-in.

Allocate

OPERATOR

Allocate (ALLOC) commits units to a specific sales channel (a particular Amazon, Flipkart, retail partner and so on) before they are packed into a shipment.

STATION ALLOC · lines D1 / D2.	YOU SCAN Batch labels (after picking a channel).	WHO OPERATOR	SIGN IN Scan your QR card per shift.
-----------------------------------	---	-----------------	---

The flow

- 1 **Select the channel first.** Choose the channel from the dropdown at the top.
- 2 **Scan each batch label.** A green tick confirms “Allocated to [channel]” (or “Re-allocated” if it was on another channel).

△ **PICK THE CHANNEL BEFORE SCANNING**

If you scan before choosing a channel you get **NO CHANNEL**, **select a channel above before scanning**. Set it once and it stays selected for every unit you allocate to that channel; change it when you switch channels.

Pack

OPERATOR

Pack puts allocated units into shipment boxes. It works two ways: packing into a named shipment, or packing direct to a channel.

STATION	YOU SCAN	WHO	OFFLINE
PACK · lines D1 / D2.	Batch labels into a box.	OPERATOR	Needs a live connection.

Shipment mode

- 1 **Select the shipment** from the dropdown (it shows the channel and how full it is).
- 2 **Open or pick a box.** For bulk channels, pick an open box (or the box bar warns “No open boxes”, in which case boxes are added from the dashboard). For per-unit channels, each scan auto-creates and closes a box.
- 3 **Scan batch labels** to add units to the open box; **Close** the box when full to print its label.

Direct mode

Pick a channel, then each scanned batch label auto-creates a box, packs it, closes it and prints, all in one go. Use this when you are not packing into a pre-built shipment.

① WHAT THE REJECTS MEAN

“No shipment” or “No channel” means you have not made the selection at the top yet; “No open box” means you need to open or add a box first. As a dispatch station it needs a live connection and your shift QR sign-in.

Dispatch Out

OPERATOR

Dispatch Out (DOUT) is the final exit scan as goods leave the building. It accepts a whole box or a single unit.

STATION DOUT · lines D1 / D2.	YOU SCAN A box label or a batch label.	WHO OPERATOR	SIGN IN Scan your QR card per shift.
----------------------------------	---	-----------------	---

The flow

Scan a **box label** (BOX-XXXXX) to send the whole box out ("Box out, N units"), or a **batch label** (LOT-XXXXXXXX-E/R) to dispatch a single unit ("Dispatched Out"). The channel is shown on success.

① ONE STATION, TWO LABEL TYPES

Dispatch Out is the only station that takes both a box label and a unit label, so you can ship a packed box in one scan or send out a loose unit. Anything else gives "Invalid label".

Restock

OPERATOR

Restock returns **unused** units to stock: orders that were cancelled, unsold inventory, sample returns. It is not for units that went out with a courier and came back; those go through Returns Intake.

STATION	YOU SCAN	WHO	OFFLINE
RESTOCK · lines D1 / D2.	The unit's LOT UPC.	OPERATOR	Queues and syncs later.

The flow

- 1 **Pick the reason** (Order Cancelled, Unsold Inventory, Sample Return, or Other). The reason sticks across scans.
- 2 **If you pick Other**, type the required reason note.
- 3 **Scan the unit's LOT UPC**. The unit goes back into stock.

 **COURIER-TOUCHED RETURNS DO NOT BELONG HERE**

The panel reminds you: a unit that physically shipped and came back must go through **Returns Intake (RTO In)**, not Restock. Restock is only for units that never left in a customer order. If you pick "Other" you must enter a note, or the scan is rejected.

PART 4

Store & Returns

Picking parts for the store, receiving returns, and channel-swap repacks.

Store Issue

OPERATOR

Store Issue is where the store picks component bags against a production run before issuing it. You select the run, then scan the bag QRs as you pick them, and a progress bar tracks how much of the run is done.

STATION	YOU SCAN	WHO	OFFLINE
STORE_ISSUE · shared.	Bag QRs (BAG-...).	OPERATOR	Needs a live connection.

The flow

- 1 Select the run** from the dropdown (runs already being picked show “Picking”). A progress bar appears: “X/Y parts picked”.
- 2 Scan each bag QR** as you pick it. A green tick logs the part and updates the progress.
- 3 Finish.** When every part is done you see “All parts picked, [run] ready to issue”.

⚠ OVER-PICKING IS ALLOWED BUT FLAGGED

If you scan more of a part than the run needs, it is still counted (so nothing is lost), but you get an orange **OVER PICK** warning so a supervisor can check it. You must select a run before scanning (else “No run selected”), and only bag QRs are accepted (else “Scan a bag QR”).

Returns Intake

OPERATOR

Returns Intake (RET_IN) receives units coming back from customers and couriers. It is a two-step scan: first the shipping label to identify the channel, then each returned unit, with a disposition that says what happens to it next.

STATION RET_IN · shared.	YOU SCAN AWB first, then unit labels.	WHO OPERATOR	MODES Shipment or Individual.
--	---	------------------------------------	---

The flow

- 1 Scan the AWB / shipping label.** This resolves the sales channel. If it cannot match one, a red picker asks you to choose the channel by hand.
- 2 Set the disposition** for the unit you are about to scan: **UDR** (good, restockable), **Repair**, or **Loss**. For Repair and Loss you also pick the box condition; for Loss you must type a note (for example "empty box").
- 3 Scan each unit's batch label.** It is logged with its disposition. In Shipment mode the AWB stays set for many units; in Individual mode it clears after each.
- 4 Close the shipment** with "Done, close shipment" when finished.

① THIS IS THE COURIER-RETURN PATH

Any unit that physically shipped and came back belongs here, not at Restock. A returned label has its -E / -R handled automatically. A "Loss" disposition always needs a note, and the unit's disposition here is what routes it to the UDR pool, the repair pool, or a loss write-off in Garage.

Repack (Channel Swap)

OPERATOR

Repack moves units from one sales channel to another (for example Retail to Ecom). Two stations work as a pair: **Repack In** frees the units from their old box, and **Repack Out** re-packs them to the new channel with a fresh label. Both pick a repack run first.

STATIONS	YOU SCAN	WHO	OFFLINE
REPACK_IN / REPACK_OUT · L1 to L5.	Old box in; car (+remote) out.	OPERATOR	Needs a live connection.

Repack In

Select the repack run, then scan the **old box label** (a BOX-XXXXX, or the unit’s existing batch label). The system frees every in-scope unit in that box and tells you how many: “N units freed, now scan at Repack Out”.

Repack Out

This works exactly like Packaging: pick the destination channel (Ecom or Retail), scan the car (then the remote if prompted), and a new label prints. Progress shows “repacked / target”, and “[run] complete” when the run is done. From here the unit re-enters the normal dispatch flow.

① RUN FIRST, THEN SCAN

Both stations need a repack run selected before scanning (else “No run selected”). Repack In takes the old box label; Repack Out takes the car UPC and behaves just like PKG, so the same “car first, channel set before scanning” rules apply.

PART 5

Repair, Outsourced & Utilities

Repair runs, inwardsing outsourced units, registering legacy units, lookup and attendance.

Repair

OPERATOR

The Repair station tracks units through a structured repair run: starting a repair, then passing or scrapping the unit. You set the mode, pick the run, and scan.

STATION	YOU SCAN	WHO	MODES
REPAIR · lines L1 to L5.	The unit's LOT UPC.	OPERATOR	Start / Pass / Scrap.

The flow

- 1 Pick a mode: Start** (begin repairing), **Pass** (repaired), or **Scrap** (cannot fix). Start also needs a repair run chosen from the dropdown.
- 2 Scan the unit's LOT UPC.** The hint changes with the mode ("Scan unit to start repair", "Scan repaired unit", "Scan unit to scrap").
- 3 See the confirmation:** "In Repair", "Repaired", or "Scrapped".

① **MODE FIRST, RUN FOR START**

If you scan without choosing a mode you get "Select mode"; if you choose Start without a run you get "Select run". The repair runs themselves are created by the team in Garage; this station just records each unit's progress through one.

Outsourced Inward

OPERATOR

Outsourced Inward (EXT_INW) brings in units that were built by an outside vendor rather than on the line. It works just like Assembly, but routes the units to their outsourced run.

STATION	YOU SCAN	WHO	OFFLINE
EXT_INW · lines L1 to L5.	The unit's LOT UPC.	OPERATOR	Queues and syncs later.

The flow

Scan each vendor unit's LOT UPC (the hint reads "Scan LOT UPC, outsourced vendor unit"). A green tick confirms it is inwarded against the outsourced run. From there the unit flows through QC and packing like any other.

① USE THIS ONLY FOR OUTSOURCED RUNS

This is the receiving point for vendor-made units, kept separate from the line's own Assembly station so outsourced production is tracked on its own run. A non-LOT code gives "WRONG BARCODE".

Legacy Registration

OPERATOR SUPERVISOR

Legacy Registration brings older, pre-system units into the system so they can be dispatched or stored. It has two modes depending on what you are doing with the unit.

STATION	YOU SCAN	WHO	MODES
LEGACY_REG · shared.	Box EAN, or the car's legacy QR.	OPERATOR SUPERVISOR	Dispatch / Store.

The two modes

- **Dispatch:** also pick the channel (Ecom / Retail) and which printer (D1 / D2). Scan the **EAN on the box exterior**; a fresh batch label is minted and printed. Stick it on the box.
- **Store:** scan the **legacy QR on the car base**; the unit is registered into stock.

① PICK THE MODE FIRST

Scanning before choosing Dispatch or Store gives "Select mode first". If a unit is already in the system you will see "Already registered" with its status, which is just information, not an error.

Lookup

OPERATOR

Lookup is a read-only tool: scan any code to see what it is, its status and history, without changing anything. It is the safe station for “what is this unit?” and for reprinting a lost label.

STATION LOOKUP · utility, no line.	YOU SCAN Any UPC, box or remote.	WHO OPERATOR	CHANGES DATA? No, read-only.
---------------------------------------	-------------------------------------	-----------------	---------------------------------

The flow

Scan any unit UPC, box label or remote. A result card shows the current status, the product, whether it is a car or remote, its paired partner, and the last several scans (with who, which line and when). You can also **reprint** the package or box label: pick a printer (L1 to L3 or D1 / D2) and tap Reprint. **Scan Again** clears it for the next lookup.

① NOTHING HERE CHANGES A UNIT

Lookup never writes a scan, so it is safe to use any time to check a unit or trace a problem. It is a deviceless utility, so it does not need station/line setup.

Attendance

OPERATOR

Attendance is a standalone clock-in / clock-out terminal. Staff scan their ID card and the system records the time, working out automatically whether they are clocking in or out.

STATION ATTENDANCE · utility, no line.	YOU SCAN Your employee QR card.	WHO OPERATOR	IN OR OUT Decided automatically.
--	---------------------------------------	-----------------	-------------------------------------

The flow

- 1 Scan your QR ID card (or tap “Type ID instead” and enter your employee number).
- 2 Confirm. Your name and the action appear; tap Confirm (it cancels itself after a few seconds if you walk away).
- 3 See the result: a green “Clocked In” or “Clocked Out” with your name and the time.

① ONE CARD, BOTH DIRECTIONS

You do not choose in or out: the system clocks you in if you are not already in, and out if you are. Attendance is a deviceless utility, so it needs no station or line setup. It is the attendance card (the LOT-FACT-XXXX employee card) that is used here, which is separate from any station login.