

Depot Operations

Dispatch back-office: outbound, returns, floor and stock audit



Version	Updated	Application
1.5.0	2026-08-25	depot.legendoftoys.com

Contents

GETTING STARTED

Welcome to Depot	5
Signing In and Navigation	8
Roles and What You Can See	10

OVERVIEW

Overview Dashboard /dashboard	13
-------------------------------	----

REPORTS

Reports /reports	17
------------------	----

OUTBOUND

Fulfilment Requests /fulfilment-requests	21
Pipeline /dispatch-pipeline	23
Shipments /dispatch-shipments	26
Challans /dispatch-challans	28
Dispatch Counts /dispatch-counts	30

RETURNS

Unit Restock /restock	33
Repack /repack-runs	35
Repack Reports /repack-runs/reports	37

FLOOR

Live Floor /dispatch	40
Lines /dispatch/lines	42
Scan Feed /scans	43
Stock Audit /dispatch-audits	45
Dispatch Roster /dispatch-roster	48

Manpower /manpower 49

SETUP

Channels /dispatch-channels 52

SCANNER

The Floor Scanner 54

Dispatch Scan Stations 56

PART 1

Getting Started

What Depot is and how to move around it

Welcome to Depot



Depot is the dispatch back-office for Legend of Toys: the home for everything that happens to a finished unit after the production line is done with it. It is where you watch finished goods land, allocate them to a sales channel, build shipments, handle returns, and keep the dispatch floor honest with stock audits. This manual is your self-serve guide to every screen in it.

APP	WHO IT'S FOR	WHAT IT DOES	SIGN-IN
Depot, at <code>depot.legendoftoys.com</code>	The dispatch team: operators, supervisors and managers.	Allocate, ship, restock and audit finished goods.	Google, company account only.

What Depot is (and isn't)

Depot is dispatch, and only dispatch. It was carved out of Redline so the dispatch team gets its own clean home, its own menu and its own dashboard, while Redline stays focused on the production floor. The two apps share one database, so an action in either one shows up instantly in the other.

Production (Redline + the line)	Where a car or remote is assembled, quality-checked and packed. When a unit is finished and packed, production hands it over to dispatch. That is where Depot picks up the story.
Depot	This app. The dispatch back-office. It tracks finished goods waiting to go out, allocates them to a sales channel, builds and ships boxes, handles returns and repacks, and audits what is physically on the dispatch floor against what the system thinks is there.
Scanner	The handheld app on the floor. The physical work is recorded there: an operator scans a unit when it is allocated, packed, dispatched, returned or counted in an audit. Most Depot screens <i>reflect</i> those scans rather than replace them.

What you can do here

The day-to-day jobs Depot is built for:

- **Watch the floor.** A live cockpit shows how many units are in the dispatch area, how many operators are clocked in, and what each line (D1 and D2) is doing right now.

- **Move goods out.** See finished goods on hand, allocate them to a channel, build shipments and delivery challans, and dispatch them.
- **Handle returns.** Restock units that come back, and run channel-swap repacks.
- **Keep it honest.** Run a governed stock audit where the floor count is approved by a second person, then self-corrects the records.

The journey of a unit through Depot

Almost every screen tracks a finished unit moving along this path. Knowing it makes each screen easier to read:

- 1 **Handed over.** Production finishes a unit and passes it to dispatch. It now sits in the dispatch area, on hand and waiting.
- 2 **Allocated.** The unit is assigned to a sales channel (for example Retail or Ecom), reserving it for a destination.
- 3 **Packed and shipped.** Allocated units are packed into shipment boxes, listed on a challan, and dispatched out.
- 4 **Returns and repacks.** Units that come back are restocked, and channel-swap repacks move stock from one channel to another. These are detours off the main path, each in its own chapter.

① DEPOT RUNS ALONGSIDE REDLINE TODAY

For now, Depot and Redline's own dispatch screens are **both live**. Depot is the new, dedicated home for dispatch, but Redline still carries a copy of the dispatch screens during the changeover. They share the same data, so it does not matter which one a teammate happens to use; nothing is duplicated underneath. Over time, dispatch will be removed from Redline and Depot will be the only place for it.

How to use this manual

Each chapter covers one Depot screen and follows the same shape: **what it is for**, **when you'd open it**, **how to read every part of it**, and **what to do** with what you see. You do not need to read cover to cover; jump to the screen you are on using the Contents page or the bookmarks panel in your PDF reader.

Role tags

Every chapter is tagged with the people who typically use that screen. If you only do one job, you can skim past chapters that are not tagged for you.

DISPATCH OPERATOR

SUPERVISOR

ADMIN

The chapter **Roles & What You Can See** explains exactly what each tag means and which screens it unlocks.

Callout boxes

Coloured boxes flag things worth slowing down for:

✓ TIP

A faster or smarter way to do something.

* ON THE FLOOR

Practical guidance for using a screen live, on a floor monitor or a phone.

⚠ WATCH OUT

A common mistake or a number that is easy to misread.

🚫 IMPORTANT

Something that affects real stock, shipments or customers: get it right.

Signing In and Navigation



Getting into Depot takes one click with your work Google account. Once inside, everything is reachable from a slim sidebar grouped around the way dispatch actually works, a top bar that tells you how fresh the numbers are, and a search-anything command bar. This chapter shows you how to sign in and find any screen in seconds.

SIGN-IN Google, <code>@Legendoftoys.com</code> only.	MAIN MENU Sidebar, grouped by purpose.	FASTEST JUMP <code>⌘K</code> command palette.	UPDATES Live screens refresh on their own.
--	--	---	--

Signing in

Open `depot.legendoftoys.com` and choose **Sign in with Google**. Use your `@legendoftoys.com` account; only company accounts are allowed in, so a personal Gmail will be refused. It is the same sign-in as every other Legend of Toys app, so if you are already signed in elsewhere it will usually let you straight through.

▲ CAN'T GET IN?

If sign-in bounces you back to the login screen, you are almost certainly signed into a personal Google account in that browser. Sign out of Google entirely, or open Depot in a fresh browser profile, then sign in with your Legend of Toys account.

The layout

Sidebar (left)	Your main menu. Screens are gathered into groups that follow how dispatch works: Overview, Outbound, Returns, Floor and Setup, plus the System Manual. Click a group to expand its screens.
Top bar	Shows where you are, an "Updated h:mm" time so you know how fresh the numbers are, and a Live indicator. Many screens refresh themselves automatically.
Command bar / <code>⌘K</code>	Press <code>⌘K</code> (<code>Ctrl+K</code> on Windows) from anywhere to jump to any screen by typing its name. This is the fastest way to get around.

The sidebar groups

The sidebar is organised by what you are trying to do, not by how the system is built:

GROUP	WHAT LIVES HERE
Overview	The live dispatch cockpit: the home screen you land on.
Outbound	Everything that goes out: Pipeline, Shipments, Challans and Dispatch Counts.
Returns	Goods coming back: Unit Restock, Repack and Repack Reports.
Floor	The live floor: Live Floor, Lines, Scan Feed, Stock Audit, Dispatch Roster and Manpower.
Setup	Do-once configuration: Channels.

Finding a screen

Three ways, fastest first:

- **Command bar.** Press **⌘K** (or **Ctrl+K**), start typing a screen name ("Shipments", "Stock audit", "Restock"), use the up and down arrows to pick, and press **Enter**. **Esc** closes it. It lists every screen, including the two live floor views.
- **Sidebar.** Open the group you want and click the screen. Good when you are browsing rather than headed somewhere specific.
- **System Manual.** This guide, in-app and searchable, with a button to download the PDF.

Keeping numbers fresh

The live screens (the Overview cockpit, the floor views and the scan feed) update on their own every half a minute or so, so they stay current without anyone touching them. The heavier on-hand and pipeline reads load once and have a manual refresh; use it after you know something just changed on the floor.

✖ ON THE FLOOR

Depot is built to live on a dispatch-area monitor as well as a laptop. The screens worth leaving running there are the **Overview** cockpit and the **Live Floor** view; they auto-refresh, so they stay current on their own. On a phone, stick to the read-only screens; the action screens are easier on a larger display.

Roles and What You Can See



Depot shows each person the screens and buttons that match their job. Operators stay focused on the floor work, supervisors run the dispatch operation, and managers configure it. This chapter explains the three roles used throughout this manual and what each one can see and do.

ROLES	SET BY	BUTTONS	KEY IDEA
Three: Operator, Supervisor, Admin.	An admin, on your account.	Appear or hide based on your permissions.	Some actions need a second person to approve.

The three roles

	Works the floor. Packs and allocates units, dispatches boxes, restocks returns and scans during a stock audit. Mostly works from the scanner; in Depot, reads the live screens to see how the day is going.
	Floor manager. Everything an operator does, plus manages shipments, channels, the roster and manpower, runs dispatch counts, opens and submits stock audits, and approves the audits of others.
	Manager / Admin. Full access: everything above, plus all configuration.

HOW ACCESS ACTUALLY WORKS

Depot does not have its own separate permissions; it uses the same account roles as the other Legend of Toys apps. Your access is decided by the **role on your account**, set by an admin. The three tags in this manual are plain-language groupings of those roles; they describe *who a screen is for*, not a literal setting. Buttons and actions simply **appear or hide** based on what your account is allowed to do, so you will only see the controls that are yours to use. If you should be able to do something but the button is not there, your account role needs changing; ask an admin.

What each role can do

Most write actions (allocating, shipping, managing channels, running counts) need floor-management rights, which supervisors and admins have. A few specific actions are gated more tightly: packing and

boxing, restock, repacks, and recording or approving a stock count each need their own permission. Operators read the live screens and do their hands-on work mainly through the scanner.

SCREEN OR ACTION	OP	SUP	ADM
Overview, Live Floor, Lines, Scan Feed	•	•	•
Pipeline (on-hand finished goods)	•	•	•
Shipments, Challans		•	•
Dispatch Counts		•	•
Unit Restock		•	•
Repack, Repack Reports		•	•
Stock Audit (open, scan, submit)		•	•
Stock Audit (approve)		•	•
Dispatch Roster, Manpower		•	•
Setup → Channels		•	•

✓ **TIP**

This table is a guide, not a rulebook; some people wear more than one hat and will have a role that combines access. The dots show the *primary* owner of each screen so you know who to ask about it.

Checks and balances

Some actions are deliberately split between two people so no single person can both make a change and bless it. The clearest example is the **stock audit**: the person who counts the floor cannot be the person who approves the result. One supervisor opens the audit and submits the count; a *different* supervisor reviews and approves it before the system corrects the records. This is built in, not just a convention.

🚫 **IMPORTANT**

An approved stock audit changes real records: missing units are written off and extra units are added back. Because of that, the approval must come from someone other than the counter. If you counted it, you will not be allowed to approve it; hand it to another supervisor. See the **Stock Audit** chapter for the full flow.

PART 2

Overview

The live warehouse cockpit

Overview Dashboard

/dashboard

OP

SUP

ADM

The Overview is Depot’s live warehouse cockpit: open it first thing and it tells you, at a glance, how much finished stock is sitting in the dispatch area, how many people are on the floor, where every unit is in the pipeline, what each line has done today, what is committed but not yet shipped, and what has gone out. It is a read-only monitor; you act on the screens it points you to.

WHAT IT’S FOR	READ OR ACT?	WHO	UPDATES
The dispatch day, top to bottom.	Read-only monitor.	OPERATOR SUPERVISOR ADMIN	Live counts every 30s; floor people every 60s.

The hero: two headline numbers

The top of the screen carries the two figures you most want to know the second you walk in:

Units in the dispatch area	Everything finished goods currently holds: stock still with production awaiting handover, stock with dispatch, and stock already allocated to a channel but not yet shipped. This is your “how full are we” number.
Operators on the floor	How many dispatch operators are clocked in right now. Shows a dash (—) if you do not have floor-viewing rights (see the note at the foot of this chapter).

The five pipeline cards

A unit moves left to right through these stages. The first three cards are a live snapshot of how much sits at each stage right now; the last two count today’s throughput.

CARD	TAG	WHAT IT COUNTS
With Production	now	Packed on the line, awaiting handover to dispatch.
With Dispatch	now	Handed over to dispatch, awaiting allocation to a channel.
Allocated	now	Committed to a channel, awaiting ship.
Dispatched	today	Units sent out today (the DOUT scan).

CARD	TAG	WHAT IT COUNTS
Shipments	today	How many shipment manifests have gone out today.

Today on the Floor

One card per dispatch line, **D1** and **D2**. Each card shows what that line has done today and who is on it:

Rostered • active	How many operators are rostered to the line today (from the Daily roster) and how many are actually scanning. If you lack floor rights the rostered figure is hidden and you just see the active count.
Packed / Allocated / Dispatched	The line's counts for the day at each of those three stages.
Active channels	The channels the line has touched today; "No channel yet" if it has not started.
last ...	The time of the line's most recent scan, so you can spot a line that has gone quiet.

✓ **ROSTERED COMES FROM THE DAILY ROSTER**

The rostered number is whoever you assigned to D1 and D2 in Manpower → Daily roster. If a line shows zero rostered but people are scanning on it, the roster has not been set for today.

Allocated: Awaiting Ship

One card per channel showing how many committed units are waiting to go out, biggest first. Sale channels are shown in full colour; non-sale channels are dimmed. The figure beside the heading is the total across all channels. This is the work still owed to customers.

On-Hand Finished Goods

A by-product table of stock physically in the dispatch area. For each product you see **PKG Out** (still with production), **With Dispatch**, **Allocated**, and an **On Hand** total. Sorted by the largest holding. This is the heavier read on the page, so it loads once when you open the screen rather than refreshing on a timer; reopen the screen to pull fresh figures.

Sent Out by Channel

What has actually shipped over a window you choose. Pick a preset (**10 Days, This Week, This Month**) or **Custom** for your own From and To dates. The summary line reads **sold** · **non-sale** · **total**; revenue channels are highlighted, cost and non-sale channels dimmed.

① FLOOR PEOPLE MAY SHOW A DASH

The two people figures (operators on the floor, and the rostered count on each line card) need floor-management rights. If you do not have them the rest of the cockpit still works in full, those two readings simply show a dash (—) rather than a number.



PART 3

Reports

Every dispatch report, any period, with CSV export

Reports

/reports

SUP

ADM

Reports is the dispatch team’s one place for every report, over any period you choose. It pulls together what the floor does — scans and activities, shipments, challans, fulfilment, returns, audits and counts — into on-screen tiles, charts and tables, each with its own **CSV** download. Pick a date range once at the top and everything below follows it.

WHAT IT’S FOR	READ OR ACT?	WHO	PERIOD
All dispatch reporting + CSV export.	Read-only, with CSV downloads.	SUPERVISOR ADMIN (needs the <i>reports</i> permission)	Any — presets or a custom range.

Picking a date range

Use the preset chips along the top: **Today**, **7 days**, **30 days**, **This month**, **This quarter**, **All time**, or **Custom**. Custom shows two date pickers (from and to). The current range is shown beside the **Refresh** button, and every tile, chart and table on the page reflects your choice. Dates are read in IST (the day a scan or shipment actually happened on the floor).

The sections

Activity – Scans & floor operations	Total dispatch scans, operators, lines and active days, with charts by activity, by line, by day and by hour of day. The By activity table has a Full scan log CSV button that exports every individual dispatch scan in the range (timestamp, activity, UPC, product, operator, line, station, batch label).
Operators – Dispatch output	Each operator with their total scans and a breakdown across the main activities (Pack, Dock, Allocate, Dispatch out, and so on) — the productivity report for the team.
Outbound	Units dispatched by channel, shipments (by status, channel and day) plus a full shipments table, delivery challans (with quantity and value) and fulfilment requests. Each table exports to CSV.

Outward – By channel & SKU	Everything that actually left, per sales channel and per SKU, over a range you set to the minute . This section has its own range controls, separate from the chips at the top of the page: quick buttons (Today, Yesterday, Last 7 days, Last 30 days, This month) or two date-and-time boxes. Three views — by channel, by SKU, or channel × SKU together — each with its own CSV.
Returns	Restocks broken down by reason and by channel, with a link across to the dedicated Repack Reports .
Audits & counts	Stock audit totals (present / missing / extra / corrected) and the audit register, plus the dispatch count sessions — each as a table you can export.

⚠ TWO OUTWARD NUMBERS, AND BOTH ARE CORRECT

Outward — By channel & SKU will not match **Units sent out by product** higher up the page, and neither is broken. The by-product figure counts units *physically scanned out* at the Dispatch Out station. The Outward section counts everything that *actually left the building* — which also includes bulk shipments closed with the **Mark shipped** button in Shipments, a normal way to ship that produces no scans at all.

Because of that, the scan-based figure runs at roughly **half** the true outward volume. **Use the Outward section for "how much went out"**, and the by-product figure when you specifically want scanning activity.

🕒 THE END TIME IS NOT COUNTED

The Outward range runs *up to* the end time, not including it. A unit sent out at exactly the end time falls into the next window — so if you run 08:00 to 20:00 and then 20:00 to 08:00, nothing is ever counted twice.

Downloading a report

Every table has a **CSV** button in its header that downloads exactly what is shown, named with the report and the date range. CSV files open in Excel or Google Sheets. The **Full scan log CSV** in the Activity section is the raw, scan-by-scan export — for very long ranges it caps at the most recent 30,000 scans, so narrow the dates if you need more history.

🕒 NUMBERS ARE SCOPED TO DISPATCH

Reports only counts dispatch activities (Ready to E-ship / Retail, Dock, Allocate, Pack, Dispatch out, RTO in, RTD return, Repack in/out) — production scans (assembly, QC, packaging) are not included here. An empty section just means there was no activity of that kind in the range you picked.

① CAN'T SEE REPORTS?

Reports needs the *reports* permission on your role. If the page shows "Access denied", ask an admin to enable it — it is on by default for supervisors and admins.



PART 4

Outbound

The ship-out flow

Fulfilment Requests

/fulfilment-requests SUP ADM

Fulfilment Requests is where sales orders come to Dispatch. When the sales team confirms an order in Snorkel (general trade, modern trade, or a quick-commerce platform), it lands here as a request waiting for you to act on. You decide whether to fulfil it, and how: as one shipment, or split across several. This is the front door for everything Dispatch ships against a sales order.

WHAT IT'S FOR	READ OR ACT?	WHO	LIFECYCLE
Accepting or rejecting sales-order fulfilment.	Action screen.	SUPERVISOR ADMIN	Pending → Accepted (Full or Split) or Rejected.

How an order reaches you

Sales raise and confirm the order in Snorkel. On confirm it becomes a **fulfilment request** here, with a status of **Pending**. You will see it two ways: a red **Fulfilment Requests** tile on the Overview dashboard showing how many are waiting (click it to come straight here), and the **Pending** tab on this screen. Nothing ships until you accept it.

Reading a request

The list shows each request's number, its sales order, the destination **warehouse** (for quick-commerce orders, the platform fulfilment centre the goods go to), the platform's PO reference, the total units requested, and its status. Click a row to open it: you see the requested items and quantities, and any shipments already created from it. Use the **Pending** and **All** tabs to switch between what needs action and the full history.

Accepting: Full or Split

An open, pending request gives you two ways to accept, plus reject.

- 1 Accept Full.** One click. Creates a single shipment for the whole requested quantity. Use this for the common case where the order goes out in one go. You can still send fewer units than asked when you actually pack and ship it (see the note below).
- 2 Accept Split.** Opens the split builder. Each shipment you add gets its own **dispatch date** and its own quantity per item. Start with the prefilled shipment, change its quantities, and use **+ Add shipment** for as many as you need. A running total per item shows green when it matches the request and red if you go over. Create them all at once.

3

Reject. Opens a reason box. Rejecting **cancels the sales order** in Snorkel, so the sales team has to raise a fresh one to try again. A reason is required.

What happens after you accept

Each shipment the request creates appears on the **Shipments** screen, where you work it exactly like any other: open boxes, pack, and mark it shipped. As shipments move, the result flows back to the Snorkel sales order automatically: the sales team sees whether it is **fully** or **partially fulfilled** (fully once the units shipped reach or beat what was requested), along with dispatch and delivery dates, and the collection clock starts on the channel's payment terms.

① FULL IS ONE-AND-DONE; SPLIT IS FOR MULTIPLE CONSIGNMENTS

A **Full** shipment can be shortened when you ship it (send fewer units), which closes the order as **partially fulfilled**. It is not topped up later. If you know up front you will send the order in more than one consignment, or on different dates, use **Split** instead.

△ SPLITS CAN BE CANCELLED INDIVIDUALLY

On a split request you can cancel any one shipment, selected ones, or all of them, on the Shipments screen. Cancelled shipments drop out of the fulfilment total, so the order settles as fully or partially fulfilled based on what actually shipped.

⊖ REJECT CANCELS THE ORDER

Rejecting a request is not a "send it back for changes" step: it **cancels the Snorkel sales order outright**. Only reject when the order genuinely should not be fulfilled. If the details just need fixing, ask sales to correct and re-confirm (which raises a new request).

Pipeline

/dispatch-pipeline

OP

SUP

ADM

The Dispatch Pipeline is your single answer to the question “what do we have ready to ship, and where is it committed?”. It’s one table showing every unit that is built but not yet shipped, broken down by product, by whether it’s still in production or finished, and by which sales channel it’s been allocated to. It’s the planning view dispatch uses to decide what to pack next.

WHAT IT’S FOR	READ OR ACT?	WHO	UPDATES
Seeing all open (un-shipped) inventory in one place.	Read-only: a planning view.	OPERATOR SUPERVISOR	On open, and on Refresh.

“OPEN INVENTORY” MEANS

Units that exist but have **not yet shipped**: anything between coming off the line and going out the door. Once a unit ships, it leaves this table. So a shrinking pipeline through the day is normal and healthy; a growing one means you’re building faster than you’re shipping.

Reading the columns

Every product is a row, and the columns split its open units into stages of readiness. Reading left to right walks a unit from “still being built” to “committed to a channel”:

Product / Variant	The product name. Click the row to expand it into its variants (model + colour). The little arrow (► / ▼) shows whether it’s open.
With Production	Units still in the production stage, built and inwarded but not yet finished and ready for dispatch . These are coming, but you can’t ship them yet.
Unalloc (R)	Unallocated, Retail . Finished, packed for the <i>Retail</i> format, but not yet committed to a specific dispatch channel. Shown in yellow: this is stock waiting for a decision.
Unalloc (E)	Unallocated, Ecom . The same, but packed for the <i>Ecom</i> format. Also yellow.
Unalloc (Total)	The two unallocated columns added together: all finished-but-uncommitted stock for the product, regardless of format.

Total Allocated	Units already committed to a channel and waiting to be packed into a shipment (green). The sum of all the channel columns to its right.
Channel columns	One column per active sales channel (Amazon, Flipkart, Cred, retail partners...), showing how many allocated units are committed to each. These are the live channels from the Channel Master.

✓ READING R VS E

"Retail" and "Ecom" here are the **packing format** a unit was finished in (the sticker it carries), not its final destination channel. A unit is first packed Retail or Ecom, then later *allocated* to a specific channel. That's why a unit moves from the yellow Unalloc columns into a green channel column as dispatch commits it.

The totals row

The bold row pinned at the top of the table sums every column across all products: your whole open pipeline at a glance, with a count of how many products it spans. Read it first to size up the day, then drill into individual products below.

Expanding a product

Click any product row to reveal its **variants**: each model and colour combination on its own indented line, with the same columns. This is how you answer questions like "we have 40 of this product unallocated, but is it the *red* one the channel wants, or the blue?". Click again to collapse.

Putting it to work

- 1 Start with the totals row.** How much is finished-but-unallocated (yellow) versus already committed (green)? A big yellow number is stock you could be allocating and shipping now.
- 2 Find products with high Unalloc.** These are your easiest wins: finished units only waiting to be pointed at a channel.
- 3 Check the channel columns against demand.** If a channel needs units and a product has them sitting unallocated in the matching format, that's the next thing to allocate and pack.
- 4 Use With Production to plan ahead.** A low ready figure but a high With Production figure means supply is on the way; don't over-promise from current stock.
- 5 Expand a product to confirm the variant** before committing; the right total of the wrong colour won't fill the order.

⚠ WATCH OUT

A dash (—) means zero: the column is empty for that product, not missing data. And remember this view is a *snapshot*: it reflects scans up to the moment you opened it or last hit Refresh. After a busy packing burst, refresh before you make a call.

① WHERE TO ACT

This screen tells you *what* to do but doesn't do it. Allocating units to a channel and packing them into boxes happens on the **Shipments** screen; the channel list itself is maintained in **Channel Master**. Both have their own chapters in this part.

Shipments

/dispatch-shipments

SUP

ADM

Shipments is the main dispatch workspace, where outbound orders are built and closed out. You create a shipment for a channel, set what it should contain (the manifest), open boxes and pack units into them, then mark it shipped. This is the one Dispatch screen where you do real work, not just watch.

WHAT IT'S FOR	READ OR ACT?	WHO	LIFECYCLE
Building & shipping outbound orders.	Full action screen.	SUPERVISOR ADMIN	Draft → Packing → Shipped.

Finding a shipment

Status tabs across the top (**All / Draft / Packing / Ready / Shipped / Cancelled**) narrow the list. Next to them is a **search box**: type a shipment number, a title, or a channel name to filter the list as you type. Press  to jump into it. Clear the box to see everything again.

The shipment lifecycle

STATUS	MEANING
Draft	Created, manifest being set. Can be edited or deleted.
Packing	Boxes open, units being packed. Can be edited or cancelled.
Ready	Fully packed against the manifest, not yet shipped (a green Ready badge).
Shipped	Sent out: all its units marked shipped.
Cancelled	Called off: its units return to the dispatch pool.

Building a shipment, step by step

- 1

+ New Shipment. Give it an optional title, pick a **channel** (required), set a scheduled date, and build the **manifest**: add each product and enter the quantity per model/colour variant. A live total shows at the bottom. Create it.
- 2

Open the shipment (click its row). A drawer slides in from the right with meta cards (Channel, Pool/Target, Packed, Scheduled), the manifest with progress bars, and the boxes list.

- 3 **+ Add Boxes.** Open one or more packing boxes. The number on the left is how many boxes to open; the **cap** field next to it is the optional max units per box (leave it blank for no limit). Units get scanned into boxes on the floor; each box shows its count (and the cap, as **N / cap**) and status. When a capped box fills up, the scanner blocks further units and moves the packer to the next box.
- 4 **Manage boxes as needed.** Expand a box to see its units; **Remove** a unit (it returns to the pool), **Reprint** a label, **Reopen** a packed box, or **Remove** an empty box.
- 5 **Shipped.** When everything's packed, mark the shipment shipped; this updates every unit in it to Shipped.

Reading the numbers

Pool / Target	Units allocated to this shipment so far versus the manifest goal (e.g. 8 / 20). This is allocation progress, not the same as packed.
Packed	Units actually packed into boxes: green when 100% of a manifest line is packed, yellow while in progress.
Box status	Open (amber) being packed; Packed / Closed (green) done.

① OFFLINE SALES ORDERS

A shipment created against an offline sales order carries an order tag and a **delivery date** field in its detail drawer. Set the date the goods reached the partner: Snorkel reads it to start the partner's payment-due clock (45 days from delivery, falling back to the dispatch date if you leave it blank). For ordinary channel shipments this field does not appear.

⚠ EDITING LIMITS

You can only edit a shipment while it's Draft or Packing, and you can't set a manifest line below what's already packed, nor remove a product that has packed units. Deleting is for drafts only.

🚚 SHIPPING IS THE COMMITMENT

Mark Shipped flips every unit in the shipment to Shipped; do it only when the consignment has genuinely left. Cancelling returns units to the dispatch pool (not lost), but "this cannot be undone", so cancel deliberately.

Challans

/dispatch-challans

SUP

ADM

Delivery Challans are the transport documents for outbound goods movements: GST-style goods-movement notes numbered `LOT-DC-YYYY-NNNN`. This screen is the register where you find, create, issue and print them.

WHAT IT'S FOR	READ OR ACT?	WHO	LIFECYCLE
Creating & managing delivery challans.	Action: create / issue / cancel / print.	SUPERVISOR ADMIN	Draft → Issued (or Cancelled).

The register

The list shows Challan No., Date, Dispatched To, Purpose, Qty, Total (₹), **EWB** and Status. Filter by status (with live counts), search by number or recipient, and set a from/to date range. Status badges: Draft (neutral), Issued (green), Cancelled (red). The EWB column reads `—` if no e-way bill is needed, a blue number when one is recorded, or an amber `Required` when needed but missing. Click any row to open that challan's detail page.

Creating a challan

- + New Challan.** This opens a fresh challan form. Set the date, purpose (Material transfer, Job work, Sample, Return for repair...) and GST rate.
- From & To.** Pick the dispatching company address (prefilled, editable) and enter the recipient's name, address and GSTIN.
- Goods supplied.** Add a line per item (search a product to auto-fill its description and HSN, or type freehand) with quantity, unit and rate. Amounts total automatically.
- Transport & e-way bill (optional).** Add mode, vehicle and transporter, and EWB number/date if you have one.
- Save as Draft or Issue Challan.** Saving as draft lets you review later; issuing locks it from edits. The number is assigned on save.

On a challan

From a challan's detail page you can **Print** it (an A4 document that opens and prints in a new tab), **Issue** a draft (locks it), or **Cancel** it with a reason.

① THE ₹50,000 E-WAY BILL LINE

When a challan's total reaches **₹50,000**, an amber banner reminds you an e-way bill is required (a quieter note appears from ₹40,000). The EWB is generated separately at the government portal; the banner is a reminder. You can still save and issue without entering one, but the register will keep flagging it **Required** until you do.

⚠ ISSUING LOCKS IT

Once issued, a challan can't be edited, only printed or cancelled. Get the details right while it's still a draft.

Dispatch Counts

/dispatch-counts

OP

SUP

ADM

Dispatch Counts is a quick scratchpad for re-checking a pile of finished, dispatch-ready units. You snapshot every unit currently in a chosen status, print a checklist, the counter marks each present or missing, and on completion the system auto-raises stock adjustments for any discrepancy. Use it when a count has strayed and you want to rebuild it fast.

WHAT IT'S FOR	READ OR ACT?	WHO	THEN
A quick scratchpad count of staged units.	Action.	OPERATOR SUPERVISOR ADMIN	Auto-creates adjustments.

① NOT THE SAME AS A STOCK AUDIT

For a governed, reviewed stock count that corrects the system of record, see the **Stock Audit** chapter. Dispatch Counts is a quick scratchpad: a fast random-scan of a pile to rebuild a strayed count, not a controlled audit.

Running a count

- 1

+ New Unit Count.

Pick the **scope status** (which units to verify: `handed_over`, `allocated`, `packed`, `rtd` or `pending_rtd`), name the area or zone and the counter, and create. Every matching unit is snapshotted into the count.
- 2

Print the sheet

and walk the staging area.
- 3

Mark each unit

present or missing; paste any UPCs found that were not on the sheet into the **Extra** box and click Add. Marks are staged as drafts, then saved with **Apply Marks**.
- 4

Complete

once nothing is pending. Missing and extra units automatically become stock adjustments, queued for L1 approval.

Reading the count

Once you open a count, the tiles across the top track it at a glance: **Expected** (how many were snapshotted), **Present**, **Missing**, **Extra** and **Pending** (not yet marked). The Complete button only appears once Pending reaches zero.

⚠ THERE IS NO LIST OF COUNTS

This screen does not show past counts. To reopen one, type its number (`UCN-NNN`) into the search box and press Enter, so note the number when you create a count. Completing a count auto-raises adjustments for missing and extra units; those still need approving and posting on Garage's Stock Adjustments screen.

① WHO CAN RECORD

Creating a count and applying marks needs the count-record permission; without it you can still open a count by number and view it, but the New, Apply Marks and Complete actions stay hidden.



PART 5

Returns

Reverse logistics

Unit Restock

/restock

OP

SUP

ADM

Unit Restock pulls units back out of the dispatch flow and into dispatch holding, so they can be allocated and sent again. When an order is cancelled, inventory comes back unsold, or a sample is returned, you paste the unit codes here and Depot returns each one to holding, ready to re-pack and re-send. It is the desk, paste-a-list version of the scanner's Restock / Remove station.

WHAT IT'S FOR	READ OR ACT?	WHO	TABS
Pulling units back into dispatch holding.	Action: returns units to dispatch.	OPERATOR SUPERVISOR ADMIN	Bulk Restock and Report.

Bulk Restock

- 1
- Pick a reason. Orders Cancelled, Unsold Inventory, Sample Return or Other. For **Other** a short note is required.
- 2
- Paste the unit codes. One per line, or comma or space separated. Duplicates are removed automatically. Up to 300 in one batch.
- 3
- Restock. Confirm the count. Each unit is returned to dispatch holding (ready to allocate and pack again) and any remote paired with a car comes back with it.
- 4
- Read the result. A table lists every code as **restocked** (with the status it came from, plus the paired remote if there was one) or **skipped** (with the reason).

Why a unit might be skipped

Unknown	The code isn't recognised, usually a typo. Check it and try again.
Already in dispatch / stock	The unit is already in holding or back in stock, so there is nothing to do.
In a box	The unit is packed into a box. Removing it has to reverse the box and shipment counts, so do it at the scanner Restock station, not from a pasted list.
Not in dispatch yet	The unit is still with production (not yet handed over to dispatch). It can't be restocked into dispatch holding.

Use the returns
or repair flow

The unit is in a state that restock won't touch (for example a return being inspected, or in repair). Handle it through Returns instead.

Report

The **Report** tab is a read-only history of every restock. Filter by reason and date range, search by unit code, and see totals broken down by reason and by sales channel. **CSV** exports whatever the current filter shows.

⚠ RESTOCK RETURNS THE UNIT TO DISPATCH HOLDING

Restocking takes a unit out of its channel allocation and back into dispatch holding, so it must be allocated and packed again before it goes out. This is the desk equivalent of the scanner's Restock / Remove station. Units already packed into a box are the one exception — remove those at the scanner, where the box and shipment counts can be reversed properly.

① RE-SELLABLE UNITS ONLY

Unit Restock is for units that are still good to sell: anything damaged, faulty or genuinely returned for inspection belongs in the Returns process, which decides whether each unit is re-dispatched, repaired or written off.

Repack

/repack-runs SUP ADM

Repack Runs track “channel swaps”: when already-packed units need re-doing for a different sales channel (say retail to ecom). A run sets a target number of units to repack; operators then physically scan boxes at the Repack In and Repack Out stations, and progress accrues against the run. This screen opens, tracks and closes those runs; the actual repacking happens on the scanner.

WHAT IT'S FOR	READ OR ACT?	WHO	REPACKING
Tracking channel-swap repacks.	Create, complete or cancel runs.	OPERATOR SUPERVISOR ADMIN	Done at the scanner stations.

How a channel swap works

A repack run is a counter for how many boxes the floor plans to redo. The physical work happens on the scanner, on a production line:

- 1 Scan the old box at Repack In.** Every unit in that box rolls back to QC Pass and everything downstream is wiped, ready to re-box for the new channel.
- 2 Re-pair at Repack Out.** The operator re-confirms the car and remote pair, picks the new channel (ecom or retail), and a fresh sticker prints.
- 3 The unit rejoins dispatch.** From there it flows through the normal pipeline (PKG Out, allocate, pack, dispatch) unchanged.

Starting a run

New Run opens a short form: a **target quantity** (how many units the floor will repack, required) and optional **notes** (for example “Flare retail to ecom”, useful for daily ops visibility). Creating the run gives it a run number and opens its detail page.

Tracking it from the list

The list shows each run’s progress (`repacked / target` with a bar and percentage) and its status: **Open**, **In Progress**, **Completed**, or **Cancelled**. Filter chips along the top narrow the list by status, each with a live count. Click any row to open its detail page.

The detail page

A run's detail page tracks the run as it fills up: the progress against target, each unit as it is scanned in and re-packed out, and the run's timestamps. **Complete** closes the run; **Cancel** stops it. Units already repacked stay repacked either way.

Reports

From the runs list, **Reports** opens the channel-swap analytics view: totals, breakdowns by direction, product, line, operator and time, with CSV export. See the Repack Reports chapter for the full breakdown.

① REPACK MAY MOVE BACK TO REDLINE LATER

Repack is really a production activity (the units are physically re-boxed on a production line); dispatch only hands the units over. It lives in Depot for now, but it may move back to Redline in a later phase. The way you open, track and close runs would stay the same.

Repack Reports

/repack-runs/reports SUP ADM

Repack Reports is the read-only analytics view for channel swaps. It counts only **completed** swaps in the chosen date range and breaks them down by direction, product, line, operator and time, so you can see how much repack work was done and where it went.

WHAT IT'S FOR	READ OR ACT?	WHO	COUNTS
Channel-swap analytics.	Read-only, with CSV export.	OPERATOR SUPERVISOR ADMIN	Completed swaps only.

Picking a date range

Use the preset chips: **7 days**, **30 days**, **This month**, **All time**, or **Custom**. Custom shows two date pickers (from and to). Everything below the range follows your choice. **Runs** takes you back to the repack runs list.

The summary cards

Swaps	Total completed channel swaps in the range.
Products	How many distinct products were swapped.
Lines	How many production lines did repack work.
Operators	How many people did the repacking.

The charts

Four bar charts break the swaps down: **by direction** (retail to ecom, ecom to retail), **by product**, **by line**, and **by hour of day** (IST). They are a quick read of where the volume sits.

The tables

Three tables give the detail, each with its own **CSV** export of exactly what is shown:

TABLE	WHAT IT LISTS
By product / colour	Each product, model and colour with its swap count.
By operator	Each operator with how many swaps they did.
By day	Swaps per day (IST) across the range.

① **COMPLETED SWAPS ONLY**

Open and in-progress runs do not show here. A unit counts once it has been re-packed out for its new channel, so an empty report just means nothing has finished in the chosen range yet.

PART 6

Floor

Live floor views, the scan feed, stock audit, roster and manpower

Live Floor

/dispatch

OP

SUP

ADM

Live Floor is the dispatch pipeline in detail: how many units sit at each stage right now, what is committed to each channel awaiting dispatch, what has gone out recently, and a lookup for any individual unit. The status cards and channel figures refresh every 30 seconds.

WHAT IT'S FOR The live dispatch pipeline, unit by unit.	READ OR ACT? Read-only.	WHO OPERATOR SUPERVISOR ADMIN	UPDATES Every 30s (the Units table loads on demand).
---	---	--	--

Live Dispatch Status

Four cards trace the pipeline a unit moves through:

CARD	MEANING
PKG Out	Packed on the line, awaiting handover to dispatch.
With Dispatch	Handed over, to be allocated to a channel (turns yellow when above zero).
Allocated	Committed to a channel, awaiting ship (turns blue when above zero).
Shipped	Total shipped.

By channel

Allocated: Awaiting Dispatch shows how many committed units wait per channel. **Sent Out by Channel** shows shipped units over a window you choose (10 Days, This Week, This Month or Custom), with a **sold** · **non-sale** · **total** summary; revenue channels are highlighted in green, cost and non-sale channels dimmed.

Units lookup

The **Units** table lists individual units (Batch Label, Product, Line, Channel, Shipment, Packed date and Status), filterable by status, channel and date range. Status badges read PKG Out (neutral), With Dispatch, Allocated (blue) and Shipped (green, with a tick).

⚠ THE UNITS TABLE IS CAPPED

It shows up to **200 rows** and does not auto-refresh; use the filters and the  Refresh button. On a heavy day, narrow by status or channel to find what you need.

Lines

/dispatch/lines

OP

SUP

ADM

Lines is today’s dispatch productivity board: how many scans happened at each stage per line, which channels each line is working, and who is doing the work. It covers today only and refreshes every 30 seconds.

WHAT IT’S FOR Live line & operator output.	READ OR ACT? Read-only.	WHO OPERATOR SUPERVISOR ADMIN	COVERS Today only, refreshed every 30s.
---	----------------------------	---	--

The four dispatch stages

Every figure on this board breaks down into the four dispatch-floor scan stages. Knowing them makes the numbers readable:

STAGE	MEANING
Alloc	Unit allocated (committed) to a sales channel.
DTK	Dispatch take: pulled to be boxed.
Pack	Packed into a shipment box.
Dout	Dispatched out: shipped.

Reading it

Dispatch Line Performance gives one card per line (D1 and D2): its active channels, a big total-scans number, the four-stage grid, the operator count, and the day’s first-to-last scan time. **Operator Output** is a table of each operator’s Alloc, DTK, Pack, Dout and total, sorted by who has done the most.

① “TEST OPERATOR” IS HIDDEN

A non-production “Test Operator” account is deliberately left out of the operator table so it does not skew the rankings.

Scan Feed

/scans

OP

SUP

ADM

The Scan Feed is the live stream of every dispatch scan as it happens on the floor. Open it when you want to see what just moved, confirm a unit was scanned at the right step, or trace one box by its UPC. It is read-only; nothing here changes a record.

WHAT IT'S FOR	READ OR ACT?	WHO	SCOPE
Watching the dispatch scan stream live.	Read-only.	OPERATOR SUPERVISOR ADMIN	Dispatch scan activities only.

What it shows

This is the dispatch slice of the wider scan log: it lists only the scan steps that belong to dispatch, so it stays uncluttered by production scans. Those steps are returned-to-ecom (RTE), returned-to-retail (RTR), DTK, Allocate, Pack, Dispatch out (DOut), returns in (RTO In), RTD Return, and the two repack steps (Repack In and Repack Out).

The table reads newest first. Each row shows the time, the unit's UPC, the activity, the line (D1 or D2), the product, the operator who scanned it, the loop count, and whether the scan is OK or has been voided.

Reading and filtering

Date and presets	Pick a single day, or use Today , This Week , This Month . Choosing a range shows a From and To field.
Summary tiles	The cards across the top count the day's scans per activity (Total, RTE, RTR, DTK, Allocated, Packed, Dispatched, Returns In, RTD Return, Voided). Click a tile to filter the table to that activity; click Total to clear.
Activity chips	The row of chips does the same filtering as the tiles, and also covers the Repack In / Repack Out steps that are kept off the headline tiles.
Search UPC	Type at least four characters of a UPC to switch into search mode: the table then shows that one unit's full dispatch history across time, not just the chosen day. Clear the box to return to the live feed.

Show Voided

Off by default. Tick it to include scans that were later voided (they appear dimmed and tagged Voided).

✓ TIP

Use the UPC search to settle a “where did this box go?” question: search the UPC and you get its trail of dispatch scans (packed, allocated, dispatched, returned) in order, with the operator and time on each. The list loads in pages; click **Load More** at the bottom to pull older scans for the selected day.

Stock Audit

/dispatch-audits

OP

SUP

ADM

Stock Audit is the trustworthy count of the finished cars that dispatch physically holds. It is not the quick Dispatch Counts scratchpad; this is a governed count that, once approved, corrects the system to match the floor. You open one when you want a real reconciliation of what is on the shelves against what the system thinks is there.

WHAT IT'S FOR	READ OR ACT?	WHO	KEY FACT
A governed, self-correcting count of held cars.	Action (open, scan, submit, approve).	OPERATOR SUPERVISOR ADMIN	The counter cannot approve their own audit.

What it counts, and why

An audit measures the cars dispatch is **holding**: every unit whose status is `handed_over` (with dispatch, not yet allocated) or `allocated` (set aside for a channel, not yet shipped). Cars that are still with production, already dispatched, or shipped are out of scope. It counts *cars only*; you never scan remotes separately, because a remote rides along with the car through their box pairing.

The point of the audit is to find the gaps honestly and then fix them. After a different supervisor approves, cars the system says you hold but nobody could find are marked **lost**, and cars you scanned that the system had written off come back into your holding. So the count is self-correcting: it does not just report a number, it repairs the records.

Reading the screen

The first screen is the **register**: every audit ever run, with its status, who opened it and when, and the headline numbers (present, missing, extra, corrected). Use the status tabs (Open, In Review, Completed, Cancelled, All) to filter. Click any row to open it.

Inside an open audit you watch four live tiles and a per-product table.

Scanned	How many car labels have been scanned into this audit so far (re-scans do not double-count).
Present	Scanned <i>and</i> held: the system and the floor agree these cars are here.
Missing	Held by the system but not yet scanned. These are the cars to go and find. The screen lists the exact batch labels.

Extra

Scanned but not currently held by the system (for example, a car the system had marked lost). These come back on approval.

① VARIANCE IS ONLY EVER ABOUT PRODUCTS YOU SCANNED

The variance table shows one row per product that was scanned at least once, comparing held against scanned. A product you never scan at all is not flagged as missing; the audit does not assume you meant to count a product you never touched. So if you are auditing only one shelf, scan that shelf and the numbers stay about that shelf.

Running an audit

- 1 Open the audit.** A supervisor clicks **Open new audit**, optionally names the area (for example, "D1 racks") and adds a note. Only **one audit can be open at a time**; if one is already open you must submit or cancel it first.
- 2 Scan the floor.** On the floor scanner go to `Dispatch → Stock Audit` and scan every car box label you physically hold (the `LOT-...-E` or `LOT-...-R` labels). Scan in any order, in as many passes as you like; re-scanning the same label is safe and simply merges. Nobody has to hunt for a specific car mid-count: you just sweep everything you have.
- 3 Watch the variance.** Back on this screen the tiles and the per-product table update as scans land. The **Missing** list gives you the exact batch labels still unaccounted for, so you can go look for them before you finish. A desk fallback, **Add scans (paste)**, lets a supervisor paste labels or UPCs if a few need adding by hand; pasted scans dedupe with the floor scans.
- 4 Submit for review.** When the count is settled, click **Submit for review**. This freezes the variance into a fixed list of discrepancies and stops further scanning. The audit moves to In Review.
- 5 A different supervisor reviews.** The reviewer opens the In Review audit, looks down the frozen discrepancy lines, and may **skip** any individual line they do not want corrected (tick its Skip box). When satisfied they click **Approve & correct**.
- 6 The system self-corrects.** On approval, each missing line (not skipped) marks its car **lost**, and each extra line brings its car back to `handed_over`. The audit becomes Completed and the corrected count is recorded. This is reversible: a later audit that scans a car previously marked lost will pick it up as an extra and restore it.

🚫 THE COUNTER CANNOT APPROVE THEIR OWN COUNT

This is a real check-and-balance, enforced by the system, not just a convention. Whoever **opened** or **submitted** an audit is blocked from approving it; the Approve button will not work for them. Approval must come from a *different* supervisor. Because approving an audit changes real inventory (writing cars off as lost and adding others back), one person must never be able to both run the count and bless it. If you counted it, hand it to someone else to approve.

Who can do what

Opening, scanning and submitting an audit need the count-record right; approving needs the count-approve right, held by a different person.

OPERATOR	Scans the held car labels at the scanner Stock Audit station during a count. Reads the audit screen.
SUPERVISOR	Opens, scans, submits an audit, and (a <i>different</i> supervisor) reviews and approves it.
ADMIN	Full access to the whole flow.

If an audit is sitting In Review and no one with approval rights is available, it simply waits; nothing is corrected until someone approves it. To abandon a count without touching any records, use **Cancel**: no corrections are applied.

Dispatch Roster

/dispatch-roster

SUP

ADM

Dispatch Roster is the daily activity log for the dispatch team on lines D1 and D2. For each operator on the floor you record what they are working on (packing, returns, or admin) and the hours spent on it, so the day’s effort is captured against the right activity.

WHAT IT’S FOR	READ OR ACT?	WHO	ROSTER FROM
Logging dispatch-team activity and hours.	Action (supervisors).	SUPERVISOR ADMIN	Manpower → Daily Roster (D1 / D2).

Using it

Pick the date. Every operator placed on D1 (pink) or D2 (cyan) gets a row. For each one, set their **Current Activity** from the dropdown, enter the **Hours** spent (in quarter-hour steps), add notes if useful, and save. The three activities are:

Order Packing / Dispatch	Packing orders and sending boxes out.
Returns Processing	Handling units that have come back.
Admin / Other	Anything else: tidying, stock moves, paperwork.

Click an operator’s name or the **History** button to see the day’s entries for that person, each with its activity, hours and notes.

① PEOPLE COME FROM THE ROSTER, NOT THIS SCREEN

The list of operators here is whoever you assigned to **D1** or **D2** on **Manpower → Daily Roster** for the date. If someone is missing, assign them there first. You must set an activity before notes or hours will save, and one Save covers both. The log is append-only: each save records a new entry rather than overwriting the last, so the history is a true record of the day. Editing needs floor-supervisor access.

Manpower

/manpower SUP ADM

Manpower is where supervisors see who is on the dispatch team today, assign people to the two dispatch lines, and track attendance and reliability over time. Everything here is scoped to dispatch: it deals in lines D1 and D2 and the dispatch team only, not the production lines.

WHAT IT'S FOR	READ OR ACT?	WHO	LINES
Dispatch attendance, rostering and reliability.	Mostly action (supervisors).	SUPERVISOR ADMIN	D1 and D2 (dispatch), not L1–L3.

This screen is for floor management; if your account does not have floor-management rights it shows a restricted notice instead. There are four tabs.

Attendance

Pick a date to see the dispatch team's clock-ins and clock-outs for that day: clock-in time (with a late flag if applicable), clock-out time (an **Auto** tag means the system auto-closed a forgotten shift at 1 AM), duration, a present streak, days absent this month, and a day-status dropdown (Normal, Half day, Absent, Leave, Holiday) that feeds payroll later. If someone is still clocked in you can **Close shift** to stamp their clock-out at the current time. Working days are counted Monday to Saturday.

Daily roster

This is where you put people on lines. The pool on the left is the dispatch operators who are **clocked in today and not yet assigned**. Drag one (or several, using multi-select) into the **D1** or **D2** bucket, or use the small plus button to search and assign. An operator can only be on one line per day; reassigning moves them.

① DAILY ROSTER FEEDS THE REST OF DEPOT

Who you place on D1 and D2 here is what the Overview shows as the rostered manpower per line, and it is the list of people who appear on the **Dispatch Roster** screen for activity logging. To fill lines quickly, enter a target headcount for D1 and D2 and use **Auto-assign**; it fills D1 first, then D2, from the clocked-in pool. The lines themselves are stationless: there are no Assembly or QC sub-stations as on the production side.

Analytics

A read-only reliability view over a window you choose (30, 60, 90 days, or this month). Each dispatch operator gets an attendance rate and a tier: **Reliable** (90% and up), **Steady** (75% and up), **Irregular** (50% and up), and **Critical** below that. A day-by-day strip shows present and absent days, alongside current and longest streaks and a trend arrow. Use it to spot who is slipping and to plan cover.

Shifts

The dispatch shift definitions (start, end, the early clock-in and late grace windows). Dispatch runs two overlapping shifts, so a person can be tied to a home shift. Editing a shift writes a new version dated today and never rewrites past attendance; old days keep the shift they were counted under. Production and store shifts are managed in their own apps and do not appear here.



PART 7

Setup

Done-once configuration

Channels

/dispatch-channels

SUP

ADM

Channel Master is the list of every dispatch and sales channel (Amazon, Flipkart, Cred, BOM Bulk, retail partners and so on) that shipments and units are assigned to. It is a small but important setup screen that defines the choices everywhere else in Depot. It is done-once setup, out of the daily flow.

WHAT IT'S FOR	READ OR ACT?	WHO	NO DELETE
Maintaining the channel list.	Action: add and edit channels.	SUPERVISOR ADMIN	Deactivate instead.

A channel's settings

Name	The channel's name (e.g. Amazon, Flipkart, BOM Bulk).
Type	Ecom, Retail or Other, shown as a colour badge across Depot.
Fulfilment model	Unit (dispatched per unit) or Bulk (warehouse transfer). Bulk channels make a "Destination Warehouse" field appear when you create a shipment for them.
Sale channel	Whether the channel generates revenue. This drives the green "sold" colouring and totals on the Dispatch Overview. Non-sale channels read as "Cost".
Active	Whether the channel is offered when creating shipments. Inactive channels show dimmed.

Adding & editing

Add Channel opens an inline form; new channels are always created active. **Edit** on any row lets you change its name, type, fulfilment model, sale flag and active state. Each row also has an **active toggle** you can flip directly, without opening the edit form.

① RETIRE, DON'T DELETE

There is no delete. A channel that is no longer used is switched to **Inactive** so its history stays intact and it simply stops appearing as a choice for new shipments.



PART 8

Scanner

The floor scanner, for dispatch stations

The Floor Scanner



Depot is the desk side of dispatch; the floor side runs on a separate handheld scanner. It is its own little app you open on a phone or floor tablet, and it is where the physical work gets recorded: a unit only moves through the pipeline you see in Depot because someone scanned it at a station. This chapter covers how you get into the scanner, sign in, and reach a Dispatch station. The Dispatch station chapter that follows covers each scan in detail.

WHERE	READ OR ACT?	WHO	GETS YOU IN
<code>scanner.legendoftoys.com</code> , on a phone or floor tablet (not inside Depot).	Action: every scan records a real move.	OPERATOR SUPERVISOR ADMIN	Dispatch PIN, then your QR badge.

The scanner is a separate app

Depot (the back office) and the floor scanner are two different things on two different screens. Depot is the dashboard where you watch the pipeline, build shipments and run audits. The scanner at `scanner.legendoftoys.com` is the handheld your team taps to record each physical move on the floor. They share the same data, so a scan on the floor shows up in Depot within a minute, but you sign into each one separately.

Departments, not a free-for-all

The scanner opens on a **Department Select** screen with four tiles: **Production**, **Store**, **Dispatch** and **Attendance**. As dispatch, you pick **Dispatch**; it leads only to dispatch stations. A Dispatch device cannot be switched to a Production or Store station by mistake, and the reverse. This walling-off is deliberate: it removes the wrong-station mis-scans that used to cause real damage, like a fresh production car being scanned through a dispatch station.

- 1 Tap Dispatch.** A 6-digit PIN keypad appears on screen (not the phone keyboard, so the PIN is never remembered by the device).
- 2 Enter the Dispatch PIN.** A wrong PIN just says “try again”; there is no lockout. The unlock then sticks until **1 AM**, even if the app is closed and reopened. Logout clears it, so you re-enter the PIN after a logout.
- 3 Sign in with your QR badge.** Scan your operator card (or tap **Type ID** and enter your employee ID). This runs once per device per shift and also expires at 1 AM. Every station that touches a unit needs this, so your name is on each scan.

- 4 **Pick a category, then line and station.** Choose your dispatch line (**D1** or **D2**) and the station you are working, then tap **Launch Scanner**.

On the scanner screen

Once launched, the top bar shows your **line and station** (and your name) on the left and **Logout** on the right. The camera fills the middle; your recent scans run along the bottom. There is **no settings button and no way to switch station in-app**. To change line or station, tap **Logout**, which takes you all the way back to Department Select, then come in again through the same flow. That friction is intentional: it stops a station drifting onto the wrong job mid-shift.

Shift is automatic

There are no Regular or OT buttons. The scanner reads the device clock and tags each scan's shift for you: dispatch stations count Regular from 09:00 to 18:00 and anything outside that window as OT. You never set it.

When a scan is rejected

⊖ A WRONG SCAN STOPS YOU WITH A FULL RED SCREEN AND A BUZZ

For almost every station, if a unit is at the wrong stage, belongs somewhere else, or the code is the wrong kind, the scanner shows a **full red reject screen with a distinct buzz** and states the exact reason (for example "not ready to dispatch"). Nothing is recorded. Read the reason, fix it, and rescan. Each reject is logged, so a pattern of them is visible to a supervisor.

① ONE STATION IS GENTLER ON PURPOSE

The new **Stock Audit** station does not red-screen the way the others do; during a count it just warns and keeps going, because every scan is only data for the count. The Dispatch station chapter explains exactly how that one differs.

Dispatch Scan Stations



These are the floor scanner stations on the Dispatch side, the ones that feed everything you watch in Depot. The **Dispatch Flow** stations walk a finished unit out the door in order: Dispatch In, Allocate, Pack, then Dispatch Out. Alongside them sit Repack Release and Restock, the new Stock Audit station, and two utilities. Dispatch stations bind to a dispatch line, D1 or D2.

WHAT IT'S FOR	READ OR ACT?	WHO	YOU SCAN
Recording each physical dispatch move on the floor.	Action: each scan moves a real unit.	OPERATOR SUPERVISOR ADMIN	Box labels (LOT-...-E/R), box refs and channels.

The Dispatch Flow, in floor order

The four flow stations run left to right. A unit reaches Dispatch In once production has packed it, then it gets a channel at Allocate, goes into a shipment box at Pack, and finally ships at Dispatch Out. Each station only accepts a unit at the right earlier stage, so you cannot skip a step.

STATION	WHAT YOU SCAN	WHAT IT DOES	WHAT IT REJECTS
Dispatch In (DTK)	The box label, LOT-...-E/R .	Takes a packed unit into the dispatch area, ready to allocate.	Anything that has not come through production's final pack step (not yet ready to dispatch).
Allocate (ALLOC)	Pick the channel first, then the box label.	Assigns the unit to a sales channel. Re-allocating to a different channel is free.	A unit not yet at Dispatch In, or already shipped.
Pack (PACK)	Pick the shipment, then the courier label and each unit's box label.	Builds the physical shipment box. The dropdown lists all open shipments, so you can pack ahead. If the box has a capacity set, it fills to that number then closes and moves you to the next box. Scanning the courier label as well is what lets us say later which customer received a given car.	A unit that does not belong to that shipment's channel or stage, a box that is already full, or a second courier label on a box that already has one.

STATION	WHAT YOU SCAN	WHAT IT DOES	WHAT IT REJECTS
Dispatch Out (DOUT)	The box ref (BOX-...) or a box label.	The final out-the-door scan. After this the unit is shipped.	Anything not packed and ready to ship.
Repack Release (REPACK_RELEASE)	Pick the repack run, then each box label.	Hands a held unit back to a repack run so production can re- box it for a different channel. This is the signed hand-over.	A unit not currently held at Dispatch In or Allocated. A unit still on the production side does not need releasing here.
Restock / Remove (RESTOCK)	Pick a reason, then the unit's box label.	Pulls a unit back out of the outbound flow and into dispatch holding, ready to allocate and pack again. Use it to remove a unit from a box you decided not to send, or to take back a dispatched unit when the order is cancelled.	A unit that has been out to a customer (that is a return); a unit still on the production side; one not yet at Allocate.
Stock Audit (STOCK_AUDIT)	Every held car box label, LOT-...-E/R .	Feeds the open audit's count. Re-scans of the same car are ignored, so multi-pass and two people scanning is safe.	Soft by design: it warns but does not stop you (see below).
Lookup (LOOKUP)	Any unit or box label.	Tells you what a unit is and where it sits. Read-only, records nothing.	Nothing; it is just a check.
Legacy Reg (LEGACY_REG)	An older unit's code.	Registers a pre-system unit so it can flow normally. A utility, used rarely.	A code that is already known to the system.

Scanning the courier label at Pack

Packing takes two scans, not one. Scan the courier label on the parcel, the long number on the Delhivery sticker that the customer tracks, and scan the unit's box label as usual. Either order works. The scanner tells them apart by their shape, so there is nothing to switch and no extra box to type into.

Scan the courier label. The scanner holds it and shows "AWB ... now scan the box label", with a beep. On its own it never packs anything, so a stray scan cannot pack the wrong car.

Scan the box label. Exactly as before. The unit goes into the box and the courier number is saved against that box.

① WHY IT MATTERS

A bulk shipment already carries its own paperwork, so we can always trace it. A single unit going out on its own did not: until now the system knew the channel it went to but not which order it filled, so “which customer got this car?” had no answer. The courier number is what closes that, and it also brings the parcel’s delivery tracking down to the individual unit.

⚠ A SECOND COURIER LABEL IS REFUSED

If a box already carries one courier number and a different one is scanned, the scanner refuses it and names the number already on the box. That is deliberate: two courier labels on one carton would send the wrong parcels to the wrong people. Check you have the right box rather than working around it.

① MISSING IT DOES NOT BLOCK ANYTHING

The courier scan is optional. A pack with no courier label goes through exactly as it always did, and nothing is lost. Never hold up a shipment for it.

Repack Release, the controlled hand-over

When production raises a repack run, the units it needs show up as a release list. Select the run, then scan each unit’s box label to release it. Releasing locks the unit out of the normal dispatch flow and lets production scan it in to be re-boxed.

⚠ RELEASE IS THE PROPER HAND-OVER, ONE BOX AT A TIME

Nobody should walk into the dispatch area, grab a unit and start repacking it. Production’s repack-in step rejects any dispatch-held unit that was not released here first. Scanning it out at Repack Release is the signed hand-over.

Restock / Remove — pull a unit back into dispatch

Restock is the scan-out station. Scanning a unit’s box label here takes it out of wherever it was in the outbound flow and puts it back into **dispatch holding** — the same place a unit sits right after Dispatch In — so it can be allocated and packed again. Because removal is a real scan, the count is always honest: a unit can’t be “taken out” on paper while it’s still in the carton, or left in while someone says they pulled it.

- If the unit was **packed into a box**, it comes out of that box, the box’s count drops by one (a closed box reopens so you can keep loading), and the shipment’s packed total drops too.
- If the unit was **allocated** but not yet packed, it simply drops its channel and returns to holding.
- If the unit was already **dispatched out** and the order was cancelled, scanning it here brings it back into holding as a fresh re-inward.

It only works from Allocate onwards; a unit still with production (not yet Dispatch In) is “not in dispatch yet” and is refused. Its paired remote comes back with it.

⚠️ A COURIER-TOUCHED RETURN NEVER GOES THROUGH RESTOCK

If a unit has been out to a customer and come back damaged or for inspection, it is a return, not a restock. It belongs in the Returns process, which decides whether it is re-dispatched, repaired or written off. Restock is for pulling good units back out of the dispatch flow, not for handling returns.

Stock Audit, the soft station

Stock Audit is the floor half of a full dispatch stock count. A supervisor opens an audit in Depot (under **Floor → Stock Audit**), then the floor scans **every held car box label** into it at this station. Hold means a car currently with dispatch, either handed over or allocated; remotes ride along with their car and are not scanned separately. Each car only counts once, so two people can scan the same shelf and a second pass just merges in.

① THIS STATION DOES NOT RED-SCREEN

Unlike every other station, Stock Audit is **soft**. If you scan an unknown label, or a car that is not currently held, it shows a quick warning but **stays green and lets you carry on**. That is on purpose: during an audit every scan is just data for the count, and the variance the supervisor reviews afterwards is where any oddity gets sorted out. You do not need to stop and fix a warning the way you would at a flow station.

⚠️ YOU NEED AN OPEN AUDIT FIRST

If no audit is open, the station tells you to open one in Depot before scanning. Nothing is counted until an audit exists to count it into. One audit is open at a time across the whole floor.

① THE FULL COUNT FLOW LIVES IN THE STOCK AUDIT CHAPTER

This station only gathers the scans. Opening an audit, reading the live variance and missing labels, submitting it, and the separate-supervisor review that self-corrects the stock are all covered in the **Stock Audit** chapter.