

User Manual

Product Name: Proscan TV Remote Replacement

Model Compatibility Code: PLDED3727A-E

Applicable for the following TV / Display models

1. Important Safety & Usage Instructions

- **Read before use:** Ensure your device model is exactly listed in Section 2 (Compatible Models).
 - **Not a universal remote/part:** This product is designed to work **only** with the specific TV models listed below.
 - **Do not force connections:** If the product does not fit or respond, check compatibility first – do not force installation.
 - **Keep away from moisture and heat.**
 - **No user-serviceable parts inside.** Do not disassemble.
-

2. Compatible Models (ONLY the following list)

Please check the back label of your TV / display. **Only the models below are fully supported.**

Brand / Series	Compatible Proscan TV Model Number (s)
PLED Series	PLEDV3282A, PLED2243A-I, PLDED3273A-E, PLDED3996A-E, PLDED4016A-D, PLDED4017, PLDED5066A-B, PLDED5068A-D, PLED5529A-G, PLED1960A-L
PLCD Series	PLCD3271A-D
SLED Series	SLED3215A-B, SLED4016A-B
PLDED Variants	PLDED5066B, PLDED5066A, PLDED5069, PLDED3281

Important: Any model number **not** appearing above is **not compatible**. Using this product with an incompatible model may cause malfunction or no response.

3. Quick Setup Guide

1. **Remove any protective film** from the product (if present).
2. **Insert fresh batteries** (if applicable) or connect as per product type.
3. **Aim at the TV IR sensor** and press the **Power** button.

4. If the device works, no further action is needed.
5. If the device does **not** respond, refer to Section 4 – Troubleshooting.

4. Troubleshooting Steps (Before requesting a return)

Use this checklist if the product appears “defective” or “not working”:

Issue	Possible cause	Solution
No response at all	Incompatible model (not in list)	Verify model number on TV back label. Stop use immediately.
No response	Weak batteries	Replace with new batteries.
Intermittent response	Obstacle between product and TV sensor	Remove any objects. Stand within 10 ft (3 meters).
Works on some buttons but not others	Wrong mode (if multi-mode product)	Refer to “Mode selection” (if applicable). Our product is single mode – if this happens, the model may be incompatible.
After checking, model is in compatible list but still no response	Possible defect	Contact us with your order ID and a short video showing the issue. We will send a replacement or refund within 48 hours.

If you receive a product that does not match your model, please stop trying to use it and contact customer service. Do not leave a negative review before contacting us – we will resolve the issue promptly.

5. Contact Customer Support

Email: xsz668@yeah.net

Response time: Within 24 hours

Please provide:

Order ID

TV model number you are trying to use with

Brief description of the problem (or short video)

6. Warranty & Return Policy

30-day return for any reason – free if product is defective or not as described.

1-year warranty against manufacturing defects.

Warranty does not cover misuse with incompatible models (not listed in Section 2).

7. Declaration of Correction (for Amazon compliance)

We confirm that this user manual has been updated to accurately list all compatible models and explicitly exclude all non-compatible models. The troubleshooting steps provided above are designed to help customers identify compatibility issues before reporting a “defective” product.

Date of manual revision: April 28, 2026

Version: 2.0 (Corrected compatibility list)

End of Manual