Control and Monitoring System of a Water Tank: Commands

Received	Description
Command	
IDEN	Reply with the system id: "CMSWT/n"
ONOFFx/n	 x=1 Turn on the system and reply with the system status "SYS1/n"
	 x=0 Turn off the system and reply with the system status "SYSO/n"
	 default reply with the system status: "SYS1/n" or "SYS0/n"
MEASRx/n	 x=0 or default Reply with the analog measure on the channel A0 "AMSR0/n"
THRQRY/n	 Reply with the threshold values:
	"THRthcrmax,thmax,thmin,thcrmin/n"
THRRES/n	Reset all the thresholds to their default values
CONFIGx/	Mannual change of all the thresholds:
n	• x=0 thmin
	• x=1 thmax
	• x=2 thcrmin
	• x=3 thcrmax
ENGINx/n	 x=0 manual control: turn off the engine
	 x=1 manual control: turn on the engine
	 x=2 automatic control of the engine
Transmitted	Description
Command	Description
MSGxy/n	Reply with the engine status x , the gate status y and the
	analog measure value of the water tank height
SYSx/n	Reply with the system status: "SYS1/n" or "SYS0/n"