to the operating instructions supplied with the Bluetooth device.

⊃ *Switching visibility* on page 11

Connecting to a Bluetooth device automatically

This function connects the last connected Bluetooth device to this product automatically as soon as the two devices are less than a few meters apart.

1 Display the "Bluetooth" screen.
⊃ *Displaying the "Bluetooth" screen* on page 10

2 Touch [Auto Connect] to switch "On" (default) or "Off".

Deleting a registered device

⚠CAUTION

Never turn this product off while the paired Bluetooth device is being deleted.

1 Display the "Bluetooth" screen.
⊃ *Displaying the "Bluetooth" screen* on page 10

2 Touch [Connection].

3 Touch [🗑].

Connecting a registered Bluetooth device manually

Connect the Bluetooth device manually in the following cases:
● Two or more Bluetooth devices are registered, and you want to manually select the device to be used.
● You want to reconnect a disconnected Bluetooth device.
● Connection cannot be established automatically for some reason.

1 Activate the Bluetooth wireless technology on your devices.

2 Display the "Bluetooth" screen.
⊃ *Displaying the "Bluetooth" screen* on page 10

3 Touch [Connection].

4 Touch the name of the device that you want to connect.

Switching visibility

This function sets whether or not to make this product visible to the other device.

1 Display the "Bluetooth" screen.
⊃ *Displaying the "Bluetooth" screen* on page 10

2 Touch [Visibility] to switch "On" (default) or "Off".

Entering the PIN code for Bluetooth wireless connection

To connect your Bluetooth device to this product, you need to enter a PIN code.
You can change the PIN code with this function.

1 Display the "Bluetooth" screen.
⊃ *Displaying the "Bluetooth" screen* on page 10

2 Touch [PIN Code Input].

3 Touch [0] to [9] to input the pin code (up to 8 -digits).

4 Touch [↵].
❐ The default PIN code is "0000".

Displaying the device information

1 Display the "Bluetooth" screen.
⊃ *Displaying the "Bluetooth" screen* on page 10

2 Touch [Device Information].
The device name and address of the Bluetooth device and this product are displayed.

Clearing the Bluetooth memory

❐ This setting is available only when you stop your vehicle in a safe place and apply the parking brake.

⚠CAUTION

Never turn this product off while the Bluetooth memory is being cleared.

1 Display the "Bluetooth" screen.
⊃ *Displaying the "Bluetooth" screen* on page 10

2 Touch [Bluetooth Memory Clear].

3 Touch [Clear].
The confirmation screen appears.

Updating Bluetooth software

This function is used to update this product with the latest Bluetooth software. For details on Bluetooth software and updating, refer to our website.
❐ The source is turned off and the Bluetooth connection is disconnected before the process starts.
❐ This setting is available only when you stop your vehicle in a safe place and apply the parking brake.
❐ You need to store the version up file to the USB storage device in advance.

⚠CAUTION

Never turn this product off and never disconnect the phone while the software is being updated.

1 Connect the USB storage device stored the version up file to this unit.
⊃ *Plugging and unplugging a USB storage device* on page 8

2 Display the "Bluetooth" screen.
⊃ *Displaying the "Bluetooth" screen* on page 10

3 Touch [BT Software Update].

4 Touch [Start].
Follow the on-screen instructions to finish updating the Bluetooth software.

Displaying the Bluetooth software version

If this product fails to operate properly, you may need to consult your dealer for repair.
In such cases, perform the following procedure to check the software version on this unit.

1 Display the "Bluetooth" screen.
⊃ *Displaying the "Bluetooth" screen* on page 10

2 Touch [BT Version Info].
The version of this product's Bluetooth module appears.

11