## 160 Index

Hook		K	
in interior	139		
in the luggage compartment	135	Key	20
		Key switch for airbag deactivation	35
I		Key switch for the front passenger airbag	
Ice scraper	٩	Key switch faulty	36
Ignition lock		Keyboard	
Images	100	Infotainment Amundsen	
Infotainment Amundsen	79	Infotainment Swing	
see digital version of the manual		Keyless locking (KESSY)	22
Immobilizer		Kick-down	103
Indicator lights		L	
Overview	11	-	
Info call		LEAVING HOME	39
Infotainment Amundsen		Lever	
Infotainment Blues		Buttons	49
Infotainment keyboard	52	High-beam assist system	39
see digital version of the manual	5	Main beam	37
Infotainment overview		Turn signal	37
Infotainment Blues	52	Windscreen wipers and washers	
Infotainment Overview	52	Liability for defects	
Infotainment Amundsen	60	see warranty	155
Infotainment Swing		Light	36
Infotainment screen	50	Automatically switch on and switch off	
Infotainment Amundsen	71	Change bulbs	39
Infotainment Swing		Changing bulbs	39
Infotainment Screen	57	Clean headlights	44
Infotainment Blues	52	CORNER function	36
Infotainment settings		Daylight running lights	36
Infotainment Amundsen	70	Driving in the opposite direction of traffic_	38
Infotainment Blues		Fog light	37
Infotainment Swing		Hazard warning light system	37
Infotainment Swing	57	Headlamp flasher	37
Instrument cluster	50	Headlight range adjustment of headlights_	38
analogue	40	High-beam assist system	39
Instrument cluster display		Indicator light	38
Instrument cluster display	40 40	Low beam	38
Interior	40	Main beam	37
lighting	12	Operation	37
Interior fittings	43	Parking light	37
12 volt socket	120	Side light	
Car park ticket holder	130	Troubleshooting	38
Coat hook		Turn signal	
Glasses compartment	139	Light Assist	
Make up mirror	130	see high beam assist system	39
Map pockets	130	Light switch	37
Storage compartments		lightbulbs	
Ticket holder	130, 139	Fog lights - change	41
Ticket holder Interior lighting	43	Front flashing light - change	40
		Tail light - change	42
Operation		Lightbulbs	
ISOFIX		Dipped beam - change	40
eyelets	34 34	High beam - Replacing	
Placement on the seat		Lighting	
FIACEITIETT OIT LITE SEAL	33	interior	43
J		outer	
		Lighting range	
Jump start cables	124	Limiter	
		see speed limiter	110