4. Configure the ANHP and specify the critical RG, as shown in Figure 9-20, Figure 9-21 on page 341, and Figure 9-22 on page 342.

Active Node Halt Policy

Move cursor to desired item and press Enter.

HMC Configuration
Configure Active Node Halt Policy

F1=Help F2=Refresh F3=Cancel F8=Image F9=Shell F10=Exit Enter=Do

Figure 9-20 Configuring the active node halt policy

Active Node Halt down Policy Type or select values in entry fields. Press Enter AFTER making all desired changes. [Entry Fields] * Active Node Halt Policy Yes * Critical Resource Group [nfsrg] F2=Refresh F3=Cancel F4=List F1=Help F5=Reset F6=Command F7=Edit F8=Image F9=Shell F10=Exit Enter=Do

Figure 9-21 Critical resource group for active node halt policy