## 11 TOYOTA INNOVA Seat Belt Warning SRS Power Source 2 3 B-O ST2 B-0 A 5 Airbag Sensor (Front LH) A 6 Airbag Sensor (Front RH) 8 (2B) I 9 Ignition SW C10 Combination Meter DLC3<3-15> 21 1 🙀 1 112 IG2 +SL GSW2 -SL A19 Airbag Sensor Assembly Center 22 20 19 IA1 5 20 3 **2B** 21 20 1 (2B) Spiral Cable 18 (2D) A21 Airbag Squib (Steering Wheel Pad) Battery Door Lock Assembly (Driver's Side) <12-3> J20 Junction Connector Instrument Panel Reinforcement Center 7 Instrument Panel Reinforcement LH Cowl Side Panel LH

3

OVERALL

**ELECTRICAL WIRING DIAGRAM**