9 TOYOTA INNOVA * 1 : w/ Map Lamp * 2 : w/ Ignition Key Cylinder Lamp * 3 : w/ Theft Deterrent System Interior Light Power Source 2 3 (*2) (*2) I 8 Ignition Key 12 (2N) Cylinder Lamp 8 (2R) Integration Relay ILE BECU DCTY PCTY C10 Combination Meter (*1) 31 20 27 20 26 20 10 20 3 2E 15 20 1(ZE) 18(ZD) 10(2N) (®3 ₽ Theft Warning ECU <13-2> 3 IA1 13 IA1 J34 Junction 3 IG1 1 IG1 J27(A), J28(B) Junction Connector Battery W-B Left Rear Side Quarter Panel Instrument Panel Reinforcement Center Instrument Panel (H) Reinforcement LH

3

OVERALL

ELECTRICAL WIRING DIAGRAM