

Harley-Davidson Forty-Eight Full Maintenance Guide (Kilometers)

■ Battery Care

- Ride every 1–2 weeks to keep the battery charged.
- Use a battery tender when parked long-term.
- Check terminals for corrosion and tightness.
- Replace every 3–5 years if weak ($\approx$ 50,000 km of use).

■ Fuel System

- Use premium fuel (high-octane).
- For storage longer than 1–2 months, add fuel stabilizer.
- Run engine briefly to circulate stabilizer into fuel lines.

■■ Engine Oil & Filter

- Change every 8,000 km or once a year.
- Change oil before winter storage.
- Use Harley-approved 20W-50 oil (synthetic or mineral depending on climate).

■■ Primary & Transmission Fluids

- Primary chaincase fluid: change every 16,000 km.
- Transmission fluid: change every 32,000 km.
- Inspect regularly for leaks.

■■ Drive Belt

- Inspect for cracks/wear every 4,000 km.
- Check belt tension and adjust if necessary.
- Keep pulleys clean, avoid harsh cleaners.

■ Brakes

- Inspect pads and rotors every 8,000 km.
- Replace pads when thickness < 3 mm.
- Replace brake fluid every 2 years.
- Check for leaks and ensure firm lever/pedal feel.

■ Tires

- Check pressure before every ride ($\approx$ 2.5 bar front / 2.75 bar rear).
- Inspect for cracks, flat spots, or uneven wear.
- Replace at 5–7 years regardless of tread condition.

■■ Controls & Cables

- Check throttle and clutch free play every 8,000 km.
- Lubricate if stiff or sticky.
- Inspect for fraying or stiffness.

■ Suspension

- Inspect fork seals for leaks.
- Adjust rear shock preload when carrying a passenger or luggage.
- Change fork oil every 32,000 km or sooner with heavy riding.

■ Spark Plugs & Air Filter

- Inspect spark plugs every 16,000 km.
- Replace spark plugs every 32,000 km.
- Clean/replace air filter every 8,000 km (more often in dusty conditions).

■ Electrical System

- Test headlights, signals, brake lights, and horn regularly.
- Keep spare fuses in your toolkit.

■■ General Pre-Ride Checks

- Tire pressure & condition.
- Oil level.
- Brake fluid level.
- Lights and signals.
- Belt tension.
- Leaks under the bike.

■ Cleaning & Storage

- Wash with mild soap, avoid high-pressure water near electrics.
- Dry and wax chrome/paint to prevent rust.
- Winter storage:
 - • Fill tank + fuel stabilizer.
 - • Keep battery on tender.
 - • Cover with breathable motorcycle cover.
 - • Slightly elevate tires for very long storage.

Maintenance Interval Checklist (Kilometers)

Interval (km / time)	Task
Every ride	Check tire pressure & condition, oil level, brake fluid, lights, belt tension, and leaks.
Every 8,000 km / 1 year	Change engine oil & filter; inspect brakes; check throttle/clutch free play; clean/replace air filter.
Every 16,000 km	Change primary chaincase fluid; inspect spark plugs.
Every 32,000 km	Change transmission fluid; replace spark plugs; change fork oil.
Every 2 years	Replace brake fluid.
Every 3–5 years	Replace battery if weak; replace tires if 5–7 years old regardless of tread.