# SCAP XML USER GUIDE

This document is the user guide for the ATR SCAP XML program for Windows. This program uses XML input/output files as defined in IATA / *Alternate SCAP Interface for Takeoff and Landing - XML Standard* / 1st Edition April 2009.

## 1. Installation

The SCAP XML program is composed of the following files:

- **SCAPApp.exe**: program executable
- **SCAPLibrary.dll**: library managing license and calling Takeoff/Landing performance engine
- **TTAM.dll**: Takeoff performance calculation engine
- **TLAM.dll**: Landing performance calculation engine

These files must be placed in the same folder, as well as the license file provided by ATR (unzipped) and the license key file.

## 2. License key file

The license key file is an XML file named **LicenseKey** that must contain the `AirlineName` tag and the `LicenseKey` tag within `<Security>` and `</Security>` tags.
Airline name and license key information are provided by ATR.

Example of LicenseKey file:

```
<?xml version="1.0"?>
<Security>
  <AirlineName>AIRLINE_NAME</AirlineName>
  <LicenseKey>XXXX-XXXXXXXXXX</LicenseKey>
</Security>
```

## 3. Execution

Execution of **SCAPApp.exe** performs Takeoff or Landing performance computation according to the input file:

- A specific input file can be used by passing its path as argument to the executable, for example :
  `SCAPApp.exe C:\PATH\SCAP.IN`
- If no argument is defined, the default input file name is SCAP.IN and its location is the program directory.

# 4. Input file deviations from IATA specification

The format of the input file is defined in IATA / *Alternate SCAP Interface for Takeoff and Landing - XML Standard* / 1st Edition April 2009.

The deviations of ATR SCAP XML from the IATA specification are listed below:

- Input file can contain multiple blocks but it is not possible to mix TAKEOFF blocks and LANDING blocks in the same input file.

- Configuration file paths:
  - `program_files` tag is not used
  - `data_files` tag defines the path of the directory containing the data files
  - paths can be absolute or relative to the input file directory

- If no configuration information is found, the default values are the following:
  - `output_file`: default path is the input file path and default name is the input file name with **.out** extension
  - `trace_file`: default path is the input file path and default name is the input file name with **.log** extension
  - `stylesheet`: no style is applied to the output XML file
  - `data_files`: default path is the program directory

# 5. Error log

License errors or missing files errors are logged into the **Error.log** file located in the program directory. This file appear only if there is an error.
Computations errors are logged into the trace/output files defined in the input file.

Possible errors logged into the **Error.log** file are listed below:

| |
|---|
| ERROR: License file is missing |
| ERROR: LicenseKey file is missing |
| ERROR: LicenseKey is not parsed |
| ERROR: License is not parsed |
| ERROR: License doesn't have SCAP software |
| ERROR: License airline is missing |
| ERROR: LicenseKey airline is missing |
| ERROR: LicenseKey license key is missing |
| ERROR: License/LicenseKey airline name doesn't match |
| ERROR: License/LicenseKey license key doesn't match |
| ERROR: License expiration date is missing |
| ERROR: License has wrong expiration date |
| ERROR: License is expired |
| ERROR: SCAP dll not found at path “%dllPath%” |
| ERROR: Input file is not found at path "%InputFilePath%"* |