RoboArm X2 Installation Manual

Chapter 1. Site requirements

The mounting surface must support a static load of at least 2,000 N.

The operating temperature range is 0 to 45 degrees Celsius.

Relative humidity must stay below 85 percent, non-condensing.

Keep a free safety zone of at least 1.2 m around the arm during commissioning.

Chapter 2. Mounting

The base is fixed with four M10 bolts tightened to a torque of 45 Nm.

The X2 can be mounted on the floor, on a table or on a wall.

Ceiling mounting is not supported because the joint brakes are not rated for it.

The controller cable between arm and controller is 5 m long.

Chapter 3. Commissioning

After power-on, run the joint calibration wizard in the web dashboard.

The calibration wizard takes about 20 minutes and must be repeated after every collision above 150 N.

Set the tool weight and center of gravity before running any program.

The default dashboard password must be changed during commissioning.

Chapter 4. Maintenance and error codes

Re-grease the joint gearboxes every 5,000 operating hours.

Inspect the cable harness every 6 months for wear.

Error code E101 indicates overcurrent in a joint motor.

Error code E204 indicates that the emergency stop circuit is open.

Error code E310 indicates a lost connection between controller and arm.