Where Air conditioning system is installed

- After parking in the sun, drive with windows rolled down for a few minutes to blow off hot air before switching on A/C.
- 2. Keep all windows rolled-up when AC system is working.
- If you feel irritation in the eyes due to smoke or during long drive, stop A/C and ventilate for half a minute by winding down door glasses or use fresh air mode provided with HVAC system.
- Before stopping the engine first switch "OFF' A/C and then the blower.
- 5. During off-season operate the air conditioner a few times every month to lubricate components.

Do's