

Rolling Mill Bearing Replacement SOP

Purpose

Standard Operating Procedure for replacing roller bearings in Rolling Mills (RM-001, RM-002).

Symptoms of Failure

High vibration (>3.5 mm/s), abnormal noise, and increased motor current (>115 A).

Required Tools

Hydraulic puller, torque wrench, bearing heater, new SKF-22236 bearing.

Procedure

Step 1: Isolate power and apply LOTO (Lockout/Tagout). Step 2: Remove the coupling and housing cover. Step 3: Use hydraulic puller to remove the old bearing. Step 4: Heat the new bearing to 90 C using the bearing heater. Step 5: Slide the new bearing onto the shaft. Step 6: Apply grease and reassemble the housing. Step 7: Torque housing bolts to 450 Nm.