

			Range	
nRbtID	robot id	unsigned int	0~5	Machine ID number, default = 0
sPathName	Trajectory name	string	-	Trajectory name

***Note:**

This instruction can be used to run the PathJ trajectory generated by the original point data type of joint coordinates or spatial coordinates. Before calling this instruction, the stateJ of the trajectory must be 3, otherwise a state error is reported.

Send successful return message: MovePathJ,OK,;

Failed to send return message: MovePathJ,Fail,ErrorCode,;

Return Value	Name	Data Type	Valid Range	Content
ErrorCode	Error Code	int	Integer Value >0	Returns the error code of a failed call

Example

```
// Start the execution of the motion with a continuous motion path of the joint
MovePathJ,0,drag_1,.
// Successful return
MovePathJ,OK,;
// Failure return
MovePathJ,Fail,20042,;
```

ReadBoxInfo

Description: read information of the electrical box.

Sends the message: ReadBoxInfo,nRbtID,;

Parameter	Name	Data Type	Valid Range	Content
nRbtID	robot id	unsigned int	0~5	Machine ID number, default = 0

Successfully sent return message:

ReadBoxInfo,OK,nConnected,n48V_ON,db48OUT_Voltag,db48OUT_Current,