










BOGNOR REGIS RASPBERRY






































ADS-B


First, aircraft obtain their position information

from the GPS satellites. Then, the ADS-B sytem


simultaneously broadcasts the aircraft's position to other aicraft.

and to ground stations.
















What's it all About?





Q: What does ADS-B stand for!?





Facebook: BognorRegisJam



Aircraft to Aicraft


Ground Station to Control Tower


GPS Satellite






































- A Raspberry Pi 2/3/4 (B or B+) with power supply.
- An Internet connection (cable or wifi).
- A micro SD card (8GB+) with operating system.





Facebook: BognorRegisJam

Twitter: @BognorRegisJam


#rjam




















- Antenna.
- FlightAware software package.



FlightAware account (free).





#riam

Facebook: BognorRegisJam

Twitter: @BognorRegisJam









You'll need an SDR Dongle



- Generic approx. £16
- Rtl-sdr v.3 approx. £25
- ProStick (Pi Hut, Moonraker) £21-£25



Make sure the dongle uses the RTL2832U chip



Facebook: BognorRegisJam Twitter: @BognorRegisJam #rjam



rtl-sdr.com v.3

ProStick

Generic











Available from:

- Amazon
- Ebay
- Specialist shops
- RTL-SDR and FlightAware stores:



https://www.rtl-sdr.com/buy-rtl-sdr-dvb-t-dongles/

- https://flightaware.com/adsb/prostick/
- Search for "RTL-SDR"



rtl-sdr.com v. 3

ProStick

Generic



Facebook: BognorRegisJam

Twitter: @BognorRegisJam

#rjam




























You'll need an antenna



- but it's the wrong length for ADS-B.
- we can fix that! see Appendix.



 You can buy a basic antenna kit ("RTL-SDR antenna kit") for about £18.





Facebook: BognorRegisJam


Twitter: @BognorRegisJam


#riam



















Short telescopic parts used fully closed - this makes them ~68mm long.










Twitter: @BognorRegisJam #rjam











Wavelength



Wavelength = Speed of light / frequency









• ADS-B Wavelength = 299792458/1090000000 = 0.275m = 27.5cm = 275mm





• Idea: Write a program to calculate wavelengths from given frequency!

Facebook: BognorRegisJam Twitter: @BognorRegisJam





#riam






on the Raspberry Pi

Aircraft Tracking









#rjam











Cantenna

Facebook: BognorRegisJam



Spider

Twitter: @BognorRegisJam






Aircraft Tracking

on the Raspberry Pi











Facebook: BognorRegisJam









Spider


Twitter: @BognorRegisJam

#rjam















https://uk.flightaware.com/adsb/piaware/build

Or see the third-party instructions at:



https://discussions.flightaware.com/t/install-piaware-5-0-on-x86-64-machines-and-rpi-armv7l-aarc h64/74699



You can also use a full Raspberry Pi OS image with PiAware preinstalled (requires a blank microSD card) – see the Appendix.




Facebook: BognorRegisJam Twitter: @BognorRegisJam #riam













Instructions are on the PiAware setup Web page.



Claim your PiAware client on FlightAware.com

You should wait about four or five minutes for your PiAware to start and then you can associate your FlightAware account with your PiAware device to receive all the benefits.

Once your device is running, please:

Look up the IP address in your router admin and go to the assigned IP address in a browser on the same network. If the device hasn't been claimed a link to claim the PiAware device will display.

Or

Claim your PiAware client on FlightAware.com

If after 5 minutes your device hasn't displayed as claimed try restarting the device, if that still doesn't work re-confirm the Wi-Fi settings (if using Wi-Fi) are correct. Lastly contact us at ADSBsupport@FlightAware.com. Check your stats page (link below) to confirm it was claimed.



6 View your ADS-B statistics

Facebook: BognorRegisJam

Twitter: @BognorRegisJam




#riam









Facebook: BognorRegisJam


Twitter: @BognorRegisJam

#rjam






FlightAware Account



Facebook: BognorRegisJam Twitter: @BognorRegisJam #rjam









Any Questions?

























Nigel Kendrick (Twitter: @linker3000)

You'll find a copy of this presentation at:

https://github.com/linker3000/Raspberry-Pi-Jams









#riam


Facebook: BognorRegisJam

Twitter: @BognorRegisJam


















- Modifying a DVB-T antenna
- Making your own antenna
- Antenna connector adapter
- Additional resources



ADS-B = Automatic Dependent Surveillance-Broadcast



Facebook: BognorRegisJam Twitter: @BognorRegisJam #rjam




















#rjam

Modifying a DVB-T antenna

- Antenna length is optimised for Digital TV (DVB-T).
- ADS-B is transmitted at a different frequency.
- Cut antenna to 69mm.

Take care when cutting the antenna:

- The metal is sharp and quite hard.
- If using snips, the bit being removed can fly off.
- Ask an adult to perform the operation ...or just buy an antenna kit!
- After the antenna is cut, it's no longer the right length for digital TV!






Facebook: BognorRegisJam Twitter: @BognorRegisJam












Making your own antenna...



https://lucsmall.com/2017/02/06/making-antennas-for-1090mhz-ads-b-aircraft-tracking/





 The UK ADS-B system operates at 1090MHz. You might see references to 978MHz, but that frequency is not used in the UK, so you don't need to follow any instructions to enable support for it.



Facebook: BognorRegisJam

Twitter: @BognorRegisJam #rjam



















- Most generic DVB-T SDR dongles (blue dongle on the far right) are fitted with a connector type called MCX
- Most antenna kits come with SMA connectors (like the first two dongles in the picture)
- For dongles with MCX connectors you need an adapter!
- Search eBay (or your favourite store site) for:





rtl-sdr.com v.3

ProStick

Generic



Facebook: BognorRegisJam Twitter: @BognorRegisJam #rjam







You might need a connector adapter


Facebook: BognorRegisJam

Example (below). A pigtail lead puts less stress on the dongle's MCX connector...











Twitter: @BognorRegisJam #rjam


















#rjam

You might need a connector adapter

...but you can get a straight adapter if you wish...







SMA






Facebook: BognorRegisJam

Twitter: @BognorRegisJam









PiAware Image



- A complete Raspberry Pi OS installation image with PiAware preinstalled.
- Follow instructions at:









