CUSTOMER GUIDE

WEATHER COMMANDER

Install on your Commander X16

Extract the ZIP and copy the entire WEATHERCMD folder to your X16 SD card, device 8. Keep every PRG and BIN together. Requires 512 KB RAM; tested on ROM r49.

At the BASIC prompt:
DOS "CD:WEATHERCMD"
LOAD "WEATHER.PRG",8
RUN

Upgrade

If upgrading from the older WEATHER folder, copy its WCSETUP.BIN into WEATHERCMD to retain saved preferences and personal cities. Back up your card first.

Demo and controls

The app starts with clearly labeled demo data when no live feed is available. Mouse selects controls; F5 opens Settings; Esc exits or goes back in setup. Demo forecasts and recorded radar are examples, not current weather.

Live weather

Use a compatible Serial & ESP32 card with ZiModem at IO7 ($9FE0). Open Settings → Wi-Fi and connections → Connect with a Wi-Fi card. Choose your network, enter its password, then Get my weather. Save and open weather stores preferences and personal city coordinates.

No bridge computer or API key is required. Philippine radar decoding can take about five minutes at 8 MHz while the rest of the interface remains available.

Validation and support

ROM r49 emulation and compiled protocol tests passed. Physical Wi-Fi card testing is pending. Unavailable or outdated radar should not be treated as live. Data provenance and licenses remain in DATA-NOTICE.TXT.

Updates and support: roddy.world · support@roddy.world