

SERVICE HINTS

HEADLIGHT RELAY

1-2 : CLOSED WITH LIGHT CONTROL SW AT **HEAD** POSITION OR DIMMER SW AT **FLASH** POSITION

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C14	32	H 1	28 (3S-GTE), 30 (5S-FE)	R 2	28 (3S-GTE), 30 (5S-FE)
C16	A 32		31 (4A-FE)		31 (4A-FE)
C17	B 32	H 2	28 (3S-GTE), 30 (5S-FE)	R 3	28 (3S-GTE), 30 (5S-FE)
F10	A 28 (3S GTE)		31 (4A-FE)		31 (4A-FE)
	B 30 (5S-FE), 31 (4A-FE)	J 6	33	R 9	33

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1A	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1E		
2A	22 (2WD)	ENGINE ROOM MAIN WIRE AND J/B NO. 2 (NEAR THE BATTERY)
2B	23 (ALL-TRAC/4WD)	
	22 (2WD)	ENGINE WIRE AND J/B NO. 2 (NEAR THE BATTERY)
2D	23 (ALL-TRAC/4WD)	
	22 (2WD)	ENGINE ROOM MAIN WIRE AND J/B NO. 2 (NEAR THE BATTERY)
2E	23 (ALL-TRAC/4WD)	
3B	23 (ALL-TRAC/4WD)	COWL WIRE AND J/B NO. 3 (BEHIND COMBINATION METER)
	25	

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IE1	44	ENGINE ROOM MAIN WIRE AND COWL WIRE (LEFT KICK PANEL)

▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
EB	38 (3S-GTE)	FRONT LEFT FENDER
	40 (5S-FE)	
	42 (4A-FE)	
ID	44	LEFT KICK PANEL

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 2	38 (3S-GTE)	ENGINE ROOM MAIN WIRE	E 3	42 (4A-FE)	ENGINE ROOM MAIN WIRE
	40 (5S-FE)		E13	38 (3S-GTE)	
	42 (4A-FE)			40 (5S-FE)	
E 3	38 (3S-GTE)		I 2	42 (4A-FE)	COWL WIRE
	40 (5S-FE)			46	



