


DISTRIBUTOR (5S-FE)

REMOVAL OF DISTRIBUTOR




1. DISCONNECT CABLE FROM NEGATIVE TERMINAL OF BATTERY

CAUTION: Work must be started after approx. 20 seconds or longer from the time the ignition switch is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.


2. REMOVE AIR CLEANER CAP, RESONATOR AND AIR CLEANER HOSE

- Disconnect the air intake temperature sensor connector.
- Disconnect the cruise control actuator cable from the clamp on the resonator.
- Loosen the air cleaner hose clamp bolt.
- Disconnect the four air cleaner cap clips.
- Disconnect the air cleaner hose from the throttle body, and remove the air cleaner cap together with the resonator and air cleaner hose.




3. DISCONNECT DISTRIBUTOR CONNECTORS**4. DISCONNECT HIGH-TENSION CORDS FROM SPARK PLUGS**

- (a) Disconnect the four high-tension cords from the spark plugs.
- (b) Disconnect the high-tension cords from the clamp on the cylinder head cover.

**5. REMOVE DISTRIBUTOR**

- (a) Remove the two hold-down bolts, and pull out the distributor.
- (b) Remove the O-ring from the distributor housing.

COMPONENTS





DISASSEMBLY OF DISTRIBUTOR

1. REMOVE DISTRIBUTOR CAP WITHOUT DISCONNECTING HIGH-TENSION CORDS
2. REMOVE ROTOR
3. REMOVE IGNITION COIL DUST COVER


4. REMOVE IGNITION COIL

- (a) Remove the two nuts, and disconnect the three wires from the ignition coil terminals.






(b) Remove the four screws and ignition coil.




5. REMOVE DISTRIBUTOR WIRE

Remove the distributor wire from the distributor housing.



6. REMOVE CONDENSER

Remove the screw and condenser.



DISTRIBUTOR INSPECTION

INSPECT SHAFT


Turn the shaft and check that it is not rough or worn. If it feels rough or worn, replace the distributor housing assembly.

DISTRIBUTOR ASSEMBLY

(See page IG-32)


1. INSTALL CONDENSER

Install the condenser with the screw.



2. INSTALL DISTRIBUTOR WIRE


Install the grommet of the wire to the distributor housing.




3. INSTALL IGNITION COIL

- (a) Remove any oil packing (FIPG) material.
- (b) Apply seal packing to the ignition coil installing surface of the housing as shown in the illustration.


Seal packing: Part No. 08826-00080 or equivalent




- (c) Install the ignition coil with the four screws.




- (d) Connect the three wires to the ignition coil terminals with the two nuts.




**NOTICE:**


- When connecting the wires to the ignition coil, insert both properly into their grooves found on the side of the ignition coil.
- Be sure the wires do not contact with signal rotor or distributor housing.

4. INSTALL IGNITION COIL DUST COVER**5. INSTALL ROTOR****6. INSTALL DISTRIBUTOR CAP AND HIGH-TENSION CORDS****INSTALLATION OF DISTRIBUTOR**(See page [IG-30](#))**1. SET NO.1 CYLINDER TO TDC/COMPRESSION**


Turn the crankshaft clockwise, and position the slit of the intake camshaft as shown.

**2. INSTALL DISTRIBUTOR**

- Install a new O-ring to the housing.
- Apply a light coat of engine oil on the O-ring.



- Align the cutout portion of the coupling with the groove of the housing.




- (d) Insert the distributor, aligning the center of the flange with that of the bolt hole on the cylinder head.
- (e) Lightly tighten the hold-down bolts.
- (f) Install the high-tension cord clamp to the rear engine hanger.

3. CONNECT HIGH-TENSION CORDS TO SPARK PLUGS

Firing order: 1 – 3 – 4 – 2

4. CONNECT DISTRIBUTOR CONNECTORS




5. INSTALL AIR CLEANER CAP, RESONATOR AND AIR CLEANER HOSE

- (a) Connect the air cleaner hose to the throttle body.
- (b) Install the air cleaner cap together with the resonator and air cleaner hose.
- (c) Connect the air intake temperature sensor connector.
- (d) Connect the cruise control actuator cable to the clamp on the resonator.

6. CONNECT CABLE TO NEGATIVE TERMINAL OF BATTERY

7. WARM UP ENGINE

Allow the engine to warm up to normal operating temperature.




8. CONNECT TACHOMETER

Connect the test probe of a tachometer to terminal IG (–) of the data link connector 1.

NOTICE:

- NEVER allow the tachometer terminal to touch ground as it could result in damage to the igniter and/or ignition coil.
- As some tachometers are not compatible with this ignition system, we recommend that you confirm the compatibility of your unit before use.




9. ADJUST IGNITION TIMING

(a) Using SST, connect terminals TE1 and E1 of the data link connector 1.

SST 09843-18020


HINT: After engine rpm are kept at 1,000 – 1,300 rpm for 5 seconds, check that they return to idle speed.



(b) Using a timing light, check the ignition timing.

Ignition timing: 10° BTDC @ idle


(Transmission in neutral position)



(c) Loosen the hold-down bolts, and adjust by turning the distributor.


(d) Tighten the hold-down bolts, and recheck the ignition timing.

Torque: 19 N·m (195 kgf·cm, 14 ft·lbf)



(e) Remove the SST.

SST 09843-18020



10. FURTHER CHECK IGNITION TIMING

Ignition timing: 13 – 22° BTDC @ idle

(Transmission in neutral position)

HINT: The timing mark moves in a position between 13° and 22°.

11. DISCONNECT TACHOMETER AND TIMING LIGHT FROM ENGINE