

TROUBLESHOOTING

Problem	Possible cause	Remedy	Page
Engine will not crank	Battery charge low	Check battery specific gravity	CH-2
	Battery cables loose, corroded or worn	Check or replace battery	CL-5
	Clutch start switch faulty (M/T)	Repair or replace cables	
	Neutral start switch faulty (A/T)	Adjust or replace clutch start switch	ST-8
	Starter relay faulty (M/T)	Adjust or repair switch	
	Fusible link blown	Replace starter relay	
	Starter faulty	Replace fusible link	
	Ignition switch faulty	Repair starter	
		Replace ignition switch	
Engine cranks slowly	Battery charge low	Check battery specific gravity	CH-2
	Battery cables loose, corroded or worn	Charge or replace battery	ST-8
	Starter faulty	Repair or replace cables	
Starter keeps running		Repair starter	ST-8
	Ignition switch faulty	Replace ignition switch	
	Short in wiring	Repair wiring	
Starter spins – engine will not crank	Pinion gear teeth broken or starter faulty	Repair starter	ST-8
	Flywheel teeth broken	Replace flywheel	