



CLUTCH MASTER CYLINDER COMPONENTS



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

CL0520



REMOVAL AND INSTALLATION OF CLUTCH MASTER CYLINDER (MAIN POINT OF REMOVAL AND INSTALLATION)

1. (For 3S-GE engine)

REMOVE FRONT SUSPENSION BRACE

2. REMOVE MASTER CYLINDER

- (a) Remove the filler cap.
- (b) Using a wrench, disconnect the clutch tube from the cylinder.
- (c) Remove the clip, clevis pin and return spring.
- (d) Remove the two nuts.
- (e) Pull out the master cylinder.

3. INSPECT MASTER CYLINDER BORE FOR SCORING OR CORROSION



If a problem is found, clean or replace the cylinder.

4. INSPECT PISTON AND CUPS FOR WEAR, SCORING, CRACKS OR SWELLING

If either one requires replacement, use the parts from the cylinder kit.

5. INSPECT PUSH ROD FOR WEAR OR DAMAGE

If necessary, replace the push rod.

**6. COAT PARTS WITH LITHIUM SOAP BASE GLYCOL GREASE AS SHOWN****7. INSTALL MASTER CYLINDER FOLLOWING REMOVAL SEQUENCE IN REVERSE**

HINT: When installing the reservoir tank, drive in the slotted spring pin with a pin punch and hammer as shown.

8. (For 3S-GE engine)**INSTALL FRONT SUSPENSION BRACE****9. BLEED SYSTEM AND ADJUST CLUTCH PEDAL**

(See page [CL-3](#) and 4)