



Fuel Pump Relay and Resistor (3S-GTE)



FI1704



FI5416

INSPECTION OF FUEL PUMP RELAY AND RESISTOR

1. INSPECT FUEL PUMP RELAY

A. Inspect relay continuity


- Using an ohmmeter, check that there is continuity between terminals 2 and 4.
- Check that there is continuity between terminals 1 and 4.
- Check that there is no continuity between terminals 3 and 4.

If continuity is not as specified, replace the relay.


B. Inspect relay operation

- Apply battery voltage across terminals 2 and 4.
- Using an ohmmeter, check that there is no continuity between terminals 1 and 4.
- Check that there is continuity between terminals 3 and 4.

If operation is not as specified, replace the relay.



FI5417



P02935

2. INSPECT FUEL PUMP RESISTOR

Using an ohmmeter, measure the resistance between the terminals.

Resistance: Approx. 0.73 Ω

If the resistance is not as specified, replace the resistor.