

THEORY OF OPERATION

The convertible top assembly installed on this vehicle is powered by a hydraulic system consisting of an electric motor/pump/reservoir assembly, two hydraulic cylinders and connecting hoses.

NOTICE: Before operating the convertible top perform the following steps:

- **Set the parking brake.**
- **Turn the ignition switch "ON"**
- **Lower the side windows.**
- **Put the transaxle in Neutral (manual transmission) "P" (automatic transaxle).**
- **Unlatch the top from the windshield header.**

When the top control switch is pressed on the OPEN side, the circuit to the motor/pump will be closed. Once the circuit is closed the motor will be activated, thus rotating the pump, forcing the fluid through the pink hoses to the top of the double-acting cylinders. The fluid forces the piston rods in the cylinders downward, thus lowering the convertible top. The fluid in the bottom of the cylinders returns through the white hoses to the pump and is recirculated to the top of the cylinders.

When the top control switch is pressed on the CLOSED side, the circuit to the motor/pump will be closed. Once the circuit is closed the motor will be activated, thus rotating the pump, forcing the fluid through the white hoses to the bottom of the double-acting cylinders. The fluid forces the piston rods in the cylinders upward, thus raising the convertible top. The fluid in the top of the cylinders returns through the pink hoses to the pump and is recirculated to the bottom of the cylinders.

The motor/pump assembly is equipped with a manual release valve which when rotated clockwise 90° to the OPEN position allows fluid to pass between both sides of the pump, allowing the convertible top to be operated up and down manually. If the top control switch is pressed to either open or close the convertible top, with the manual release valve open, the pressure generated by the pump will be equalized on both sides of the pump, rather than the pressure being applied to the cylinders.

When the manual release valve is rotated counterclockwise 90° to the CLOSED position, the fluid is now directed through the hoses to the cylinders, allowing the convertible top to be operated up and down by the top control switch therefore the pressure generated by the pump will be applied to the cylinders.