



SERVICE HINTS

A15(C), A16(A) (B) ALTERNATOR

- (C) 1-GROUND: **13.9–15.1 VOLTS** WITH ENGINE RUNNING AT **2000 RPM** AND **25°C (77°F)**
13.5–14.3 VOLTS WITH ENGINE RUNNING AT **2000 RPM** AND **115°C (239°F)**
 (A) 1, (B) 2 -GROUND : **0–4 VOLTS** WITH IGNITION SW AT **ON** POSITION AND ENGINE NOT RUNNING

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
A15	C	28 (3S–GTE), 30 (5S–FE)	A16	B	30 (5S–FE), 31 (4A–FE)
	C	31 (4A–FE)	C15		32
A16	A	28 (3S–GTE)	F10	A	28 (3S–GTE)
			F10	B	30 (5S–FE), 31 (4A–FE)
			J 3		33

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1B	20	COWL WIRE AND J/B NO. 1 (LEFT KICK PANEL)
1D		
2B	22 (2WD)	ENGINE WIRE AND J/B NO. 2 (NEAR THE BATTERY)
	23 (ALL–TRAC/4WD)	

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
IG2	44	ENGINE WIRE AND COWL WIRE (UNDER THE ENGINE ECU)

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 5	46	COWL WIRE			

