SCHEMATIC - every wire of the set, grouped by job; read, not to scale

Cables are shown per capacity of the wire count used: pairs for PWM/CAN, triads for 3-phase bus runs, or 1 wire. Wire label at AWG. colour (black-banded). Stashed = built with the harness marked in its table; grey header = an end on another harness.

WIRE COLOUR CODE: BLACK · RED · WHITE · BLUE · GREEN · GREY · BROWN · ORANGE · YELLOW · PINK · VIOLET · **BOOT SHADE (RUBY):** ■ Rear ■ Yellow ▭ Deep ▭ ▭ = 2 wire · ▭▭▭ = 3 wire

THROUGH THE BULKHEAD - every wire that lands on the DRB102 (signals, sensor rails, feeds)

ECU-A - Link GAS plug A (centre dash)

A	Injector 4 drive (-)	wire_ecu_a_01.0r.b1
B	Injector 3 drive (-)	wire_ecu_a_02.0r.b1
C	Injector 2 drive (-)	wire_ecu_a_03.0r.b1
D	Injector 1 drive (-)	wire_ecu_a_04.0r.b1
E	Crank sensor signal	wire_ecu_a_05.0r.b1
F	Cam 4 trigger (EST)	wire_ecu_a_06.0r.b1
G	Cam 3 trigger (EST)	wire_ecu_a_07.0r.b1
H	Cam 2 trigger (EST)	wire_ecu_a_08.0r.b1
J	Cam 1 trigger (EST)	wire_ecu_a_09.0r.b1
K	Coolant temp signal	wire_ecu_a_10.0r.b1
L	Coolant temp gnd	wire_ecu_a_11.0r.b1
M	MAP sensor signal	wire_ecu_a_12.0r.b1
N	Knock sensor(+)	wire_ecu_a_13.0r.b1
P	Knock sensor shield	wire_ecu_a_14.0r.b1
R	EWPS pump speed	wire_ecu_a_15.0r.b1
S	Turbo speed signal	wire_ecu_a_16.0r.b1
T	Turbo speed gnd	wire_ecu_a_17.0r.b1
U	Throttle pot 2 sdc	wire_ecu_a_18.0r.b1

ECU-B (Link GAS plug B, centre dash)

A	12V ACC	wire_ecu_b_01.0r.b2
B	12V ACC	wire_ecu_b_02.0r.b2
C	12V ACC	wire_ecu_b_03.0r.b2
D	12V ACC	wire_ecu_b_04.0r.b2
E	12V ACC	wire_ecu_b_05.0r.b2
F	12V ACC	wire_ecu_b_06.0r.b2
G	12V ACC	wire_ecu_b_07.0r.b2
H	12V ACC	wire_ecu_b_08.0r.b2
J	12V ACC	wire_ecu_b_09.0r.b2
K	12V ACC	wire_ecu_b_10.0r.b2
L	12V ACC	wire_ecu_b_11.0r.b2
M	12V ACC	wire_ecu_b_12.0r.b2
N	12V ACC	wire_ecu_b_13.0r.b2
P	12V ACC	wire_ecu_b_14.0r.b2
R	12V ACC	wire_ecu_b_15.0r.b2
S	12V ACC	wire_ecu_b_16.0r.b2
T	12V ACC	wire_ecu_b_17.0r.b2
U	12V ACC	wire_ecu_b_18.0r.b2

DRB102 CABIN - DRB102 receptacle (RH firewall)

A	Cam 4 trigger (EST)	wire_ecu_a_06.0r.b1
B	Cam 3 trigger (EST)	wire_ecu_a_07.0r.b1
C	Cam 2 trigger (EST)	wire_ecu_a_08.0r.b1
D	Cam 1 trigger (EST)	wire_ecu_a_09.0r.b1
E	Coolant temp signal	wire_ecu_a_10.0r.b1
F	Coolant temp gnd	wire_ecu_a_11.0r.b1
G	MAP sensor signal	wire_ecu_a_12.0r.b1
H	Knock sensor(+)	wire_ecu_a_13.0r.b1
J	Knock sensor shield	wire_ecu_a_14.0r.b1
K	Dist 5v + MAP	wire_ecu_a_15.0r.b1
L	Dist sensor gnd	wire_ecu_a_16.0r.b1
M	Hall/opt 3 drive (-)	wire_ecu_a_17.0r.b1
N	Hall/opt 3 sense (+)	wire_ecu_a_18.0r.b1
P	+5 V stabd primary	wire_ecu_b_01.0r.b2
R	Crankcl press signal	wire_ecu_b_02.0r.b2
S	Crankcl press gnd	wire_ecu_b_03.0r.b2
T	Dist sh/ch/trans	wire_ecu_b_04.0r.b2
U	Dist sh/ch/trans	wire_ecu_b_05.0r.b2
V	Cam 4 sensor (LOOC 5W)/12.7.6 fuse	wire_ecu_b_06.0r.b2
W	Cam gnd	wire_ecu_b_07.0r.b2
X	Throttle pot 1 sdc	wire_ecu_b_08.0r.b2
Y	Throttle pot 1 sig	wire_ecu_b_09.0r.b2
Z	+5 V stabd primary	wire_ecu_b_10.0r.b2
a	Throttle pot 2 sig	wire_ecu_b_11.0r.b2
b	Throttle pot 2 sdc	wire_ecu_b_12.0r.b2
c	Throttle pot 2 sig	wire_ecu_b_13.0r.b2
d	Throttle pot 1 sdc	wire_ecu_b_14.0r.b2
e	Throttle pot 1 sig	wire_ecu_b_15.0r.b2
f	Throttle pot 2 sdc	wire_ecu_b_16.0r.b2
g	Throttle pot 2 sig	wire_ecu_b_17.0r.b2
h	Throttle pot 1 sdc	wire_ecu_b_18.0r.b2

SHIELD GROUND - 10 AWG/14 AWG

1	Shield drain	wire_shield_drain_01.0r.b3
2	Shield drain	wire_shield_drain_02.0r.b3
3	Shield drain	wire_shield_drain_03.0r.b3
4	Shield drain	wire_shield_drain_04.0r.b3
5	Shield drain	wire_shield_drain_05.0r.b3
6	Shield drain	wire_shield_drain_06.0r.b3
7	Shield drain	wire_shield_drain_07.0r.b3
8	Shield drain	wire_shield_drain_08.0r.b3
9	Shield drain	wire_shield_drain_09.0r.b3
10	Shield drain	wire_shield_drain_10.0r.b3
11	Shield drain	wire_shield_drain_11.0r.b3
12	Shield drain	wire_shield_drain_12.0r.b3
13	Shield drain	wire_shield_drain_13.0r.b3
14	Shield drain	wire_shield_drain_14.0r.b3
15	Shield drain	wire_shield_drain_15.0r.b3
16	Shield drain	wire_shield_drain_16.0r.b3
17	Shield drain	wire_shield_drain_17.0r.b3
18	Shield drain	wire_shield_drain_18.0r.b3

SP-SHIELD-A - 6 mm behind the ECU-A plug - SP-SHIELD-A: drai...

1	Shield drain	wire_shield_drain_01.0r.b3
2	Shield drain	wire_shield_drain_02.0r.b3
3	Cam sensor shield	wire_shield_drain_03.0r.b3
4	Cam sensor shield	wire_shield_drain_04.0r.b3
5	Flex fuel shield	wire_shield_drain_05.0r.b3
6	Throttle shield	wire_shield_drain_06.0r.b3

SP-SHIELD-B - 6 mm behind the ECU-B plug - SP-SHIELD-B: drai...

1	Knock sensor shield	wire_shield_drain_07.0r.b3
2	TPS master shield	wire_shield_drain_08.0r.b3
3	Throttle pot 1 shield	wire_shield_drain_09.0r.b3
4	Throttle pot 2 shield	wire_shield_drain_10.0r.b3
5	Shield drain B	wire_shield_drain_11.0r.b3
6	Shield drain B	wire_shield_drain_12.0r.b3

SP-SHIELD-B-MAP - At the rear MS inline - SP-SHIELD-B-MAP: s...

1	MS-III screen drain	wire_shield_drain_13.0r.b3
2	Shield drain B	wire_shield_drain_14.0r.b3

SP-SHIELD-B-MSP - At the rear MS inline - SP-SHIELD-B-MSP: s...

1	Shield drain	wire_shield_drain_15.0r.b3
2	MS-III screen drain	wire_shield_drain_16.0r.b3
3	Shield drain B	wire_shield_drain_17.0r.b3

SP-SHIELD-A-APS - At the pedal branch - SP-SHIELD-A-APS: pas...

1	Shield drain	wire_shield_drain_18.0r.b3
2	Pedal 1 cable shield	wire_apc_sh_screen
3	Pedal 2 cable shield	wire_apc_sh_screen

ENGINE BAY - DRB102 ENGINE HALF TO EVERY ENGINE DEVICE (ECU HARNESS)

SP-CHASSIS-ENG - Coil ground splice - Engine block ground strut (RAISLOW engine gro...

A	Coil 4 ground	wire_coil_04_gnd
B	Coil 3 ground	wire_coil_03_gnd
C	Coil 2 ground	wire_coil_02_gnd
D	Coil 1 ground	wire_coil_01_gnd
E	Coil ground	wire_coil_gnd

SP-ENG-END - Coil +12 V splice - BH-A pin 3 (LOOC COP 15...

A	BH-A key_A_off +/-LOOC COP 15 A fuse	wire_coil_bh_01.0r.b1
B	BH key_A_off +/-LOOC COP 15 A fuse	wire_coil_bh_02.0r.b1
C	BH key_A_off +/-LOOC COP 15 A fuse	wire_coil_bh_03.0r.b1
D	BH key_A_off +/-LOOC COP 15 A fuse	wire_coil_bh_04.0r.b1

SP-CRANKSHAFT-ENG - Sensor return splice - all-wing and cha...

A	Dual charge temp	wire_dual_charge_temp
B	Dual charge temp	wire_dual_charge_temp
C	Dual charge temp	wire_dual_charge_temp

SP-CRANKSHAFT-ENG - Sensor return splice - BH-B pin 10 (C...

A	Dual distributorless	wire_dual_distributorless
B	Dual distributorless	wire_dual_distributorless
C	Dual distributorless	wire_dual_distributorless
D	Dual charge temp	wire_dual_charge_temp

SP-CRANKSHAFT-ENG - Sensor return splice - BH-A pin 10 (C...

A	Dual coil 5/TPS/resolver	wire_dual_coil_5_tps_resolver
B	Dual flex fuel	wire_dual_flex_fuel
C	Dual throttle sensor	wire_dual_throttle_sensor
D	Dual throttle sensor	wire_dual_throttle_sensor

SP-BH-END - Injector +12 V splice - BH-A pin 2 (LOOC INJ 2...

A	BH key_A_off +/-LOOC INJ 15 A fuse	wire_inj_bh_01.0r.b1
B	BH key_A_off +/-LOOC INJ 15 A fuse	wire_inj_bh_02.0r.b1
C	BH key_A_off +/-LOOC INJ 15 A fuse	wire_inj_bh_03.0r.b1
D	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_04.0r.b1

SP-ENG-B - CAN-Lambda +12 V splice - 12 AWG from BH...

A	LoCAN-Lambda +12 V power	wire_lambda_power
B	LoCAN-Lambda ground	wire_lambda_gnd

SP-ENG-END - Switched +12 V splice - BH-A pin 15 (LOOC ...

A	BH key_A_off +/-LOOC INJ 15 A fuse	wire_inj_bh_05.0r.b1
B	BH key_A_off +/-LOOC INJ 15 A fuse	wire_inj_bh_06.0r.b1
C	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_07.0r.b1

DRB102 ENGINE - ECU-A/ECU-B

A	BH key_A_off +/-LOOC COP 15 A fuse	wire_coil_bh_01.0r.b1
B	BH key_A_off +/-LOOC INJ 15 A fuse	wire_inj_bh_05.0r.b1
C	Coil 4 trigger (EST)	wire_ecu_a_06.0r.b1
D	Coil 3 trigger (EST)	wire_ecu_a_07.0r.b1
E	Coil 2 trigger (EST)	wire_ecu_a_08.0r.b1
F	Coil 1 trigger (EST)	wire_ecu_a_09.0r.b1
G	+5 V fuel pressure	wire_ecu_b_01.0r.b2
H	Fuel pressure signal	wire_ecu_b_02.0r.b2
J	Fuel pressure gnd	wire_ecu_b_03.0r.b2
K	Hall/opt 3 drive (-)	wire_ecu_a_17.0r.b1
L	Hall/opt 3 sense (+)	wire_ecu_a_18.0r.b1
M	Dist 5v + MAP	wire_ecu_a_15.0r.b1
N	MAP sensor signal	wire_ecu_a_12.0r.b1
P	Dist sensor gnd	wire_ecu_a_16.0r.b1
R	Crankcl press signal	wire_ecu_b_02.0r.b2
S	Crankcl press gnd	wire_ecu_b_03.0r.b2
T	Dist sh/ch/trans	wire_ecu_b_04.0r.b2
U	Dist sh/ch/trans	wire_ecu_b_05.0r.b2
V	Cam 4 sensor (LOOC 5W)/12.7.6 fuse	wire_ecu_b_06.0r.b2
W	Cam gnd	wire_ecu_b_07.0r.b2
X	Throttle pot 1 sdc	wire_ecu_b_08.0r.b2
Y	Throttle pot 1 sig	wire_ecu_b_09.0r.b2
Z	+5 V stabd primary	wire_ecu_b_10.0r.b2
a	Throttle pot 2 sig	wire_ecu_b_11.0r.b2
b	Throttle pot 2 sdc	wire_ecu_b_12.0r.b2
c	Throttle pot 2 sig	wire_ecu_b_13.0r.b2
d	Throttle pot 1 sdc	wire_ecu_b_14.0r.b2
e	Throttle pot 1 sig	wire_ecu_b_15.0r.b2
f	Throttle pot 2 sdc	wire_ecu_b_16.0r.b2
g	Throttle pot 2 sig	wire_ecu_b_17.0r.b2
h	Throttle pot 1 sdc	wire_ecu_b_18.0r.b2

ENG-END-RING - Engine block ground stud (RAISLOW engine gro...

A	Coil ground	wire_coil_gnd

CGIL-1 - CGP-1 (LCC)

A	BH key_A_off +/-LOOC COP 15 A fuse	wire_coil_bh_02.0r.b1
B	Cam 1 trigger (EST)	wire_ecu_a_09.0r.b1
C	Cam 1 signal (HEI)	wire_ecu_a_05.0r.b1

SP-CHASSIS-END - Chassis ground splice - SP-CHASSIS-END: ...

A	Coil ground	wire_coil_gnd
B	Dual distributorless	wire_dual_distributorless
C	Dual charge temp	wire_dual_charge_temp
D	Dual throttle sensor	wire_dual_throttle_sensor
E	Throttle pot 1 sdc	wire_ecu_b_14.0r.b2
F	Flex fuel signal	wire_ecu_a_18.0r.b1
G	Knock sensor signal	wire_ecu_a_13.0r.b1
H	Knock sensor shield	wire_ecu_a_14.0r.b1
J	Crank sensor signal	wire_ecu_a_05.0r.b1
K	Crank sensor shield	wire_ecu_a_04.0r.b1
L	Flex fuel shield	wire_shield_drain_05.0r.b3
M	Throttle shield	wire_shield_drain_06.0r.b3
N	+5 V hall/opt primary	wire_ecu_b_10.0r.b2
P	+5 V hall/opt sensor	wire_ecu_a_17.0r.b1
R	Hall/opt 3 sense (+)	wire_ecu_a_18.0r.b1
S	Turbo speed signal	wire_ecu_a_16.0r.b1
T	Turbo speed shield	wire_shield_drain_18.0r.b3
U	Turbo speed gnd	wire_ecu_a_17.0r.b1
V	Turbo speed(+)	wire_ecu_a_18.0r.b1
W	Turbo speed shield	wire_shield_drain_17.0r.b3
X	Oil temp signal	wire_ecu_b_01.0r.b2
Y	Oil temp gnd	wire_ecu_b_02.0r.b2
Z	Cam sensor signal	wire_cam_sensor_signal
a	Cam sensor shield	wire_cam_sensor_shield
b	Crankcl press signal	wire_ecu_b_02.0r.b2
c	Crankcl press gnd	wire_ecu_b_03.0r.b2
d	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_04.0r.b1
e	Coil/cam/dist shield	wire_coil_cam_dist_shield
f	Coil/cam/dist gnd	wire_coil_cam_dist_gnd
g	Coil/cam/dist gnd	wire_coil_cam_dist_gnd
h	Coil/cam/dist gnd	wire_coil_cam_dist_gnd

SP-ENG-END - Coil +12 V splice - BH-A pin 3 (LOOC COP 15...

A	BH key_A_off +/-LOOC COP 15 A fuse	wire_coil_bh_03.0r.b1
B	Coil 4 trigger (EST)	wire_ecu_a_06.0r.b1
C	Coil 4 signal (HEI)	wire_ecu_a_04.0r.b1

CGIL-2 - CGP-2 (RCC)

A	BH key_A_off +/-LOOC COP 15 A fuse	wire_coil_bh_04.0r.b1
B	Cam 2 trigger (EST)	wire_ecu_a_08.0r.b1
C	Cam 2 signal (HEI)	wire_ecu_a_03.0r.b1

SP-CHASSIS-END - Chassis ground splice - BH-B pin 10 (C...

A	Dual distributorless	wire_dual_distributorless
B	Dual throttle sensor	wire_dual_throttle_sensor
C	Throttle pot 2 sdc	wire_ecu_b_12.0r.b2
D	Throttle pot 2 sig	wire_ecu_b_13.0r.b2
E	Knock sensor shield	wire_ecu_a_14.0r.b1
F	Knock sensor signal	wire_ecu_a_13.0r.b1
G	Crank sensor signal	wire_ecu_a_05.0r.b1
H	Crank sensor shield	wire_ecu_a_04.0r.b1
J	Cam sensor signal	wire_cam_sensor_signal
K	Cam sensor shield	wire_cam_sensor_shield
L	Flex fuel signal	wire_ecu_a_18.0r.b1
M	Flex fuel shield	wire_shield_drain_05.0r.b3
N	Oil temp signal	wire_ecu_b_01.0r.b2
P	Oil temp gnd	wire_ecu_b_02.0r.b2
R	Cam sensor signal	wire_cam_sensor_signal
S	Cam sensor shield	wire_cam_sensor_shield
T	Throttle pot 1 sig	wire_ecu_b_09.0r.b2
U	Throttle pot 1 sdc	wire_ecu_b_14.0r.b2
V	Coil/cam/dist shield	wire_coil_cam_dist_shield
W	Coil/cam/dist gnd	wire_coil_cam_dist_gnd
X	Coil/cam/dist gnd	wire_coil_cam_dist_gnd
Y	Coil/cam/dist gnd	wire_coil_cam_dist_gnd

A-TERM - Start Relay (mounted in the POWER box RS - ACTIVE)

86	Hall 200 A fuse + start relay 86	wire_hall_ac_86.0r.b2

A-CLUSTER - ignition + cruise on CGEC

A	ACC power feeds	wire_acc_a_01.0r.b2

A-FUEL/LVL - 47/9 fuel level pull-up to +5V

A	+5 V fuel pressure	wire_ecu_b_01.0r.b2

SP-ENG-ECU - ECU splice point - SP-ENG-ECU: ECU power gros...

A	ECU power feeds	wire_ecu_a_01.0r.b2
B	ECU power feeds	wire_ecu_a_02.0r.b2
C	ECU power feeds	wire_ecu_a_03.0r.b2
D	ECU power feeds	wire_ecu_a_04.0r.b2

SP-ENG-B - Injector splice - SP-ENG-B: switched +12 V (LOOC S...

A	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_06.0r.b1
B	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_07.0r.b1

BUS-DASH/OT-A - DTR6 12 plug (ECU splice point)

A	+5 V fuel pressure	wire_ecu_b_01.0r.b2
B	Fuel pressure signal	wire_ecu_b_02.0r.b2
C	Fuel pressure gnd	wire_ecu_b_03.0r.b2

SP-ENG-ECU - ECU splice point - SP-ENG-ECU: switched +12 V (LOOC S...

A	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_08.0r.b1
B	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_09.0r.b1

BUS-DASH/OT-A - DTR6 12 plug (ECU splice point)

A	+5 V fuel pressure	wire_ecu_b_01.0r.b2
B	Fuel pressure signal	wire_ecu_b_02.0r.b2
C	Fuel pressure gnd	wire_ecu_b_03.0r.b2

BUS-DASH/OT-B - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

SP-ENG-ECU - ECU splice point - SP-ENG-ECU: switched +12 V (LOOC S...

A	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_10.0r.b1
B	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_11.0r.b1

BUS-DASH/OT-A - DTR6 12 plug (ECU splice point)

A	+5 V fuel pressure	wire_ecu_b_01.0r.b2
B	Fuel pressure signal	wire_ecu_b_02.0r.b2
C	Fuel pressure gnd	wire_ecu_b_03.0r.b2

BUS-DASH/OT-B - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

D-ICE MAKE - ICE valve diode (JAN802)

1	ICE valve feed	wire_ice_valve_feed
2	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_12.0r.b1

BUS-DASH/OT-A - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

BUS-DASH/OT-B - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

D-ICE MAKE - ICE valve diode (JAN802)

1	ICE valve feed	wire_ice_valve_feed
2	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_13.0r.b1

SP-ENG-ECU - ECU splice point - SP-ENG-ECU: switched +12 V (LOOC S...

A	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_14.0r.b1
B	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_15.0r.b1

BUS-DASH/OT-A - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

BUS-DASH/OT-B - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

D-ICE MAKE - ICE valve diode (JAN802)

1	ICE valve feed	wire_ice_valve_feed
2	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_16.0r.b1

SP-ENG-ECU - ECU splice point - SP-ENG-ECU: switched +12 V (LOOC S...

A	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_17.0r.b1
B	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_18.0r.b1

BUS-DASH/OT-A - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

BUS-DASH/OT-B - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

D-ICE MAKE - ICE valve diode (JAN802)

1	ICE valve feed	wire_ice_valve_feed
2	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_19.0r.b1

SP-ENG-ECU - ECU splice point - SP-ENG-ECU: switched +12 V (LOOC S...

A	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_20.0r.b1
B	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_21.0r.b1

BUS-DASH/OT-A - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

BUS-DASH/OT-B - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

D-ICE MAKE - ICE valve diode (JAN802)

1	ICE valve feed	wire_ice_valve_feed
2	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_22.0r.b1

SP-ENG-ECU - ECU splice point - SP-ENG-ECU: switched +12 V (LOOC S...

A	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_23.0r.b1
B	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_24.0r.b1

BUS-DASH/OT-A - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

BUS-DASH/OT-B - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

D-ICE MAKE - ICE valve diode (JAN802)

1	ICE valve feed	wire_ice_valve_feed
2	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_25.0r.b1

SP-ENG-ECU - ECU splice point - SP-ENG-ECU: switched +12 V (LOOC S...

A	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_26.0r.b1
B	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_27.0r.b1

BUS-DASH/OT-A - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

BUS-DASH/OT-B - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

D-ICE MAKE - ICE valve diode (JAN802)

1	ICE valve feed	wire_ice_valve_feed
2	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_28.0r.b1

SP-ENG-ECU - ECU splice point - SP-ENG-ECU: switched +12 V (LOOC S...

A	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_29.0r.b1
B	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_30.0r.b1

BUS-DASH/OT-A - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

BUS-DASH/OT-B - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

D-ICE MAKE - ICE valve diode (JAN802)

1	ICE valve feed	wire_ice_valve_feed
2	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_31.0r.b1

SP-ENG-ECU - ECU splice point - SP-ENG-ECU: switched +12 V (LOOC S...

A	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_32.0r.b1
B	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_33.0r.b1

BUS-DASH/OT-A - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

BUS-DASH/OT-B - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

D-ICE MAKE - ICE valve diode (JAN802)

1	ICE valve feed	wire_ice_valve_feed
2	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_34.0r.b1

SP-ENG-ECU - ECU splice point - SP-ENG-ECU: switched +12 V (LOOC S...

A	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_35.0r.b1
B	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_36.0r.b1

BUS-DASH/OT-A - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

BUS-DASH/OT-B - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

D-ICE MAKE - ICE valve diode (JAN802)

1	ICE valve feed	wire_ice_valve_feed
2	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_37.0r.b1

SP-ENG-ECU - ECU splice point - SP-ENG-ECU: switched +12 V (LOOC S...

A	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_38.0r.b1
B	BH key_A_off +/-LOOC INJ 7.5 A fuse	wire_inj_bh_39.0r.b1

BUS-DASH/OT-A - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

BUS-DASH/OT-B - DTR6 12 plug (ECU splice point)

A	+5 V flex fuel	wire_ecu_a_18.0r.b1
B	Flex fuel signal	wire_ecu_a_18.0r.b1
C	Flex fuel shield	wire_shield_drain_05.0r.b3

D-ICE MAKE - ICE valve diode (JAN802)

1	ICE valve feed	wire_ice_valve_feed
2	BH key_A_off +/-LOOC INJ 7.5 A fuse	w