SCHEMATIC - every wire of the set, grouped by job; read, not to scale
Cables are grouped by job (engine bay / dash / doors / roof / boot / underfloor / CAN / earths). Wire colour: (black banding). Dashed = built with the harness marked in its table; grey header = an end on another harness.
WIRE COLOUR CODES: BK/WH = black/white · BK/RD = black/red · BK/BU = black/blue · BK/GN = black/green · BK/YE = black/yellow · BK/GY = black/grey · BK/OR = black/orange · BK/VT = black/violet · BK/BN = black/brown · WH/BK = white/black · WH/RD = white/red · WH/BU = white/blue · WH/GN = white/green · WH/YE = white/yellow · WH/GY = white/grey · WH/OR = white/orange · WH/VT = white/violet · WH/BN = white/brown · RD/BK = red/black · RD/WH = red/white · RD/BU = red/blue · RD/GN = red/green · RD/YE = red/yellow · RD/GY = red/grey · RD/OR = red/orange · RD/VT = red/violet · RD/BN = red/brown · BU/BK = blue/black · BU/WH = blue/white · BU/RD = blue/red · BU/GN = blue/green · BU/YE = blue/yellow · BU/GY = blue/grey · BU/OR = blue/orange · BU/VT = blue/violet · BU/BN = blue/brown · GN/BK = green/black · GN/WH = green/white · GN/RD = green/red · GN/BU = green/blue · GN/YE = green/yellow · GN/GY = green/grey · GN/OR = green/orange · GN/VT = green/violet · GN/BN = green/brown · YE/BK = yellow/black · YE/WH = yellow/white · YE/RD = yellow/red · YE/BU = yellow/blue · YE/GN = yellow/green · YE/GY = yellow/grey · YE/OR = yellow/orange · YE/VT = yellow/violet · YE/BN = yellow/brown · GY/BK = grey/black · GY/WH = grey/white · GY/RD = grey/red · GY/BU = grey/blue · GY/GN = grey/green · GY/YE = grey/yellow · GY/OR = grey/orange · GY/VT = grey/violet · GY/BN = grey/brown · OR/BK = orange/black · OR/WH = orange/white · OR/RD = orange/red · OR/BU = orange/blue · OR/GN = orange/green · OR/YE = orange/yellow · OR/GY = orange/grey · OR/VT = orange/violet · OR/BN = orange/brown · VT/BK = violet/black · VT/WH = violet/white · VT/RD = violet/red · VT/BU = violet/blue · VT/GN = violet/green · VT/YE = violet/yellow · VT/GY = violet/grey · VT/OR = violet/orange · VT/BN = violet/brown · BN/BK = brown/black · BN/WH = brown/white · BN/RD = brown/red · BN/BU = brown/blue · BN/GN = brown/green · BN/YE = brown/yellow · BN/GY = brown/grey · BN/OR = brown/orange · BN/VT = brown/violet
BOLD = 2.5 mm² · thin = 1.5 mm² · dashed = built with the marked harness · ■ Red ■ Yellow ■ Grey · = = = built with another harness

THROUGH THE BULKHEAD - every wire that lands on the DRB102 (signals, sensor rails, feeds)

ECU A - Link G4X plug A (centre duct)

1	Injector 3 drive (↓)	wt/yl_c
2	Injector 4 drive (↓)	wt/gn_c
3	Injector 2 drive (↓)	wt/bu_c
4	Injector 1 drive (↓)	wt/rd_c
5	Crank sensor signal	wt/bk_c
6	Coil 4 trigger (IGT)	wt/yl_c
7	Coil 3 trigger (IGT)	wt/gn_c
8	Coil 2 trigger (IGT)	wt/bu_c
9	Coil 1 trigger (IGT)	wt/rd_c
10	Coolant temp signal	wt/bk_c
11	Fuel level signal	wt/gy_c
12	Fuel temp signal	wt/vt_c
13	Knock sensor (↑)	wt/bn_c
14	Knock sensor (↓)	wt/or_c
15	DVP3 pump signal	wt/wh_c
16	Turbo speed signal	wt/gy_c
17	Boost sensor (↑)	wt/vt_c
18	Throttle pot 2 (↓)	wt/bn_c

ECU B (Link G4X plug B, centre duct)

1	TP temp signal	wt/bk_c
2	Throttle pot 1 (↑)	wt/wh_c
3	Knock sensor signal	wt/or_c
4	Oil pressure signal	wt/yl_c
5	Map sensor signal	wt/gn_c
6	Air temp signal	wt/bu_c
7	ETB motor (↑)	wt/rd_c
8	Ignition switch signal	wt/bk_c

BUS 01 - DTM-12 plug (ECU splice point)

1	ECU 5 Volts+ sensor	A_wt_bk_c
2	+5 V MAF sensor	A_bu_c_bk
3	+5 V TPS sensor	A_gn_c_bk
4	+5 V oil pressure	A_yl_c_bk
5	+5 V fuel pressure	A_bu_c_wt
6	+5 V coolant press.	A_gn_c_wt

BUS 02 - DTM-12 plug (ECU splice point)

1	Coil 4 ECU control	A_wt_gn/yl_c
2	Coil 3 ECU control	A_wt_yl/bu_c
3	Coil 2 ECU control	A_wt_gn/rd_c
4	Coil 1 ECU control	A_wt_yl/rd_c
5	Inj 4 ECU control	A_wt_gn/bu_c
6	Inj 3 ECU control	A_wt_yl/bu_c
7	Inj 2 ECU control	A_wt_gn/rd_c
8	Inj 1 ECU control	A_wt_yl/rd_c

BUS 03 - DTM-12 plug (ECU splice point)

1	Crank sensor screen	A_bk_c
2	Cam sensor signal	A_wt_bk_c
3	Cam sensor screen	A_bk_c
4	Crank sensor signal	A_wt_bk_c

BUS 04 - DTM-12 plug (ECU splice point)

1	Sensor ground A	A_bk_c
2	Sensor ground B	A_bk_c
3	Sensor ground C	A_bk_c
4	Sensor ground D	A_bk_c

BUS 05 - DTM-12 plug (ECU splice point)

1	Inj 6 ECU control	A_wt_gn/wh_c
2	Inj 5 ECU control	A_wt_yl/wh_c
3	Inj 8 ECU control	A_wt_gn/gy_c
4	Inj 7 ECU control	A_wt_yl/gy_c
5	Coil 6 ECU control	A_wt_gn/vt_c
6	Coil 5 ECU control	A_wt_yl/vt_c
7	Coil 8 ECU control	A_wt_gn/bn_c
8	Coil 7 ECU control	A_wt_yl/bn_c

BUS 06 - DTM-12 plug (ECU splice point)

1	Sensor ground E	A_bk_c
2	Sensor ground F	A_bk_c
3	Sensor ground G	A_bk_c
4	Sensor ground H	A_bk_c

SP-GND-ENG - Coil 4 splice - BH-A pin 1 (LOOSE CSP 15...

1	Coil 4 power (LOOSE CSP 15)	A_rd_wt/gn_c
2	EFI relay 5, eff = LOOSE CSP 15 A fuse	wt/rd_c
3	EFI relay 5, eff = LOOSE CSP 15 A fuse	wt/rd_c
4	EFI relay 5, eff = LOOSE CSP 15 A fuse	wt/rd_c

SP-GNDOUT-ENG1 - Sensor return splice - BH-A pin 24 (ECU...

1	Coil charge temp	A_wt/bk_c
2	Coil charge temp	A_wt/bk_c
3	Coil charge temp	A_wt/bk_c

SP-GNDOUT-ENG2 - Sensor return splice - BH-B pin 20 (E...

1	Fuel distributor	A_wt/bk_c
2	Fuel distributor	A_wt/bk_c
3	Fuel distributor	A_wt/bk_c
4	Fuel distributor	A_wt/bk_c

SP-GNDOUT-ENG3 - Sensor return splice - BH-A pin 10 (ECU...

1	Coil 4 PTP/crankshaft	A_wt/bk_c
2	Coil 4 PTP/crankshaft	A_wt/bk_c
3	Grid throttle sensor	A_wt/bk_c
4	Grid throttle sensor	A_wt/bk_c

SP-BU-ENG1 - Injector +12 V splice - BH-A pin 3 (LOOSE INJ 1...

1	EFI relay 5, eff = LOOSE INJ 1/2 A fuse	wt/bu_c
2	EFI relay 5, eff = LOOSE INJ 1/2 A fuse	wt/bu_c
3	EFI relay 5, eff = LOOSE INJ 1/2 A fuse	wt/bu_c
4	EFI relay 5, eff = LOOSE INJ 1/2 A fuse	wt/bu_c

SP-LAMG-B - CAN-Lambda ground splice - 12 AWG from BH...

1	EFI relay 5, eff = LOOSE CAN 7.5 A fuse	wt/bk_c
2	EFI relay 5, eff = LOOSE CAN 7.5 A fuse	wt/bk_c

SP-BU-ENG2 - Injector +12 V splice - BH-A pin 13 (LOOSE INJ 3...

1	EFI relay 5, eff = LOOSE INJ 3/4 A fuse	wt/bu_c
2	EFI relay 5, eff = LOOSE INJ 3/4 A fuse	wt/bu_c
3	EFI relay 5, eff = LOOSE INJ 3/4 A fuse	wt/bu_c
4	EFI relay 5, eff = LOOSE INJ 3/4 A fuse	wt/bu_c

DRB102 CABIN - DRB102 receptacle (RH firewall)

1	Coil 4 trigger (IGT)	wt/yl_c
2	Coil 3 trigger (IGT)	wt/gn_c
3	Coil 2 trigger (IGT)	wt/bu_c
4	Coil 1 trigger (IGT)	wt/rd_c
5	Crank sensor signal	wt/bk_c
6	Cam sensor signal	wt/wh_c
7	Coolant temp signal	wt/gy_c
8	Fuel level signal	wt/vt_c
9	Fuel temp signal	wt/bn_c
10	Knock sensor (↑)	wt/or_c
11	Knock sensor (↓)	wt/yl_c
12	DVP3 pump signal	wt/gn_c
13	Turbo speed signal	wt/bu_c
14	Boost sensor (↑)	wt/rd_c
15	Throttle pot 2 (↓)	wt/bk_c
16	Throttle pot 1 (↑)	wt/wh_c
17	Knock sensor signal	wt/or_c
18	Oil pressure signal	wt/yl_c
19	Map sensor signal	wt/gn_c
20	Air temp signal	wt/bu_c
21	ETB motor (↑)	wt/rd_c
22	Ignition switch signal	wt/bk_c
23	Coil 4 power (LOOSE CSP 15 A fuse	rd/wt_c
24	Coil 3 power (LOOSE INJ 1/2 A fuse	rd/wt_c
25	Coil 2 power (LOOSE INJ 3/4 A fuse	rd/wt_c
26	Coil 1 power (LOOSE INJ 3/4 A fuse	rd/wt_c
27	Grid fan + MAP	rd/bu_c
28	Grid fan + MAP	rd/bu_c
29	Injector 3 drive (↓)	wt/bu_c
30	Injector 4 drive (↓)	wt/gn_c
31	+5 V coolant press.	rd/bu_c
32	Coolant press signal	wt/bu_c
33	Oil pressure signal	wt/yl_c
34	Grid sensor screen	bk/wh_c
35	Grid sensor screen	bk/wh_c
36	Grid sensor screen	bk/wh_c
37	Grid sensor screen	bk/wh_c
38	Coolant press signal	wt/bu_c
39	Oil pressure signal	wt/yl_c
40	Fuel pressure signal	wt/bu_c
41	+5 V twin speed	rd/wh_c
42	Twin speed signal	wt/wh_c
43	Twin speed signal	wt/wh_c
44	Boost solenoid (↓)	wt/gy_c
45	Boost solenoid (↑)	wt/vt_c
46	Boost solenoid (↓)	wt/gy_c
47	EFI relay 5, eff = LOOSE CAN 7.5 A fuse	rd/wt_c
48	EFI relay 5, eff = LOOSE CAN 7.5 A fuse	rd/wt_c
49	Cam sensor signal	wt/wh_c
50	Cam sensor screen	bk/wh_c
51	Cam sensor shield	wt/wh_c
52	Coolant temp signal	wt/gy_c
53	Fuel temp signal	wt/vt_c
54	Gearbox speed (↑)	wt/bn_c
55	Knock sensor (↑)	wt/or_c
56	Knock sensor (↓)	wt/yl_c
57	Coils-Lambda shield	bk/wh_c
58	Coils-Lambda shield	bk/wh_c
59	Oil temp signal	wt/yl_c
60	Air temp signal	wt/gn_c
61	Throttle pot 2 sensor	wt/bn_c
62	Throttle pot 1 sensor	wt/wh_c
63	Reverse no +12 V out	wt/gy_c
64	Cold-Hi-Cmb-Lambda	wt/bu_c
65	Cold-Lo-Cmb-Lambda	wt/bk_c
66	Coils-Lambda shield	bk/wh_c
67	Oil temp signal	wt/yl_c
68	Air temp signal	wt/gn_c

ETACS/BCM/TRANSPO - Starter solenoid (+30) terminal post, s...

1	Starter solenoid S	rd/wt_c

ENG-GND-RING - Engine block ground stud (RADLOW engine gro...

1	Coil ground	A_bk/wh_c

CGNL-1 - CGP-1 (LCC)

1	EFI relay 5, eff = LOOSE CGP 15 A fuse	wt/rd_c
2	Coil 1 trigger (IGT)	wt/yl_c
3	Coil 1 power	rd/wt_c

CGNL-2 - CGP-2 (LCC)

1	EFI relay 5, eff = LOOSE CGP 15 A fuse	wt/rd_c
2	Coil 2 trigger (IGT)	wt/bu_c
3	Coil 2 power	rd/wt_c

CGNL-3 - CGP-3 (LCC)

1	EFI relay 5, eff = LOOSE CGP 15 A fuse	wt/rd_c
2	Coil 3 trigger (IGT)	wt/gn_c
3	Coil 3 power	rd/wt_c

CGNL-4 - CGP-4 (LCC)

1	EFI relay 5, eff = LOOSE CGP 15 A fuse	wt/rd_c
2	Coil 4 trigger (IGT)	wt/yl_c
3	Coil 4 power	rd/wt_c

SP-GNDOUT-ENG2 - Sensor return splice - BH-B pin 10 (E...

1	Grid throttle sensor	wt/bk_c
2	Grid throttle sensor	wt/bk_c
3	Grid throttle sensor	wt/bk_c
4	Grid throttle sensor	wt/bk_c

SP-BU-ENG3 - Injector +12 V splice - BH-A pin 23 (LOOSE INJ 2...

1	EFI relay 5, eff = LOOSE INJ 2/3 A fuse	wt/bu_c
2	EFI relay 5, eff = LOOSE INJ 2/3 A fuse	wt/bu_c
3	EFI relay 5, eff = LOOSE INJ 2/3 A fuse	wt/bu_c
4	EFI relay 5, eff = LOOSE INJ 2/3 A fuse	wt/bu_c

SP-LAMG-A - CAN-Lambda ground splice - 12 AWG from BH...

1	EFI relay 5, eff = LOOSE INJ 2/3 A fuse	wt/bk_c
2	EFI relay 5, eff = LOOSE INJ 2/3 A fuse	wt/bk_c

DRB102 ENGINE - BULKHEAD

1	Coil 4 trigger (IGT)	wt/yl_c
2	Coil 3 trigger (IGT)	wt/gn_c
3	Coil 2 trigger (IGT)	wt/bu_c
4	Coil 1 trigger (IGT)	wt/rd_c
5	Crank sensor signal	wt/bk_c
6	Cam sensor signal	wt/wh_c
7	Coolant temp signal	wt/gy_c
8	Fuel level signal	wt/vt_c
9	Fuel temp signal	wt/bn_c
10	Knock sensor (↑)	wt/or_c
11	Knock sensor (↓)	wt/yl_c
12	DVP3 pump signal	wt/gn_c
13	Turbo speed signal	wt/bu_c
14	Boost sensor (↑)	wt/rd_c
15	Throttle pot 2 (↓)	wt/bk_c
16	Throttle pot 1 (↑)	wt/wh_c
17	Knock sensor signal	wt/or_c
18	Oil pressure signal	wt/yl_c
19	Map sensor signal	wt/gn_c
20	Air temp signal	wt/bu_c
21	ETB motor (↑)	wt/rd_c
22	Ignition switch signal	wt/bk_c
23	Coil 4 power (LOOSE CSP 15 A fuse	rd/wt_c
24	Coil 3 power (LOOSE INJ 1/2 A fuse	rd/wt_c
25	Coil 2 power (LOOSE INJ 3/4 A fuse	rd/wt_c
26	Coil 1 power (LOOSE INJ 3/4 A fuse	rd/wt_c
27	Grid fan + MAP	rd/bu_c
28	Grid fan + MAP	rd/bu_c
29	Injector 3 drive (↓)	wt/bu_c
30	Injector 4 drive (↓)	wt/gn_c
31	+5 V coolant press.	rd/bu_c
32	Coolant press signal	wt/bu_c
33	Oil pressure signal	wt/yl_c
34	Grid sensor screen	bk/wh_c
35	Grid sensor screen	bk/wh_c
36	Grid sensor screen	bk/wh_c
37	Grid sensor screen	bk/wh_c
38	Coolant press signal	wt/bu_c
39	Oil pressure signal	wt/yl_c
40	Fuel pressure signal	wt/bu_c
41	+5 V twin speed	rd/wh_c
42	Twin speed signal	wt/wh_c
43	Twin speed signal	wt/wh_c
44	Boost solenoid (↓)	wt/gy_c
45	Boost solenoid (↑)	wt/vt_c
46	Boost solenoid (↓)	wt/gy_c
47	EFI relay 5, eff = LOOSE CAN 7.5 A fuse	rd/wt_c
48	EFI relay 5, eff = LOOSE CAN 7.5 A fuse	rd/wt_c
49	Cam sensor signal	wt/wh_c
50	Cam sensor screen	bk/wh_c
51	Cam sensor shield	wt/wh_c
52	Coolant temp signal	wt/gy_c
53	Fuel temp signal	wt/vt_c
54	Gearbox speed (↑)	wt/bn_c
55	Knock sensor (↑)	wt/or_c
56	Knock sensor (↓)	wt/yl_c
57	Coils-Lambda shield	bk/wh_c
58	Coils-Lambda shield	bk/wh_c
59	Oil temp signal	wt/yl_c
60	Air temp signal	wt/gn_c
61	Throttle pot 2 sensor	wt/bn_c
62	Throttle pot 1 sensor	wt/wh_c
63	Reverse no +12 V out	wt/gy_c
64	Cold-Hi-Cmb-Lambda	wt/bu_c
65	Cold-Lo-Cmb-Lambda	wt/bk_c
66	Coils-Lambda shield	bk/wh_c
67	Oil temp signal	wt/yl_c
68	Air temp signal	wt/gn_c

ENGINE BAY - DRB102 ENGINE HALF TO EVERY ENGINE DEVICE (ECU HARNESS)

CS03 - SWITCH INPUTS, CRUISE LADDER, OPTO BOARD

SW-CRUISE LADDER - Cruise ladder splice - stalk pin 5, to p...

1	Cruise ladder	A_wt/rd_c
2	Cruise ladder	A_wt/rd_c
3	Cruise ladder	A_wt/rd_c

SP-CSB-GND - CSB1 ground splice - CSB1 pin 1, spare board ...

1	CSB1 ground	A_bk/wh_c
2	Cruise cable ground	A_bk/wh_c
3	Cruise cable ground	A_bk/wh_c

CSB1 - ECUMaster CSB1 - PowerCAN/Switch I/O

1	EFI relay 5, eff = LOOSE CSB 7.5 A fuse	wt/rd_c
2	CAN 1 high	wt/vt_c
3	Opto in 1	A_wt/yl_c
4	Opto out ground	A_wt/bk_c
5	Opto in 2	A_wt/gn_c
6	Cruise MAIN set	A_wt/bu_c
7	Cruise RESUME set	A_wt/rd_c
8	Opto out +12 V	A_wt/wh_c
9	CAN 1 low	wt/gy_c

7-CLUSTER-HL - Centre cluster headlight-sense input (28 pi...

28	Headlight sense 3 (dim)	A_wt/rd_c

DRB shorter Harness RH pin 1 (left of the steering wheel)...

1	Lights on +12 V	A_wt/rd_c

DRB relay temp switch 50 pin 1 (pedal), O-W wire

1	Brake on +12 V	A_wt/rd_c

SW-CRUISE LADDER - Cruise ladder splice - stalk pin 6, to p...

1	Cruise ladder	A_wt/rd_c
2	Cruise ladder	A_wt/rd_c
3	Cruise ladder	A_wt/rd_c

SW-CRUISE - Cruise main switch C14 pin 5, W wire

5	Cruise ladder	A_wt/rd_c

SW-CRUISE - x cruise

1	Cruise ladder	A_wt/rd_c

SW-CRUISE - Cruise main switch C14 pin 17, BR wire

17	Cruise main power	A_rd/bn_c

SW-CRUISE - Cruise main switch C14 pin 15, YB wire

15	Cruise MAIN set	A_wt/yl_c

SW-CRUISE - Cruise main switch C14 pin 7, R wire

7	Cruise power out	A_rd/wh_c

SP-CSB-GND - CSB1 ground splice - CSB1 pin 2, spare board ...

1	CSB1 ground	A_bk/wh_c
2	Cruise cable ground	A_bk/wh_c
3	Cruise cable ground	A_bk/wh_c

SP-CAN-LAW - CAN 1 pin - bulkhead, Lambda, 120 ohm end

1	Lambda CAN 1 high	wt/vt_c
2	CAN 1 to CSB1	wt/vt_c
3	CAN 1 to Nodebox	wt/vt_c
4	CAN 1 to Nodebox	wt/vt_c

SP-CAN-LAW - CAN 1 pin - ECU, CSB1, cluster, PI, bulkhead

1	ECU 1 high	wt/vt_c
2	ECU 1/2/R CAN hi	wt/vt_c
3	CAN 1 to CSB1	wt/vt_c
4	CAN 1 to cluster	wt/vt_c
5	CAN 1 to Nodebox	wt/vt_c
6	CAN 1 to Nodebox PI	wt/vt_c

SP-CAN - CAN 1 pin - ECU, CSB1, cluster, PI, bulkhead

1	ECU 1 high	wt/vt_c
2	ECU 1/2/R CAN hi	wt/vt_c
3	CAN 1 to CSB1	wt/vt_c
4	CAN 1 to cluster	wt/vt_c
5	CAN 1 to Nodebox PI	wt/vt_c

SP-CAN-LAW - CAN 1 pin - bulkhead, Lambda, 120 ohm end

1	Lambda CAN 1 high	wt/vt_c
2	CAN 1 to CSB1	wt/vt_c

SP-CAN-LAW - CAN 1 pin - bulkhead, Lambda, 120 ohm end

1	Lambda CAN 1 high	wt/vt_c
2	CAN 1 to CSB1	wt/vt_c

SP-CAN-SH-CLU - CAN braids, cluster branch - SP-CAN-SH-CLU ...

1	ECU CAN screen bonds	bk/wh_c
2	ECU CAN shield	bk/wh_c
3	Cluster CAN shield	bk/wh_c
4	Cluster CAN screen	bk/wh_c
5	Nodebox CAN shield	bk/wh_c

SP-CAN-SH-RU - CAN trunk, RealDash PI branch - SP-CAN-SH-R...

1	PI CAN shield	bk/wh_c
2	CAN screen bonds	bk/wh_c

SP-SKV - Dash 12 V split - cluster + RealDash PI, center dash

1	Cluster ground	A_bk/wh_c
2	Nodebox ground	A_bk/wh_c
3	PI ground	A_bk/wh_c

DRB 40 way - HEAD RH splice - HR 12A fuse to HEAD RH relay pin...

1	Hdlt RH/LO 50 A fuse = LOOSE HR 12 A f...	A_rd/wh_c
2	Hdlt RH/LO 50 A fuse = LOOSE HR 12 A f...	A_rd/wh_c
3	Hdlt RH/LO 50 A fuse = LOOSE HR 12 A f...	A_rd/wh_c

SP-HC - HEAD LO splice - HL 15A fuse to HEAD LO relay pin...

1	Hdlt RH/LO 50 A fuse = LOOSE HL 15 A f...	A_rd/wh_c
2	Hdlt RH/LO 50 A fuse = LOOSE HL 15 A f...	A_rd/wh_c
3	Hdlt RH/LO 50 A fuse = LOOSE HL 15 A f...	A_rd/wh_c

SP-HORN - Horn feed splice - LH + RH horns, front centre...

1	Horn feed	A_rd/wh_c
2	Horn feed	A_rd/wh_c

SP-HORN-GND - Horn ground splice - LH + RH horns, front ce...

1	Horn ground	A_bk/wh_c
2	Horn ground	A_bk/wh_c

SP-HC - HEAD LO splice - HL 15A fuse to HEAD LO relay pin...

1	Hdlt RH/LO 50 A fuse = LOOSE HL 15 A f...	A_rd/wh_c
2	Hdlt RH/LO 50 A fuse = LOOSE HL 15 A f...	A_rd/wh_c
3	Hdlt RH/LO 50 A fuse = LOOSE HL 15 A f...	A_rd/wh_c

SP-HR - HEAD RH splice - HR 12A fuse to HEAD RH relay pin...

1	Hdlt RH/LO 50 A fuse = LOOSE HR 12 A f...	A_rd/wh_c
2	Hdlt RH/LO 50 A fuse = LOOSE HR 12 A f...	A_rd/wh_c
3	Hdlt RH/LO 50 A fuse = LOOSE HR 12 A f...	A_rd/wh_c

SP-HC - HAZ/HORN splice - HZ 15A fuse to the hazard feed s...

1	Hdlt RH/LO 50 A fuse = LOOSE HZ 15 A f...	A_rd/wh_c
2	Hdlt RH/LO 50 A fuse = LOOSE HZ 15 A f...	A_rd/wh_c
3	Hdlt RH/LO 50 A fuse = LOOSE HZ 15 A f...	A_rd/wh_c

SP-HZ - Alarm ignition splice - LOOSE ALMG 15 fuse to alar...

1	Hdlt RH/LO 50 A fuse = LOOSE ALMG 15 A...	A_rd/wh_c
2	Hdlt RH/LO 50 A fuse = LOOSE ALMG 15 A...	A_rd/wh_c
3	Hdlt RH/LO 50 A fuse = LOOSE ALMG 15 A...	A_rd/wh_c

DRB102 CABIN - DRB102 receptacle (RH firewall)

1	Coil 4 trigger (IGT)	wt/yl_c
2	Coil 3 trigger (IGT)	wt/gn_c
3	Coil 2 trigger (IGT)	wt/bu_c
4	Coil 1 trigger (IGT)	wt/rd_c
5	Crank sensor signal	wt/bk_c
6	Cam sensor signal	wt/wh_c
7	Coolant temp signal	wt/gy_c
8	Fuel level signal	wt/vt_c
9	Fuel temp signal	wt/bn_c
10	Knock sensor (↑)	wt/or_c
11	Knock sensor (↓)	wt/yl_c
12	DVP3 pump signal	wt/gn_c
13	Turbo speed signal	wt/bu_c
14	Boost sensor (↑)	wt/rd_c
15	Throttle pot 2 (↓)	wt/bk_c
16	Throttle pot 1 (↑)	wt/wh_c
17	Knock sensor signal	wt/or_c
18	Oil pressure signal	wt/yl_c
19	Map sensor signal	wt/gn_c
20	Air temp signal	wt/bu_c
21	ETB motor (↑)	wt/rd_c
22	Ignition switch signal	wt/bk_c
23	Coil 4 power (LOOSE CSP 15 A fuse	rd/wt_c
24	Coil 3 power (LOOSE INJ 1/2 A fuse	rd/wt_c
25	Coil 2 power (LOOSE INJ 3/4 A fuse	rd/wt_c
26	Coil 1 power (LOOSE INJ 3/4 A fuse	rd/wt_c
27	Grid fan + MAP	rd/bu_c
28	Grid fan + MAP	rd/bu_c
29	Injector 3 drive (↓)	wt/bu_c
30	Injector 4 drive (↓)	wt/gn_c
31	+5 V coolant press.	rd/bu_c
32	Coolant press signal	wt/bu_c
33	Oil pressure signal	wt/yl_c
34	Grid sensor screen	bk/wh_c
35	Grid sensor screen	bk/wh_c
36	Grid sensor screen	bk/wh_c
37	Grid sensor screen	bk/wh_c
38	Coolant press signal	wt/bu_c
39	Oil pressure signal	wt/yl_c
40	Fuel pressure signal	wt/bu_c
41	+5 V twin speed	rd/wh_c
42	Twin speed signal	wt/wh_c
43	Twin speed signal	wt/wh_c
44	Boost solenoid (↓)	wt/gy_c
45	Boost solenoid (↑)	wt/vt_c
46	Boost solenoid (↓)	wt/gy_c
47	EFI relay 5, eff = LOOSE CAN 7.5 A fuse	rd/wt_c
48	EFI relay 5, eff = LOOSE CAN 7.5 A fuse	rd/wt_c
49	Cam sensor signal	wt/wh_c
50	Cam sensor screen	bk/wh_c
51	Cam sensor shield	wt/wh_c
52	Coolant temp signal	wt/gy_c
53	Fuel temp signal	wt/vt_c
54	Gearbox speed (↑)	wt/bn_c
55	Knock sensor (↑)	wt/or_c
56	Knock sensor (↓)	wt/yl_c
57	Coils-Lambda shield	bk/wh_c
58	Coils-Lambda shield	bk/wh_c
59	Oil temp signal	wt/yl_c
60	Air temp signal	wt/gn_c
61	Throttle pot 2 sensor	wt/bn_c
62	Throttle pot 1 sensor	wt/wh_c
63	Reverse no +12 V out	wt/gy_c
64	Cold-Hi-Cmb-Lambda	wt/bu_c
65	Cold-Lo-Cmb-Lambda	wt/bk_c
66	Coils-Lambda shield	bk/wh_c
67	Oil temp signal	wt/yl_c
68	Air temp signal	wt/gn_c

ANTI-THEFT - ALARM MODULE, SIREN, TRIGGERS, STATUS LED

ECU-B (Link G4X plug B, centre duct)

12	Trans fault sens.	A_wt/wh/rd_c

SP-AT-CZV - Alarm +12 V splice - LOOSE ALM 5A fuse to alar...

1	Alarm +12 V feed - LOOSE ALM 5 A fuse	A_rd/wh_c

SP-DOOR - Door trigger splice - door courtesy switches to al...

1	Door trigger	A_wt/bk_c
2	Door trigger	A_wt/bk_c

SP-HOOD - Hood trigger splice - hood pin switch to alarm pi...

1	Hood pin	A_wt/bk_c

SP-IG - Alarm ignition splice - LOOSE ALMG 15 fuse to alar...

1	EFI relay 5, eff = LOOSE ALMG 7.5 fuse	A_rd/wh_c

SP-PARK - Park lights splice - alarm pin 8 to the park lamp rel...

1	Park lamp feed	A_wt/rd_c
2	Park lamp feed	A_wt/rd_c

SP-TRUNK - Trunk pin switch to alarm pi...

1	Trunk trigger	A_wt/bk_c
2	Trunk trigger	A_wt/bk_c

ANOCH ADM100R - Shock / tilt sensor *

1	12V ACC SO 10 A fuse = LOOSE ALMG 5 A f...	A_rd/wh_c
2	Shock sensor ground	A_bk/wh_c
3	Shock trigger	A_wt/wh_c

BIRDS - Siren (engine bay, under firewall behind the engine) ...

1	Siren	A_wt/wh_c
2	Siren ground	A_bk/wh_c

ETACS/LAS-LED - Status LED (dash)

1	Status LED +	A_wt/wh_c
2	Status LED grd	A_bk/wh_c

VALET - Valet / transponder switch (hidden)

1	Valet switch	A_wt/wh_c
2	Valet switch ground	A_bk/wh_c

7-AT-DOOR - OEM door courtesy switch feed (tap sand and END ...

1	Door trigger	A_wt/bk_c

7-AT-HOOD - Hood pin switch feed (new switch, fits front via bra...

1	Hood pin	A_wt/bk_