SCHEMATIC - every wire of the set, grouped by job; read, not to scale
Tables are drawn left-to-right. Legend of the wire-level shorthand: every WIRE TABLE shows four rows of #. Wire label at #WIR. colour (black-barred). Stashed = built with the harness marked in its table; grey header = at end-on another harness.
WIRE COLOUR CODES: #WH WHITE #BK BLACK #RD RED #GN GREEN #BU BLUE #YE YELLOW #OR ORANGE #VI VIOLET #GY GREY #PK PINK #BN BROWN #TQ TURQUOISE #SL SLATE/GREY (RARE) ■ Brown ■ Red ■ Yellow ■ Orange = = = = = built with another harness

THROUGH THE BULKHEAD - every wire that lands on the DRB102 (signals, sensor rails, feeds)

ECU-A - Link ECU plug A (centre dash)

#	WIRE	
1	#GN	Injector 3 drive (-)
2	#BU	Injector 4 drive (-)
3	#VI	Injector 2 drive (-)
4	#GY	Injector 1 drive (-)
5	#WH	Crank sensor signal
6	#BK	Coil 4 trigger (EST)
7	#RD	Coil 3 trigger (EST)
8	#YE	Coil 2 trigger (EST)
9	#OR	Coil 1 trigger (EST)
10	#GN	Coolant temp signal
11	#BU	Inlet air temp signal
12	#VI	MAP sensor signal
13	#GY	Knock sensor(+)
14	#WH	Knock sensor(-)
15	#BK	EVAP purge signal
16	#RD	Turbo speed signal
17	#YE	Fuel level signal
18	#OR	Throttle pot 2 sig.

ECU-B (LS4 GAS plug B, centre dash)

#	WIRE	
19	#BK	TPS throttle sig.1
20	#RD	TPS throttle sig.2
21	#YE	Knock sensor signal
22	#GN	Oil pressure signal
23	#BU	Rear RH wheel spd
24	#VI	Rear right wheel spd
25	#GY	Throttle pot 1 sig.
26	#WH	Throttle pot 2 sig.
27	#BK	Fuel level signal
28	#RD	Inlet air temp signal

BUS-5V - DTRM-12 plug (ECU spice point)

#	WIRE	
1	#RD	+5 V MAP sensor
2	#BK	+5 V throttle pot
3	#YE	+5 V oil pressure
4	#GN	+5 V fuel pressure
5	#BU	+5 V knock sensor

BUS-SNSOUT-A - DTRM-12 plug (ECU spice point)

#	WIRE	
6	#VI	Coolant temp sensor
7	#GY	Inlet air temp sensor
8	#WH	Fuel level sensor
9	#BK	Fuel tank pressure sensor

BUS-SNSOUT-B - DTRM-12 plug (ECU spice point)

#	WIRE	
6	#RD	Knock sensor(-)
7	#YE	Knock sensor(+)
8	#GN	Crank sensor signal
9	#BU	Cam sensor signal

SP-5V - ECU spice point - SP-5V: +5 V cam sensor supply (ECU ...

#	WIRE	
1	#RD	+5 V cam sensor supply

SP-12V - ECU spice point - SP-12V: +12 V ignition supply (ECU ...

#	WIRE	
1	#RD	+12 V ignition supply

SP-CAN+ - CAN H join - ECU, CSB1 cluster, PL bulkhead

#	WIRE	
1	#YE	CAN H to ECU
2	#YE	CAN H to CSB1
3	#YE	CAN H to PL bulkhead

SP-CAN- - CAN L join - ECU, CSB1 cluster, PL bulkhead

#	WIRE	
1	#BU	CAN L to ECU
2	#BU	CAN L to CSB1
3	#BU	CAN L to PL bulkhead

SP-REV - reverse switch out to CSB3 spds + reverse relay

#	WIRE	
1	#WH	Reverse sw +12 V out

SP-IGN1-ECUB - ECUB ignition - IGN 1 feed to reverse s...

#	WIRE	
1	#RD	+12 V ignition

SP-SW12 - ECU spice point - SP-SW12: switched +12 V (LO...

#	WIRE	
1	#RD	+12 V switched

K-RTL - MED-5 RTL pump relay (#K3110), glow time, throttle ...

#	WIRE	
86	#BK	RTL pump relay coil

LOGIC box - custom fuse + relay box, glove box inboard (ca...

#	WIRE	
30	#RD	Battery +12 V feed

BOOST SOL - Boost Control Solenoid

#	WIRE	
1	#RD	+12 V switched

POWER-NEG-BAR - POWER box NEG bar M6 stud (glove box)

#	WIRE	
1	#BK	Earth return

DRB102 CABIN - DRB102 receptacle (RH firewall)

#	WIRE	
1	#GN	Coil 4 trigger (EST)
2	#BU	Coil 3 trigger (EST)
3	#VI	Coil 2 trigger (EST)
4	#GY	Coil 1 trigger (EST)
5	#WH	Crank sensor signal
6	#BK	Cam sensor signal
7	#RD	Coil driver/key
8	#YE	Fuel pump signal
9	#OR	Coil 4 trigger (EST)
10	#GN	Coil 3 trigger (EST)
11	#BU	Coil 2 trigger (EST)
12	#VI	Coil 1 trigger (EST)
13	#GY	Fuel pressure signal
14	#WH	Fuel tank pressure signal
15	#BK	Fuel pump relay
16	#RD	Fuel pump relay
17	#YE	Coil driver/key
18	#OR	Fuel pump relay
19	#GN	Fuel pressure signal
20	#BU	Fuel tank pressure signal
21	#VI	Crank sensor signal
22	#GY	Cam sensor signal
23	#WH	Tacho signal
24	#BK	Tacho signal
25	#RD	Fuel level signal
26	#YE	Fuel level signal
27	#OR	Tacho signal
28	#GN	Tacho signal
29	#BU	Cam sensor signal
30	#VI	Crank sensor signal
31	#GY	Fuel pump relay
32	#WH	Fuel pump relay
33	#BK	Fuel level signal
34	#RD	Fuel level signal
35	#YE	Fuel pressure signal
36	#OR	Fuel pressure signal
37	#GN	Fuel tank pressure signal
38	#BU	Fuel tank pressure signal
39	#VI	Fuel pump relay
40	#GY	Fuel pump relay

K-COOLING - condenser + blower on CSB3

#	WIRE	
1	#YE	+12 V cooling system

K-FUELLVL - EFMI fuel level pull-up to +5V

#	WIRE	
1	#YE	+5 V fuel level pull-up

K-EVAP - 2.2k evap thermistor pull-up to +5V

#	WIRE	
1	#YE	+5 V evap thermistor pull-up

K-FUELLVL - EFMI fuel level pull-up to +5V

#	WIRE	
1	#YE	+5 V fuel level pull-up

SP-SNS - ECU spice points - SP-SNS: ECU sensor ground (ECU ...

#	WIRE	
1	#BK	ECU sensor ground
2	#BK	ECU sensor ground
3	#BK	ECU sensor ground
4	#BK	ECU sensor ground

SP-EV - ECU spice point - SP-EV: +5 V cam sensor supply (ECU ...

#	WIRE	
1	#RD	+5 V cam sensor supply

SP-SW2 - ECU spice point - SP-SW2: switched +12 V (ECU ...

#	WIRE	
1	#RD	+12 V switched

BUS-SNSOUT-A - DTRM-12 plug (ECU spice point)

#	WIRE	
6	#BK	Sensor gnd from ECU
7	#BK	Sensor gnd from ECU
8	#BK	Fuel PRV ground
9	#BK	ECU sensor ground

BUS-SNSOUT-B - DTRM-12 plug (ECU spice point)

#	WIRE	
6	#BK	+5 V from ECU #2
7	#BK	+5 V from ECU #2
8	#BK	+5 V from ECU #2
9	#BK	+5 V from ECU #2

BUS-5V - DTRM-12 plug (ECU spice point)

#	WIRE	
1	#RD	+5 V from ECU #1
2	#RD	+5 V from ECU #1
3	#RD	+5 V from ECU #1
4	#RD	+5 V from ECU #1
5	#RD	+5 V from ECU #1

K-A/C PRESS - A/C pressure switch, top

#	WIRE	
1	#VI	A/C pressure sw out
2	#BK	A/C pressure sw gnd

K-A/C PULLUP - Cam pull-up 1.8 k to +5 V

#	WIRE	
1	#YE	+5 V cam pull-up

K-CAN-PULLUP - Cam pull-up 1.8 k to +5 V

#	WIRE	
1	#YE	+5 V cam pull-up

K-EVAP - 2.2k evap thermistor pull-up to +5V

#	WIRE	
1	#YE	+5 V evap thermistor pull-up

K-FUELLVL - EFMI fuel level pull-up to +5V

#	WIRE	
1	#YE	+5 V fuel level pull-up

K-FUEL P - 10-PUEL inline to fuel sender feed (trunk end)

#	WIRE	
1	#YE	Fuel level signal

K-EVAP-TEMP - OEM evaporator thermistor A/X pin 1, at the ...

#	WIRE	
1	#YE	Evap thermistor sig

OEM JB No.1 (LH kick panel) 1H pin 7, B-O

#	WIRE	
7	#BK	Earth return

T-ECU-M BTSC - OEM evaporator thermistor A/X pin 1, at the v...

#	WIRE	
1	#YE	Evap thermistor sig

OEM JB No.2 (LH kick panel) 1H pin 7, B-O

#	WIRE	
7	#BK	Earth return

DRB102 CABIN - DRB102 receptacle (RH firewall)

#	WIRE	
41	#BK	Throttle shield
42	#BK	Fuel level shield
43	#BK	Turbo speed shield
44	#BK	Cam sensor shield
45	#BK	Crank sensor shield
46	#BK	Knock sensor shield
47	#BK	Coil driver/key
48	#BK	Cam sensor shield
49	#BK	Crank sensor shield
50	#BK	Throttle shield
51	#BK	Fuel level shield
52	#BK	Turbo speed shield
53	#BK	Knock sensor shield
54	#BK	Coil driver/key
55	#BK	Fuel pump shield
56	#BK	Fuel pump shield
57	#BK	Coil driver/key
58	#BK	Fuel pressure shield
59	#BK	Fuel tank pressure shield
60	#BK	Fuel pump shield
61	#BK	Fuel pump shield
62	#BK	Coil driver/key
63	#BK	Fuel pressure shield
64	#BK	Fuel tank pressure shield
65	#BK	Fuel pump shield
66	#BK	Fuel pump shield
67	#BK	Coil driver/key
68	#BK	Fuel pressure shield
69	#BK	Fuel tank pressure shield
70	#BK	Fuel pump shield
71	#BK	Fuel pump shield
72	#BK	Coil driver/key
73	#BK	Fuel pressure shield
74	#BK	Fuel tank pressure shield
75	#BK	Fuel pump shield
76	#BK	Fuel pump shield
77	#BK	Coil driver/key
78	#BK	Fuel pressure shield
79	#BK	Fuel tank pressure shield
80	#BK	Fuel pump shield

ENGINE BAY - DRB102 ENGINE HALF TO EVERY ENGINE DEVICE (ECU HARNESS)

SP-CHASSIS-ENG - Coil ground splice - ignition coil(s) 1-4 to b...

#	WIRE	
1	#BK	Coil 4 ground
2	#BK	Coil 3 ground
3	#BK	Coil 2 ground
4	#BK	Coil 1 ground

SP-GP-END - Coil +12 splice - BH-A pin 1 (LOOC CSP 15...

#	WIRE	
1	#RD	+12 V to coil 4 driver
2	#RD	+12 V to coil 3 driver
3	#RD	+12 V to coil 2 driver
4	#RD	+12 V to coil 1 driver

SP-GNDOUT-A - Sensor return splice - BH-A pin 16 (ECU ...

#	WIRE	
1	#BK	Coil driver/key return
2	#BK	Coil driver/key return
3	#BK	Throttle pot 1 return
4	#BK	Throttle pot 2 return
5	#BK	ETB return
6	#BK	Oil pressure return
7	#BK	+5 V turbo speed
8	#BK	Turbo speed return
9	#BK	Fuel tank speed
10	#BK	Boost solenoid(-)
11	#BK	Boost solenoid(+)
12	#BK	Oil temp signal
13	#BK	+5 V cam sensor
14	#BK	Cam sensor return
15	#BK	+5 V throttle sensor
16	#BK	Throttle pot 1 sig.
17	#BK	Throttle pot 2 sig.
18	#BK	ETB sig.1 return
19	#BK	ETB sig.2 return
20	#BK	Throttle pot 1 sig.
21	#BK	Throttle pot 2 sig.
22	#BK	Oil temp signal
23	#BK	Oil pressure signal
24	#BK	Inlet air temp sig.
25	#BK	Coolant temp signal
26	#BK	Coolant temp sig.
27	#BK	Knock sensor(-)
28	#BK	Knock sensor(+)
29	#BK	Crank sensor signal
30	#BK	Cam sensor signal
31	#BK	Reverse sw +12 V out
32	#BK	Cclnv to Cclnv Lambda
33	#BK	Cclnv to Cclnv Lambda
34	#BK	Coil driver/key
35	#BK	Coil driver/key
36	#BK	Cclnv to Cclnv Lambda

SP-GNDOUT-B - Sensor return splice - BH-A pin 34 (ECU ...

#	WIRE	
1	#BK	Coil driver/key return
2	#BK	Fan low speed
3	#BK	Fan high speed
4	#BK	Fan low speed
5	#BK	Fan high speed
6	#BK	Fan low speed
7	#BK	Fan high speed
8	#BK	Fan low speed
9	#BK	Fan high speed
10	#BK	Fan low speed
11	#BK	Fan high speed
12	#BK	Fan low speed
13	#BK	Fan high speed
14	#BK	Fan low speed
15	#BK	Fan high speed
16	#BK	Fan low speed
17	#BK	Fan high speed
18	#BK	Fan low speed
19	#BK	Fan high speed
20	#BK	Fan low speed
21	#BK	Fan high speed
22	#BK	Fan low speed
23	#BK	Fan high speed
24	#BK	Fan low speed
25	#BK	Fan high speed
26	#BK	Fan low speed
27	#BK	Fan high speed
28	#BK	Fan low speed
29	#BK	Fan high speed
30	#BK	Fan low speed
31	#BK	Fan high speed
32	#BK	Fan low speed
33	#BK	Fan high speed
34	#BK	Fan low speed
35	#BK	Fan high speed
36	#BK	Fan low speed
37	#BK	Fan high speed
38	#BK	Fan low speed
39	#BK	Fan high speed
40	#BK	Fan low speed

SP-GNDOUT-C - Sensor return splice - BH-A pin 50 (ECU ...

#	WIRE	
1	#BK	Coil driver/key return
2	#BK	Coil driver/key return
3	#BK	Coil driver/key return
4	#BK	Coil driver/key return
5	#BK	Coil driver/key return
6	#BK	Coil driver/key return
7	#BK	Coil driver/key return
8	#BK	Coil driver/key return
9	#BK	Coil driver/key return
10	#BK	Coil driver/key return
11	#BK	Coil driver/key return
12	#BK	Coil driver/key return
13	#BK	Coil driver/key return
14	#BK	Coil driver/key return
15	#BK	Coil driver/key return
16	#BK	Coil driver/key return
17	#BK	Coil driver/key return
18	#BK	Coil driver/key return
19	#BK	Coil driver/key return
20	#BK	Coil driver/key return
21	#BK	Coil driver/key return
22	#BK	Coil driver/key return
23	#BK	Coil driver/key return
24	#BK	Coil driver/key return
25	#BK	Coil driver/key return
26	#BK	Coil driver/key return
27	#BK	Coil driver/key return
28	#BK	Coil driver/key return
29	#BK	Coil driver/key return
30	#BK	Coil driver/key return
31	#BK	Coil driver/key return
32	#BK	Coil driver/key return
33	#BK	Coil driver/key return
34	#BK	Coil driver/key return
35	#BK	Coil driver/key return
36	#BK	Coil driver/key return
37	#BK	Coil driver/key return
38	#BK	Coil driver/key return
39	#BK	Coil driver/key return
40	#BK	Coil driver/key return

ENG-GND-RING - Engine block ground stud (RADLOW engine gro...

#	WIRE	
1	#BK	Coil ground

CSDL-1 - CDP 1 (LCC)

#	WIRE	
1	#BK	CDP relay A, pin 7 = LOOC CDP 15 A fuse
2	#BK	Coil 1 trigger (EST)
3	#BK	CDP relay A, pin 7 = LOOC CDP 15 A fuse

CSDL-2 - CDP 2 (LCC)

#	WIRE	
1	#BK	CDP relay A, pin 7 = LOOC CDP 15 A fuse
2	#BK	Coil 2 trigger (EST)
3	#BK	CDP relay A, pin 7 = LOOC CDP 15 A fuse

SP-GNDOUT-D-ENG2 - Sensor return splice - BH-A pin 35 (ECU ...

#	WIRE	
1	#BK	Coil driver/key return
2	#BK	Coil driver/key return
3	#BK	Coil driver/key return
4	#BK	Coil driver/key return

SP-GNDOUT-E-ENG2 - Sensor return splice - BH-A pin 51 (ECU ...

#	WIRE	
1	#BK	Coil driver/key return
2	#BK	Coil driver/key return
3	#BK	Coil driver/key return
4	#BK	Coil driver/key return

SP-GNDOUT-F-ENG2 - Sensor return splice - BH-A pin 36 (ECU ...

#	WIRE	
1	#BK	Coil driver/key return
2	#BK	Coil driver/key return
3	#BK	Coil driver/key return
4	#BK	Coil driver/key return

SP-BU-ENG - Battery +12 V splice - BH-A pin 2 (LOOC INJ 7...

#	WIRE	
1	#RD	ERV relay A, pin 7 = LOOC CDP 15 A fuse
2	#RD	ERV relay A, pin 7 = LOOC INJ 15 A fuse
3	#RD	ERV relay A, pin 7 = LOOC INJ 15 A fuse
4	#RD	ERV relay A, pin 7 = LOOC INJ 15 A fuse

SP-IGN1-E - Ignition +12 V splice - 12 AWG from BH-...

#	WIRE	
1	#RD	ERV relay A, pin 7 = LOOC CDP 15 A fuse

SP-LAMG-E - CAN-Lambda ground splice - 12 AWG from BH-...

#	WIRE	
1	#BK	Cclnv to Cclnv Lambda
2	#BK	Cclnv to Cclnv Lambda

SP-SW12-ENG - Switched +12 V splice - BH-A pin 30 (LOOC ...

#	WIRE	
1	#RD	ERV relay A, pin 7 = LOOC INJ 15 A fuse
2	#RD	ERV relay A, pin 7 = LOOC INJ 15 A fuse
3	#RD	ERV relay A, pin 7 = LOOC INJ 15 A fuse

SP-BU-ENG2 - Battery +12 V splice - BH-A pin 3 (LOOC INJ 7...

#	WIRE	
1	#RD	ERV relay A, pin 7 = LOOC CDP 15 A fuse
2	#RD	ERV relay A, pin 7 = LOOC INJ 15 A fuse
3	#RD	ERV relay A, pin 7 = LOOC INJ 15 A fuse
4	#RD	ERV relay A, pin 7 = LOOC INJ 15 A fuse

DRB102 ENGINE - DRB102 receptacle (RH firewall)

#	WIRE	
1	#GN	Coil 4 trigger (EST)
2	#BU	Coil 3 trigger (EST)
3	#VI	Coil 2 trigger (EST)
4	#GY	Coil 1 trigger (EST)
5	#WH	Crank sensor signal
6	#BK	Cam sensor signal
7	#RD	+5 V fuel pressure
8	#YE	Fuel pump signal
9	#OR	+5 V MAP sensor
10	#GN	+5 V throttle pot
11	#BU	+5 V oil pressure
12	#VI	+5 V fuel pressure
13	#GY	+5 V knock sensor
14	#WH	Fuel pressure signal
15	#BK	Fuel tank pressure signal
16	#RD	Fuel pump relay
17	#YE	Fuel pump relay
18	#OR	Coil driver/key
19	#GN	Fuel pressure signal
20	#BU	Fuel tank pressure signal
21	#VI	Crank sensor signal
22	#GY	Cam sensor signal
23	#WH	Tacho signal
24	#BK	Tacho signal
25	#RD	Fuel level signal
26	#YE	Fuel level signal
27	#OR	Tacho signal
28	#GN	Tacho signal
29	#BU	Cam sensor signal
30	#VI	Crank sensor signal
31	#GY	Fuel pump relay
32	#WH	Fuel pump relay
33	#BK	Fuel level signal
34	#RD	Fuel level signal
35	#YE	Fuel pressure signal
36	#OR	Fuel pressure signal
37	#GN	Fuel tank pressure signal
38	#BU	Fuel tank pressure signal
39	#VI	Fuel pump relay
40	#GY	Fuel pump relay

K-RTB - Start Relay (moved to the POWER box M3) - ACTIVE...

#	WIRE	
30	#RD	Battery +12 V feed
87	#YE	Start relay output

ANTI-THEFT - ALARM MODULE, SIREN, TRIGGERS, STATUS LED

ECU-B (LS4 GAS plug B, centre dash)

#	WIRE	
29	#BK	Tach output

SP-AT-12V - Alarm +12 V splice - LOOC ALM 5A fuse to alar...

#	WIRE	
1	#RD	BUS 30 A fuse = LOOC ALM 5 A fuse

SP-DOOR - Door trigger splice - door courtesy switches to al...

#	WIRE	
1	#BK	Door trigger
2	#BK	Door trigger

SP-HOOD - Hood trigger splice - hood pin switch to alarm pi...

#	WIRE	
1	#BK	Hood trigger

SP-AL - Alarm trigger splice - LOOC ALM01 to Core to alar...

#	WIRE	
1	#BK	LOOC ALM01 = LOOC ALM01 A fuse

SP-PARK - Park flash splice - alarm pin 5 to the park lamp wi...

#	WIRE	
1	#BK	Park lamp fuse = LOOC PARK 10 A fuse

SP-TRUNK - Trunk trigger splice - trunk pin switch to alarm pi...

#	WIRE	
1	#BK	Trunk trigger
2	#BK	Trunk trigger

SHOCK-SENSOR - Shock / tilt sensor *

#	WIRE	
1	#RD	+12 V to sensor
2	#BK	Shock sensor ground
3	#YE	Shock sensor signal

SIREN - Siren (engine bay, center firewall behind the engine) ...

#	WIRE	
1	#BK	Siren ground
2	#RD	Siren power

VALET-SW - Valet / program switch (hidden)

#	WIRE	
1	#BK	Valet switch
2	#BK	Valet switch ground

T-AT-DOOR - OEM door courtesy switch feed (tap spot and END) ...

#	WIRE	
1	#BK	Door courtesy switch feed

T-AT-HOOD - Hood pin switch feed (new switch, 5th front via bu...

#	WIRE	
1	#BK	Hood pin switch feed

T-AT-PARK - Park lamp feed relay load (cabin relay, part and spli...

#	WIRE	
1	#BK	Park lamp feed

ALARM - Alarm module main harness (DTM-12A)

#	WIRE	
1	#RD	BUS 30 A fuse = LOOC ALM 5 A fuse
2	#BK	Siren ground
3	#BK	ERV relay A, pin 7 = LOOC ALM01 A fuse
4	#BK	ERV relay A, pin 7 = LOOC ALM01 A fuse
5	#BK	Park lamp fuse = LOOC PARK 10 A fuse
6	#BK	Door trigger
7	#BK	Hood trigger
8	#BK	Trunk trigger
9	#BK	Anti-theft input
10	#BK	Valet switch
11	#BK	Valet switch
12	#BK	Shock trigger

T-AT-CAR-B - Cabin ground stud near the alarm (yard and END) ...

#	WIRE	
1	#BK	Alarm ground

T-AT-CAR-C - Cabin ground stud near the alarm (yard and END) ...

#	WIRE	
1	#BK	Valet switch ground

SP-CAN-LAM - CAN-Lambda splice - bulkhead, Lambda, 120 ohm end

#	WIRE	
1	#BK	Cclnv to Cclnv Lambda

CAB-CAN-LAM-cable screen (floats at the device end)

#	WIRE	
1	#BK	Cclnv to Cclnv Lambda

STARTER-TRIGGER - Starter solenoid S (20) terminal post, spade

#	WIRE	
1	#RD	ERV 30 A fuse = start relay coil, 86

CAN TRUNK - ECU, CSB1, CLUSTER, REALDASH P1, BULKHEAD, CAN-LAMBDA

ECUC - ECU CommsTuning Port

#	WIRE	
1	#BK	CAN screen trunk
2	#YE	CAN C high
3	#BU	CAN C low

SP-CAN-SV-BH - CAN trunk, bulkhead B branch - SP-CAN-S...

#	WIRE	
1	#BK	CAN screen trunk

SP-CAN-SH-CSB - CAN trunk, CSB3 branch - SP-CAN-SH-CS...

#	WIRE	
1	#BK	CAN screen trunk
2	#BK	CAN screen trunk

H-TERM-ECU - ⊏ term. ecu

#	WIRE	
1	#YE	ECU 120R CAN H
2	#BU	ECU 120R CAN L

K-TERM-END - ⊏ term. end

#	WIRE	
1	#YE	Cummins 120R CAN H
2	#BU	Cummins 120R CAN L

CAN-LAMBDA - CAN CANLambda

#	WIRE	
1	#BK	Cclnv to CANLambda
2	#BK	Cclnv to CANLambda

CSB1 - ECUMaster CSB1 - PowerCANSwitch HT

#	WIRE	
1	#YE	CAN H to CSB1
2	#BU	CAN L to CSB1

T-CLUSTER-CAN - Cluster CAN board CANH / CANL pins on...

#	WIRE	
1	#BK	Cclnv to cluster
2	#BK	Cclnv to cluster
3	#BK	Cclnv to cluster

T-CLUSTER-GND-LEAD - Cluster buck converter 9v pin (old ...

#	WIRE	
1	#BK	Cclnv to cluster

T-CLUSTER-PWR - Cluster buck converter 9v pin (old radio ...

#	WIRE	
1	#BK	Cclnv to cluster

T-DEALDASH-CAN - P1 USB CAN adapter CANH + CANL pin...

#	WIRE	
1	#BK	Cclnv to Realdash P1

T-REALDASH-PWR - P1 12-to-5 V supply 5V pin (center dash)

#	WIRE	
1	#BK	Cclnv to Realdash P1

CAB-CAN-ECU-cable screen (floats at the device end)

#	WIRE	
1	#BK	ECU CAN screen

CAB-CAN-ECU-cable screen (floats at the device end)

#	WIRE	
1	#BK	ECU CAN screen

CAB-CAN-CSB-cable screen (floats at the device end)

#	WIRE	
1	#BK	CSB1 CAN screen

CAB-CAN-CSB-CSB cable screen (floats at the device end)

#	WIRE	
1	#BK	CSB1 CAN screen

SP-CAN-LAM - CAN-Lambda splice - bulkhead, Lambda, 120 ohm end

#	WIRE	
1	#BK	CANLambda CAN Cclnv to CANLambda

SP-CAN+ - CAN H join - ECU, CSB1, cluster, PL bulkhead

#	WIRE	
1	#YE	CAN H to ECU
2	#YE	CAN H to CSB1
3	#YE	CAN H to cluster
4	#YE	CAN H to PL bulkhead

SP-CAN- - CAN L join - ECU, CSB1, cluster, PL bulkhead

#	WIRE	
1	#BU	CAN L to ECU
2	#BU	CAN L to CSB1
3	#BU	CAN L to cluster
4	#BU	CAN L to PL bulkhead

SP-CAN-SH-CLU - CAN trunk, cluster branch - SP-CAN-SH-CLU

#	WIRE	
1	#BK	CAN screen trunk
2	#BK	CAN screen trunk

SP-CAN-SH-RD - CAN trunk, RealDash P1 branch - SP-CAN-SH-R...

#	WIRE	
1	#BK	CAN screen trunk

POWER-NEG-BAR - POWER box NEG bar M6 stud (glove box)

#	WIRE	
1	#BK	Chassis ground
2	#BK	RealDash P ground

SP-BAT - Batt 12 V split - cluster + RealDash P, center dash

#	WIRE	
1	#RD	ERV relay A, pin 7 = LOOC CDP 15 A fuse
2	#RD	ERV relay A, pin 7 = LOOC ERV 15 A fuse

CS03 - SWITCH INPUTS, CRUISE LADDER, OPTO BOARD

SP-CRUISE-LADDER - Cruise ladder splice - stalk pin 5, to p...

#	WIRE	
1	#BK	Cruise ladder
2	#BK	Cruise ladder

SP-CSB-GND - CSB3 ground splice - CSB3 pin 2, optic board ...

#	WIRE	
1	#BK	CSB3 ground
2	#BK	Cruise cable ground
3	#BK	Cruise cable ground

CSB3 - ECUMaster CSB3 - PowerCANSwitch HT

#	WIRE	
1	#YE	CAN H to ECU, LOOC ACM 7.5 A fuse
2	#BU	CAN L to ECU
3	#BK	Ground
4	#BK	Sim out ground
5	#BK	Cruise GND out
6	#BK	Cruise MAIN out
7	#BK	Clutch pedal sw
8	#BK	Brake pedal sw
9	#BK	Reverse sw +12 V out

DRW stop lamp switch 5V pin 1 (analog, to IO wire ...

#	WIRE	
1	#BK	Brake sw +12 V

OEM cruise stalk switch C14 pin 5, W wire

#	WIRE	
1	#BK	Cruise ladder

K-CRUISE - ⊏ cruise

#	WIRE	
1	#BK	Cruise ladder

OEM cruise stalk switch C14 pin 17, GR wire

#	WIRE	
1	#BK	Cruise ladder

OEM cruise control clutch switch C17 pin 2, B wire

#	WIRE	
1	#BK	Clutch pedal sw

OEM cruise stalk switch C14 pin 15, T-B wire

#	WIRE	
1	#BK	Cruise MAIN sw

OEM cruise control clutch switch C17 pin 1, B wire

#	WIRE	
1	#BK	Clutch pedal sw

OPTO-A - Optocoupler board, 4 channel (Opto's, generic 6-PI...

#	WIRE	
1	#BK	Opto board ground
2	#BK	Opto board ground
3	#BK	Opto board ground
4	#BK	Opto board ground

OPTO-B - Optocoupler board, 4 channel (Opto's, generic 6-PI...

#	WIRE	
1	#BK	Opto board ground
2	#BK	Opto board ground
3	#BK	Opto board ground
4	#BK	Opto board ground

CABIN POWER - POWER + LOGIC BOXES TO EVERY CABIN FEED, RELAY COIL AND OEM TAP

ECU-A - Link ECU plug A (centre dash)

#	WIRE	
35	#BK	ETB relay coil (-)
36	#BK	Start cut relay

ECU-B (LS4 GAS plug B, centre dash)

#	WIRE	