ST185 FUSE BOX ASSEMBLIES - WIRING BLOCK DIAGRAM

FRONT of car

POWER box + LOGIC box (glove box) and battery relay block (trunk). Sources: sot/channels.csv, cad/fusebox/src/spec.py, docs/harness/interfaces.json.

Generated by docs/build/wiring-diagrams/build_wiring_diagrams.py - do not edit by hand.

POWER BOX
glove box, outboard - AMI fuse bar (IN row feeds the relays, OUT row feeds the cabin) - rev 7
w_strl_ac | 10 AWG | Red (White-Yellow)
-> Starter solenoid S spade lug (A-engine loom) - start relay output
w_str85_cp | 18 AWG | White (White-Yellow)
-> ECU plug A pin 26 (Link ECU, center dash) - Aux 8 sinks the start relay coil
w_k_str_86_cp | 18 AWG | Red (Blue)
-> SW12 bus plug DT06-12 (glove box, by LOGIC box) pin 6
k_str
R3 starter
30
85
86
87
TE 1-1414147-0
w_fb_k_str_87_cp
12 AWG Red (White-Yellow)
IN-3 30 A
STR
+ BAR
OUT-2 30 A
RTR
w_pmu_rtr_cp | 10 AWG | Red (Yellow-Yellow-Yellow)
-> OEM cowl plug IE1 pin 3 (LH kick), W wire - RTR 30A to retract relay R8 (EWD 1993 p.116)
w_fan_pwr_ac | 8 AWG | Red (Yellow-White)
-> Radiator fan plug pin + (loom C, front) - radiator fan +12 V, 8 AWG
w_fan85_cp | 18 AWG | White (Yellow-White)
-> ECU plug A pin 29 (Link ECU, center dash) - Aux 5 sinks the radiator fan relay coil
w_k_fan_86_cp | 18 AWG | Red (Blue)
-> SW12 bus plug DT06-12 (glove box, by LOGIC box) pin 4
k_fan
R4 radiator fan
TE 1-1414147-0
w_fb_k_fan_87_cp
8 AWG Red (Yellow-White)
IN-4 40 A
FAN
OUT-3 40 A
AM1
w_pdb_am1_cp | 8 AWG | White (Yellow-Yellow-White)
-> OEM cowl plug IE1 pin 10 (LH kick), W wire - AM1 to ignition switch (EWD p.31)
w_fan2_pwr_bc | 8 AWG | Red (White-Blue)
-> Condenser fan plug pin + (loom C, front) - condenser fan +12 V, 8 AWG
w_fan285_cp | 18 AWG | Violet (White-Blue)
-> ECU plug B pin 13 (Link ECU, center dash) - Ign 5 sinks the condenser fan relay coil
w_k_fan2_86_cp | 18 AWG | Red (Blue)
-> SW12 bus plug DT06-12 (glove box, by LOGIC box) pin 7
k_fan2
R5 condenser fan
TE 1-1393304-0
w_fb_k_fan2_87_ac
8 AWG Red (White-Blue)
IN-5 30 A
FAN2
OUT-4 30 A
AM2
w_pdb_am2_cp | 10 AWG | Brown (Yellow-White-Blue)
-> OEM cowl plug IE1 pin 17 (LH kick), B-R wire - AM2 to ignition switch (EWD p.31)
w_htr_87a_cp
14 AWG Black (Yellow)
w_rb2_cp | 10 AWG | Red (Yellow-Yellow)
-> OEM old R/B2 relay lead pin 1 (LH kick), W-G wire - power windows (EWD 1993 p.137)
w_pwr_86_cp | 18 AWG | Red (Yellow-Yellow)
-> OEM old R/B2 relay lead pin 2 (LH kick), L-Y - GAUGE 15A, ignition on (EWD 1993 p.137)
k_pwr
R6 power window
TE 1-1393304-0
w_pwr_87_cp
10 AWG Red (Yellow-Yellow)
IN-6 30 A
PWR
OUT-5 60 A
JB1
w_pdb_jb1_cp | 6 AWG | White
-> OEM J/B 1 plug 1I pin 1 (LH kick), B wire - J/B 1 main B+ (EWD p.18-19)
w_htr_30_cp | 8 AWG | Red (Yellow)
-> Heater relay output splice (4 AWG) - blower motor + and the ACPS fuse
w_htr_85_cp | 18 AWG | Violet (Yellow)
-> OEM old R/B4 heater relay lead pin 1 (RH kick), L-W - A/C amp HR (EWD 1993 p.215)
w_htr_86_cp | 18 AWG | Red (Yellow)
-> OEM old R/B4 heater relay lead pin 3 (RH kick), R-L - coil + feed (EWD 1993 p.215)
k_htr
R1 heater 1-form-C
87a
TE 1-1414687-0
w_htr_87_cp
8 AWG Red (Yellow)
IN-1 40 A
HTR
OUT-6 60 A
EPS
w_fb_k_eps_30_ac | 8 AWG | Red (Blue-Blue-Blue)
-> MR-S EHPS pump relay (HCR150, glove box, beside the POWER box) pin 30
w76_cp | 18 AWG | White (Blue-Yellow)
-> ECU plug A pin 28 (Link ECU, center dash) - Aux 6 sinks the EFI relay coil
k_efi
R2 EFI main
TE 1-1414147-0
w_fb_k_efi_87_cp
12 AWG Red (Blue-Yellow)
IN-2 30 A
EFI
OUT-1 50 A
BUS1
w_htr_acps | 14 AWG | Red (Yellow)
-> Heater relay output splice (4 AWG) - blower motor + and the ACPS fuse
IN
ACPS 10 A
mini ATM
OUT
w_acp_1_cp | 18 AWG | Violet (Blue-Yellow-White)
-> A/C pressure switch A5 pin 1 (loom C, engine bay) - switch +12 V (1990 EWD p.152)
w_h1_pdb | 53.5 mm2 | Red
-> Kill switch MAIN 2 stud, trunk RH rear (HeavyDC) - battery + after the switch, via H1
POWER + bar: M8 studs
(1/0 battery cable in; alternator / starter out)
BAT+ c1
ALT/STR c2
w_pdb_rlp | 53.5 mm2 | Red
-> RADLOK + stud, cabin side, RH firewall (HeavyDC) - to starter B+
w_h2_pdb | 53.5 mm2 | Black
-> Battery negative terminal post, trunk RH rear (HeavyDC) - battery - via H2
w_pwr_85_cp
18 AWG Black (Yellow-Yellow)
w_pdb_rln | 53.5 mm2 | Black
-> RADLOK negative stud, cabin side, RH firewall (HeavyDC) - to engine block
k_htr 87a
k_pwr 85
POWER NEG bar: M8 ground studs
GND c8
k_rev 85 (LOGIC)
w_gnd_id | 53.5 mm2 | Black
-> Ground stud ID, left kick panel (EWD ground point ID) - POWER box NEG strap
w_gnd_ig | 53.5 mm2 | Black
-> Ground bolt IG, right kick (EWD ground point IG) - POWER box NEG strap
w_hc_fb
8 AWG Red (White-Blue-White)
w77_cp
10 AWG Red (Blue-Yellow)
LOGIC BOX
glove box, inboard - Bus 1 / Bus 2 mini-fuse strips and 7 micro relays - rev 7
w_k_efi_86_cp
18 AWG Red (Blue-Yellow)
BUS1-1 5 A
EFI86
w_hl_85_cp | 18 AWG | Violet (Blue-Yellow-Blue)
-> Headlight coil splice - HEAD LH and RH relay coils to cowl plug IE1 pin 2
w_pmu_hl_cp | 14 AWG | Red (Blue-Blue-Yellow)
-> LH headlight plug H1 pin 3 (loom C, LH front) - headlight LH +12 V (EWD 1993 p.116)
k_hl
HEAD LH
TE 5-1393292-8
w_hl_30_cp
14 AWG Red (Blue-Blue-Yellow)
w_hl_cp
14 AWG Red (Blue-Blue-Yellow)
sp_hl
w_hl_86_cp
16 AWG Red (Blue-Blue-Yellow)
BUS1-2 15 A
HL
w_hr_85_cp | 18 AWG | Violet (Blue-Yellow-Blue)
-> Headlight coil splice - HEAD LH and RH relay coils to cowl plug IE1 pin 2
w_pmu_hr_cp | 14 AWG | Red (Blue-Blue-White)
-> RH headlight plug H2 pin 3 (loom C, RH front) - headlight RH +12 V (EWD 1993 p.116)
k_hr
HEAD RH
TE 5-1393292-8
w_hr_30_cp
14 AWG Red (Blue-Blue-White)
w_hr_cp
14 AWG Red (Blue-Blue-White)
sp_hr
w_hr_86_cp
16 AWG Red (Blue-Blue-White)
BUS1-3 15 A
HR
BUS 1 (permanent) strip
w81_cp | 20 AWG | Gray (White-White)
-> ECU plug A pin 20 (Link ECU, center dash) - Aux 2 sinks the ETB relay coil
w_k_etb_86_cp | 20 AWG | Red (Blue)
-> SW12 bus plug DT06-12 (glove box, by LOGIC box) pin 5
w82_ac | 18 AWG | Red (White-White)
-> ECU plug B pin 5 (Link ECU, center dash) - ETB motor supply from the ETB relay
k_etb
ETB power
TE 4-1904124-2
w_fb_k_etb_30_cp
16 AWG Red (White-White)
BUS1-10 10 A
ETB
w_hz_cp | 14 AWG | Red (Blue-Blue)
-> HAZ-HORN splice - HZ 15A fuse to the hazard feed and the horn relay
BUS1-4 15 A
HZ
w_pmu_dome_cp | 14 AWG | Red (Yellow-Blue-White)
-> OEM J/B 1 plug 1H pin 2 (LH kick), L-Y wire - DOME 20A feed (EWD 1993 p.132)
BUS1-5 20 A
DM
w_rb2_wl_cp | 14 AWG | Red (Yellow-Yellow-Blue)
-> OEM old R/B2 relay lead pin 2 (LH kick), W-L wire - door lock + tilt-away (EWD p.137)
BUS1-6 15 A
WL
w_at_12v_tie_cp | 20 AWG | Red (Yellow-White-Yellow)
-> Alarm +12 V splice (AntiTheft loom, center dash) - alarm pin 1 constant +12 V
BUS1-7 5 A
ALM
w_at_12v_shk_tie_cp | 20 AWG | Red (Yellow-White-White)
-> Shock sensor +12 V splice (AntiTheft loom, ECU area) - shock sensor pin A
BUS1-8 2 A
ALMS
w_alt_s_cp | 20 AWG | White (White-Blue-Yellow)
-> Alternator plug G2 pin 1 (engine bay, via loom C) - S battery sense (EWD 1993 p.74-75)
BUS1-9 2 A
ALTS
k_rev
REVERSE
TE 6-1419137-4
w_rev_85_fb
20 AWG Black (White)
w_rev_30_cp | 16 AWG | Red (White)
-> GAUGE 15A splice - J/B 3 feed to reverse relay pin 30 and the back-up switch
w_rev_86_cp | 16 AWG | Red (White)
-> Reverse switch splice (B-cabin loom) - back-up switch B1 pin 1, +12 V in reverse
w_rev_87_cp | 16 AWG | Red (White)
-> Back-up lamp splice (RearLights loom, rear) - R11 and R12 pin 4 back-up lamps
k_horn
HORN
TE 4-1904124-3
w_horn_30_cp | 16 AWG | Red (Blue-Blue)
-> HAZ-HORN splice - HZ 15A fuse to the hazard feed and the horn relay
w_horn_85_cp | 18 AWG | Violet (Blue-Blue)
-> OEM cowl plug IE1 pin 19 (LH kick), G wire - horn switch line (EWD 1993 p.185)
w_horn_86_cp | 16 AWG | Red (Blue-Blue)
-> HAZ-HORN splice - HZ 15A fuse to the hazard feed and the horn relay
w_pmu_horn_cp | 14 AWG | Red (Blue-Blue)
-> Horn splice (loom C, front) - horn relay output to horns H3 and H4 pin 1
BUS2-8 10 A
ACC
w_fb_k_acc_30_cp
16 AWG Red (Yellow-Blue)
k_acc
A/C clutch
TE 6-1419137-4
w_acc_trig_cp | 18 AWG | Violet (Yellow-Blue)
-> ECU plug B pin 10 (Link ECU, center dash) - Ign 8 sinks the A/C clutch relay coil
w_acc86_cp | 18 AWG | Yellow (Yellow-Blue)
-> A/C pressure switch splice (A-cabin loom) - switch A5 pin 4 output to the clutch relay
w_acc_clutch_cp | 16 AWG | Red (Yellow-Blue)
-> A/C magnet clutch A4 pin 4 (loom C, compressor) - clutch +12 V (1990 EWD p.152)
BUS2-7 7.5 A
EPSEN
w_fb_k_eps_en_30_cp
18 AWG Red (Blue-White)
k_eps_en
EPS enable
TE 6-1419137-4
w_eps_trig_cp | 18 AWG | Violet (Blue-White)
-> ECU plug B pin 12 (Link ECU, center dash) - Ign 6 sinks the EPS enable relay coil
w_k_eps_en_86_cp | 18 AWG | Red (Blue)
-> SW12 bus plug DT06-12 (glove box, by LOGIC box) pin 9
w_k_eps_en_87_cp
18 AWG Red (Blue-White)
BUS2-12 7.5 A
MRS
IN
OUT
w_fb_mrs_en_cp | 20 AWG | Red (Blue-White)
-> Bulkhead A pin 42 (DRB102, RH firewall) - EHPS pump logic enable (pump pin C1)
BUS 2 (switched, k_efi 30) strip
BUS2-1 7.5 A
LAM
w_lam12_cp | 14 AWG | Red (Blue-White-White)
-> Bulkhead B pin 95 (DRB102, RH firewall) - CAN-Lambda +12 V
BUS2-2 7.5 A
SW12
w_cp_sw12_in | 16 AWG | Red (Blue)
-> SW12 bus plug DT06-12 (glove box, by LOGIC box) pin 1
BUS2-3 15 A
COP
w_cop_pwr_c_ac | 14 AWG | Red (Blue-White-Yellow)
-> Bulkhead A pin 2 (DRB102, RH firewall) - COP coil +12 V rail (COP 15A)
BUS2-4 15 A
INJ
w_inj_pwr_c_ac | 14 AWG | Red (Blue-White-Blue)
-> Bulkhead A pin 1 (DRB102, RH firewall) - injector +12 V rail (INJ 15A)
BUS2-5 5 A
CSB
w_csb12_cp | 20 AWG | Red (Yellow-Blue-Blue)
-> CSB3 plug pin 1 (CSB3 box under the cluster) - CSB3 +12 V switched
BUS2-6 15 A
DEV
w_dev_cp | 16 AWG | Red (Yellow-Blue-Yellow)
-> Dash device +12 V splice (CAN loom) - center cluster and RealDash Pi +12 V
BUS2-9 2 A
ALMIG
w_at_ig_tie_cp | 20 AWG | Gray (White-Blue-Blue)
-> Alarm ignition splice (AntiTheft loom, center dash) - alarm pin 3 ignition sense
BUS2-13 2 A
B30
w_start_in_cp | 20 AWG | Green (Blue-Yellow-Yellow)
-> OEM starter relay socket R/B4 pin 1, B-W wire - ignition ST1 start request (EWD 1993 p.66)
w_start_cp | 20 AWG | Green (Blue-Yellow-Yellow)
-> ECU plug B pin 30 (Link ECU, center dash) - DI 7 start request
BATTERY RELAY BLOCK
trunk, passenger side between the rear wall and the battery - fuel pump relay and its fuse (rev 7)
w_fp_feed | 10 AWG | Red (White-White-Blue)
-> Kill switch pin MAIN 2
BATT+ stud
M6 on the bar
AMI FP 40 A
fuel pump fuse
w_fp_30
10 AWG Red (White-White-Blue)
k_fp
HCR150 fuel pump relay
TE 1416010-1
w_fp87_h | 10 AWG | Red (White-White-Blue)
-> Fuel pump plug pin 1 (in the tank; RearFuel) - pump +12 V
w_fp85_h | 18 AWG | White (White-White-Blue)
-> ECU A pin 19 (Link ECU, center dash; A-cabin) - fuel pump relay drive
w_fp86_h | 18 AWG | Red (Blue)
-> SW12 splice after LOGIC Bus 2 pin 2 (glove box; CabinPower) - switched 12 V

How to read

🟥 one wire, drawn in its insulation colour; the label is "wire id | gauge | colour (ident bands)"

A line that crosses another with a gap does not connect to it. A dot is a pin or stud. The brown bar is a copper bus bar / strip.

A wire that leaves the assembly ends at the stub; the text after "->" is where that far end lands (DECISIONS R156). Overhead block view, not to scale.

Rows are grouped for readable wires, not in physical order: every fuse and relay carries its cavity number (BUS1-n, BUS2-n, AMI IN-n, AMI OUT-n).