IDENTIFICATION

PRODUCT CODE: AC-F1238-MC

PRODUCT NAME: CZRLJB0 RL01/02 DRIVE TEST 2

DATE CREATED: 5-JAN-79

REVISED: 7-DEC-79

MAINTAINER: DIAGNOSTIC ENGINEERING

AUTHORS: D. DEKNIS, C. CAMPBELL

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1977, 1979 DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

1.0 GENERAL INFORMATION
1.1 PROGRAM ABSTRACT
1.1.1 STRUCTURE OF PROGRAM
1.1.2 DIAGNOSTIC INFORMATION
1.2 SYSTEM REQUIREMENTS
1.2.1 HARDWARE REQUIREMENTS
1.2.2 SOFTWARE REQUIREMENTS
1.3 RELATED DOCUMENTS AND STANDARDS
1.4 DIAGNOSTIC HIERARCHY PREREQUISITES
1.5 ASSUMPTIONS

2.0 OPERATING INSTRUCTIONS
2.1 HOW TO RUN THIS DIAGNOSTIC
2.1.1 THE FIVE STEPS OF EXECUTION
2.1.2 SAMPLE RUN-THROUGH
2.2 CHAIN MODE OPERATION
2.3 DETAILS OF COMMANDS AND SYNTAX
2.3.1 TABLE OF COMMAND VALIDITY
2.3.2 COMMAND SYNTAX
2.4 EXTENDED P-TABLE DIALOGUE
2.5 HARDWARE PARAMETERS
2.6 SOFTWARE PARAMETERS

3.0 ERROR INFORMATION
3.1 ERROR REPORTING
3.1.2 SPECIFIC RESULT MESSAGES
3.1.3 OTHER MESSAGES
3.2 ERROR HALTS

4.0 PERFORMANCE AND PROGRESS REPORTS
4.1 PERFORMANCE REPORTS
4.2 PROGRESS REPORTS

5.0 DEVICE INFORMATION TABLES

6.0 TEST SUMMARIES

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

1.1.1 STRUCTURE OF PROGRAM

THIS DIAGNOSTIC COMPATIBLE WITH BOTH XXDP+ AND ACT. IT CAN BE RUN STANDALONE UNDER XXDP, AND CAN BE CHAINED UNDER XXDP+, ACT AND APT IN ACT MODE (SEE 2.2 ''CHAIN MODE OPERATION'' FOR DETAILS OF CHAINING PROCEDURE). IT IS A SINGLE PROGRAM FROM THE STANDPOINT OF THE DIAGNOSTIC USER, WHICH AT RUN TIME IS APPENDED TO A COMMON FRONT-END PIECE OF SUPERVISOR SOFTWARE THROUGH WHICH THE DIAGNOSTICS PROGRAM INTERFACES TO THE ENVIRONMENT AS IT EXECUTES.

WHEN THIS DIAGNOSTIC IS STARTED AT ADDRESS 200, CONTROL GOES FIRST TO THE SUPERVISOR PORTION, WHICH WILL ASK CERTAIN ''HARD CORE'' QUESTIONS ABOUT THE ENVIRONMENT. THEN IT WILL ENTER COMMAND MODE, INDICATED BY A PROMPT CHARACTER (DR>). AT COMMAND MODE THE OPERATOR MAY ENTER ANY OF SEVERAL COMMANDS AS DESCRIBED IN 2.0 ''OPERATING INSTRUCTIONS''.

THE DIAGNOSTIC PROGRAM IS LOADED IN THE LOWER 8K OF MEMORY. THE DIAGNOSTIC SUPERVISOR CODING OCCUPIES 6.25K OF THE UPPER PART OF MEMORY JUST BELOW THE XXDP+ MONITOR WHICH RESIDES IN THE UPPERMOST 1.5K OF MEMORY SPACE.

1.1.2 DIAGNOSTIC INFORMATION

THIS PROGRAM TESTS AND EXERCISES RL01/02 DISK DRIVES RL11/RLV11 CONTROLLERS (4 DRIVES PER CONTROLLER). THE ENTIRE PROGRAM IS RUN ON THE FIRST DRIVE BEFORE STARTING ON THE SECOND. THE PROGRAM STARTS BY TESTING THE SIMPLEST FUNCTIONS FIRST USING THE LOGIC TESTED IN EARLIER TESTS TO TEST MORE COMPLEX FUNCTIONS.

THIS PROGRAM TESTS THE RL01/02 OUTER AND INNER GUARD BAND DETECTION. SEEK OPERATIONS UNDERGO A BROAD RANGE OF TESTING USING SINGLE DIFFERENCES, PROCEEDING TO SEEKS OF GREATER DIFFERENCES.

1.2 SYSTEM REQUIREMENTS

1.2.1 HARDWARE REQUIREMENTS

* PDP-11/LSI-11 PROCESSOR WITH 16K OR MORE OF MEMORY
* CONSOLE DEVICE (LA30,LA36,VT50,ETC.)
* 1 OR 2 RL11/RLV11 CONTROLLER(S) WITH:

  1 - 8 RL01 DRIVES WITH RL01K CARTRIDGES CONTAINING A 'BAD SECTOR FILE'
  1 - 8 RL02 DRIVES WITH RL02K CARTRIDGES CONTAINING A 'BAD SECTOR FILE'

* LINE PRINTER (OPTIONAL)

1.2.2 SOFTWARE REQUIREMENTS

CZRLJB0 RL01/02 DRIVE TEST PART 2 (FORMERLY CZRLDB0)

1.3 RELATED DOCUMENTS AND STANDARDS

RL01/02 DISK SUBSYSTEM USER'S GUIDE (EK-RL01-UG-002)
XXDP+/SUPERVISOR USER'S MANUAL

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE RL01/02 SUBSYSTEM SHOULD HAVE SUCCESSFULLY RUN THE FOLLOWING PROGRAMS:

CVRLAB0	RLV11 RL01 DISKLESS TEST (RLV11 ONLY)
CZRLGB0	RL11/RLV11 RL01/02 CONTROLLER TEST (PART 1)
CZRLHB0	RL11/RLV11 RL01/02 CONTROLLER TEST (PART 2)
CZRLIB0	RL01/02 DRIVE TEST (PART 1)

1.5 ASSUMPTIONS

THE HARDWARE OTHER THAN THE RL01/02 SUBSYSTEM IS ASSUMED TO WORK PROPERLY. FALSE ERRORS MAY BE REPORTED IF THE PROCESSOR, ETC., DO NOT FUNCTION PROPERLY.

2.0 OPERATING INSTRUCTIONS

2.1 HOW TO RUN THIS DIAGNOSTIC

2.1.1 THE FIVE STEPS OF EXECUTION

THIS DIAGNOSTIC PROGRAM SHOULD BE LOADED AND STARTED USING NORMAL XXDP+ PROCEDURES. START THE EXECUTION OF THE XXDP+ MONITOR BY USING THE APPROPRIATE BOOTSTRAP PROGRAM. THE MONITOR WILL PRINT A MESSAGE IDENTIFYING ITSELF AND REQUESTING THAT THE CURRENT DATE BE ENTERED. AN EXAMPLE OF THIS MESSAGE IS GIVEN BELOW FOR THE XXDP+ MONITOR:

```
CHMDKA0 XXDP+ DK MONITOR NNK
BOOTED VIA UNIT 0
ENTER DATE (DD-MMM-YY):
```

AFTER THE DATE HAS BEEN ACCEPTED BY THE MONITOR THE RESTART ADDRESS OF THE MONITOR IS PRINTED. THEN THE FOLLOWING TWO QUESTIONS ARE ASKED:

```
50 HZ ? N
LSI ?   N
```

THE DEFAULTS ARE BOTH "NO". TYPE "R" AND THE PROGRAM NAME TO RUN THE PROGRAM. DO NOT TYPE THE EXTENSION.

WHEN THIS DIAGNOSTIC IS STARTED THE FOLLOWING STEPS WILL OCCUR:

```
**********
* STEP 1 *
**********
```

THE DIAGNOSTIC WILL ISSUE THE PROMPT "DR>". FROM THIS POINT UNTIL THE TIME WHEN YOU RESTART XXDP+, YOU WILL BE TALKING TO THE DIAGNOSTIC, NOT XXDP+. WE WILL REFER TO THE PRESENCE OF THIS PROMPT AS BEING IN DIAGNOSTIC COMMAND MODE, AS OPPOSED TO XXDP+ COMMAND MODE.

AT THIS POINT YOU WILL ENTER A "START" COMMAND. THIS IS NOT THE SAME AS THE XXDP+ "START" COMMAND, WHICH YOU ALREADY ISSUED IN RESPONSE TO THE XXDP+ DOT PROMPT. THIS "START" COMMAND CAN TAKE A NUMBER OF SWITCHES AND FLAGS (ALL OPTIONAL) AND THE DETAILS OF THESE ARE SET FORTH IN 2.3 "DETAILS OF COMMANDS AND SYNTAX". HOWEVER, IN ORDER TO USE THE PROGRAM, ALL YOU NEED TO SAY IS SOMETHING LIKE THIS:

```
STA/PASS:1/FLAGS:HOE
```

THINGS TO NOTE HERE:

1. ONLY THE FIRST THREE CHARACTERS OF THIS OR ANY COMMAND AT THE 'DR>' LEVEL NEED TO BE TYPED.

2. THE 'PASS' SWITCH SPECIFIES HOW MANY PASSES YOU DESIRE. A PASS CONSISTS OF RUNNING THE FULL DIAGNOSTIC AGAINST ALL UNITS BEING TESTED (THIS WILL BE EXPLAINED SHORTLY). ONE PASS IS SPECIFIED IN THE ABOVE EXAMPLE.

3. THE 'FLAGS' SWITCH MAY SPECIFY ANY OF A NUMBER OF FLAGS, BUT THE MAIN USEFUL ONES ARE:

PNT	PRINT NUMBER OF TEST BEING EXECUTED
LOE	LOOP ON ERROR
HOE	HALT ON ERROR
IER	INHIBIT ERROR PRINTOUT

   THE HOE FLAG IS SPECIFIED IN THE ABOVE EXAMPLE (WE'LL SEE WHY SHORTLY).

```
**********
* STEP 2 *
**********
```

WHEN YOU HAVE TYPED IN A 'START' COMMAND, THE DIAGNOSTIC WILL COME BACK WITH THE QUESTION '# UNITS?' TO WHICH YOU SHOULD RESPOND BY TYPING IN THE NUMBER OF DEVICES YOU WISH TO TEST.

A WORD OF WARNING HERE: THE NUMBER OF UNITS DEPENDS ON THE TARGET DEVICE OF THE DIAGNOSTIC. FOR EXAMPLE, IF THE DIAGNOSTIC IS DIRECTED AT A DISK DRIVE, THEN THE NUMBER OF UNITS WOULD BE THE NUMBER OF DRIVES TO BE TESTED. WHEREAS IF THE DIAGNOSTIC WAS DIRECTED AT THE DISK CONTROLLER, THEN THE NUMBER OF UNITS WOULD BE THE NUMBER OF CONTROLLERS. THE TARGET DEVICE OF A DIAGNOSTIC CAN ALWAYS BE DETERMINED BY INSPECTING THE 'HEADER' STATEMENT NEAR THE BEGINNING OF THE SOURCE CODE. ONE OF THE OPERANDS OF THIS 'HEADER' STATEMENT SHOULD BE THE DEVICE TYPE OF THE DIAGNOSTIC.

```
**********
* STEP 3 *
**********
```

WHEN YOU HAVE TYPED IN THE NUMBER OF UNITS TO BE TESTED, THE DIAGNOSTIC WILL ASK YOU THE 'HARDWARE QUESTIONS'. THE ANSWERS TO THESE QUESTIONS ARE USED TO BUILD TABLES IN CORE, CALLED 'HARDWARE P-TABLES'. ONE HARDWARE P-TABLE WILL BE BUILT FOR EACH UNIT TO BE TESTED.

THERE ARE SEVERAL HARDWARE QUESTIONS AND THE ENTIRE SERIES WILL BE POSED N TIMES, WHERE N IS THE NUMBER OF UNITS.

THIS REPRESENTS A NEW PHILOSOPHY IN DIAGNOSTIC ENGINEERING. DIAGNOSTICS IN THE FUTURE WILL NOT BE WRITTEN TO AUTOSIZE OR ASSUME STANDARD ADDRESSES: INSTEAD, THEY WILL ASK THE OPERATOR FOR ALL THE INFORMATION THEY NEED TO TEST THE DEVICE.

```
**********
* STEP 4 *
**********
```

AFTER YOU HAVE ANSWERED ALL THE HARDWARE QUESTIONS (SEC 2.5) FOR ALL THE UNITS, YOU WILL BE ASKED "CHANGE SW?" IF YOU WANT TO BE ASKED THE SOFTWARE QUESTIONS THAT DETERMINE THE BEHAVIOR OF THIS PROGRAM, TYPE 'Y'. IF YOU WANT TO TAKE ALL THE DEFAULTS TO THESE QUESTIONS, TYPE 'N'. IF YOU TYPE 'Y' YOU WILL BE ASKED THE SOFTWARE QUESTIONS (SEC 2.6), AND THE ANSWERS WILL BE PUT INTO THE SOFTWARE P-TABLE IN THE PROGRAM. THE SERIES OF QUESTIONS WILL BE ASKED JUST ONCE, REGARDLESS OF THE NUMBER OF UNITS TO BE TESTED.

```
**********
* STEP 5 *
**********
```

AFTER YOU HAVE ANSWERED THE SOFTWARE QUESTIONS, THE DIAGNOSTIC WILL BEGIN TO EXECUTE THE HARDWARE TEST CODE. THERE ARE SEVERAL THINGS THAT CAN HAPPEN NEXT, DEPENDING ON WHETHER A HARDWARE ERROR IS ENCOUNTERED AND ALSO ON WHAT SWITCH VALUES YOU SELECTED ON THE START COMMAND. CONSIDER THE POSSIBILITIES:

1. IF NO ERROR IS ENCOUNTERED, THEN THE DIAGNOSTIC WILL SIMPLY EXECUTE THE DESIRED NUMBER OF PASSES AND RETURN TO COMMAND MODE (PROMPT DR>).

2. IF AN ERROR IS ENCOUNTERED, THEN ONE OF THREE THINGS HAPPENS, DEPENDING ON THE SETTINGS OF THE HOE AND LOE FLAGS.

   HOE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND THE DIAGNOSTIC WILL RETURN TO COMMAND MODE.

   LOE SET: THE DIAGNOSTIC WILL LOOP ENDLESSLY ON THE BLOCK OF CODE THAT DETECTED THE ERROR.

   NEITHER HOE NOR LOE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND NORMAL EXECUTION WILL RESUME AS IF NO ERROR HAD OCCURRED.

2.1.2 SAMPLE RUN-THROUGH

LET'S SEE HOW ALL THIS WORKS IN A REAL SITUATION. RECALL THAT WE ENTERED THE COMMAND "STA/PASS:1/FLAGS:HOE". THIS WOULD BE A VERY TYPICAL WAY TO RUN THE DIAGNOSTIC. IF NO ERRORS ARE ENCOUNTERED, THE SINGLE REQUESTED PASS WILL BE EXECUTED AND THE PROMPT WILL BE RE-ISSUED.

IF AN ERROR IS ENCOUNTERED, THE ERROR WILL BE REPORTED AND THE PROMPT WILL BE REISSUED (BECAUSE THE HOE FLAG IS SET). AT THIS POINT THERE ARE FOUR DIFFERENT WAYS YOU CAN GET THE PROGRAM GOING AGAIN:

1. ISSUE ANOTHER "START" COMMAND (THUS GOING THRU ALL OF STEPS 1, 2, 3, 4, AND 5 AGAIN)

2. ISSUE A "RESTART" COMMAND (SAME AS START COMMAND EXCEPT THAT THE HARDWARE QUESTIONS ARE NOT ASKED)

3. ISSUE A "CONTINUE" COMMAND (EXECUTION WILL RESUME AT THE BEGINNING OF THE PARTICULAR HARDWARE TEST (MOST DIAGNOSTICS CONSIST OF A NUMBER OF THESE) THAT IT WAS IN WHEN THE ERROR HALT OCCURRED. NO QUESTIONS ASKED.

4. ISSUE A "PROCEED" COMMAND: EXECUTION WILL RESUME AT THE INSTRUCTION FOLLOWING THE ERROR REPORT (THIS IS A SPECIAL COMMAND AND CAN BE ISSUED ONLY AT A HALT ON ERROR).

THE MOST TYPICAL THING TO DO HERE IS TO ISSUE THE PROCEED, BUT WITH DIFFERENT FLAG SETTINGS. PROBABLY YOU WOULD WANT TO SAY:

```
PRO/FLAGS:IER:LOE:HOE=0
```

THIS WILL DO THE FOLLOWING:

1. TURN ON THE IER (INHIBIT ERROR PRINTOUT) FLAG

2. TURN ON THE LOE FLAG

3. TURN OFF THE HOE FLAG

4. RESUME EXECUTION AT INSTRUCTION AFTER ERROR REPORT

THE DIAGNOSTIC WILL NOW LOOP ON THE BLOCK OF CODE THAT DETECTED AND REPORTED THE ERROR, BUT NO ERROR PRINTOUT WILL OCCUR. THUS YOU CAN STUDY THE ERROR OR SCOPE IT OR WHATEVER.

WHEN YOU'VE SEEN ENOUGH, YOU MAY HIT CONTROL/C. THIS WILL TAKE YOU OUT OF THE LOOP AND PUT YOU BACK INTO COMMAND MODE. YOU NOW HAVE THREE CHOICES:

1. START
2. RESTART
3. CONTINUE

LET'S SAY YOU'VE REPAIRED THE DEFECT FOUND ABOVE AND WANT TO FINISH RUNNING THE DIAGNOSTIC. YOU WOULD TYPE

```
CON/FLAGS:HOE:IER=0:LOE=0
```

THIS WILL RESTORE THE FLAGS TO THEIR ORIGINAL VALUES AND RESUME EXECUTION AT THE BEGINNING OF THE HARDWARE TEST YOU WERE IN. IF THE ERROR DOES NOT RECUR, THE EXECUTION WILL FLOW RIGHT ON THRU TO THE NEXT ERROR OR TO END OF PASS.

IF AT END OF PASS YOU WANT TO RUN THE DIAGNOSTIC AGAIN, YOU HAVE TWO CHOICES:

1. START
2. RESTART

YOU WOULD CHOOSE ONE, DEPENDING ON WHETHER YOU WANTED TO ANSWER THE HARDWARE QUESTIONS AGAIN.

THE FULL PRINT-OUT FROM THE ABOVE DIALOGUE MIGHT LOOK LIKE THIS
(O=OPERATOR, D=DIAGNOSTIC):

```
                                        BY
                                        WHOM
                                        ENTERED:
                                        -------

.R CZRLJB                               O
DRS LOADED                              D
DIAG. RUN-TIME SERVICES REV. D APR-79   D
CZRLJ-B-0                               D
CZRLJ TESTS OUTER & INNER GUARD         D
BAND DETECTION AND SEEK OPERATIONS
UNIT IS RL01, RL02                      D
DR>STA/PASS:1/FLAGS:HOE                 D,O

# UNITS (D) ? 2                         D,O

UNIT 0                                  D
RL11 (L) Y ?                            D,O
BUS ADDRESS (O) 174400 ?                D,O
VECTOR (O) 160 ?                        D,O
DRIVE (O) 0 ?                           D,O
DRIVE TYPE = RL01 (L) Y ?               D,O
BR LEVEL (O) 5 ?                        D,O

UNIT 1                                  D
RL11 (L) Y ?                            D,O
BUS ADDRESS (O) 174400 ?                D,O
VECTOR (O) 160 ?                        D,O
DRIVE (O) 0 ? 1                         D,O
DRIVE TYPE = RL01 (L) ? N               D,O (N=RL02)
BR LEVEL (O) 5 ?                        D,O

CHANGE SW (L) ? Y                       D,O

USE ALL CYL (L) N ?                     D,O
USE ALL SECT (L) N ?                    D,O
LOW SEEK LIMIT (L) N ?                  D,O
UPPER SEEK LIMIT (L) N ?                D,O
USE ONLY ONE SURF (L) N ?               D,O
INPUT ERROR LIMIT (D) 20 ?              D,O
DATA CMP ERR LMT (D) 10 ?               D,O


CZRLJ HRD ERR 00004 TST 003 SUB 002 PC:004130
ERR HLT

DR>PRO/FLAGS:IER:LOE:HOE=0              D,O
```

```
**************************************************
AT THIS POINT THE DIAGNOSTIC IS LOOPING ON THE
ERROR WITHOUT PRINTING ANYTHING.  YOU CAN SCOPE
THE ERROR UNTIL YOU HAVE LOCATED IT, THEN ^C OUT.
**************************************************

^C                                          0

DR>CON/FLAGS:HOE:IER:LOE=0                  D,0

CHANGE SW (L) ? N                           D,0

CZRLJ EOP 1                                 D
^C

DR>RESTART/PASS:1                           D,0

CHANGE SW (L) ? N                           D,0
-------------------
-------------------
-------------------
-------------------
```

2.2 CHAIN MODE OPERATION

CHAIN MODE OPERATION CONSISTS OF THE SEQUENTIAL EXECUTION OF PROGRAMS WITHOUT OPERATOR INTERVENTION. ONLY PROGRAMS THAT HAVE BEEN MODIFIED TO RUN IN CHAIN MODE CAN BE CHAINED. CHAINABLE PROGRAMS ARE IDENTIFIED IN THE DIRECTORY BY A BIC EXTENSION.

TO RUN CHAIN MODE, THE XXDP+ MONITOR USES AN ASCII FILE (KNOWN AS A CHAIN FILE) LISTING THE PROGRAMS TO BE RUN AND THE NUMBER OF PASSES EACH PROGRAM SHOULD RUN. THIS FILE MUST BE ON THE SYSTEM DEVICE.

A CHAIN FILE MAY BE GENERATED BY USE OF THE XTECO TEXT EDITOR. THIS FILE MUST HAVE A CCC EXTENSION. THE CHAIN FILE MAY CONTAIN ANY OF THE COMMANDS SUPPORTED BY THE XXDP+ MONITOR. THE COMMANDS IN THE ASCII FILE ARE EXECUTED IN THE ORDER IN WHICH THEY ARE ENCOUNTERED.

TO EXECUTE A CHAIN FILE THE USER TYPES:

```
C FILNAM <CR> OR
C FILNAM/QV  <CR>
```

IN THE FIRST CASE THE PASS COUNT SPECIFIED IN THE CHAIN FILE IS USED BY THE XXDP+ MONITOR TO DETERMINE THE NUMBER OF PASSES TO EXECUTE EACH PROGRAM. IN THE SECOND CASE THE PROGRAM COUNT IS NOT USED AND EACH PROGRAM IS EXECUTED ONLY ONCE. THE /QV SWITCH PROVIDES A SINGLE EXECUTION MODE OF OPERATION OF QUICK VERIFY.

WHEN PROGRAMS ARE RUN IN CHAIN MODE, THE SOFTWARE SWITCH REGISTER SHOULD BE SET TO 000000. THE XXDP+ MONITOR PRINTS EACH COMMAND TAKEN FROM THE CHAIN FILE AND THEN EXECUTES THE COMMAND. WHEN THE LAST COMMAND OTHER THAN ANOTHER C COMMAND HAS BEEN EXECUTED THE XXDP+ MONITOR TERMINATES CHAIN MODE AND TYPES A PROMPT (.). IT IS READY TO ACCEPT ANOTHER COMMAND FROM THE CONSOLE. IF THE LAST COMMAND IS ANOTHER C COMMAND, THE CHAIN MODE WILL CONTINUE AND THE CHAIN FILE SPECIFIED BY THIS NEW C COMMAND WILL BE USED.

IF THE USER WISHES TO TERMINATE CHAIN MODE BEFORE ITS NORMAL TERMINATION HE MAY DO SO BY TYPING A CONTROL/C. HOWEVER, THE MONITOR WILL NOT ABORT THE CHAIN MODE UNTIL IT RECEIVES PROGRAM CONTROL FROM THE PROGRAM CURRENTLY RUNNING.

2.3 DETAILS OF COMMANDS AND SYNTAX

2.3.1 TABLE OF COMMAND VALIDITY

THERE ARE FOUR WAYS OF ENTERING DIAGNOSTIC COMMAND MODE, AND DIFFERENT SUBSETS OF THE DIAG COMMAND SET ARE AVAILABLE WITH EACH:

HOW ENTERED	LEGAL COMMANDS
1. OPERATOR ENTERED 'RUN DIAG'	START PRINT DISPLAY FLAGS ZFLAGS EXIT
2. DIAGNOSTIC HAS FINISHED ALL ITS REQUESTED PASSES	START RESTART PRINT DISPLAY FLAGS ZFLAGS EXIT
3. OPERATOR INTERRUPTED THE	START PRINT DISPLAY FLAGS ZFLAGS EXIT

4.	AN ERROR WAS ENCOUNTERED WITH THE HOE FLAG SET SET	START RESTART CONTINUE PROCEED PRINT DISPLAY FLAGS ZFLAGS EXIT

2.3.2 COMMAND SYNTAX

```
*********************************************************************
STA(RT)/TESTS:TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR
*********************************************************************
```

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. THE MESSAGE "# UNITS?" IS PRINTED. THE START COMMAND MAY BE ISSUED WHEN DIAGNOSTIC COMMAND MODE HAS BEEN ENTERED VIA ONE OF THE FOLLOWING: A) OPERATOR TYPED "RUN DIAGNOSTIC" B) DIAGNOSTIC FINISHED EXECUTING C) ERROR WAS ENCOUNTERED WITH HOE FLAG SET D) OPERATOR ENTERED CONTROL/C. AFTER THE OPERATOR RESPONDS TO "# UNITS?", THE HARDWARE DIALOGUE IS INITIATED. WHEN IT IS COMPLETED, THE QUESTIONS "CHANGE SW?" IS ISSUED, AND THE ANSWERS, IF GIVEN, BECOME THE NEW DEFAULTS. THEREFORE IT IS NECESSARY TO RELOAD THE PROGRAM IN ORDER TO RETURN TO THE LOAD DEFAULTS.

THE SWITCH ARGUMENTS ARE AS FOLLOWS:

"TEST-LIST" IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.) THAT SPECIFY THE TESTS TO BE EXECUTED. THE NUMBERS ARE SEPARATED BY COLONS. THE NUMBERS RANGE FROM 1 TO THE LARGEST TEST NUMBER IN THE DIAGNOSTIC. THEY MAY BE SPECIFIED IN ANY ORDER. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS.

"PASS-CNT" IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS) AGAINST ALL UNITS SUBMITTED. THE DEFAULT IS NON-ENDING TEST EXECUTION. "FLAG-LIST" IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPARATED BY COLONS, WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

HOE HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED

LOE LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR

IER INHIBIT ERROR REPORTING

IBE INHIBIT BASIC ERROR REPORTS

IXE INHIBIT EXTENDED ERROR REPORTS

PRI DIRECT ALL MESSAGES TO A LINE PRINTER

PNT PRINT NUMBER OF TEST BEING EXECUTED

BOE BELL ON ERROR

UAM RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION TESTS

ISR INHIBIT STATISTICAL REPORTS

IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC

ADR EXECUTE AUTODROP CODE

LOT LOOP ON TEST

EVL EVALUATE

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED.

''EOP-INCR'' IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS.

****
RES(TART)/TEST:TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR/UNITS:UNIT-LIST
****

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. HOWEVER, NEW ''P-TABLES'' ARE NOT BUILT. INSTEAD, THE ONES IN CORE ARE USED.

THE QUESTION ''CHANGE SW?'' IS ASKED AND THE ANSWERS GIVEN BECOME THE NEW DEFAULTS. THE COMMAND MAY BE ISSUED WHEN COMAND MODE HAS BEEN ENTERED VIA A) DIAGNOSTIC IS FINISHED B) HALT ON ERROR C) CONTROL/C.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. ''UNIT-LIST'' IS A SEQUENCE OF LOGICAL UNIT NUMBERS RANGING FROM 1 THRU N (N = NUMBER OF UNITS BEING TESTED) SPECIFYING WHICH UNITS ARE TO BE TESTED. THE LOGICAL UNIT NUMBER DESIGNATES THE POSITION OF THE P-TABLE IN CORE, ACCORDING TO THE ORDER IN WHICH THEY WERE BUILT. THE UNITS SPECIFIED MUST NOT HAVE BEEN DROPPED BY THE OPERATOR DROP COMMAND. THE UNIT-LIST DEFAULTS TO ''ALL THAT HAVE NOT BEEN DROPPED BY OPERATOR COMMAND''. THE EFFECT OF THE UNIT-LIST LASTS UNTIL THE NEXT START (WHERE IT IS AUTOMATICALLY RESET TO ''ALL'') OR THE NEXT RESTART.

2. ALL UNSPECIFIED FLAG SETTINGS ARE UNCHANGED.

****
CON(TINUE)/PASS:<PASS-CNT/FLAGS:<FLAG-LIST>
****

COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE RE-EXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. DEFAULT FOR PASS-CNT IS THE UNSATISFIED PASS-CNT FROM THE PREVIOUS START OR RESTART

2. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

****
PRO(CEED)/FLAGS:<FLAG-LIST>
****

COMMAND MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE PARAMETERS MAY BE ALTERED.

THE SWITCH ARGUMENTS ARE THE SAME AS THE START COMMAND EXCEPT:

1. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

****
EXIT
****

RETURN TO XXDP+ PROMPT MODE.

****
DRO(P)/UNITS:UNIT-LIST
****

THE UNITS SPECIFIED ARE DROPPED FROM TESTING UNTIL THEY ARE ADDED BACK OR UNTIL A START COMMAND IS GIVEN. A DROP CANNOT BE FOLLOWED BY A PROCEED.

THERE IS ALSO A "DROP" MACRO INTERNAL TO THE DIAGNOSTIC, WHICH GIVES THE FACILITY OF AUTO-DROPPING. THE DURATION OF A PROGRAM DROP, HOWEVER, IS ONLY UNTIL THE NEXT START OR RESTART.

****
ADD/UNITS:UNIT-LIST
****

THE UNITS SPECIFIED ARE ADDED BACK (THEY MUST HAVE BEEN PREVIOUSLY DROPPED BY THE DROP COMMAND) TO THE TEST SEQUENCE. AN ADD CANNOT BE FOLLOWED BY A PROCEED.

****
PRI(NT)
****

ALL STATISTICS TABLES ACCUMULATED BY THE DIAGNOSTIC ARE PRINTED. THE ISR (INHIBIT STATISTICAL REPORTING) FLAG IS CLEARED.

****
DIS(PLAY)/UNITS:<UNIT-LIST>
****

THE HARDWARE P-TABLES FOR ALL UNITS UNDER TEST ARE PRINTED OUT IN THE FORMAT IN WHICH THEY WERE ENTERED. ANY UNITS THAT WERE DROPPED BY THE OPERATOR "DROP" COMMAND ARE SO DESIGNATED.

****
FLA(GS)
****

THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.

****
ZFL(AGS)
****

ALL FLAGS ARE CLEARED.

2.4 EXTENDED P-TABLE DIALOGUE

THE FULL CAPABILITY OF THE HARDWARE DIALOGUE IS REVEALED BY THE FOLLOWING DISCUSSION OF WHAT HAPPENS INTERNALLY.

AS SOON AS THE QUESTION "# UNITS?" IS ANSWERED (WITH THE NUMBER N), SPACE IN CORE IS ALLOCATED FOR "N" P-TABLES. ALL OF THE P-TABLES ARE OF THE SAME FORMAT, AND THERE IS A ONE-TO-ONE CORRESPONDENCE BETWEEN THE HARDWARE PARAMETER QUESTIONS AND THE SLOTS IN THE P-TABLE FORMAT.

IN GIVING A STRING OF VALUES, COMMAS WITHOUT INTERVENING VALUES MAY BE USED TO INDICATE A REPETITION OF THE LAST NAMED VALUE.

A STRING OF VALUES MAY BE GIVEN AS A RANGE (6-10 FOR EXAMPLE). IF THE VALUES REPRESENT PURE NUMERICAL DATA, THIS SAMPLE RANGE TRANSLATES TO THE STRING 6,7,8,9,10 (AN INCREMENT OF 1). IF THE VALUES ARE ADDRESSES, THE SAMPLE RANGE TRANSLATES TO THE STRING 6,8,10 (AN INCREMENT OF 2).

NOW LET US SEE HOW WE COULD USE THESE CAPABILITIES TO CONSTRUCT A SET OF P-TABLES. ASSUME THAT WE HAVE 8 RL UNITS, AND THAT THERE ARE FIVE (5) HARDWARE PARAMETERS FOR EACH (5 SLOTS IN THE P-TABLE, 5 HARDWARE QUESTIONS IN THE DIALOGUE).

FOLLOWING IS THE DIALOGUE FOR THIS 8 RL0X DRIVE SYSTEM. THIS SYSTEM HAS TWO (2) RL11 TYPE CONTROLLERS ALL TO BE SET AT "BR LEVEL" 5. THE FIRST 4 DRIVES ARE RL01'S AND THE LAST 4 DRIVES ARE RL02'S (ON THE SECOND CONTROLLER):

```
# UNITS (D) ? 8

UNIT 0
RL11 (L) Y ?
BUS ADDDRESS (O) 174400 ?
VECTOR (O) 160 ?
DRIVE (O) 0 ? 0-3
DRIVE TYPE = RL01 (L) Y ?
BR LEVEL (O) 5 ?

UNIT 4
RL11 (L) Y ?
BUS ADDRESS (O) 174400 ? 175400
VECTOR (O) 160 ? 164
DRIVE (O) 0 ? 0-3
DRIVE TYPE = RL01 (L) Y ? N
BR LEVEL (O) 5 ?
```

THE FIRST TIME THRU THE P-TABLE QUESTIONS THE DEFAULT VALUES ARE USED FOR THE CONTROLLER TYPE (QUESTION #1), CSR ADDRESS OF THE CONTROLLER (QUESTION #2), THE CONTROLLER VECTOR ASSIGNMENT (QUESTION #3), THE DRIVE TYPE (QUESTION #5), AND THE "BR LEVEL" (QUESTION #6). THE ACTUAL UNIT NUMBERS OF THE RL01'S FOR QUESTION #4 WAS ASSIGNED 0 THRU 3 FOR THE FIRST 4 P-TABLE SLOTS.

THE SECOND TIME THRU THE P-TABLE QUESTIONS (FOR THE RL02 ASSIGNMENT ON THE SECOND CONTROLLER), THE FIRST QUESTION DEFAULTED TO "RL11" TYPE CONTROLLER. THE SECOND QUESTION WAS ANSWERED TO REFLECT THE CHANGE IN CSR ADDRESS FOR THE RL02 CONTROLLER (175400). THE SECOND CONTROLLER'S VECTOR WAS ALSO CHANGED TO 164 IN QUESTION #3. THE RL02 TEST UNIT NUMBERS WERE ASSIGNED VALUES 0 TO 3 IN QUESTION #4 AND THE DRIVF TYPE WAS SET FOR RL02'S FOR THE REMAINING 4 UNITS IN QUESTION #5. THE LAST QUESTION WAS DEFAULTED USING THE "BR LEVEL" FROM THE FIRST PASS.

2.5 HARDWARE PARAMETERS

THE FOLLOWING QUESTIONS WILL BE ASKED ON A START COMMAND. THE VALUE LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ON A CARRIAGE RETURN RESPONSE.

RL11 (L) Y?

ANSWER YES(Y) IF YOU HAVE AN RL11 CONTROLLER, NO(N) IF YOU HAVE AN RLV11 CONTROLLER.

BUS ADDRESS (O) 174400?

ANSWER WITH THE BUS ADDRESS OF THE CONTROLLER.

VECTOR (O) 160?

ANSWER WITH THE INTERRUPT VECTOR OF THE CONTROLLER.

DRIVE (O) 0?

ANSWER WITH THE DRIVE(S) CONNECTED TO THE CONTROLLER

DRIVE TYPE = RL01 (L) ?

ANSWER NO (N) IF DRIVE IS AN RL02

BR LEVEL (O) 5?

ANSWER WITH THE INTERRUPT PRIORITY OF THE CONTROLLER.

2.6 SOFTWARE PARAMETERS

THE FOLLOWING QUESTIONS ARE ASKED IF REQUESTED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES. THE SOFTWARE PARAMETERS GIVE THE PROGRAM FLEXIBILITY IN THE WAY IT RUNS. THE PARAMETERS CAN BE MODIFIED ON A START, RESTART, OR CONTINUE BY ANSWERING (Y)ES TO THE FOLLOWING QUESTION:

CHANGE S.W. ?

A YES ANSWER WILL ASK THE FOLLOWING SOFTWARE PARAMETER QUESTIONS, WITH THE PRESENT DEFAULT VALUE PRINTED TO THE LEFT OF THE QUESTION MARK. (THE LAST ANSWER GIVEN IS THE DEFAULT) THE DEFAULT IS TAKEN ON A <CR>. CONTROL Z (^Z) WILL DEFAULT ALL REMAINING QUESTIONS AND START THE TEST.

USE ALL CYLINDERS (N)?

IF "YES", THOSE TESTS THAT NORMALLY USE A SELECTED SET OF CYLINDERS WILL TEST EVERY CYLINDER ON THE CARTRIDGE.

USE ALL SECTORS (N)?

IF 'YES', THOSE TESTS THAT NORMALLY USE A SINGLE SECTOR TO TEST A GIVEN OPERATION (SUCH AS SEEK DESTINATION) WILL READ AND VERIFY EVERY SECTOR HEADER.

LOWER SEEK LIMIT (N)?

IF 'YES', THE NEXT PARAMETER IS REQUESTED.

ENTER VALUE (DECIMAL) (0)?

THIS LIMIT IS IMPOSED ON ALL SEEK OPERATIONS SUCH THAT TESTING IS NOT DONE BELOW THAT LIMIT. IN ADDITION, SETTING THIS LIMIT (OR THE UPPER LIMIT, SEE BELOW) CAUSES THE FORWORD AND REVERSE OSCILLATING SEEK TESTS TO PERFORM DIFFERENTLY (SEE TEST DESCRIPTION). TESTS THAT REQUIRE ACCESS TO A SPECIFIC CYLINDER THAT FALLS BELOW THE SPECIFIED LIMIT WILL IGNORE THE LIMIT (SEE WRITE/READ TEST PART 1).

UPPER SEEK LIMIT (N)?

IF 'YES', AN UPPER CYLINDER LIMIT IS IMPOSED IN THE SAME MANNER AS THE LOWER SEEK LIMIT. A 'YES' RESPONSE WILL CAUSE THE FOLLOWING PARAMETER REQUEST.

ENTER VALUE (DECIMAL) (255)?

USE ONLY ONE SURFACE (N)?

IF 'YES', THE NEXT PARAMETER IS REQUESTED.

SPECIFY SURFACE (0 OR 1) (DECIMAL) (0)?

WHICHEVER SURFACE IS SPECIFIED IS THE ONLY SURFACE TESTED IN THE ENTIRE PROGRAM. ANY TEST THAT IS DESIGNED TO TEST THE OTHER SURFACE IS AUTOMATICALLY BYPASSED. THE PROGRAM DOES NOT PRINT ANY INDICATION THAT A TEST IS BYPASSED IN THIS CASE.

SPECIFY ERROR LIMIT (DECIMAL) (20)?

THIS PARAMETER SPECIFIES THE MAXIMUM NUMBER OF ERRORS ALLOWED. THIS LIMIT IS ON A PER DRIVE BASIS IN A SINGLE PASS. IF THE ERROR LIMIT IS EXCEEDED, THE DRIVE IS DROPPED FROM FURTHUR TESTING.

DATA COMPARE ERROR LIMIT (DECIMAL) (20)?

THIS PARAMETER SPECIFIES THE NUMBER OF DATA COMPARE ERRORS THAT WILL BE LISTED FOR A GIVEN COMPARE OPERATION. AFTER THE LIMIT IS REACHED, THE DATA ERRORS ARE NOT PRINTED BUT THE COMPARE CONTINUES UNTIL THE END OF THE DATA FIELD. A TOTAL IS REPORTED AT THE END OF THE COMPARE.

3.0 ERROR INFORMATION

ALL ERRORS ARE PRINTED VIA CONSOLE DEVICE. THE ERROR INCLUDES ERROR NUMBER, TYPE AND PROGRAM LOCATION. ERRORS INCLUDE REGISTERS BEFORE AND AT ERROR WITH RELEVENT DATA.

3.1 ERROR REPORTING

THE OPERATION MESSAGE (LINE 4) IS GENERATED IN A DYNAMIC MANNER BASED ON THE SUBSYSTEM FUNCTION BEING EXECUTED AT THE TIME OF THE ERROR AND THE STATE OF THE FLAGS IN THE LOCATION TAGGED 'OPFLAGS'. THE POSSIBLE OPERATION MESSAGES ARE GIVEN BELOW.

SEEK - FROM (CYL NUM) DIFF (CYL DIFF) SGN (0 OR 1) HD (0 OR 1) WHERE THE VALUES ARE GIVEN IN OCTAL. THIS MESSAGE IS THE RESULT OF A SEEK OPERATION THAT WAS VERIFIED BY A READ HEADER AND THE HEAD POSITION AFTER A SEEK IS IN ERROR. (THE ACTUAL HEAD POSITION IN THIS ERROR SITUATION IS GIVEN IN THE RESULT LINE, LINE 5.)

READ DATA - IS A READ DATA OPERATION WHERE SOME FORM OF ERROR WAS DETECTED IN THE ACTUAL READ OPERATION. THIS ERROR COULD BE HARDWARE DETECTED SUCH AS DATA CRC, HEADER CRC, HEADER NOT FOUND, ETC., OR A SOFTWARE DETECTED ERROR SUCH AS DRIVE READY RESET AFTER A READ DATA COMPLETED.

READ DATA WITH DATA COMPARE - IS AN ERROR THAT WAS DETECTED AS BAD DATA IN THE BUFFER AFTER

A READ DATA OPERATION. WHEN THIS OPERATION IS REPORTED IT INDICATES THE ACTUAL READ DATA OPERATION COMPLETED WITH NO DETECTED ERRORS BUT THE DATA WAS WRONG.

READ HEADER - READ HEADER FOR 40 HEADERS - READ HEADER FOR 40 HEADERS WITH HEADER COMPARE - HAVE THE SAME GENERAL MEANING AS THE READ DATA AND READ DATA WITH DATA COMPARE. MESSAGES HAVING THE OPERATION OF READ HEADER OR READ HEADER FOR 40 HEADERS ARE THE RESULT OF ERRORS DETECTED IN THE ACTUAL OPERATION WHILE THE READ HEADER FOR 40 HEADERS WITH HEADER COMPARE INDICATES NO ERROR IN THE ACTUAL OPERATION BUT THE HEADER DATA ITSELF WAS IN ERROR.

WRITE DATA - RESET - GET STATUS - GET STATUS WITH RESET - ARE ALL BASIC OPERATIONS. AS BEFORE, THE ERROR DETECTION CAN BE EITHER HARDWARE OR SOFTWARE. THE RESULT LINE (LINE 5) WILL DEFINE THE REASON FOR THE REPORT.

LD DRV - UNLD DRV - ARE OPERATION MESSAGES THAT WILL APPEAR IN THE REPORT WHEN THE DRIVE LOAD AND UNLOAD SEQUENCE IS BEING TESTED.

ANOTHER GROUP OF OPERATION QUALIFIERS WILL BE REPORTED FOR OPERATIONS THAT FAIL IN SPECIFIC TESTS. THESE TESTS ARE THE WRITE/READ TEST PART 2, OVERWRITE TEST, AND THE ADJACENT CYLINDER INTERFERENCE TEST.

OPERATION	QUALIFIER
READ DATA WITH DATA COMPARE	FOL 0 TO CC SEEK
READ DATA	FOL 255 TO CC SEEK
WRITE DATA	FOL WRITE (NO SEEK)
READ HEADER	ADJ. CYL WRITTEN AFTER FWD SK
	ADJ. CYL WRITTEN AFTER REV SK
	SK FWD, WRT-SK REV, OVERWRT
	SK REV, WRT-SK FWD, OVERWRT

THE ABOVE OPERATIONS CAN BE REPORTED WITH ANY OF THE QUALIFIERS. THE QUALIFIERS IN THESE TESTS ARE AN ATTEMPT TO MAKE THE REPORT MORE MEANINGFUL BY PROVIDING INFORMATION ABOUT THE SEQUENCE OF OPERATIONS BEING DONE.

THE QUALIFIERS ''FOL 0 TO CC SEEK'' AND ''FOL 255 TO CC SEEK'' INDICATE THAT THE SEQUENCE OF OPERATIONS INCLUDED A SEEK OF A GIVEN DIRECTION TO THE CYLINDER WHERE THE TEST IS BEING PERFORMED.

THE ''FOL WRITE (NO SEEK)'' QUALIFIER MEANS THAT THE OPERATION WAS DONE AFTER A WRITE WITH NO HEAD MOVEMENT BETWEEN THE WRITE AND READ.

THE QUALIFIER ''ADJ CYL WRITTEN AFTER FWD SK'' AND ''ADJ CYL WRITTEN AFTER REV SK'' WILL BE REPORTED ONLY IN THE ADJACENT CYLINDER INTERFERENCE TEST. THESE QUALIFIERS ARE USED WHEN THE ERROR OCCURS ON THE CYLINDER UNDER TEST AND DEFINE THE DIRECTION THE HEADS WERE MOVED WHEN THE ADJACENT CYLINDER WAS WRITTEN.

THE QUALIFIERS ''SK FWD, WRT-SK REV, OVERWRT'' AND ''SK REV, WRT-SK FWD, OVERWRT'' WILL BE REPORTED ONLY IN THE OVERWRITE TEST. THESE QUALIFIERS DEFINE THE DIRECTION OF HEAD MOTION BEFORE THE INITIAL WRITE AND THE OVERWRITE.

THE QUALIFIER ''ON BAD SEC FILES'' WILL BE REPORTED WITH THE WRITE DATA COMMAND IF THE PROGRAM ABORTS THAT COMMAND BECAUSE THE WRITE WOULD BE ON THE BAD SECTOR FILES.

3.1.2 SPECIFIC RESULT MESSAGES

THE RESULT MESSAGE (LINE 5) IS GENERATED DYNAMICALLY BASED ON THE EXPECTED RESULT OF THE OPERATION BEING TESTED. SINCE OPERATIONS ARE MONITORED DURING EXECUTION THE RESULT MESSAGE MAY REPORT AN ERROR DETECTED DURING THE OPERATION AS WELL AS THE ERRORS SEEN AT THE END OF THE OPERATION. ONLY THE FIRST ERROR SEEN IS REPORTED IN ALL CASES.

THE GENERAL FORMAT FOR THE RESULT LINE IS:

RESULT:(VAR 1) IS (VAR 2) SB (VAR 3) (OPTIONAL QUALIFIER)
WHERE VARIABLE 1 CAN BE ONE OF THE FOLLOWING:

CONT ERR	(CONTROLLER ERROR)
DRV ERR	(DRIVE ERROR)
NON-EXSTNT MEM	(NON-EXISTANT MEMORY)
HDR CRC	(HEADER CRC ERROR)
DATA CRC	
HDR NOT FND	(HEADER NOT FOUND)
DATA LATE	
HDR NOT FND/HDR CRC/OPI	(ALL 3 BITS SET)
DRV RDY	(DRIVE READY)
SELECTED HEAD	
VOL CHK	(VOLUME CHECK)
COVER OPEN	
BRUSH HME	(BRUCH HOME)
WRT LCK	(WRITE LOCK)
HDS OUT	(HEADER OUT)
DRV SEL ERR	(DRIVE SELECT ERROR)
DRV STATE	(DRIVE STATE)
SPIN TIMEOUT	(SPINDLE TIMEOUT SPD ERROR)
WRT GAT ERR	(WRITE GATE ERROR)
SEEK TIMEOUT	(SKTO ERROR)
CUR HEAD ERR	(CURRENT IN HEAD ERROR)
WRT DAT ERR	(WRITE DATA ERROR)
OP INCOMPLETE	(OPI ERROR)
HDR/DAT ERR	(HDR CRC OR DATA CRC ERROR BIT 11 OF CS REGISTER)
HDR NOT FND/DAT LATE	(HDR NOT FOUND OR DATA LATE ERROR BIT 12 OF CS REGISTER)
CYL	(CYLINDER WHEN REPORTING A SEEK ERROR)

VARIABLE 2 WILL BE A VALUE THAT DEFINES WHAT THE RESULT ACTUALLY IS. THIS CAN BE A 1 OR 0 TO INDICATE A SET OF RESULT CONDITIONS, A NUMBER 0 TO 7 TO INDICATE THE DRIVE STATE, OR A NUMBER 0 TO 377 (OCTAL) TO IDENTIFY A CYLINDER NUMBER.

VARIABLE 3 DEFINES THAT THE VALUE GIVEN IS VARIABLE 2 SHOULD BE. THE OPTIONAL QUALIFIER IS PROVIDED WHEN IT IS USEFUL TO KNOW WHEN THE ERROR WAS DETECTED IN THE OPERATION BEING PERFORMED. THIS QUALIFIER IS USED TO REPORT RESULTS SUCH AS:

```
BRUSH HME IS 1 SB 0 IN STATE 2
HEADS OUT IS 0 SB 1 IN STATE 3
DRV RDY   IS 0 SB 1 IN DATA XFER
SELECTED HEAD IS 1 SB 0 IN CYCLE UP
DRV RDY   IS 0 SB 1 IN STATE 5
DRV RDY   IS 1 SB 0 IN SEEK W/O MOTION
DRV RDY   IS 0 SB 1 IN 10MS
DRV RDY   IS 0 SB 1 IN 500MS
DRV RDY   IS 0 SB 1 IN 5SECONDS
```

THESE RESULTS, WHEN SEEN WITH THE OPERATION MESSAGE, WILL BE SELF EXPLANATORY.

OTHER RESULT MESSAGES THAT CAN BE PART OF AN ERROR REPORT ARE:

''INTERRUPT TOO LATE''

WHICH INDICATES THAT THE OPERATION BEING PERFORMED DID NOT COMPLETE IN THE EXPECTED AMOUNT OF TIME. THIS RESULT CAN BE CAUSED BY THE DRIVE LOOSING READY BEFORE STARTING A READ HEADER AND THEREFORE NOT COMPLETING THE READ HEADER IN 1MS.

''FAIL TO RELOAD HEADS AFTER ERR CLEAR''

THIS IS REPORTED WHEN AN ERROR CAUSES HEADS TO UNLOAD AND AFTER THE ERROR IS CLEARED THE HEADS DO NOT RELOAD.

''UNKN DRV STATE-NO RDY, NO ERR, HDS OUT''

THIS IS REPORTED WHEN THE PROGRAM CANNOT DETERMINE THE DRIVE STATE OR STATUS.

''WRITE ABORTED''

THIS IS REPORTED WHEN THE PROGRAM ABORTS A WRITE TO PROTECT THE BAD SECTOR FILES.

''COULD NOT RETRIEVE DRIVE STATUS''

THIS IS REPORTED IF THE GET STATUS COMMAND DOES NOT COMPLETE SUCCESSFULLY WHEN THE STATUS IS REQUIRED TO REPORT AN ERROR.

''OPI SET-NO DRIVE RESPONSE''

THIS IS REPORTED AS THE RESULT WHEN THE GET STATUS COMMAND IS TIMED OUT (OPI SETS) WHEN THAT COMMAND IS BEING USED IN THE EARLY TESTS TO CHECK THE DRIVE INTERFACE.

''NO INTERRUPT ON CMND COMPLETE''

THIS IS REPORTED WHEN THE COMMAND SUCCESSFULLY COMPLETES BUT THE CONTROLLER HAS NOT GENERATED AN INTERRUPT.

''ERR DID NOT CLEAR''

THIS IS REPORTED WHEN THE RESET COMMAND DOES NOT CLEAR THE CONTROLLER ERRORS. THIS IS A CONTROLER RELATED PROBLEM BUT IS REPORTED IF SEEN IN THE DRIVE TEST PROGRAMS.

'DRV ERR IS NOT CLEARED''

THIS IS REPORTED WHEN THE GET STATUS W/RESET COMMAND DOES NOT CLEAR ALL DRIVE ERRORS.

'UNEXPECTED ERR''

THIS IS REPORTED WHEN THE CONTROLLER SENSES AN ERROR BUT NO ERROR BITS ARE SET.

'BAD SEC FILE FMT ERR''

THIS IS REPORTED IF THE CONTENTS OF THE FILES DO NO CORRESPOND TO THE EXPECTED FORMAT. (REFER TO DEC STANDARD 144 FOR FORMAT SPECIFICS.)

3.1.3 OTHER MESSAGES

OTHER INFORMATION IS REPORTED UNDER VARIOUS CIRCUMSTANCES. THESE ARE:

'BAD SEC FILES NOT STRD. ALL SEC ASSUMED GOOD.''

THIS MESSAGE IS PRINTED WHEN A PARTICULAR TEST REQUIRES THE BAD SECTOR FILES BUT THEY HAVE NOT BEEN STORED. THIS SITUATION WILL OCCUR IF THIS TEST IS STARTED OUT OF THE NORMAL PROGRAM SEQUENCE OR IF THE BAD SECTOR FILES COULD NOT BE READ.

'ERROR LIMIT EXCEEDED-UNIT DROPPED''

THIS IS REPORTED (WITH THE UNIT NUMBER) WHEN MORE THAN THE SPECIFIED NUMBER OF ERRORS (DEFAULT 20) HAVE OCCURED IN ANY SINGLE PASS.

MOST ERROR REPORTS HAVE THE FOLLOWING FORMAT.

```
(1)   PROG NAME   ERR NUM   TEST NUM   SUBTEST NUM   ERR PC
(2)   ROUTINE TRACE SEQ (IN SEQ CALLED)
         (ADDRESS)
         (ADDRESS)
            .
            .
         (ADDRESS)
(3)   TEST DESCRIPTION
(4)   OPERATION:
(5)   RESULT:
(6)   ADDRESS OF UNIT UNDER TEST
```

```
(7)                RLCS    RLDA    RLBA    RLMP    CYL     HD
(8)   OP INIT
(9)   CP DONE
(10)        DRIVE STATUS
(11)               WORD NUM IS (XXXXXX) SB (YYYYYY)
(12)   TOTAL COMPARE ERRS: (ZZZ) OF (128)
```

THE ONLY EXCEPTION TO THE ABOVE FORMAT IS PURE DATA COMPARE ERRORS (NOT DETECTED BY READ ERROR). THEN THE FORMAT DOES NOT INCLUDE LINES 5 THROUGH 10.

LINE 1 IS THE ERROR HEADER AND IS PROVIDED BY THE SUPERVISOR. THE PROGRAM IS IDENTIFIED BY NAME WITH THE NUMBER OF TEST AND SUBTEST PRESENTLY BEING EXECUTED.

THE SUBTEST NUMBER IS UNIQUE IN THIS PROGRAM IN THAT IT DOES NOT REFER TO A PHYSICAL SUBTEST WITHIN A GIVEN TEST. RATHER IT REFLECTS THE NUMBER OF TIMES A SUBTEST HAS BEEN EXECUTED WITHIN A TEST. CONSEQUENTLY, ON A TEST THAT TESTS AN INCREMENTAL TYPE OF OPERATION (SUCH A INCREMENTAL SEEKS, READ ALL HEADERS FROM BOTH SURFACES, ETC.) THE SUBTEST WILL BE DESCRIPTIVE OF WHERE IN THE TEST THE ERROR OCCURRED.

THE ERROR P.C. IS THE PHYSICAL MEMORY LOCATION WHERE THE ERROR REPORT WAS INITIATED. SINCE MANY FUNCTIONS ARE SUBROUTINED, AND ERRORS ARE REPORTED FROM SUBROUTINES, THE ERROR P.C. IS NOT SUFFICIENT TO IDENTIFY THE LOCATION OF THE ERROR CALL AND THE ROUTINE TRACE SEQUENCE IS PROVIDED.

LINE 2 IS THE ROUTINE TRACE SEQUENCE. IF THE ERROR CALL IS INITIATED FROM WITHIN THE TEST (AS OPPOSED TO WITHIN A ROUTINE), THIS PORTION OF THE REPORT IS OMITTED. IF THE CALL IS INITIATED FROM A ROUTINE (WHICH MAY BE CALLED BY ANOTHER ROUTINE, WHICH MAY BE CALLED BY ANOTHER ROUTINE, ETC. SEVERAL LEVELS DEEP) THE ROUTINE TRACE SEQUENCE PROVIDES A TRAIL TO THE ACTUAL LOCATION WITHIN THE TEST THAT CALLED THE FIRST ROUTINE. THE FIRST ENTRY LISTED IS THE LOCATION WHERE THE FIRST ROUTINE WAS CALLED.

LINE 3 IS THE TEST DESCRIPTION AND IS ROUGHLY IDENTICAL TO THE NAME OF THE TEST BEING PERFORMED.

LINE 4 IDENTIFIES THE ACTUAL HARDWARE FUNCTION THAT IS BEING PERFORMED. ADDITIONAL INFORMATION ON THIS LINE IS DESCRIPTIVE OF SPECIFIC USE OF THE FUNCTION. FOR EXAMPLE, THE OPERATION LINE WILL READ 'READ HEADERS FOR 40 HEADERS'' WHEN ALL HEADERS ARE BEING READ FROM A TRACK.

LINE 5 IDENTIFIES THE ERROR THAT HAS BEEN DETECTED. THE CONTENT OF LINE 5 IDENTIFIES WHAT WAS BENG TESTED (SUCH AS DRIVE READY, CONTROLLER ERROR, DRIVE STATE, ETC.), WHAT IT IS AND WHAT IT SHOULD BE. LINE 5 MAY BE REPEATED IF MORE THAN ONE TESTED ITEM IS FOUND IN ERROR.

IN ADDITION LINE 5 WILL REPORT ANY HARDWARE DETECTED ERRORS SUCH AS OPERATION INCOMPLETE, HEADER CRC, ETC. IN THIS CASE THE FIRST LINE PRINTED AS RESULT WILL BE DETERMINED BY THE THREE ERROR BITS OPI, HNF/DLT, AND HCRC/DCRC. THE LINE WILL BE DETERMINED AS IN THE FOLLOWING TRUTH TABLE:

HNF/DLT	DCRC/HCRC	OPI	MESSAGE
1	1	1	HDR NOT FND/HDR CRC/OPI ERROR
0	1	1	HDR CRC ERROR
1	0	1	HDR NOT FND ERROR
0	1	0	DATA CRC ERROR
1	0	0	DATA LATE ERROR

LINE 6 IDENTIFIES THE PHYSICAL ADDRESS OF THE UNIT UNDER TEST. THIS ADDRESS IS BY UNIBUS ADDRESS OF THE CONTROLLER AND DRIVE NUMBER.

LINE 7 NAMES THE CONTROLLER REGISTERS (AND CYLINDER AND HEAD WHERE THESE ARE APPLICABLE IN THE REPORT) TO BE REPORTED.

LINE 8 PROVIDES THE CONTENTES OF CONTROLLER REGISTERS WHEN THE OPERATION WAS INITIATED.

LINE 9 PROVIDES THE CONTENTS OF THE CONTROLLER REGISTERS WHEN THE ERROR BEING REPORTED WAS DETECTED. FREQUENTLY THE REGISTER CONTENTS OF OP INIT AND OP DONE WILL BE DIFFERENT. OP INIT MAY INDICATE A SEEK WAS BEING PERFORMED BUT OP DONE MAY INDICATE THE ERROR WAS DETECTED BY A READ HEADER. THE REASON IS THAT A SEEK WAS EXECUTED AND DID NOT PROPERLY POSITION HEADS AND WHEN THE READ HEADER WAS DONE THE HEADS WERE ON THE WRONG CYLINDER.

LINE 10 IS THE DRIVE STATUS. THIS LINE IS ONLY REPORTED IF THE RLMP REGISTER DOES NOT CONTAIN THE ACTUAL DRIVE STATUS.

LINE 11 AND LINE 12 ARE REPORTED IF THE ERROR WAS DETECTED AS A COMPARE OPERATION, EITHER DATA OR HEADERS. IN ADDITION, GOOD AND BAD DATA IS REPORTED FOR ALL READ ERRORS.

3.2 ERROR HALTS

ERROR HALTS ARE SUPPORTED PER DESCRIBED IN THE PREVIOUS SECTION WITH /FLAG:HOE. THERE ARE NO OTHER HALTS.

4.0 PERFORMANCE AND PROGRESS REPORTS

4.1 PERFORMANCE REPORTS

THIS PROGRAM WILL NOT GIVE ANY PERFORMANCE REPORTS.

4.2 PROGRESS REPORTS

THIS PROGRAM WILL NOT GIVE ANY PROGRESS REPORTS.

5.0 DEVICE INFORMATION TABLES

THE RL11/RLV11 CONTROLLER HAS THE FOLLOWING FOUR(4) REGISTERS FOR CONTROL OF THE SUBSYSTEM.

RLCS - CONTROL AND STATUS REGISTER (XXXXX0)

```
BIT 15 - COMPOSITE ERROR
BIT 14 - DRIVE ERROR
BIT 13 - NON EXISTANT MEMORY ERROR
BIT 12 - HEADER NOT FOUND (WITH BIT 10 SET)
       - DATA LATE (WITH BIT 10 CLEAR)
BIT 11 - HEADER CRC (WITH BIT 10 SET)
       - DATA CRC (WITH BIT 10 CLEAR)
BIT 10 - OPERATION INCOMPLETE
BIT  9/8 - DRIVE SELECT (0-3)
BIT  7 - CONTROLLER READY
BIT  6 - INTERRUPT ENABLE
BIT  5 - EXTENDED BUS ADDRESS (BIT 17)
BIT  4 - EXTENDED BUS ADDRESS (BIT 16)
BIT 3-1 - FUNCTION CODE
        0 - NOP (PDP-11) MAINT (LSI-11)
        1 - WRITE CHECK
        2 - GET DRIVE STATUS
        3 - SEEK
        4 - READ HEADER
        5 - WRITE DATA
        6 - READ DATA
        7 - READ WITHOUT HEADER COMPARE

BIT  0 - DRIVE READY
```

RLBA - BUS ADDRESS REGISTER (XXXXX2)

BITS 15-1 BUS ADDRESS OF DATA TRANSFER
BIT 0 SHOULD BE 0

RLDA - DISK ADDRESS REGISTER (XXXXX4)

FOR READ/WRITE FUNCTIONS

BIT 15-7 - CYLINDER ADDRESS FOR TRANSFER
BIT 6 - SURFACE FOR TRANSFER
BIT 5-0 - SECTOR FOR TRANSFER (1-40.)

FOR SEEK FUNCTION

BIT 15-7 - DIFFERENCE TO NEW CYLINDER
BIT 6-5 - MUST BE ZERO (0)
BIT 4 - SURFACE (0=UPPER, 1=LOWER)
BIT 3 - MUST BE ZERO (0)
BIT 2 - SEEK DIRECTION(1=IN / 0=OUT)
BIT 1 - MUST BE ZERO (0)
BIT 0 - MUST BE ONE (1)

FOR GET STATUS FUNCTION

BIT 15-4 - IGNORED SHOULD BE ZERO (0)
BIT 3 - DRIVE RESET
BIT 2 - MUST BE ZERO (0)
BIT 1 - MUST BE ONE (1)
BIT 0 - MUST BE ONE (1)

RLMP - MULTIPURPOSE REGISTER

FOR READ/WRITE FUNCTION

BIT 15 - 0 - WORD COUNT (TWO'S COMPLIMENT)

FOR READ HEADER FUNCTION

BIT 15-0 - DISK HEADER OF SECTOR (FIRST READ)
- ZERO WORD (SECOND READ)
- HEADER CRC (THIRD READ)

FOR GET STATUS FUNCTION

HAS DRIVE STATUS

BIT 15 - WRITE DATA ERROR
BIT 14 - CURRENT HEAD ERROR (CHE)
BIT 13 - WRITE LOCK STATUS (WL)
BIT 12 - SEEK TIME OUT (SKTO)
BIT 11 - SPIN ERROR (SPE)
BIT 10 - WRITE GATE ERROR (WGE)
BIT 9 - VOLUME CHECK (VC)

BIT 8 - DRIVE SELECT ERROR (DSE)
BIT 7 - DRIVE TYPE IS RL02 IF SET
BIT 6 - SURFACE (0=UPPPER, 1=LOWER)
BIT 5 - COVER OPEN
BIT 4 - HEADS HOME
BIT 3 - BRUSHES HOME
BIT 2-0 -STATE BITS
0 - LOAD STATE
1 - SPIN UP
2 - BRUSH CYCLE
3 - LOAD HEADS
4 - SEEK - TRACK COUNTING
5 - SEEK - LINEAR MODE
6 - UNLOAD HEADS
7 - SPIN DOWN

6.0 TEST SUMMARIES

TEST 1 OUTER GUARD BAND DETECTION TEST
******

DO READ HEADER, WAIT FOR INTERRUPT. CHECK IF AT CYLINDER 0. IF NOT, SEEK REVERSE 1 CYLINDER AT A TIME UNTIL CYLINDER 0 IS REACHED. IF ANY REVERSE SEEK FAILS TO MOVE THE HEADS IN 10 TRIES:

DETECTION OF GUARD BAND PREMATURE.

WHEN AT CYLINDER 0, DO SEEK DIFFERENCE OF 1, SIGN 0, HEAD 0. WAIT FOR INTERRUPT, WAIT FOR READY. READY SHOULD SET IN 20MS>T>15MS. IF NOT:

FAILED TO DETECT GUARD BAND

DO READ HEADER. WAIT FOR INTERRUPT. CHECK FOR CYLINDER 0. IF NOT:

FAILED TO SEEK BACK TO ZERO

DO SEEK WITH DIFFERENCE OF 1, SIGN 0, HEAD 1. DO SAME TESTS AS ABOVE WITH REGARD TO READY VS TIME AND CYLINDER FOUND IN HEADER.

NOTE: CHOOSING A SINGLE SURFACE WILL LIMIT THE TESTING TO THAT SURFACE.

TEST 2 INCREMENTAL FORWARD SEEK HEAD 0 TEST
******

POSITION HEADS AT CYLINDER 'LOLIMIT'' USING SEEKS WITH DIFFERENCE OF ONE, HEAD 0.

DO SEEK WITH DIFFERENCE OF 1, SIGN 1, HEAD 0. WAIT FOR INTERRUPT, WAIT FOR DRIVE READY. CHECK READY IS SET IN 15 MS. IF NOT:

POSITIONING PROBLEM AT A SPECIFIC CYLINDER
MECHANICAL OBSTRUCTION

CHECK THAT THIS CYLINDER IS OLD CYLINDER + 1. IF NOT:

DIFFERENCE REGISTER OR COUNT LOGIC FAILURE
TRACK CROSSING DETECTION FAILURE

REPEAT SEEKS AND READS UNTIL CYLINDER READ IS 'HILIMIT''.

NOTE 1: IF THE 'USE ALL SECTORS'' PARAMETER IS SPECIFIED AS 'Y'', THE TEST WILL READ AND TEST ALL 40 HEADERS (CARTRIDGE VERIFY).

NOTE 2: TESTING WILL BE DONE BETWEEN UPPER AND LOWER CYLINDER LIMITS. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE. THIS TEST WILL BE BYPASSED IF SURFACE 1 IS CHOSEN.

TEST 3 INCREMENTAL REVERSE SEEK HEAD 0 TEST
******

POSITION HEADS AT CYLINDER 'HILIMIT'' USING SEEKS WITH DIFFERENCE OF 1, HEAD 0.

DO SEEK WITH DIFFERENCE OF 1, SIGN 0, HEAD 0. WAIT FOR INTERRUPT, WAIT FOR DRIVE READY. CHECK READY SET IN 15 MS:

POSITIONING PROBLEM AT A SPECIFIC CYLINDER

DO READ HEADER, WAIT FOR INTERRUPT. CHECK THAT THIS CYLINDER IS OLD CYLINDER - 1. IF NOT:

DIFFERENCE REGISTER OR COUNT LOGIC FAILURE
TRACK CROSSING DETECTION FAILURE

REPEAT SEEK AND CHECKS UNTIL CYLINDER IS 'LOLIMIT''.

NOTE: IF THE 'USE ALL SECTORS'' PARAMETER IS SPECIFIED AS 'Y'', THE TEST WILL READ AND TEST ALL 40 HEADERS (CARTRIDGE VERIFY).

NOTE: TESTING WILL BE DONE BETWEEN UPPER AND LOWER CYLINDER LIMITS. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE. THIS TEST WILL BE BYPASSED IF SURFACE 1 IS CHOSEN.

TEST 4 INCREMENTAL FORWARD SEEK HEAD 1 TEST
******

POSITION HEADS AT CYLINDER 'HILIMIT' USING SEEKS WITH DIFFERENCE OF ONE, HEAD 0.

DO SEEK WITH DIFFERENCE OF 1, SIGN 1, HEAD 1. WAIT FOR INTERRUPT, WAIT FOR DRIVE READY. CHECK READY IS SET IN 15 MS. IF NOT:

POSITIONING PROBLEM AT A SPECIFIC CYLINDER

DO READ HEADER, WAIT FOR INTERRUPT. CHECK THAT THIS CYLINDER IS OLD CYLINDER + 1. IF NOT:

DIFFERENCE REGISTER OR COUNT LOGIC FAILURE
TRACK CROSSING DETECTION FAILURE

REPEAT SEEKS AND READS UNTIL CYLINDER READ IS 'HILIMIT'.

NOTE 1: IF THE 'USE ALL SECTORS' PARAMETER IS SPECIFIED AS 'Y', THE TEST WILL READ AND TEST ALL 40 HEADERS (CARTRIDGE VERIFY).

NOTE 2: TESTING WILL BE DONE BETWEEN UPPER AND LOWER CYLINDER LIMITS. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE. THIS TEST WILL BE BYPASSED IF SURFACE 0 IS CHOSEN.

TEST 5 INNER GUARD BAND DETECTION TEST
******

POSITION HEADS AT CYLINDER 'HILIMIT' USING SEEK WITH DIFFERENCE OF 1, HEAD 0.

WHEN AT MAX CYLINDER, DO SEEK WITH DIFFERENCE OF 1, SIGN 1, HEAD 0. WAIT FOR INTERRUPT, WAIT FOR DRIVE READY. READY SHOULD SET IN 20MS>T>15MS. IF NOT:

FAILED TO DETECT GUARD BAND

DO READ HEADER. WAIT FOR INTERRUPT. CHECK FOR MAX. CYLINDER IF NOT:

FAILED TO SEEK BACK TO MAX CYLINDER

DO SEEK WITH DIFFERENCE OF 1, SIGN 1, HEAD 1. DO SAME TESTS AS ABOVE.

NOTE: CHOOSING A SINGLE SURFACE WILL LIMIT THE TESTING TO

THAT SURFACE.

TEST 6 INCREMENTAL REVERSE SEEK HEAD 1 TEST
******

POSITION HEADS AT CYLINDER 'HILIMIT'' USING SEEKS WITH DIFFERENCE OF 1, HEAD 0.

DO SEEK WITH DIFFERENCE OF 1, SIGN 0, HEAD 1. WAIT FOR INTERRUPT, WAIT FOR DRIVE READY. CHECK READY SET IN 15 MS:

POSITIONING PROBLEM AT A SPECIFIC CYLINDER

DO READ HEADER, WAIT FOR INTERRUPT. CHECK THAT THIS CYLINDER IS OLD CYLINDER - 1. IF NOT:

DIFFERENCE REGISTER OR COUNT LOGIC FAILURE
TRACK CROSSING DETECTION FAILURE

REPEAT SEEK AND CHECKS UNTIL CYLINDER IS 'LOLIMIT''.

NOTE 1: IF PROGRAM MODE 2 IS USED AND THE 'USE ALL SECTORS'' PARAMETER IS SPECIFIED AS 'Y', THE TEST WILL READ AND TEST ALL 40 HEADERS (CARTRIDGE VERIFY).

NOTE 2: TESTING WILL BE DONE BETWEEN UPPER AND LOWER CYLINDER LIMITS. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE. THI TEST WILL BE BYPASSED IF SURFACE 0 IS CHOSEN.

TEST 7 SEEK TESTS
******

POSITION HEADS AT CYLINDER 'LOLIMIT'' USING SEEKS WITH DIFFERENCE OF 1, HEAD 0.

DO READ HEADER, RECORD POSITION. DO SEEK WITH DIFFERENCE OF 2 (MAX DISTANCE AT 3 IPS), SIGN 1, HEAD 0. DO READ HEADER, CHECK NEW CYLINDER IS OLD CYLINDER + DISTANCE. IF NOT:

TRACK CROSSING DETECTION FAILURE
DIFFERENCE COUNTER FAILURE
COUNT PULSE GENERATION FAILURE
VELOCITY ROM FAILURE

REPEAT ABOVE UNTIL OLD CYLINDER + DISTANCE > MAX. POSITION AT MAX.

DO READ HEADER, RECORD POSITION. DO SEEK WITH DIFFERENCE OF 2 (MAX DISTANCE AT 3 IPS), SIGN 0, HEAD 0. DO READ HEADER, CHECK NEW CYLINDER IS OLD CYLINDER - DISTANCE. IF NOT:

TRACK CROSSING DETECTION FAILURE

REPEAT UNTIL OLD CYLINDER - DISTANCE < 0. REPEAT ALL OF THE ABOVE USING HEAD 1.

REPEAT ALL OF THE ABOVE TESTS USING THE FOLLOWING DISTANCES: 2, 6, 9, 12, 17, 22, 27, 34, 41, 128, 256 FOR RL01 OR 4, 12, 18, 24, 34, 44, 54, 68, 82, 256, 512 FOR RL02. THESE DISTANCES ARE SPECIFIED BECAUSE THEY REPRESENT THE MAXIMUM DISTANCE FOR EACH VELOCITY LEVEL USED IN THE DRIVE.

NOTE: TESTING WILL BE DONE BETWEEN UPPER AND LOWER CYLINDER LIMITS. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE.

TEST 8 FORWARD OSCILLATING SEEK TEST
******

POSITION HEADS AT CYLINDER 0.

DO OSCILLATING SEEK USING HEAD 0 (SEEK FROM 0 TO 1 TO 0, 0 TO 2 TO 0, 0 TO 3 TO 0, ...0 TO MAX CYL TO 0). AFTER EACH SEEK READ HEADER AND VERIFY POSITION.

REPEAT TEST USING HEAD 1.

NOTE: IF EITHER CYLINDER LIMIT IS SPECIFIED, THE TEST WILL SEEK BETWEEN UPPER AND LOWER LIMITS FOR EACH SURFACE. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE. NOTE THAT LOOPING ON TEST THEN PROVIDES A FIXED DISTANCE SEEK LOOP.

TEST 9 REVERSE OSCILLATING SEEK TEST
******

POSITION HEADS AT MAX CYLINDER. DO OSCILLATING SEEK USING HEAD 0. (IF RL01 SEEK FROM 255 TO 254 TO 255, 255 TO 253 TO 255,....255 TO 0 TO 255.) AFTER EACH SEEK READ HEADER AND VERIFY POSITION.

REPEAT TEST USING HEAD 1.

NOTE: IF EITHER CYLINDER LIMIT IS SPECIFIED, THE TEST WILL SEEK BETWEEN UPPER AND LOWER LIMITS FOR EACH SURFACE. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE. NOTE THAT LOOPING ON TEST THEN PROVIDES A FIXED DISTANCE SEEK LOOP.

@

18	MACRO DEFINITIONS
88	GLOBAL DATA SECTION
222	GLOBAL DATA SECTION
643	GLOBAL MESSAGES
874	ERROR MESSAGES
1210	INITIALIZATION SECTION
1343	AUTO DROP SECTION
1383	CLEANUP CODE SECTION
1413	GLOBAL SUBROUTINES
2664	*TEST 1 **OUTER GUARD BAND DETECTION
2717	*TEST 2 **INCREMENTAL FORWARD SEEK HEAD 0
2765	*TEST 3 **INCREMENTAL REVERSE SEEK HEAD 0
2812	*TEST 4 **INCREMENTAL FORWARD SEEK HEAD 1
2864	*TEST 5 **INNER GUARD BAND DETECTION
2912	*TEST 6 **INCREMENTAL REVERSE SEEK HEAD 1
2961	*TEST 7 **SEEK TESTS
3025	*TEST 8 **FORWARD OSCILLATING SEEK
3084	*TEST 9 **REVERSE OSCILLATING SEEK
3147	PARAMETER CODING

```
                                        PART2==1
        000001                                  .ENABLE ABS
                                                .ENABLE AMA
        002000                                  .=2000
                                                .MCALL  SVC

002000                                          SVC
        000001                                  SVCTST=1
        000001                                  SVCSUB=1
        000001                                  SVCBGL=1
        000000                                  SVCINS=0
        000000                                  SVCTAG=0
```

```
                        .SBTTL  MACRO DEFINITIONS

                        .MACRO  WAITUS  ARG             ;MACRO MICRO-SEC WAIT
                                MOV     ARG,XDELAY      ;SAVE ARGUMENT
                                JSR     PC,TIME         ;CALL TIMING ROUTINE
                        .ENDM

                        .MACRO  WAITMS  ARG             ;MACRO MILLI-SEC WAIT
                                MOV     ARG,YDELAY      ;SAVE ARGUMENT
                                JSR     PC,XTIME        ;CALL TIMING ROUTINE
                        .ENDM

                        .MACRO  ABORTWAIT               ;MACRO CLEAR UNELAPSED TIME
                                MOV     XDELAY,TEMPO    ;SAVE MICRO-SEC RUN TIME
                                MOV     YDELAY,TEMP     ;SAVE MILLI-SEC RUN TIME
                                CLR     XDELAY          ;ABORT MICRO-SEC WAIT
                                CLR     YDELAY          ;ABORT MILLI-SEC WAIT
                        .ENDM

                        .MACRO  GETTIM  ARG             ;MACRO GET ELAPSED TIME
                                MOV     @#CLKCTR,ARG    ;STORE CLOCK COUNTER CONTENTS
                                CLR     @#CLKCSR        ;EVENT FINISHED, STOP CLOCK
                        .ENDM

                        .MACRO  STCLK                   ;MACRO START P-CLOCK
                                CLR     @#CLKCSB        ;CLEAR CLOCK COUNT SET BUFFER
                                CLR     @#CLKCTR        ;CLEAR CLOCK COUNTER
                                MOV     #23,@#CLKCSR    ;INITIALIZE CLOCK FOR COUNT-UP MODE,
                                                        ;/10 KHZ RATE, AND START CLOCK
                        .ENDM
```

```
 52
 53                                  .NLIST  CND,MD,ME
 54
 55
 56  002000                                  POINTER BGNSW,BGNSFT,BGNDU
 57
 58  002000                          BGNMOD  MDHEDR
 63  002000                          HEADER  CZRLJ,B,0,30000,0
(4)  002000      103                         .ASCII /C/
(4)  002001      132                         .ASCII /Z/
(4)  002002      122                         .ASCII /R/
(4)  002003      114                         .ASCII /L/
(4)  002004      112                         .ASCII /J/
(6)  002005      000                         .BYTE   0
(6)  002006      000                         .BYTE   0
(5)  002007      000                         .BYTE   0
(4)  002010      102                         .ASCII  /B/
(4)  002011      060                         .ASCII  /0/
(4)  002012   000000                         .WORD   0
(4)  002014   030000                         .WORD   30000
(4)  002016   030624                         .WORD   L$HARD
(4)  002020   031000                         .WORD   L$SOFT
(4)  002022   013540                         .WORD   L$HW
(4)  002024   013556                         .WORD   L$SW
(4)  002026   031342                         .WORD   L$LAST
(4)  002030   000000                         .WORD   0
(4)  002032   000000                         .WORD   0
(4)  002034   000000                         .WORD   0
(4)  002036   000000                         .WORD   0
(4)  002040   013574                         .WORD   L$DISPATCH
(4)  002042   000000                         .WORD   0
(4)  002044   000000                         .WORD   0
(4)  002046   000000                         .WORD   0
(4)  002050      003                         .BYTE   C$REVISION
(3)  002051      003                         .BYTE   C$EDIT
(4)  002052   000000                         .WORD   0
(5)  002054   000000                         .WORD   0
(4)  002056   000000                         .WORD   0
(4)  002060   002226                         .WORD   L$DVTYP
(4)  002062   000000                         .WORD   0
(4)  002064   000000                         .WORD   0
(4)  002066   000000                         .WORD   0
(4)  002070   000000                         .WORD   0
(4)  002072   015252                         .WORD   L$DU
(4)  002074   000000                         .WORD   0
(4)  002076   002122                         .WORD   L$DESC
(4)  002100   104035                         EMT     E$LOAD
(4)  002102   000000                         .WORD   0
(4)  002104   013616                         .WORD   L$INIT
(4)  002106   015124                         .WORD   L$CLEAN
(4)  002110   014566                         .WORD   L$AUTO
(4)  002112   013530                         .WORD   L$PROT
(4)  002114   000000                         .WORD   0
(4)  002116   000000                         .WORD   0
(4)  002120   000000                         .WORD   0
 65  002122                          ENDMOD
```

```
 66  002122                                  DESCRIPT <CZRLJ TESTS OUTER & INNER GUARD BAND DETECTION AND SEEK OPERATIONS>
(3)  002122  055103  046122  020112          .ASCIZ  /CZRLJ TESTS OUTER & INNER GUARD BAND DETECTION AND SEEK OPERATIONS/
(3)  002130  042524  052123  020123
(3)  002136  052517  042524  020122
(3)  002144  020046  047111  042516
(3)  002152  020122  052507  051101
(3)  002160  020104  040502  042116
(3)  002166  042040  052105  041505
(3)  002174  044524  047117  040440
(3)  002202  042116  051440  042505
(3)  002210  020113  050117  051105
(3)  002216  052101  047511  051516
(3)  002224     000
(2)          002226                         .EVEN
 67  002226                                  DEVTYP  <RL01,RL02>
(3)  002226  046122  030460  051054          .ASCIZ  /RL01,RL02/
(3)  002234  030114  000062
(2)                                         .EVEN
 68
 69                                         ;COPYRIGHT (C) 1979
 70                                         ;THIS SOFTWARE IS FURNISHED UNDER LICENSE FOR USE ONLY
 71                                         ;ON A SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH
 72                                         ;THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS
 73                                         ;SOFTWARE, OR ANY COPIES THEREOF, MAY NOT BE PROVIDED
 74                                         ;OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT
 75                                         ;FOR USE ON SUCH SYSTEM, AND TO ONE WHO AGREES TO THESE
 76                                         ;LICENSE TERMS. TITLE TO OWNERSHIP OF THE SOFTWARE SHALL
 77                                         ;AT ALL TIMES REMAIN IN DEC.
 78                                         ;
 79                                         ;THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE
 80                                         ;WITHOUT NOTICE AND SHALL NOT BE CONSTRUED AS A COMMITMENT
 81                                         ;BY DIGITAL EQUIPMENT CORPORATION.
 82                                         ;
 83                                         ;DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY
 84                                         ;OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.
 85
 86
 87
 88                                 .SBTTL  GLOBAL DATA SECTION
 89
 90  002240                         BGNMOD  GLBEQAT
 91
 92  002240                         EQUALS
(1)                                 ;
(1)                                 ; BIT DIFINITIONS
(1)                                 ;
(1)          100000                 BIT15== 100000
(1)          040000                 BIT14== 40000
(1)          020000                 BIT13== 20000
(1)          010000                 BIT12== 10000
(1)          004000                 BIT11== 4000
(1)          002000                 BIT10== 2000
(1)          001000                 BIT09== 1000
(1)          000400                 BIT08== 400
(1)          000200                 BIT07== 200
(1)          000100                 BIT06== 100
```

```
(1)     000040          BIT05== 40
(1)     000020          BIT04== 20
(1)     000010          BIT03== 10
(1)     000004          BIT02== 4
(1)     000002          BIT01== 2
(1)     000001          BIT00== 1
(1)                     ;
(1)     001000          BIT9==  BIT09
(1)     000400          BIT8==  BIT08
(1)     000200          BIT7==  BIT07
(1)     000100          BIT6==  BIT06
(1)     000040          BIT5==  BIT05
(1)     000020          BIT4==  BIT04
(1)     000010          BIT3==  BIT03
(1)     000004          BIT2==  BIT02
(1)     000002          BIT1==  BIT01
(1)     000001          BIT0==  BIT00
(1)                     ;
(1)                     ; EVENT FLAG DEFINITIONS
(1)                     ;   EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
(1)                     ;
(1)     000040          EF.START==      32.                     ; START COMMAND WAS ISSUED
(1)     000037          EF.RESTART==    31.                     ; RESTART COMMAND WAS ISSUED
(1)     000036          EF.CONTINUE==   30.                     ; CONTINUE COMMAND WAS ISSUED
(1)     000035          EF.NEW==        29.                     ; A NEW PASS HAS BEEN STARTED
(1)     000034          EF.PWR==        28.                     ; A POWER-FAIL/POWER-UP OCCURRED
(1)                     ;
(1)                     ;
(1)                     ; PRIORITY LEVEL DEFINITIONS
(1)                     ;
(1)     000340          PRI07== 340
(1)     000300          PRI06== 300
(1)     000240          PRI05== 240
(1)     000200          PRI04== 200
(1)     000140          PRI03== 140
(1)     000100          PRI02== 100
(1)     000040          PRI01== 40
(1)     000000          PRI00== 0
(1)                     ;
(1)                     ;OPERATOR FLAG BITS
(1)                     ;
(1)     000004          EVL==        4
(1)     000010          LOT==       10
(1)     000020          ADR==       20
(1)     000040          IDU==       40
(1)     000100          ISR==      100
(1)     000200          UAM==      200
(1)     000400          BOE==      400
(1)     001000          PNT==     1000
(1)     002000          PRI==     2000
(1)     004000          IXE==     4000
(1)     010000          IBE==    10000
(1)     020000          IER==    20000
(1)     040000          LOE==    40000
(1)     100000          HOE==   100000
 93                     ;       OFFSETS FOR HARDWARE P-TABLE
```

```
000000          CSR     =0                      ;BUS ADDRESS
000002          VECT    =2                      ;VECTOR ADDRESS
000004          PRIOR   =4                      ;PRIORITY
000006          TYPDR=6
000010          DRSB    =10                     ;DRIVE SELECT BIT
000012          CNT     =12                     ;CONTROLLER TYPE

                ;       OFFSET FOR SOFTWARE P-TABLE
000000          MISWI   =0                      ;SOFTWARE PARAMETERS SWITCHES
000002          LOLIM   =2                      ;CYLINDER LOWER LIMIT
000004          HILIM   =4                      ;CYLINDER HIGH LIMIT
000006          HEAD    =6                      ;SELECTED HEAD FOR RUNNING TESTS
000010          ERLIM   =10                     ;ERROR LIMIT
000012          DCLIM   =12                     ;DATA COMPARE ERROR LIMIT

                ;       BIT ASSIGNMENT FOR SOFTWARE P-TABLE SWITCHES
000001          ALLCYL  =BIT00                  ;USE ALL CYLINDERS
000002          ALLSEC  =BIT01                  ;USE ALL SECTORS
000004          DRSELT  =BIT02                  ;EXECUTE DRIVE SELECT TEST
000010          HDALIGN =BIT03                  ;EXECUTE HEAD ALIGNMENT TEST
010000          HEADLM  =BIT12                  ;HEAD LIMIT SPECIFIED FLAG
020000          HICYL   =BIT13                  ;HI LIMIT SPECIFIED FLAG
040000          LOCYL   =BIT14                  ;LO LIMIT SPECIFIED
100000          MITEST  =BIT15                  ;EXECUTE MANUAL INTERVENTION TESTS

                ;       SUBSYSTEM FUNCTIONS
000102          CKDATA  =102                    ;WRITE CHECK
000104          GTSTAT  =104                    ;GET STATUS
000106          SEEK    =106                    ;SEEK
000110          RDHEAD  =110                    ;READ HEADER
000112          WTDATA  =112                    ;WRITE DATA
000114          RDDATA  =114                    ;READ DATA
000116          RDNOHR  =116                    ;READ DATA, IGNORE HEADERS
000100          NOOP    =100                    ;NO OPERATION

                ;       OPERATION FLAGS
007777          COMPOP  =7777                   ;COMPOSITE OPERATION FLAGS
000002          HDRCMP  =BIT0                   ;HEADER COMPARE OPERATION
000001          DATACMP =BIT00                  ;DATA COMPARE OPERATION
000004          CYLUP   =BIT02                  ;CYCLE UP OPERATION
000010          ULOAD   =BIT03                  ;UNLOAD OPERATION
000020          INOUTS  =BIT04                  ;IN-OUT SEEK OPERATION
000040          OUTINS  =BIT05                  ;OUT-IN SEEK OPERATION
000100          FOLWRT  =BIT06                  ;FOLLOWING WRITE OPERATION
000200          REVSKS  =BIT07                  ;REV SEEK SEQ (ADJ INTERFERENCE)
000400          FWDSKS  =BIT08                  ;FWD SEEK SEQ (ADJ INTERFERENCE)
001000          REVSKO  =BIT09                  ;REV SEEK SEQ (OVERWRITE)
002000          FWDSKO  =BIT10                  ;FWD SEEK SEQ (OVERWRITE)
004000          BADADD  =BIT11                  ;BAD DISK ADDRESS
010000          SEEKOP  =BIT12                  ;SEEK OPERATION
020000          RORWOP  =BIT13                  ;READ OR WRITE OPERATION
040000          RELDWT  =BIT14                  ;RELOAD WAIT
100000          HDR40   =BIT15                  ;40 HEADER OPERATION
003760          MQUALS  =OUTINS!INOUTS!FOLWRT!REVSKS!FWDSKS!REVSKO!FWDSKO
                                                ;MESSAGE QUALIFIER BITS
```

```
                        ;       ERROR FLAGS FROM SUBROUTINES
000001                  TOSLOW  =BIT00                  ;OPERATION TOOK TOO LONG
000002                  NOIRPT  =BIT01                  ;NO INTERRUPT FROM OPERATION
000004                  CONHNG  =BIT02                  ;CONTROLLER HUNG
000010                  NOCLR   =BIT03                  ;BAD CONTROLLER CLEAR

000000                  RLCS    =0                      ;CONTROL AND STATUS REGISTER
000002                  RLBA    =2                      ;BUS ADDRESS REGISTER
000004                  RLDA    =4                      ;DISK ADDRESS REGISTER
000006                  RLMP    =6                      ;MULTI-PURPOSE REGISTER

                        ;       REGISTER BIT DEFINITIONS - CONTROL STATUS REGISTER
000000                  RLCSR   =0                      ;CONTROL AND STATUS REGISTER
100000                  ANYERR  =100000                 ;ANY ERROR BIT
040000                  DRVERR  =40000                  ;DRIVE ERROR BIT
020000                  NXMERR  =20000                  ;NON-EXISTANT MEMORY ERROR
010000                  DLTERR  =10000                  ;DATA LATE ERROR
010000                  HNFERR  =10000                  ;HEADER NOT FOUND ERROR
004000                  DCKERR  =4000                   ;DATA CHECK ERROR
004000                  HCRCERR =4000                   ;HEADER CHECK ERROR
002000                  OPIERR  =2000                   ;OPERATION INCOMPLETE ERROR
001400                  DSMSK   =1400                   ;DRIVE SELECT MASK
000200                  CRDYMSK =200                    ;CONTROLLER READY MASK
000100                  INTEBL  =100                    ;INTERRUPT ENABLE MASK
000060                  BAMSK   =60                     ;BUS ADDRESS UPPER MASK
000001                  DRDYMSK =1                      ;DRIVE READY MASK

                        ;       REGISTER BIT DEFINITIONS - DISK ADDRESS FOR DATA XFER
000077                  SAMSK   =77                     ;SECTOR ADDRESS MASK
000100                  HSMSK   =100                    ;HEAD SELECT MASK

                        ;       REGISTER BIT DEFINITIONS - DISK ADDRESS FOR SEEK
000001                  MBSET0  =1                      ;MUST BE SET, BIT 0
000004                  DIRBIT  =4                      ;DIRECTION BIT
000020                  HDSEL   =20                     ;HEAD SELECT BIT

                        ;       REGISTER BIT DEFINITIONS - DISK ADDRESS FOR GET STATUS
000003                  GETSTAT =3                      ;GET STATUS SETUP
000010                  DRSET   =10                     ;DRIVE RESET MASK

                        ;       REGISTER BIT DEFINITIONS - MP FOR DATA XFER
017777                  WCMSK   =17777                  ;WORD COUNT MASK
160000                  WCRNG   =160000                 ;WORD COUNT RANGE MASK

                        ;       REGISTER BIT DEFINITIONS - MP FOR READ HEADER
000077                  HDSEC   =77                     ;SECTOR MASK
000100                  HDHSEL  =100                    ;HEAD SELECT MASK

                        ;       REGISTER BIT DEFINITIONS - MP FOR GET STATUS
000007                  STAMSK  =7                      ;STATE MASK
000010                  BHSTAT  =10                     ;BRUSH HOME STATUS
000020                  HOSTAT  =20                     ;HEADS OUT STATUS
000040                  COSTAT  =40                     ;COVER OPEN STATUS
000100                  HSSTAT  =100                    ;HEAD SELECT STATUS
000400                  DSESTAT =400                    ;DRIVE SELECT ERROR STATUS
001000                  VCSTAT  =1000                   ;VOLUME CHECK STATUS
```

```
        002000          WGESTAT =2000                   ;WRITE GATE ERROR STATUS
        004000          SPDSTAT =4000                   ;SPIN ERROR STATUS
        010000          STOSTAT =10000                  ;SEEK TIMEOUT ERROR STATUS
        020000          WLSTAT  =20000                  ;WRITE LOCK STATUS
        040000          HCESTAT =40000                  ;HEAD CURRENT ERROR STATUS
        100000          WDESTAT =100000                 ;WRITE DATA ERROR STATUS

                        ;       P-CLOCK REGISTERS
        172540          CLKCSR  =172540                 ;CLOCK CONTROL AND STATUS REGISTER
        172542          CLKCSB  =172542                 ;CLOCK COUNT SET BUFFER
        172544          CLKCTR  =172544                 ;CLOCK COUNTER

002240                  ENDMOD


                        .SBTTL  GLOBAL DATA SECTION

002240                  BGNMOD  GLBDAT

                        ;       TABLE OF OPERATION MESSAGES

002240  000000          OPMSGS: .WORD   0               ;FILLER
002242  005405                  .WORD   MWRCHK          ;MESSAGE FOR WRITE CHECK
002244  005430                  .WORD   MGTSTA          ;             GET STATUS
002246  005360                  .WORD   MSEEK           ;             SEEK
002250  005375                  .WORD   MREADH          ;             READ HEADER
002252  005416                  .WORD   MWRITE          ;             WRITE DATA
002254  005364                  .WORD   MREAD           ;             READ DATA
002256  005513                  .WORD   MWRSET          ;             WITH RESET
002260  005442                  .WORD   MDATCP          ;             WITH DATA COMPARE
002262  005461                  .WORD   MHDRCP          ;             WITH HEADER COMPARE
002264  005560                  .WORD   MCYLUP          ;             LOAD HEADS
002266  005547                  .WORD   MULOAD          ;             UNLOAD HEADS
002270  005607                  .WORD   MINOUT          ;                IN-OUT SEQ
002272  005570                  .WORD   MOUTIN          ;                OUT-IN SEQ
002274  005630                  .WORD   MFOLWRT         ;                FOLLOWING WRITE
002276  005650                  .WORD   MREVSK          ;                REV SEEK
002300  005701                  .WORD   MFWDSK          ;                FWD SEEK
002302  005766                  .WORD   MRESKO          ;                REV SEEK
002304  005732                  .WORD   MFWSKO          ;                FWD SEEK
002306  006022                  .WORD   MBADAD          ;                BAD DISK ADD FOR WRITE
002310  005477                  .WORD   M40HDR          ;             40 HEADER OPERATION
002312  000000          T.DRIVE: .WORD  0
002314  000000          JJJ:    .WORD   0
002316  000000          HLMTW:  .WORD   0
002320  000000          CLRBYT: .WORD   0
002322  000000          NXTHL:  .WORD   0
002324  000000          GBND:   .WORD   0
002326  000000          CAMSK:  .WORD   0
002330  000000          DIRMSK: .WORD   0
002332  000000          HDCYL:  .WORD   0

                        ;       TABLE OF RESULT NAME MESSAGE ADDRESSES
002334  007771          RESTBL: .WORD   MCERR           ;CONTROLLER ERROR
002336  010102                  .WORD   MDRERR          ;DRIVE ERROR
```

```
002340  010320                    .WORD   MNEERR          ;NON-EXISTANT MEMORY ERROR
002342  010272                    .WORD   MFLERR          ;HEADER NOT FOUND-DATA LATE
002344  010255                    .WORD   MHDERR          ;HEADER OR DATA ERROR
002346  010245                    .WORD   MOPERR          ;OPERATION INCOMPLETE
002350  010352                    .WORD   MNDRST          ;NO DRIVE STATUS AVAILABLE
002352  000000                    .WORD   0
002354  010230                    .WORD   MWDERR          ;WRITE DATA ERROR
002356  010212                    .WORD   MHCERR          ;HEAD CURRENT ERROR
002360  000000                    .WORD   0
002362  010176                    .WORD   MSTERR          ;SEEK TIMEOUT ERROR
002364  010143                    .WORD   MSPERR          ;SPINDLE ERROR
002366  010161                    .WORD   MWGERR          ;WRITE GATE ERROR
002370  000000                    .WORD   0
002372  010113                    .WORD   MDSERR          ;DRIVE SELECT ERROR

                          ;       PATTERN TABLE
002374  005102            PATTBL: .WORD   PAT1
002376  005104                    .WORD   PAT2
002400  005144                    .WORD   PAT3
002402  005204                    .WORD   PAT4
002404  005244                    .WORD   PAT5
002406  005252                    .WORD   PAT6
002410  005312                    .WORD   PAT7
002412  005314                    .WORD   PAT8
002414  005354                    .WORD   PAT9
002416  005356                    .WORD   PAT10


                          ;       SUBROUTINE CALLING STACK
002420  000000            SUBSTK: .WORD   0               ;STACK IS 12 WORDS LONG
002422  000000                    .WORD   0
002424  000000                    .WORD   0
002426  000000                    .WORD   0
002430  000000                    .WORD   0
002432  000000                    .WORD   0
002434  000000                    .WORD   0
002436  000000                    .WORD   0
002440  000000                    .WORD   0
002442  000000                    .WORD   0

                          ;RL01 TABLE OF CYLINDERS
002444  000002            T25TBL: .WORD   2               ;TABLE OF DIFFERENCES
002446  000006                    .WORD   6
002450  000011                    .WORD   9.
002452  000014                    .WORD   12.
002454  000021                    .WORD   17.
002456  000026                    .WORD   22.
002460  000033                    .WORD   27.
002462  000042                    .WORD   34.
002464  000051                    .WORD   41.
002466  000200                    .WORD   128.
002470  000377                    .WORD   255.

                          ;RL02 TABLE OF CYLINDERS
002472  000004            T25TB2: .WORD   4
002474  000014                    .WORD   12.
```

```
002476  000022                          .WORD   18.
002500  000030                          .WORD   24.
002502  000042                          .WORD   34.
002504  000054                          .WORD   44.
002506  000066                          .WORD   54.
002510  000104                          .WORD   68.
002512  000122                          .WORD   82.
002514  000400                          .WORD   256.
002516  000777                          .WORD   511.

                                ;       TABLE TO BE USED TO BUILD AND STORE THE CYLINDERS

002520  000020                  T33TBL: .BLKW   16.
002560  000020                  TBT:    .BLKW   16.


002620      002                 CYLTBL: .BYTE   2               ;TABLE OF DEFAULT CYLINDERS
002621      007                         .BYTE   7.
002622      016                         .BYTE   14.
002623      024                         .BYTE   20.
002624      033                         .BYTE   27.
002625      041                         .BYTE   33.
002626      046                         .BYTE   38.
002627      055                         .BYTE   45.
002630      064                         .BYTE   52.
002631      072                         .BYTE   58.
002632      101                         .BYTE   65.
002633      110                         .BYTE   72.
002634      115                         .BYTE   77.
002635      124                         .BYTE   84.
002636      133                         .BYTE   91.
002637      141                         .BYTE   97.
002640      146                         .BYTE   102.
002641      154                         .BYTE   108.
002642      161                         .BYTE   113.
002643      170                         .BYTE   120.
002644      177                         .BYTE   127.
002645      206                         .BYTE   134.
002646      213                         .BYTE   139.
002647      222                         .BYTE   146.
002650      230                         .BYTE   152.
002651      235                         .BYTE   157.
002652      244                         .BYTE   164.
002653      252                         .BYTE   170.
002654      261                         .BYTE   177.
002655      270                         .BYTE   184.
002656      275                         .BYTE   189.
002657      303                         .BYTE   195.
002660      312                         .BYTE   202.
002661      317                         .BYTE   207.
002662      326                         .BYTE   214.
002663      334                         .BYTE   220.
002664      343                         .BYTE   227.
002665      352                         .BYTE   234.
002666      361                         .BYTE   241.
002667      367                         .BYTE   247.
```

```
374  002670    375                          .BYTE   253.
375  002671    000                          .BYTE   0
376  002672  000401                         .WORD   257.
377  002674  000406                         .WORD   262.
378  002676  000415                         .WORD   269.
379  002700  000423                         .WORD   275.
380  002702  000432                         .WORD   282.
381  002704  000445                         .WORD   293.
382  002706  000454                         .WORD   300.
383  002710  000463                         .WORD   307.
384  002712  000471                         .WORD   313.
385  002714  000500                         .WORD   320.
386  002716  000507                         .WORD   327.
387  002720  000514                         .WORD   332.
388  002722  000523                         .WORD   339.
389  002724  000532                         .WORD   346.
390  002726  000540                         .WORD   352.
391  002730  000545                         .WORD   357.
392  002732  000553                         .WORD   363.
393  002734  000560                         .WORD   368.
394  002736  000567                         .WORD   375.
395  002740  000576                         .WORD   382.
396  002742  000605                         .WORD   389.
397  002744  000612                         .WORD   394.
398  002746  000621                         .WORD   401.
399  002750  000627                         .WORD   407.
400  002752  000634                         .WORD   412.
401  002754  000643                         .WORD   419.
402  002756  000651                         .WORD   425.
403  002760  000660                         .WORD   432.
404  002762  000667                         .WORD   439.
405  002764  000674                         .WORD   444.
406  002766  000702                         .WORD   450.
407  002770  000711                         .WORD   457.
408  002772  000716                         .WORD   462.
409  002774  000725                         .WORD   469.
410  002776  000733                         .WORD   475.
411  003000  000742                         .WORD   482.
412  003002  000751                         .WORD   489.
413  003004  000760                         .WORD   496.
414  003006  000766                         .WORD   502.
415  003010  000774                         .WORD   508.
416  003012  000774                         .WORD   508.
417  003014  000000                         .WORD   0
418  003016  000000              SSINDX:    .WORD   0              ;SUBROUTINE STACK INDEX POINTER
419
420                              ;         OPERATIONAL FLAGS
421  003020  000000              OPFLAG:    .WORD   0              ;OPERATION FLAGS
422  003022  000000              DONE:      .WORD   0              ;OPERATION COMPLETE FLAG
423  003024  000000              HADONE:    .WORD   0              ;HEAD ALIGNMENT DONE FLAG
424  003026  000000              ERHEAD:    .WORD   0              ;ADDRESS OF ERROR HEADER
425  003030  000000              MORECE:    .WORD   0              ;MORE THAN 1 COMPARE ERROR
426  003032  000000              ERRSWI:    .WORD   0              ;ERROR RETURN SWITCH
427  003034  000000              BSFLAG:    .WORD   0              ;BAD SECTOR FLAGS
428  003036  000000              WRTSWI:    .WORD   0              ;WRITE SWITCH
429  003040  000000              TBLSTR:    .WORD   0              ;TABLE STORAGE
```

```
003042  000000          RLBAS:   .WORD   0          ;RL11 BASE ADDRESS
003044  000000          RLVEC:   .WORD   0          ;RL11 VECTOR ADDRESS
003046  000000          RLDRV:   .WORD   0          ;DRIVE NUMBER UNDER TEST

003050  000000          L.CS:    .WORD   0          ;CONTROLLER REGISTER STORAGE
003052  000000          L.BA:    .WORD   0          ;BEFORE OPERATION
003054  000000          L.DA:    .WORD   0
003056  000000          L.MP:    .WORD   0
003060  000000          T.CS:    .WORD   0          ;CONTROLLER REGISTER STORAGE
003062  000000          T.BA:    .WORD   0          ;   AFTER OPERATION
003064  000000          T.DA:    .WORD   0
003066                  T.MP:
003066  000000          HDWRD1:  .WORD   0          ;HEADER WORD STORAGE
003070  000000          HDWRD2:  .WORD   0
003072  000000          HDWRD3:  .WORD   0

003074  000000          T.STAT:  .WORD   0          ;DRIVE STATE STORAGE

003076  000000          RESPARM: .WORD   0          ;PARAM BLOCK FOR REASON REPORT
003100  000000                   .WORD   0
003102  000000                   .WORD   0
003104  000000                   .WORD   0
003106  000000                   .WORD   0

003110  000000          DRVCNT:  .WORD   0          ;DRIVE COUNT FOR DRIVES UNDER TEST
003112  000000          DIFAUG:  .WORD   0          ;DIFFERENCE AUGMENT FOR SEEK
003114  000000          OLDCYL:  .WORD   0          ;OLD CYLINDER
003116  000000          NEWCYL:  .WORD   0          ;NEW CYLINDER
003120  000000          CURCYL:  .WORD   0          ;CURRENT CYLINDER
003122  000000          DESDIF:  .WORD   0          ;DESIRED DIFFERENCE
003124  000000          DESSGN:  .WORD   0          ;DESIRED SIGN
003126  000000          DESHD:   .WORD   0          ;DESIRED HEAD
003130  000000          DESSEC:  .WORD   0          ;DESIRED SECTOR
003132  000000          TEMP0:   .WORD   0          ;TEMPORARY STORAGE
003134  000000          TEMP1:   .WORD   0          ;TEMPORARY STARAGE
003136  000000          TEMP2:   .WORD   0          ;TEMPORARY STORAGE
003140  000000          TEMP3:   .WORD   0          ;TEMPORARY STORAGE
003142  000000          TEMP4:   .WORD   0          ;TEMPORARY STORAGE
003144  000000          TEMP5:   .WORD   0          ;TEMPORARY STORAGE
003146  000000          TEMP6:   .WORD   0          ;TEMPORARY STORAGE
003150  000000          TEMP7:   .WORD   0          ;TEMPORARY STORAGE
003152  000000          TEMP8:   .WORD   0          ;TEMPORARY STORAGE
                        ;        TIMER STORAGE
003154  000000          OFIN:    .WORD   0          ;ONE CYLINDER FORWARD INNER
003156  000000          OFINU:   .WORD   0          ;       UPPER
003160  000000          OFMID:   .WORD   0          ;ONE CYLINDER FORWARD MIDDLE
003162  000000          OFMIDU:  .WORD   0          ;       UPPER
003164  000000          OFOUT:   .WORD   0          ;ONE CYLINDER FORWARD OUTER
003166  000000          OFOUTU:  .WORD   0          ;       UPPER
003170  000000          ORIN:    .WORD   0          ;ONE CYLINDER REVERSE INNER
003172  000000          ORINU:   .WORD   0          ;       UPPER
003174  000000          ORMID:   .WORD   0          ;ONE CYLINDER REVERSE MIDDLE
003176  000000          ORMIDU:  .WORD   0          ;       UPPER
003200  000000          OROUT:   .WORD   0          ;ONE CYLINDER REVERSE OUTER
003202  000000          OROUTU:  .WORD   0          ;       UPPER
```

```
003204  000000          HFIN:    .WORD   0          ;128 CYLINDER FORWARD INNER
003206  000000          HFINU:   .WORD   0          ;       UPPER
003210  000000          HFOUT:   .WORD   0          ;128 CYLINDER FORWARD OUTER
003212  000000          HFOUTU:  .WORD   0          ;       UPPER
003214  000000          HRIN:    .WORD   0          ;128 CYLINDER REVERSE INNER
003216  000000          HRINU:   .WORD   0          ;       UPPER
003220  000000          HROUT:   .WORD   0          ;128 CYLINDER REVERSE OUTER
003222  000000          HROUTU:  .WORD   0          ;       UPPER
003224  000000          AFMID:   .WORD   0          ;256 CYLINDER FORWARD
003226  000000          AFMIDU:  .WORD   0          ;       UPPER
003230  000000          ARMID:   .WORD   0          ;256 CYLINDER REVERSE
003232  000000          ARMIDU:  .WORD   0          ;       UPPER

003234  000226          EXOCYL:  .WORD   150.       ;EXPECTED TIME ONE CYLINDER
003236  001046          EXHCYL:  .WORD   550.       ;EXPECTED TIME 128 CYLINDER
003240  001750          EXACYL:  .WORD   1000.      ;EXPECTED TIME 256 CYLINDER
003242  000372          EXROT:   .WORD   250.       ;EXPECTED ROTATION TIME
003244  000004          ERRVEC:  .WORD   4          ;ERROR VECTOR

                        ;       MISCELLANEOUS COUNTERS
003246  000000          PASCNT:  .WORD   0          ;PASS COUNTER (LOCAL TO A TEST)
003250  000000          COUNT:   .WORD   0          ;A COUNTER (LOCAL TO A TEST)
003252  000000          ERRPOINT: .WORD  0          ;ERROR POINTER
003254  000100          ERRCNT:  .BLKW   64.        ;ERROR COUNTER FOR PROGRAM
003454  000000          PASNUM:  .WORD   0          ;PASS NUMBER FOR PROGRAM
003456  000000          PSETNM:  .WORD   0          ;COUNTER FOR PARAMETER SET NUMBER IN USE
003460     000          LOCERR:  .BYTE   0          ;LOCAL ERROR COUNTER
003461     000          NOERCT:  .BYTE   0          ;INHIBIT ERROR COUNTING FLAG
003462  000000          TRPFLG:  .WORD   0          ;HARDWARE TRAP OCCURANCE
003464  000000          PWRFLG:  .WORD   0          ;POWER FAILURE OCCURANCE
003466  000000          XDELAY:  .WORD   0
003470  000000          YDELAY:  .WORD   0
003472  000000          MININC:  .WORD   0
003474  000000          TEMP:    .WORD   0
003476  000000          TIM.US:  .WORD   0
003500  000000          TAG:     .WORD   0
003502  000000          MAJINC:  .WORD   0
003504  000000          CLKFLG:  .WORD   0          ;FLAG INDICATING PRESENCE OF A P-CLOCK
003506  000000          CLKADR:  .WORD   0          ;POINTER TO DIAGNOSTIC MONITOR CLOCK TABLE


                        ;       BAD SECTOR TABLES AND POINTERS
003510  000000          BSFVAL:  .WORD   0          ;BAD SECTORS FILES VALID FLAG

003512  000076          SBSFIL:  .BLKW   76         ;SOFTWARE BAD SECTOR FILE
003706  000076          FBSFIL:  .BLKW   76         ;FACTORY BAD SECTOR FILE

004102  000200          IBUFF:   .BLKW   200        ;INPUT BUFFER
004502  000200          OBUFF:   .BLKW   200        ;OUTPUT BUFFER

005102  000000          PAT1:    .WORD   0          ;PATTERN 1 (ALL ZEROS)
005104  177772          PAT2:    .WORD   177772
005106  177777                   .WORD   177777
005110  177777                   .WORD   177777
005112  052525                   .WORD   052525
005114  052525                   .WORD   052525
```

```
005116  052525                        .WORD   052525
005120  177777                        .WORD   177777
005122  177777                        .WORD   177777
005124  052525                        .WORD   052525
005126  052525                        .WORD   052525
005130  177777                        .WORD   177777
005132  052525                        .WORD   052525
005134  177252                        .WORD   177252
005136  177252                        .WORD   177252
005140  172765                        .WORD   172765
005142  172765                        .WORD   172765

005144  000003                PAT3:   .WORD   000003
005146  000000                        .WORD   000000
005150  000000                        .WORD   000000
005152  177777                        .WORD   177777
005154  177777                        .WORD   177777
005156  177777                        .WORD   177777
005160  000000                        .WORD   000000
005162  000000                        .WORD   000000
005164  177777                        .WORD   177777
005166  177777                        .WORD   177777
005170  000000                        .WORD   000000
005172  177777                        .WORD   177777
005174  000000                        .WORD   000000
005176  177777                        .WORD   177777
005200  000000                        .WORD   000000
005202  177777                        .WORD   177777

005204  025252                PAT4:   .WORD   025252
005206  052525                        .WORD   052525
005210  052525                        .WORD   052525
005212  125252                        .WORD   125252
005214  125252                        .WORD   125252
005216  125252                        .WORD   125252
005220  052525                        .WORD   052525
005222  052525                        .WORD   052525
005224  125252                        .WORD   125252
005226  125252                        .WORD   125252
005230  052525                        .WORD   052525
005232  125252                        .WORD   125252
005234  052525                        .WORD   052525
005236  125252                        .WORD   125252
005240  052525                        .WORD   052525
005242  125252                        .WORD   125252

005244  155555                PAT5:   .WORD   155555
005246  133333                        .WORD   133333
005250  066666                        .WORD   066666

005252  121105                PAT6:   .WORD   121105
005254  150442                        .WORD   150442
005256  064221                        .WORD   064221
005260  132110                        .WORD   132110
005262  055044                        .WORD   055044
005264  026442                        .WORD   026442
```

```
005266  013211                          .WORD   013211
005270  105504                          .WORD   105504
005272  042642                          .WORD   042642
005274  021321                          .WORD   021321
005276  110550                          .WORD   110550
005300  044264                          .WORD   044264
005302  022132                          .WORD   022132
005304  011055                          .WORD   011055
005306  104426                          .WORD   104426
005310  042213                          .WORD   042213

005312  177777                  PAT7:   .WORD   177777

005314  045513                  PAT8:   .WORD   045513
005316  122645                          .WORD   122645
005320  151322                          .WORD   151322
005322  064551                          .WORD   064551
005324  132264                          .WORD   132264
005326  055132                          .WORD   055132
005330  026455                          .WORD   026455
005332  113226                          .WORD   113226
005334  045513                          .WORD   045513
005336  122645                          .WORD   122645
005340  151322                          .WORD   151322
005342  064551                          .WORD   064551
005344  132264                          .WORD   132264
005346  055132                          .WORD   055132
005350  026455                          .WORD   026455
005352  113226                          .WORD   113226

005354  125252                  PAT9:   .WORD   125252

005356  155555                  PAT10:  .WORD   155555

005360                          ENDMOD



                                .SBTTL  GLOBAL MESSAGES

005360                          BGNMOD  GLBTXT

005360  045523  000040          MSEEK:  .ASCIZ  /SK /
005364  042122  042040  052101  MREAD:  .ASCIZ  /RD DATA /
005375     122  020104  042110  MREADH: .ASCIZ  /RD HDR /
005405     127  052122  041440  MWRCHK: .ASCIZ  /WRT CHCK/
005416  051127  020124  040504  MWRITE: .ASCIZ  /WRT DATA /
005430  042507  020124  052123  MGTSTA: .ASCIZ  /GET STAT /
005442  044527  044124  042040  MDATCP: .ASCIZ  /WITH DATA CMP /
005461     127  052111  020110  MHDRCP: .ASCIZ  /WITH HDR CMP /
005477     106  051117  032040  M40HDR: .ASCIZ  /FOR 40 HDRS/
005513     127  052111  020110  MWRSET: .ASCIZ  /WITH RESET /
005527     117  042520  035122  MOPER:  .ASCIZ  /OPER: /
005536  042522  052523  052114  MRSLT:  .ASCIZ  /RESULT:        /
```

```
659  005547     125  046116  020104  MULOAD: .ASCIZ  /UNLD DRV/
660  005560  042114  042040  053122  MCYLUP: .ASCIZ  /LD DRV /
661  005570  047506  020114  020060  MOUTIN: .ASCIZ  /FOL 0 TO CC SK/
662  005607     106  046117  031040  MINOUT: .ASCIZ  /FOL 255 TO CC SK/
663  005630  047506  020114  051127  MFOLWRT:        .ASCIZ  /FOL WRT (NO SK)/
664  005650  042101  020112  054503  MREVSK: .ASCIZ  /ADJ CYL WRTTN AFT REV SK/
665  005701     101  045104  041440  MFWDSK: .ASCIZ  /ADJ CYL WRTTN AFT FWD SK/
666  005732  045523  043040  042127  MFWSKO: .ASCIZ  /SK FWD,WRT - SK REV,OVERWRT/
667  005766  045523  051040  053105  MRESKO: .ASCIZ  /SK REV,WRT - SK FWD,OVERWRT/
668  006022  047117  041040  042101  MBADAD: .ASCIZ  /ON BAD SEC FILES/
669  006043     103  047101  052047  MBADSF: .ASCIZ  /CAN'T GET BAD SEC FILES/
670  006073     102  042101  051440  MFMTER: .ASCIZ  /BAD SEC FILE FMT ERR/
671  006120  047524  046440  047101  MTMBS:  .ASCIZ  /TO MANY BAD SEC /
672  006141     102  051525  040440  BASADD: .ASCIZ  /BUS ADD=/
673  006152  051104  036526     000  DRVNAM: .ASCIZ  /DRV=/
674  006157     116  020117  051104  DRVNAV: .ASCIZ  /NO DRV FOR TST/
675  006176  051104  020126  044504  NOPWR:  .ASCIZ  /DRV DID NOT REC'R FROM PWR FAIL/
676  006236  046122  051503     000  CSNAM:  .ASCIZ  /RLCS/
677  006243     122  041114  000101  BANAM:  .ASCIZ  /RLBA/
678  006250  046122  040504     000  DANAM:  .ASCIZ  /RLDA/
679  006255     122  046514  000120  MPNAM:  .ASCIZ  /RLMP/
680  006262  050117  044440  044516  LAB1:   .ASCIZ  /OP INIT = /
681  006275     117  020120  047504  LAB2:   .ASCIZ  /OP DONE = /
682  006310  047527  042122  000040  MWORD:  .ASCIZ  /WORD /
683  006316  047111  051124  052120  MTOSLOW: .ASCIZ /INTRPT TOO LATE/
684  006336  047516  042040  053122  MDRRES: .ASCIZ  /NO DRV RSPNSE/
685  006354  047516  044440  052116  MNOINT: .ASCIZ  /NO INTRPT ON CMND COMPLETE/
686  006407     103  052116  051114  MCONHNG: .ASCIZ /CNTLR HUNG /
687  006423     105  051122  042040  MNOCLR: .ASCIZ  /ERR DID NOT CLR/
688  006443     126  046117  041440  VCNRST: .ASCIZ  /VOL CHK NOT RSET/
689  006464  047125  050130  052103  UNXERR: .ASCIZ  /UNXPCTED ERR/
690  006501     040  042524  052123  TSTLAB: .ASCIZ  / TEST/
708  006507     117  052125  043440  P2T03E: .ASCIZ  /OUT GRD BAND /
709  006525     111  041516  051440  P2T04E: .ASCIZ  /INC SK FWD HD 0/
710  006545     111  041516  051440  P2T05E: .ASCIZ  /INC SK REV HD 0/
711  006565     111  041516  051440  P2T06E: .ASCIZ  /INC SK FWD HD 1/
712  006605     111  047116  043440  P2T07E: .ASCIZ  /INN GRD BAND /
713  006623     111  041516  051440  P2T08E: .ASCIZ  /INC SK REV HD 1/
714  006643     123  000113         P2T09E: .ASCIZ  /SK/
715  006646  053506  020104  051517  P2T10E: .ASCIZ  /FWD OSC SK/
716  006661     122  053105  047440  P2T11E: .ASCIZ  /REV OSC SK/
717  006674  045523  052040  046511  P2T12E: .ASCIZ  /SK TIMING/
718  006706  051502  020103  042122  P2T13E: .ASCIZ  /BSC RD DATA/
719  006722  051127  027524  042122  P2T14E: .ASCIZ  &WRT/RD DATA (P1)&
720  006743     123  044520  042116  P2T15E: .ASCIZ  /SPINDLE ROT TIMING/
721  006766  051127  027524  042122  P2T16E: .ASCIZ  &WRT/RD DATA (P2)&
722  007007     127  052122  046040  P2T17E: .ASCIZ  /WRT LCK ERR AND DATA PROT/
723  007041     101  045104  041440  P2T18E: .ASCIZ  /ADJ CYL INTERFNCE/
724  007063     117  042526  053522  P2T19E: .ASCIZ  /OVERWRT/
725  007073     123  020113  044524  SKTMES: .ASCIZ  /SK TIMES /
726  007105     123  044520  042116  SRTMES: .ASCIZ  /SPINDLE ROT TIME /
727  007127     050  047111  030440  VALDES: .ASCIZ  /(IN 100'S OF U-SEC)/
728  007153     101  050120  047522  MAPROX: .ASCIZ  /APPROX /
729  007163     111  047116  051105  LABIN:  .ASCIZ  /INNER/
730  007171     115  042111  046104  LABMID: .ASCIZ  /MIDDLE/
731  007200  052517  042524  000122  LABOUT: .ASCIZ  /OUTER/
```

```
007206  040515  020130  044524  LABEXP: .ASCIZ  /MAX TIME/
007217     061  041440  046131  LABOCF: .ASCIZ  /1 CYL FWD/
007231     061  041440  046131  LABOCR: .ASCIZ  /1 CYL REV/
007243     115  042111  041440  LABHCF: .ASCIZ  /MID CYL FWD/
007257     115  042111  041440  LABHCR: .ASCIZ  /MID CYL REV/
007273     115  054101  041440  LABACF: .ASCIZ  /MAX CYL FWD/
007307     115  054101  041440  LABACR: .ASCIZ  /MAX CYL REV/
007323     110  051504  043040  HDMOVF: .ASCIZ  /HDS FAILED TO MV IN 10 TRYS/
007357     122  051505  052105  OPR12:  .ASCIZ  /RESET WRT LCK /
007376  047117  000040          OPR1A:  .ASCIZ  /ON /
007402  047117  042040  053122  OPR1B:  .ASCIZ  /ON DRV /
007412  047125  042504  020122  UNDTST: .ASCIZ  /UNDER TEST/
007425     123  052105  053440  OPR004: .ASCIZ  /SET WRT LCK /
007442  044504  043106  000040  DIFWD:  .ASCIZ  /DIFF /
007450  043523  020116     000  SGNWD:  .ASCIZ  /SGN /
007455     110  020104     000  HDWD:   .ASCIZ  /HD /
007461     123  041505  000040  SECWD:  .ASCIZ  /SEC /
007466  054503  020114     000  CYLWD:  .ASCIZ  /CYL /
007473     106  047522  020115  FRMWD:  .ASCIZ  /FROM /
007501     040  054502  040520  BYPSNM: .ASCIZ  / BYPASSED /
007514  047522  052125  047111  SEQMES: .ASCIZ  /ROUTINE TRACE SEQ:/
007537     104  053122  051440  STAMES: .ASCIZ  /DRV STAT/
007550  040502  020104  042523  BSNSTR: .ASCIZ  /BAD SEC FILES NOT STRD. ALL SEC ASSUMED OK./
007624  047524  040524  020114  TCERR:  .ASCIZ  /TOTAL CMP ERRS: /
007645     104  044522  042526  NOCTLR: .ASCIZ  /DRIVE DROPPED - NO CONTROLLER/
007703     104  044522  042526  NOTRDY: .ASCIZ  /DRIVE DROPPED - DID NOT RESPOND WITH 'READY'/


                                  ;       RESULT NAMES
007760  051104  020126  042122  MDRDY:  .ASCIZ  /DRV RDY /
007771     103  047117  020124  MCERR:  .ASCIZ  /CONT ERR /
010003     110  051104  041440  MHCRC:  .ASCIZ  /HDR CRC/
010013     104  052101  020101  MDCRC:  .ASCIZ  /DATA CRC/
010024  042110  020122  047516  MHNF:   .ASCIZ  /HDR NOT FND/
010040  040504  040524  046040  MDLT:   .ASCIZ  /DATA LATE/
010052  042110  020122  047516  MHFCRC: .ASCIZ  &HDR NOT FND/HDR CRC/OPI&
010102  051104  020126  051105  MDRERR: .ASCIZ  /DRV ERR /
010113     104  053122  051440  MDSERR: .ASCIZ  /DRV SEL ERR /
010130  051104  020126  052123  MDRVST: .ASCIZ  /DRV STATE /
010143     123  044520  020116  MSPERR: .ASCIZ  /SPIN TIMEOUT /
010161     127  052122  043440  MWGERR: .ASCIZ  /WRT GAT ERR /
010176  045523  052040  046511  MSTERR: .ASCIZ  /SK TIMEOUT /
010212  042510  042101  041440  MHCERR: .ASCIZ  /HEAD CUR ERR /
010230  051127  020124  040504  MWDERR: .ASCIZ  /WRT DAT ERR /
010245     117  051120  044455  MOPERR: .ASCIZ  /OPR-INC/
010255     110  051104  042057  MHDERR: .ASCIZ  &HDR/DAT ERR &
010272  042110  020122  047516  MFLERR: .ASCIZ  &HDR NOT FND/DAT LATE &
010320  047516  026516  054105  MNEERR: .ASCIZ  /NON-EXISTENT MEMORY /
010345     103  046131  000040  MCYLOC: .ASCIZ  /CYL /
010352  040503  023516  020124  MNDRST: .ASCIZ  /CAN'T GET DRV STAT/
010375     125  045516  020116  MUNDEF: .ASCIZ  /UNKN DRV STATE-NO RDY,NO ERR,HDS OUT/
010442  040506  046111  052040  MRLFAL: .ASCIZ  /FAIL TO RELD HDS AFTER ERR CLR/
010501     127  052122  040440  MWRTAB: .ASCIZ  /WRT ABRTD/
010513     040  053117  020122  MEXERS: .ASCIZ  / OVR ERR LIMIT - UNIT DRPPD /
010550  042440  051122     000  MERRS:  .ASCIZ  / ERR/
010555     207  177777     000  BELL:   .ASCIZ  <207><377><377>
```

```
                                                  ;       RESULT SETTINGS
010561     111  020123     000  RESE3:   .ASCIZ  /IS /
010565     040  041123  000040  RESE4:   .ASCIZ  / SB /

                                                  ;       RESULT CONDITIONS
010572  044440  020116     000  RESE5:   .ASCIZ  / IN /
010577     040  043117  000040  RESE6:   .ASCIZ  / OF /
010604  052123  052101  020105  STATE2:  .ASCIZ  /STATE 2/
010614  052123  052101  020105  STATE3:  .ASCIZ  /STATE 3/
010624  052123  052101  020105  STATE5:  .ASCIZ  /STATE 5/
010634  051461  020124  020063  C10MS:   .ASCIZ  /1ST 3 MS/
010645     065  030060  051515  C500MS:  .ASCIZ  /500MS/
010653     103  041531  052440  CCYLUP:  .ASCIZ  /CYC UP/
010662  040504  040524  054040  CAFDT:   .ASCIZ  /DATA XFR/
010673     065  051440  041505  C5SEC:   .ASCIZ  /5 SEC/

010701     045  022516  022524  FMTOP1:  .ASCIZ  /%N%T%N%T%T%06%S%T%01%N/
010730  047045  052045  047445  FMTOP2:  .ASCIZ  /%N%T%01%S1%T%01%N/
010752  047045  052045  047445  FMTOP3:  .ASCIZ  /%N%T%01%S1%T%T%N/
010773     045  022524  000124  FMT1:    .ASCIZ  /%T%T/
011000  047045  052045  052045  FMT1.1:  .ASCIZ  /%N%T%T/
011007     045  000124          FMT2:    .ASCIZ  /%T/
011012  047045     000          FMT3:    .ASCIZ  /%N/
011015     045  022516  022524  FMT4:    .ASCIZ  /%N%T%T%N/
011026  047045  052045  047445  FMT5:    .ASCIZ  /%N%T%06%S1%T%01/
011046  047045  051445  030461  FMT6:    .ASCIZ  /%N%S11%T%S4%T%S4%T%S4%T%S4%T%S2%T/
011110  047045  052045  047445  FMT7:    .ASCIZ  /%N%T%06%S2%06%S2%06%S2%06%S3%03%S2%01%N/
011160  047045  052045  047445  FMT8:    .ASCIZ  /%N%T%06%S2%06%S2%06%S2%06/
011212  047045  052045     000  FMT9:    .ASCIZ  /%N%T/
011217     045  022524  030517  FMT11:   .ASCIZ  /%T%01/
011225     045  022524  031517  FMT12:   .ASCIZ  /%T%03/
011233     045  022516  030523  FMT13:   .ASCIZ  /%N%S11%T%03%S1%T%03%S1%T%01%S1%T%01/
011277     045  022516  022524  FMT14:   .ASCIZ  /%N%T%T%D3%S1%T%06%S1%T%06/
011331     045  022516  030523  FMT15:   .ASCIZ  /%N%S11%T%D3%S1%T%06%S1%T%06/
011365     045  022516  032523  FMT16:   .ASCIZ  /%N%S5%06/
011376  051445  030061  052045  FMT17:   .ASCIZ  /%S10%T%N%S11%06%N/
011420  047045  051445  032461  FMT18:   .ASCIZ  /%N%S15%T%S5%T%S4%T%S5%T%N/
011452  052045  051445  022464  FMT19:   .ASCIZ  /%T%S4%D6%S4%D6%S4%D6%S4%D6%N/
011507     045  022524  031123  FMT20:   .ASCIZ  /%T%S2%D6%S14%D6%S4%D6%N/
011537     045  022524  030523  FMT21:   .ASCIZ  /%T%S12%D6%S14%D6%N/
011562  047045  051445  030461  FMT22:   .ASCIZ  /%N%S11%T%03%S1%T%01%S1%T%02/
011616  052045  052045  052045  FMT23:   .ASCIZ  /%T%T%T%01%N/
011632  047045  052045     000  FMT24:   .ASCIZ  /%N%T/
011637     045  022516  031104  FMT25:   .ASCIZ  /%N%D2%T/
011647     045  022516  030523  FMT26:   .ASCIZ  /%N%S1%T%D4%T%T%D3%N/
011673     045  022516  022524  FMT27:   .ASCIZ  /%N%T%D3%T%D3%N/
011712  047045  052045  052045  FMT28:   .ASCIZ  /%N%T%T%T/

011723                          ENDMOD
```

```
                                .SBTTL  ERROR MESSAGES
011724                          BGNMOD  GLBERR
                                ;       ERR1    R3 POINTS TO RESULT MESSAGE
                                ;                RESULT: (R3)

                                ;       ERR2    R3 POINTS TO RESULT NAME
                                ;                RESULT: (R3) IS 1 SB 0

                                ;       ERR3    R3 POINTS TO RESULT NAME
                                ;                RESULT: (R3) IS 0 SB 1

                                ;       ERR4    R3 POINTS TO RESULT NAME
                                ;                R4 POINTS TO RESULT CONDITIONS
                                ;                RESULT: (R3) IS 1 SB 0 (R4)

                                ;       ERR5    R3 POINTS TO RESULT NAME
                                ;                R4 POINTS TO RESULT CONDITIONS
                                ;                RESULT: (R3) IS 0 SB 1 (R4)

                                ;       ERR6    RESULT ROUTINE DETERMINES WHICH ERROR(S) ARE SET AND
                                ;                REPORTS ALL
                                ;                RESULT: "ERROR" IS 1 SB 0

                                ;       ERR7    DRIVE STATE ERROR REPORT
                                ;                R3 CONTAINS EXPECTED STATE
                                ;                T.STAT CONTAINS BAD STATE
                                ;                RESULT: DRIVE STATE IS (T.STAT) SB (R3)

                                ;       ERR8    HEAD POSITIONING ERROR REPORT
                                ;                NEWCYL CONTAINS EXPECTED CYLINDER
                                ;                HDWRD1 CONTAINS BAD CYLINDER
                                ;                RESULT: CYLINDER IS (HDWRD1) SB (NEWCYL)

                                ;       ERR9    UTILITY RESULT REPORT
                                ;                R3 POINTS TO RESULT NAME
                                ;                R4 POINTS TO VALUE 1
                                ;                R5 POINTS TO VALUE 2
                                ;                RESULT: (R3-NAME) IS (R4-VALUE 1) SB (R5-VALUE 2)

                                ;       ERR10   COMPARE ERROR REPORT
                                ;                R3 CONTAINS THE BAD WORD NUMBER
                                ;                R4 POINTS TO BAD WORD
                                ;                R5 POINTS TO GOOD WORD
                                ;                RESULT: WORD (R3) IS (R4) SB (R5)


011724                          BGNMSG  ERR1
011724  105737  003461                  TSTB    NOERCT          ;TEST IF ERROR COUNTING INHIBITED
011730  001002                          BNE     1$              ;YES - SKIP
011732  005277  171314                  INC     @ERRPOINT       ;ELSE BUMP ERROR COUNT
011736  010146                  1$:     MOV     R1,-(SP)        ;STORE R1
011740  004737  024514                  JSR     PC,RPTOP        ;REPORT OPERATION
011744  012721  000001                  MOV     #1,(R1)+        ;SET PARAM NUMBER
011750  010321                          MOV     R3,(R1)+        ;INSERT MESSAGE ADDRESS POINTER
011752  004737  025302                  JSR     PC,RPTRES       ;REPORT RESULTS
011756  004737  025510                  JSR     PC,RPTREM       ;REPORT REMAINDER
```

```
011762  012601                          MOV     (SP)+,R1        ;RESTORE R1
011764  004737  015664                  JSR     PC,CKERLM       ;GO CHECK IF ERROR COUNT EXCEEDED
011770                          ENDMSG
(3) 011770                      L10000:
(3) 011770  104423                      TRAP    C$MSG

011772                          BGNMSG  ERR2
011772  005277  171254                  INC     @ERRPOINT       ;BUMP ERROR COUNT
011776  010146                          MOV     R1,-(SP)        ;STORE R1
012000  004737  024514                  JSR     PC,RPTOP        ;REPORT OPERATION
012004  012721  000003                  MOV     #3,(R1)+        ;SET PARAM NUMBER
012010  010321                          MOV     R3,(R1)+        ;INSERT NAME ADD POINTER
012012  012721  000001                  MOV     #1,(R1)+        ;SET IS VALUE
012016  005021                          CLR     (R1)+           ;SET SB VALUE
012020  004737  025302                  JSR     PC,RPTRES       ;REPORT RESULTS
012024  004737  025510                  JSR     PC,RPTREM       ;REPORT REMAINDER
012030  012601                          MOV     (SP)+,R1        ;RESTORE R1
012032  004737  015664                  JSR     PC,CKERLM       ;GO CHECK IF ERROR COUNT EXCEEDED
012036                          ENDMSG
(3) 012036                      L10001:
(3) 012036  104423                      TRAP    C$MSG

012040                          BGNMSG  ERR3
012040  005277  171206                  INC     @ERRPOINT       ;BUMP ERROR COUNT
012044  010146                          MOV     R1,-(SP)        ;STORE R1
012046  004737  024514                  JSR     PC,RPTOP        ;REPORT OPERATION
012052  012721  000003                  MOV     #3,(R1)+        ;SET PARAM NUMBER
012056  010321                          MOV     R3,(R1)+        ;INSERT NAME ADD POINTER
012060  005021                          CLR     (R1)+           ;SET IS VALUE
012062  012721  000001                  MOV     #1,(R1)+        ;SET SB VALUE
012066  004737  025302                  JSR     PC,RPTRES       ;REPORT RESULTS
012072  004737  025510                  JSR     PC,RPTREM       ;REPORT REMAINDER
012076  012601                          MOV     (SP)+,R1        ;RESTORE R1
012100  004737  015664                  JSR     PC,CKERLM       ;GO CHECK IF ERROR COUNT EXCEEDED
012104                          ENDMSG
(3) 012104                      L10002:
(3) 012104  104423                      TRAP    C$MSG

012106                          BGNMSG  ERR4
012106  005277  171140                  INC     @ERRPOINT       ;BUMP ERROR COUNT
012112  010146                          MOV     R1,-(SP)        ;STORE R1
012114  004737  024514                  JSR     PC,RPTOP        ;REPORT OPERATION
012120  012721  000004                  MOV     #4,(R1)+        ;SET PARAM NUMBER
012124  010321                          MOV     R3,(R1)+        ;INSERT NAME ADD POINTER
012126  012721  000001                  MOV     #1,(R1)+        ;SET IS VALUE
012132  005021                          CLR     (R1)+           ;SET SB VALUE
012134  010411                          MOV     R4,(R1)         ;INSERT ADD OF CONDITION POINTER
012136  004737  025302                  JSR     PC,RPTRES       ;REPORT RESULTS
012142  004737  025510                  JSR     PC,RPTREM       ;REPORT REMAINDER
012146  012601                          MOV     (SP)+,R1        ;RESTORE R1
012150  004737  015664                  JSR     PC,CKERLM       ;GO CHECK IF ERROR COUNT EXCEEDED
012154                          ENDMSG
(3) 012154                      L10003:
(3) 012154  104423                      TRAP    C$MSG

012156                          BGNMSG  ERR5
```

```
012156  005277  171070                  INC     @ERRPOINT          ;BUMP ERROR COUNT
012162  010146                          MOV     R1,-(SP)           ;STORE R1
012164  004737  024514                  JSR     PC,RPTOP           ;REPORT OPERATION
012170  012721  000004                  MOV     #4,(R1)+           ;SET PARAM NUMBER
012174  010321                          MOV     R3,(R1)+           ;INSERT NAME ADD POINTER
012176  005021                          CLR     (R1)+              ;SET IS VALUE
012200  012721  000001                  MOV     #1,(R1)+           ;SET SB VALUE
012204  010411                          MOV     R4,(R1)            ;INSERT ADD OF CONDITION POINTER
012206  004737  025302                  JSR     PC,RPTRES          ;REPORT RESULTS
012212  004737  025510                  JSR     PC,RPTREM          ;REPORT REMAINDER
012216  012601                          MOV     (SP)+,R1           ;RESTORE R1
012220  004737  015664                  JSR     PC,CKERLM          ;GO CHECK IF ERROR COUNT EXCEEDED
012224                          ENDMSG
(3) 012224                      L10004:
(3) 012224  104423                      TRAP    C$MSG

012226                          BGNMSG  ERR6
012226  105737  003461                  TSTB    NOERCT             ;TEST IF ERROR COUNTING INHIBITED
012232  001002                          BNE     17$                ;YES - SKIP
012234  005277  171012                  INC     @ERRPOINT          ;ELSE BUMP ERROR COUNT
012240  010146                  17$:    MOV     R1,-(SP)           ;STORE R1
012242  010346                          MOV     R3,-(SP)           ;STORE R3
012244  010446                          MOV     R4,-(SP)           ;STORE R4
012246  010546                          MOV     R5,-(SP)           ;STORE R5
012250  004737  024514                  JSR     PC,RPTOP           ;REPORT OPERATION
012254  012721  000003                  MOV     #3,(R1)+           ;SET PARAM NUMBER
012260  012761  000001  000002          MOV     #1,2(R1)           ;INSERT IS VALUE
012266  005037  003140                  CLR     TEMP3              ;CLEAR FOR STATUS STORAGE
012272  013703  003060                  MOV     T.CS,R3            ;GET T.CS
012276  042703  177761                  BIC     #177761,R3         ;AND CLEAR ALL BUT FUNCTION
012302  022703  000004                  CMP     #4,R3              ;CHECK IF IT WAS GET STATUS
012306  001434                          BEQ     1$                 ;YES - STATUS IS IN T.MP, SKIP
012310  012762  000003  000004          MOV     #GETSTAT,RLDA(R2)  ;ELSE DO GET STATUS
012316  012703  000004                  MOV     #4,R3
012322  053703  003046                  BIS     RLDRV,R3
012326  010362  000000                  MOV     R3,RLCS(R2)
012332                                  WAITUS  #10.               ;WAIT FOR CONTROLLER READY
012344  032762  000200  000000          BIT     #CRDYMSK,RLCS(R2)          ;TEST IF READY
012352  001003                          BNE     10$                ;YES - SKIP
012354  012703  001000          9$:     MOV     #BIT9,R3           ;ELSE SET NO DRIVE STATUS BIT
012360  000413                          BR      2$                 ;IN MESSAGE WORD AND SKIP
012362  016203  000006          10$:    MOV     RLMP(R2),R3        ;STORE STATUS FOR REPORT
012366  010337  003140                  MOV     R3,TEMP3
012372  113703  003141                  MOVB    TEMP3+1,R3         ;GET ERROR BITS IN PROPER POSITION
012376  000402                          BR      13$
012400  113703  003067          1$:     MOVB    T.MP+1,R3          ;GET ERROR BITS FROM MP REG
012404  042703  177442          13$:    BIC     #177442,R3         ;CLEAR UNUSED BITS
012410  013704  003060          2$:     MOV     T.CS,R4            ;GET ERROR BITS FROM CS REG
012414  042704  001777                  BIC     #1777,R4           ;CLEAR UNUSED BITS
012420  050403                          BIS     R4,R3              ;MAKE ONE WORD OF POSSIBLE ERRORS
012422  032703  002000                  BIT     #OPIERR,R3         ;TEST IF OPI SET
012426  001442                          BEQ     115$               ;NO - SKIP
012430  032703  010000                  BIT     #HNFERR,R3         ;TEST IF HDR NOT FOUND ERROR
012434  001026                          BNE     107$               ;YES - SKIP
012436  032703  004000                  BIT     #HCRCERR,R3        ;TEST IF HDR CRC ERR
012442  001020                          BNE     105$               ;YES - SKIP
```

```
 1032  012444  012704  010245                 MOV     #MOPERR,R4          ;SET OPI ALONE MESSAGE
 1033  012450                          100$:  PRINTB  #FMT28,#MRSLT,R4,#MERRS ;REPORT ERROR
  (10) 012450  012746  010550                 MOV     #MERRS,-(SP)
  (9)  012454  010446                         MOV     R4,-(SP)
  (8)  012456  012746  005536                 MOV     #MRSLT,-(SP)
  (7)  012462  012746  011712                 MOV     #FMT28,-(SP)
  (6)  012466  012746  000004                 MOV     #4,-(SP)
  (3)  012472  010600                         MOV     SP,R0
  (4)  012474  104414                         TRAP    C$PNTB
  (4)  012476  062706  000012                 ADD     #12,SP
 1034  012502  000430                         BR      120$                ;SKIP
 1035  012504  012704  010003          105$:  MOV     #MHCRC,R4           ;HDR CRC MESSAGE
 1036  012510  000757                         BR      100$
 1037  012512  032703  004000          107$:  BIT     #HCRCERR,R3         ;TEST IF HCRC WITH HDR NOT FND
 1038  012516  001003                         BNE     109$                ;YES - SKIP
 1039  012520  012704  010024                 MOV     #MHNF,R4            ;MESSAGE HEADER NOT FOUND
 1040  012524  000751                         BR      100$
 1041  012526  012704  010052          109$:  MOV     #MHFCRC,R4          ;HNF AND HCRC MESSAGE
 1042  012532  000746                         BR      100$                ;SKIP
 1043  012534  032703  004000          115$:  BIT     #DCKERR,R3          ;TEST IF DATA CHECK SET, NOT OPI
 1044  012540  001403                         BEQ     118$                ;NO - SKIP
 1045  012542  012704  010013                 MOV     #MDCRC,R4           ;SET MESSAGE DATA CHECK
 1046  012546  000740                         BR      100$                ;SKIP
 1047  012550  032703  010000          118$:  BIT     #DLTERR,R3          ;TEST IF DATA LATE ERROR
 1048  012554  001403                         BEQ     120$                ;NO - SKIP
 1049  012556  012704  010040                 MOV     #MDLT,R4            ;SET MESSAGE DATA LATE
 1050  012562  000732                         BR      100$                ;SKIP
 1051  012564  012705  100000          120$:  MOV     #BIT15,R5           ;SET BIT POINTER FOR TEST
 1052  012570  005004                         CLR     R4                  ;CLEAR R4 FOR TABLE COUNT
 1053  012572  030503                   3$:   BIT     R5,R3               ;TEST IF BIT IS SET
 1054  012574  001005                         BNE     6$                  ;YES - SKIP TO REPORT
 1055  012576  005724                   4$:   TST     (R4)+               ;ELSE BUMP TABLE POINTER
 1056  012600  000241                         CLC                         ;CLEAR CARRY
 1057  012602  006005                         ROR     R5                  ;SHIFT BIT POINTER TO NEXT BIT
 1058  012604  001372                         BNE     3$                  ;LOOP IF NOT 0
 1059  012606  000405                         BR      7$                  ;ELSE REPORT REMAINDER
 1060  012610  016411  002334            6$:  MOV     RESTBL(R4),(R1)     ;INSERT NAME ADDRESS
 1061  012614  004737  025302                 JSR     PC,RPTRES           ;REPORT RESULTS
 1062  012620  000766                         BR      4$                  ;GET NEXT BIT
 1063  012622  004737  025510            7$:  JSR     PC,RPTREM           ;REPORT REMAINDER
 1064  012626  005737  003140                 TST     TEMP3               ;TEST IF ANY NEW STATUS
 1065  012632  001414                         BEQ     15$                 ;NO - SKIP
 1066  012634                                 PRINTB  #FMT17,#STAMES,TEMP3
  (9)  012634  013746  003140                 MOV     TEMP3,-(SP)
  (8)  012640  012746  007537                 MOV     #STAMES,-(SP)
  (7)  012644  012746  011376                 MOV     #FMT17,-(SP)
  (6)  012650  012746  000003                 MOV     #3,-(SP)
  (3)  012654  010600                         MOV     SP,R0
  (4)  012656  104414                         TRAP    C$PNTB
  (4)  012660  062706  000010                 ADD     #10,SP
 1067  012664  032737  004000  003060   15$:  BIT     #DCKERR,T.CS        ;TEST IF DATA CHECK ERROR
 1068  012672  001453                         BEQ     25$                 ;NO - SKIP
 1069  012674  032737  002000  003060         BIT     #OPIERR,T.CS        ;TEST IF OPI SET
 1070  012702  001047                         BNE     25$                 ;YES - SKIP
 1071  012704  005037  003030                 CLR     MORECE              ;CLEAR COMPARE ERROR COUNT
 1072  012710  012701  000200                 MOV     #128.,R1            ;SET COMPARE LENGTH
```

```
 1073  012714  012703  000001                  MOV     #1,R3              ;SET WORD COUNT
 1074  012720  012705  004502                  MOV     #OBUFF,R5          ;SET GOOD WORD POINTER
 1075  012724  012704  004102                  MOV     #IBUFF,R4          ;SET TEST WORD POINTER
 1076  012730  021514                  18$:    CMP     (R5),(R4)          ;CHECK WORD
 1077  012732  001427                          BEQ     19$                ;GOOD - SKIP
 1078  012734  023727  003030  000012          CMP     MORECE,#10.        ;TEST IF COMPARE LIMIT REACHED
 1079  012742  003021                          BGT     20$                ;YES - SKIP
 1080  012744                                  PRINTB  #FMT15,#MWORD,R3,#RESE3,(R4),#RESE4,(R5)
  (13) 012744  011546                          MOV     (R5),-(SP)
  (12) 012746  012746  010565                  MOV     #RESE4,-(SP)
  (11) 012752  011446                          MOV     (R4),-(SP)
  (10) 012754  012746  010561                  MOV     #RESE3,-(SP)
  (9)  012760  010346                          MOV     R3,-(SP)
  (8)  012762  012746  006310                  MOV     #MWORD,-(SP)
  (7)  012766  012746  011331                  MOV     #FMT15,-(SP)
  (6)  012772  012746  000007                  MOV     #7,-(SP)
  (3)  012776  010600                          MOV     SP,R0
  (4)  013000  104414                          TRAP    C$PNTB
  (4)  013002  062706  000020                  ADD     #20,SP
 1081  013006  005237  003030          20$:    INC     MORECE             ;BUMP ERROR COUNTER
 1082  013012  022524                  19$:    CMP     (R5)+,(R4)+        ;BUMP POINTERS
 1083  013014  005203                          INC     R3                 ;BUMP COUNTER
 1084  013016  005301                          DEC     R1                 ;DEC LENGTH COUNT
 1085  013020  001343                          BNE     18$                ;LOOP IF NOT DONE
 1086  013022  005737  003030          25$:    TST     MORECE             ;TEST IF ANY COMPARE ERRORS
 1087  013026  001421                          BEQ     27$                ;NO - SKIP
 1088  013030  012701  000200                  MOV     #128.,R1           ;SET COMPARE LENGTH
 1089  013034                                  PRINTB  #FMT27,#TCERR,MORECE,#RESE6,R1
  (11) 013034  010146                          MOV     R1,-(SP)
  (10) 013036  012746  010577                  MOV     #RESE6,-(SP)
  (9)  013042  013746  003030                  MOV     MORECE,-(SP)
  (8)  013046  012746  007624                  MOV     #TCERR,-(SP)
  (7)  013052  012746  011673                  MOV     #FMT27,-(SP)
  (6)  013056  012746  000005                  MOV     #5,-(SP)
  (3)  013062  010600                          MOV     SP,R0
  (4)  013064  104414                          TRAP    C$PNTB
  (4)  013066  062706  000014                  ADD     #14,SP
 1090  013072  012605                  27$:    MOV     (SP)+,R5           ;RESTORE R5, 4, 3, 1
 1091  013074  012604                          MOV     (SP)+,R4
 1092  013076  012603                          MOV     (SP)+,R3
 1093  013100  012601                          MOV     (SP)+,R1
 1094  013102  004737  015664                  JSR     PC,CKERLM          ;GO CHECK IF ERROR COUNT EXCEEDED
 1095  013106                          ENDMSG
  (3)  013106                          L10005:
  (3)  013106  104423                          TRAP    C$MSG
 1096
 1097  013110                          BGNMSG  ERR7
 1098  013110  005277  170136                  INC     @ERRPOINT          ;BUMP ERROR COUNT
 1099  013114  010146                          MOV     R1,-(SP)           ;STORE R1
 1100  013116  004737  024514                  JSR     PC,RPTOP           ;REPORT OPERATION
 1101  013122  012721  000003                  MOV     #3,(R1)+           ;SET PARAM NUMBER
 1102  013126  012721  010130                  MOV     #MDRVST,(R1)+      ;INSERT NAME ADD POINTER
 1103  013132  013721  003074                  MOV     T.STAT,(R1)+       ;INSERT IS VALUE
 1104  013136  010311                          MOV     R3,(R1) ;INSERT SB VALUE
 1105  013140  004737  025302                  JSR     PC,RPTRES          ;REPORT RESULTS
 1106  013144  004737  025510                  JSR     PC,RPTREM          ;REPORT REMAINDER
```

```
 1107  013150  012601                          MOV     (SP)+,R1          ;RESTORE R1
 1108  013152  004737  015664                   JSR     PC,CKERLM         ;GO CHECK IF ERROR COUNT EXCEEDED
 1109  013156                            ENDMSG
  (3)  013156                            L10006:
  (3)  013156  104423                            TRAP    C$MSG
 1110
 1111  013160                            BGNMSG  ERR8
 1112  013160  005277  170066                    INC     @ERRPOINT         ;BUMP ERROR COUNT
 1113  013164  010146                            MOV     R1,-(SP)          ;STORE R1
 1114  013166  010346                            MOV     R3,-(SP)          ;STORE R3
 1115  013170  004737  024514                    JSR     PC,RPTOP          ;REPORT OPERATION
 1116  013174  012721  000003                    MOV     #3,(R1)+          ;SET PARAM NUMBER
 1117  013200  012721  010345                    MOV     #MCYLOC,(R1)+     ;INSERT NAME ADD POINTER
 1118  013204  013711  003066                    MOV     HDWRD1,(R1)       ;GET HEADER WORD
 1119  013210  012703  000007                    MOV     #7,R3             ;SET SHIFT COUNT
 1120  013214  000241                     3$:    CLC
 1121  013216  006011                            ROR     (R1)              ;ALIGN CHAR FOR PRINTING
 1122  013220  005303                            DEC     R3                ;  AS IS VALUE
 1123  013222  001374                            BNE     3$
 1124  013224  005721                            TST     (R1)+             ;BUMP PARAM POINTER
 1125  013226  013711  003116                    MOV     NEWCYL,(R1)       ;INSERT SB VALUE
 1126  013232  004737  025302                    JSR     PC,RPTRES         ;REPORT RESULTS
 1127  013236  004737  025510                    JSR     PC,RPTREM         ;REPORT REMAINDER
 1128  013242  012603                            MOV     (SP)+,R3          ;RESTORE R3
 1129  013244  012601                            MOV     (SP)+,R1          ;RESTORE R1
 1130  013246  004737  015664                    JSR     PC,CKERLM         ;GO CHECK IF ERROR COUNT EXCEEDED
 1131  013252                            ENDMSG
  (3)  013252                            L10007:
  (3)  013252  104423                            TRAP    C$MSG
 1132
 1133  013254                            BGNMSG  ERR9
 1134  013254  005277  167772                    INC     @ERRPOINT         ;BUMP ERROR COUNT
 1135  013260  010146                            MOV     R1,-(SP)          ;STORE R1
 1136  013262  004737  024514                    JSR     PC,RPTOP          ;REPORT OPERATION
 1137  013266  012721  000003                    MOV     #3,(R1)+          ;SET PARAM NUMBER
 1138  013272  010321                            MOV     R3,(R1)+          ;INSERT NAME ADD POINTER
 1139  013274  010421                            MOV     R4,(R1)+          ;SET IS VALUE
 1140  013276  010521                            MOV     R5,(R1)+          ;SET SB VALUE
 1141  013300  004737  025302                    JSR     PC,RPTRES         ;REPORT RESULTS
 1142  013304  004737  025510                    JSR     PC,RPTREM         ;REPORT REMAINDER
 1143  013310  012601                            MOV     (SP)+,R1          ;RESTORE R1
 1144  013312  004737  015664                    JSR     PC,CKERLM         ;GO CHECK IF ERROR COUNT EXCEEDED
 1145  013316                            ENDMSG
  (3)  013316                            L10010:
  (3)  013316  104423                            TRAP    C$MSG
 1146  013320                            BGNMSG  ERR10
 1147  013320  010146                            MOV     R1,-(SP)          ;STORE R1
 1148  013322  005737  003030                    TST     MORECE            ;TEST IF 2ND BAD LINE
 1149  013326  001051                            BNE     3$                ;YES - SKIP
 1150  013330  005277  167716                    INC     @ERRPOINT         ;BUMP ERROR COUNT
 1151  013334  004737  024514                    JSR     PC,RPTOP          ;REPORT OPERATION
 1152  013340                                    PRINTB  #FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1> ;REPORT ID
 (11)  013340  005046                            CLR     -(SP)
 (11)  013342  153716  003047                    BISB    RLDRV+1,(SP)
 (10)  013346  012746  006152                    MOV     #DRVNAM,-(SP)
  (9)  013352  013746  003042                    MOV     RLBAS,-(SP)
```

```
  (8)  013356  012746  006141                MOV     #BASADD,-(SP)
  (7)  013362  012746  011026                MOV     #FMT5,-(SP)
  (6)  013366  012746  000005                MOV     #5,-(SP)
  (3)  013372  010600                        MOV     SP,R0
  (4)  013374  104414                        TRAP    C$PNTB
  (4)  013376  062706  000014                ADD     #14,SP
 1153  013402                                PRINTB  #FMT14,#MRSLT,#MWORD,R3,#RESE3,(R4),#RESE4,(R5)
  (14) 013402  011546                        MOV     (R5),-(SP)
  (13) 013404  012746  010565                MOV     #RESE4,-(SP)
  (12) 013410  011446                        MOV     (R4),-(SP)
  (11) 013412  012746  010561                MOV     #RESE3,-(SP)
  (10) 013416  010346                        MOV     R3,-(SP)
  (9)  013420  012746  006310                MOV     #MWORD,-(SP)
  (8)  013424  012746  005536                MOV     #MRSLT,-(SP)
  (7)  013430  012746  011277                MOV     #FMT14,-(SP)
  (6)  013434  012746  000010                MOV     #10,-(SP)
  (3)  013440  010600                        MOV     SP,R0
  (4)  013442  104414                        TRAP    C$PNTB
  (4)  013444  062706  000022                ADD     #22,SP
 1154  013450  000421                        BR      4$
 1155  013452                        3$:     PRINTB  #FMT15,#MWORD,R3,#RESE3,(R4),#RESE4,(R5) ;REPORT DATA
  (13) 013452  011546                        MOV     (R5),-(SP)
  (12) 013454  012746  010565                MOV     #RESE4,-(SP)
  (11) 013460  011446                        MOV     (R4),-(SP)
  (10) 013462  012746  010561                MOV     #RESE3,-(SP)
  (9)  013466  010346                        MOV     R3,-(SP)
  (8)  013470  012746  006310                MOV     #MWORD,-(SP)
  (7)  013474  012746  011331                MOV     #FMT15,-(SP)
  (6)  013500  012746  000007                MOV     #7,-(SP)
  (3)  013504  010600                        MOV     SP,R0
  (4)  013506  104414                        TRAP    C$PNTB
  (4)  013510  062706  000020                ADD     #20,SP
 1156  013514  005237  003030        4$:     INC     MORECE          ;INC COMPARE ERROR COUNT
 1157  013520  012601                        MOV     (SP)+,R1        ;RESTORE R1
 1158  013522  004737  015664                JSR     PC,CKERLM       ;GO CHECK IF ERROR COUNT EXCEEDED
 1159  013526                        ENDMSG
  (3)  013526                        L10011:
  (3)  013526  104423                        TRAP    C$MSG
 1160  013530                        ENDMOD
 1161
 1162                               ;LOAD PROTECTION TABLE
 1163  013530                        BGNPROT
 1164  013530  000000                        .WORD    0              ;OFFSET OF CSR IN P-TABLE
 1165  013532  177777                        .WORD   -1              ;NOT A MASS-BUS DRIVE
 1166  013534  000010                        .WORD   10              ;OFFSET OF DRIVE IN P-TABLE
 1167  013536                        ENDPROT
 1168
 1169                                        .EVEN
 1170
 1171  013536                        BGNMOD  HPTCODE
 1172  013536                        BGNHW
  (3)  013536  000006                        .WORD   L10013-L$HW/2
 1173  013540  174400                        .WORD   174400          ;CSR BASE ADDRESS DEFAULT
 1174  013542  000160                        .WORD   160             ;VECTOR DEFAULT
 1175  013544  000240                        .WORD   240             ;PRIORITY DEFAULT
 1176  013546  000001                        .WORD   1               ;TYPE OF DRIVE
```

```
 1177  013550  000000                          .WORD   0                ;DRIVE NUMBER DEFAULT
 1178  013552  000001                          .WORD   1                ;RL11 CONTROLLER
 1179  013554                          ENDHW
  (3)  013554                          L10013:
 1180  013554                          ENDMOD
 1181
 1182  013554                          BGNMOD  SPTCODE
 1183  013554                          BGNSW
  (3)  013554  000006                          .WORD   L10014-L$SW/2
 1184  013556  000000                  MISWIW: .WORD   0                ;BIT 0 = USE ALL CYLINDERS
 1185                                                                   ;BIT 1 = USE ALL SECTORS
 1186                                                                   ;BIT 2 = EXECUTE DRIVE SELECT TEST
 1187                                                                   ;BIT 3 = EXECUTE HEAD ALIGNMENT
 1188                                                                   ;BIT 12 = HEAD SELECT SUPPLIED FLAG
 1189                                                                   ;BIT 13 = HILIMIT SPECIFIED FLAG
 1190                                                                   ;BIT 14 = LO LIMIT SPECIFIED FLAG
 1191  013560  000000                  LOLIMW: .WORD   0
 1192  013562  000377                  HILIMW: .WORD   255.
 1193  013564  000000                  HEADW:  .WORD   0
 1194  013566  000024                  ERLIMW: .WORD   20.              ;ERROR LIMIT
 1195  013570  000012                  DCLIMW: .WORD   10.              ;COMPARE ERROR LIMIT
 1196  013572                          ENDSW
  (3)  013572                          L10014:
 1197  013572                          ENDMOD
 1198
 1199  013572                          BGNMOD  DSPCODE
 1204  013572                          DISPATCH        9
  (4)  013572  000011                          .WORD   9
  (6)  013574  025774                          .WORD   T1
  (6)  013576  026216                          .WORD   T2
  (6)  013600  026426                          .WORD   T3
  (6)  013602  026636                          .WORD   T4
  (6)  013604  027062                          .WORD   T5
  (6)  013606  027270                          .WORD   T6
  (6)  013610  027516                          .WORD   T7
  (6)  013612  030026                          .WORD   T8
  (6)  013614  030324                          .WORD   T9
 1206  013616                          ENDMOD
 1207
 1208
```

```
                                        .SBTTL  INITIALIZATION SECTION

013616                                  BGNMOD  INITCODE
013616                                  BGNINIT

                                        ;CHECK FOR PRESENCE OF A P-CLOCK
013616  005037  003504                          CLR     CLKFLG          ;CLEAR CLOCK FLAG
013622                                          CLOCK   P,CLKADR        ;P-CLOCK?
(3) 013622  012700  000120                      MOV     #'P,R0
(3) 013626  104462                              TRAP    C$CLCK
(3) 013630  010037  003506                      MOV     R0,CLKADR
013634                                          BNCOMPLETE      1$      ;BRANCH IF NO P-CLOCK
(2) 013634  103002                              BCC     1$
013636  005237  003504                          INC     CLKFLG          ;INDICATE PRESENCE OF A P-CLOCK
013642                                  1$:     SETPRI  #340            ;SET PRIORITY TO 7 TO INHIBIT ALL INTERRUPTS
(3) 013642  012700  000340                      MOV     #340,R0
(3) 013646  104441                              TRAP    C$SPRI
013650                                          BRESET                  ;FOR LSI-11 CPU'S
(3) 013650  104433                              TRAP    C$RESET
013652  042737  100014  013556                  BIC     #MITEST!DRSELT!HDALIGN,MISWIW ;CLEAR ALL MANUAL
                                                                        ; INTERVENTION FLAGS
013660  005037  003016                          CLR     SSINDX          ;CLEAR SUBROUTINE STACK INDEX
013664                                          READEF  #EF.PWR         ;POWER FAILURE
(3) 013664  012700  000034                      MOV     #EF.PWR,R0
(3) 013670  104447                              TRAP    C$REFG
013672                                          BNCOMPLETE  4$          ;NO, GO CHECK NEW PASS
(2) 013672  103005                              BCC     4$
013674  013737  002012  003464                  MOV     L$UNIT,PWRFLG   ;SET POWER FAIL FLAG
013702  000137  014314                          JMP     PWCON           ;GO SERVICE POWER FAIL
013706                                  4$:     READEF  #EF.START       ;CHECK IF START
(3) 013706  012700  000040                      MOV     #EF.START,R0
(3) 013712  104447                              TRAP    C$REFG
013714                                          BNCOMPLETE      RESTART ;NO - SKIP
(2) 013714  103034                              BCC     RESTART

                                        ;       ON START INITIALIZE TO START AT FIRST DRIVE, CLEAR INTERNAL
                                        ;       PASS COUNT, AND ERROR COUNT.

013716  013737  002012  003110                  MOV     L$UNIT,DRVCNT   ;SET UP UNIT COUNT
013724  005037  003454                  RSTRT:  CLR     PASNUM          ;CLEAR PASS NUMBER
013730  012700  003254                          MOV     #ERRCNT,R0
013734  012701  000100                          MOV     #64.,R1         ;GET A COUNT
013740  005020                          1$:     CLR     (R0)+           ;CLEAR AN ERROR COUNTER STORAGE AREA
013742  005301                                  DEC     R1
013744  001375                                  BNE     1$              ;LOOP TILL ALL CLEARED
013746  012737  003252  003252                  MOV     #ERRCNT-2,ERRPOINT ;INIT ERROR POINTER
013754  012737  177777  003456                  MOV     #-1,PSETNM      ;SET PARAM SELECT TO INITIAL VALUE
013762  012737  177777  003024                  MOV     #-1,HADONE      ;PRESET HEAD ALIGN DONE FLAG
013770  032737  040000  013556          LAB:    BIT     #LOCYL,MISWIW   ;TEST IF LO LIMIT SET
013776  001002                                  BNE     5$              ;YES - SKIP
014000  005037  013560                          CLR     LOLIMW          ;ELSE CLEAR LO LIMIT
014004  000432                          5$:     BR      SETDON
014006                                  RESTART:
014006                                          READEF  #EF.RESTART     ;CHECK IF RESTART
(3) 014006  012700  000037                      MOV     #EF.RESTART,R0
(3) 014012  104447                              TRAP    C$REFG
```

```
014014                                          BCOMPLETE       RSTRT   ;NO - SKIP
(2) 014014  103743                              BCS     RSTRT
014016                                  CONTINUE:
014016                                          READEF  #EF.CONTINUE    ;TEST IF CONTINUE
(3) 014016  012700  000036                      MOV     #EF.CONTINUE,R0
(3) 014022  104447                              TRAP    C$REFG
014024                                          BCOMPLETE       PWCON
(2) 014024  103533                              BCS     PWCON
                                        ;       ON CONTINUE PICK UP UNIT LAST UNDER TEST
014026                                          READEF  #EF.NEW         ;CHECK IF STARTING NEW PASS
(3) 014026  012700  000035                      MOV     #EF.NEW,R0
(3) 014032  104447                              TRAP    C$REFG
014034                                          BCOMPLETE       PASNEW
(2) 014034  103403                              BCS     PASNEW
014036                                  NXTPAS:
014036  005737  003110                          TST     DRVCNT          ;TEST IF ALL UNITS CHECKED
014042  001013                                  BNE     SETDON          ;NO - SKIP
014044  005237  003454                  PASNEW: INC     PASNUM          ;ELSE BUMP PASS COUNT
014050  012737  003252  003252                  MOV     #ERRCNT-2,ERRPOINT ;INIT ERROR POINTER
014056  013737  002012  003110                  MOV     L$UNIT,DRVCNT   ;GET ALL DRIVES
014064  012737  177777  003456                  MOV     #-1,PSETNM      ;SET PARAM SELECT TO INITIAL
014072  005237  003456                  SETDON: INC     PSETNM          ;NEXT SET OF PARAMETERS
014076  005337  003110                          DEC     DRVCNT          ;DOWN COUNT DRIVE TOTAL
014102  062737  000002  003252                  ADD     #2,ERRPOINT     ;UPDATE THE ERROR POINTER
014110  013700  003456                          MOV     PSETNM,R0       ;SET UP TO GET PARAMETERS
014114  012702  003042                          MOV     #RLBAS,R2
014120                                          GPHARD  R0,R1
(3) 014120  104442                              TRAP    C$GPHRD
(3) 014122  010001                              MOV     R0,R1
014124                                          BCOMPLETE       7$      ;SKIP IF GOOD PARAM
(2) 014124  103406                              BCS     7$
014126  005737  003464                          TST     PWRFLG          ;RECENT POWER FAILURE
014132  001741                                  BEQ     NXTPAS  ;NO
014134  005337  003464                          DEC     PWRFLG          ;ACCOUNT FOR DRIVE
014140  000736                                  BR      NXTPAS
014142  012122                          7$:     MOV     (R1)+,(R2)+     ;STORE PARAMETERS CSR
014144  012122                                  MOV     (R1)+,(R2)+     ;                   VECTOR
014146  005721                                  TST     (R1)+           ;BUMP PAST PRIORITY
014150  012137  002312                          MOV     (R1)+,T.DRIVE
014154  012122                                  MOV     (R1)+,(R2)+
014156  022737  000001  002312                  CMP     #1,T.DRIVE
014164  001426                                  BEQ     65$
014166  012737  000776  002322                  MOV     #510.,NXTHL
014174  012737  000777  002316                  MOV     #511.,HLMTW
014202  012737  001000  002324                  MOV     #512.,GBND
014210  012737  177600  002326                  MOV     #177600,CAMSK
014216  012737  177600  002330                  MOV     #177600,DIRMSK
014224  012737  177600  002332                  MOV     #177600,HDCYL
014232  012737  177000  002320                  MOV     #177000,CLRBYT
014240  000425                                  BR      PWCON

014242  012737  000377  002316          65$:    MOV     #255.,HLMTW
014250  012737  000400  002324                  MOV     #256.,GBND
014256  012737  077600  002326                  MOV     #77600,CAMSK
014264  012737  077600  002330                  MOV     #77600,DIRMSK
014272  012737  077600  002332                  MOV     #77600,HDCYL
```

```
 1297  014300  012737  000376  002322          MOV     #254.,NXTHL
 1298  014306  012737  177400  002320          MOV     #177400,CLRBYT
 1299
 1300  014314  032737  020000  013556  PWCON:  BIT     #HICYL,MISWIW
 1301  014322  001003                          BNE     1$
 1302  014324  013737  002316  013562          MOV     HLMTW,HILIMW
 1303  014332                          1$:     SETVEC  RLVEC,#INTHLR,#340      ;SET UP VECTOR
  (7)  014332  012746  000340                  MOV     #340,-(SP)
  (6)  014336  012746  015604                  MOV     #INTHLR,-(SP)
  (5)  014342  013746  003044                  MOV     RLVEC,-(SP)
  (4)  014346  012746  000003                  MOV     #3,-(SP)
  (3)  014352  104437                          TRAP    C$SVEC
  (2)  014354  062706  000010                  ADD     #10,SP
 1304  014360                                  SETPRI  #0              ;SET PRIORITY
  (3)  014360  012700  000000                  MOV     #0,R0
  (3)  014364  104441                          TRAP    C$SPRI
 1305  014366  013702  003042                  MOV     RLBAS,R2        ;SET RL11 BASE ADDRESS POINTER
 1316                             ;CHECK IF POWER FAILURE WAIT IS NEEDED
 1317
 1318  014372  005737  003464                  TST     PWRFLG          ;NEEDED???
 1319  014376  001472                          BEQ     8$              ;NO, SKIP
 1320
 1321  014400  013705  003046                  MOV     RLDRV,R5        ;DRIVE SELECT
 1322  014404  052705  000200                  BIS     #CRDYMSK,R5     ;SET CRDY
 1323  014410  010562  000000                  MOV     R5,RLCS(R2)     ;SELECT DRIVE
 1324  014414  012701  000170                  MOV     #120.,R1        ;INITIALIZE WAIT COUNT
 1325  014420  032762  000001  000000  9$:     BIT     #DRDYMSK,RLCS(R2)       ;DRIVE UP YET?
 1326  014426  001056                          BNE     8$              ;YES START TEST
 1327
 1328  014430                                  WAITMS  #10.            ;WAIT A SECOND
 1329  014442  005301                          DEC     R1              ;SIXTY GONE BY
 1330  014444  001365                          BNE     9$              ;NO
 1331  014446                                  PRINTF  #FMT24,#NOPWR
  (8)  014446  012746  006176                  MOV     #NOPWR,-(SP)
  (7)  014452  012746  011632                  MOV     #FMT24,-(SP)
  (6)  014456  012746  000002                  MOV     #2,-(SP)
  (3)  014462  010600                          MOV     SP,R0
  (4)  014464  104417                          TRAP    C$PNTF
  (4)  014466  062706  000006                  ADD     #6,SP
 1332  014472                                  PRINTF  #FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
 (11)  014472  005046                          CLR     -(SP)
 (11)  014474  153716  003047                  BISB    RLDRV+1,(SP)
 (10)  014500  012746  006152                  MOV     #DRVNAM,-(SP)
  (9)  014504  013746  003042                  MOV     RLBAS,-(SP)
  (8)  014510  012746  006141                  MOV     #BASADD,-(SP)
  (7)  014514  012746  011026                  MOV     #FMT5,-(SP)
  (6)  014520  012746  000005                  MOV     #5,-(SP)
  (3)  014524  010600                          MOV     SP,R0
  (4)  014526  104417                          TRAP    C$PNTF
  (4)  014530  062706  000014                  ADD     #14,SP
 1333  014534                                  PRINTF  #FMT3
  (7)  014534  012746  011012                  MOV     #FMT3,-(SP)
  (6)  014540  012746  000001                  MOV     #1,-(SP)
  (3)  014544  010600                          MOV     SP,R0
  (4)  014546  104417                          TRAP    C$PNTF
  (4)  014550  062706  000004                  ADD     #4,SP
```

```
 1334  014554                                  DODU    PSETNM          ;DROP DRIVE
  (3)  014554  013700  003456                  MOV     PSETNM,R0
  (3)  014560  104451                          TRAP    C$DODU
 1335  014562                                  DOCLN
  (3)  014562  104444                          TRAP    C$DCLN
 1336  014564                          8$:
 1337
 1338  014564                          ENDINIT
  (3)  014564                          L10015:
  (3)  014564  104411                          TRAP    C$INIT
 1339  014566                          ENDMOD
 1340
```

```
                                        .SBTTL  AUTO DROP SECTION

                                        ;THE AUTO DROP SECTION IS INVOKED BY THE DIAGNOSTIC SUPERVISOR WHENEVER THE
                                        ;"ADR" FLAG IS SET BY THE OPERATOR. IT IS EXECUTED AFTER THE INITIALIZATION
                                        ;CODE AND CHECKS THE DRIVE TO DETERMINE IF IT IS READY TO RECEIVE A COMMAND.
                                        ;IF THE DRIVE IS NOT READY IT IS DROPPED FROM THE TEST CYCLE AND THE NEXT
                                        ;DRIVE IS ACCESSED. IF THE DRIVE IS READY THE HARDWARE TESTS ARE PERFORMED
                                        ;AFTER WHICH THE NEXT DRIVE IS ACCESSED.

014566                                  BGNAUTO
014566  005037  003462                          CLR     TRPFLG          ;CLEAR TRAP FLAG
014572                                          SETVEC  ERRVEC,#TRPHAN,#340     ;SET UP TRAP VECTOR TO DETECT
(7)  014572  012746  000340                     MOV     #340,-(SP)
(6)  014576  012746  015576                     MOV     #TRPHAN,-(SP)
(5)  014602  013746  003244                     MOV     ERRVEC,-(SP)
(4)  014606  012746  000003                     MOV     #3,-(SP)
(3)  014612  104437                             TRAP    C$SVEC
(2)  014614  062706  000010                     ADD     #10,SP
                                                                        ;/NON-EXISTENT CONTROLLER
014620  013702  003042                          MOV     RLBAS,R2        ;GET RL11 BASE ADDRESS
014624  005762  000000                          TST     RLCS(R2)        ;ACCESS DRIVE CONTROLLER ADDRESS
014630  005737  003462                          TST     TRPFLG          ;DID TRAP OCCUR?
014634  001447                                  BEQ     1$              ;BRANCH TO CHECK DRIVE IF TRAP DID NOT OCCUR
014636                                          PRINTF  #FMT24,#NOCTLR  ;ELSE, PRINT MSG. 'DRIVE DROPPED - NO CONTROLLER'
(8)  014636  012746  007645                     MOV     #NOCTLR,-(SP)
(7)  014642  012746  011632                     MOV     #FMT24,-(SP)
(6)  014646  012746  000002                     MOV     #2,-(SP)
(3)  014652  010600                             MOV     SP,R0
(4)  014654  104417                             TRAP    C$PNTF
(4)  014656  062706  000006                     ADD     #6,SP
014662                                          PRINTF  #FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
(11) 014662  005046                             CLR     -(SP)
(11) 014664  153716  003047                     BISB    RLDRV+1,(SP)
(10) 014670  012746  006152                     MOV     #DRVNAM,-(SP)
(9)  014674  013746  003042                     MOV     RLBAS,-(SP)
(8)  014700  012746  006141                     MOV     #BASADD,-(SP)
(7)  014704  012746  011026                     MOV     #FMT5,-(SP)
(6)  014710  012746  000005                     MOV     #5,-(SP)
(3)  014714  010600                             MOV     SP,R0
(4)  014716  104417                             TRAP    C$PNTF
(4)  014720  062706  000014                     ADD     #14,SP
                                                                        ;PRINT DRIVE INFORMATION
014724                                          PRINTF  #FMT3
(7)  014724  012746  011012                     MOV     #FMT3,-(SP)
(6)  014730  012746  000001                     MOV     #1,-(SP)
(3)  014734  010600                             MOV     SP,R0
(4)  014736  104417                             TRAP    C$PNTF
(4)  014740  062706  000004                     ADD     #4,SP

014744                                          DODU    PSETNM          ;DO DROP UNIT ON DRIVE
(3)  014744  013700  003456                     MOV     PSETNM,R0
(3)  014750  104451                             TRAP    C$DODU
014752  000460                                  BR      2$              ;BRANCH TO EXIT
014754  013705  003046                  1$:     MOV     RLDRV,R5        ;ELSE, GET DRIVE NUMBER
014760  052705  000200                          BIS     #CRDYMSK,R5     ;SET CONTROLLER READY
```

```
 1369  014764  010562  000000                  MOV     R5,RLCS(R2)        ;LOAD IN THE DRIVE NUMBER
 1370  014770  032762  000001  000000          BIT     #DRDYMSK,RLCS(R2)        ;IS DRIVE READY?
 1371  014776  001046                          BNE     2$                 ;BRANCH TO PERFORM TESTS IF DRIVE IS READY
 1372  015000                                  PRINTF  #FMT24,#NOTRDY     ;PRINT MSG. 'DRIVE DROPPED - DID NOT RESPOND
  (8)  015000  012746  007703                  MOV     #NOTRDY,-(SP)
  (7)  015004  012746  011632                  MOV     #FMT24,-(SP)
  (6)  015010  012746  000002                  MOV     #2,-(SP)
  (3)  015014  010600                          MOV     SP,R0
  (4)  015016  104417                          TRAP    C$PNTF
  (4)  015020  062706  000006                  ADD     #6,SP
 1373                                                                    ;/WITH 'READY'''
 1374  015024                                  PRINTF  #FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
  (11) 015024  005046                          CLR     -(SP)
  (11) 015026  153716  003047                  BISB    RLDRV+1,(SP)
  (10) 015032  012746  006152                  MOV     #DRVNAM,-(SP)
  (9)  015036  013746  003042                  MOV     RLBAS,-(SP)
  (8)  015042  012746  006141                  MOV     #BASADD,-(SP)
  (7)  015046  012746  011026                  MOV     #FMT5,-(SP)
  (6)  015052  012746  000005                  MOV     #5,-(SP)
  (3)  015056  010600                          MOV     SP,R0
  (4)  015060  104417                          TRAP    C$PNTF
  (4)  015062  062706  000014                  ADD     #14,SP
 1375                                                                    ;PRINT DRIVE INFORMATION
 1376  015066                                  PRINTF  #FMT3
  (7)  015066  012746  011012                  MOV     #FMT3,-(SP)
  (6)  015072  012746  000001                  MOV     #1,-(SP)
  (3)  015076  010600                          MOV     SP,R0
  (4)  015100  104417                          TRAP    C$PNTF
  (4)  015102  062706  000004                  ADD     #4,SP
 1377  015106                                  DODU    PSETNM             ;DO DROP UNIT ON DRIVE
  (3)  015106  013700  003456                  MOV     PSETNM,R0
  (3)  015112  104451                          TRAP    C$DODU
 1378  015114                          2$:     CLRVEC  ERRVEC             ;RELEASE ERROR VECTOR
  (3)  015114  013700  003244                  MOV     ERRVEC,R0
  (3)  015120  104436                          TRAP    C$CVEC
 1379  015122                          ENDAUTO
  (3)  015122                          L10016:
  (3)  015122  104461                          TRAP    C$AUTO
 1380
```

```
                                        .SBTTL  CLEANUP CODE SECTION

015124                                  BGNMOD  CLNCODE
015124                                  BGNCLN

015124                                          SETVEC  ERRVEC,#TRPHAN,#340
(7)  015124  012746  000340                     MOV     #340,-(SP)
(6)  015130  012746  015576                     MOV     #TRPHAN,-(SP)
(5)  015134  013746  003244                     MOV     ERRVEC,-(SP)
(4)  015140  012746  000003                     MOV     #3,-(SP)
(3)  015144  104437                             TRAP    C$SVEC
(2)  015146  062706  000010                     ADD     #10,SP

015152                                          SETPRI #7                       ;SET PRIORITY TO 7
(3)  015152  012700  000007                     MOV     #7,R0
(3)  015156  104441                             TRAP    C$SPRI
015160  032762  000200  000000  2$:             BIT     #CRDYMSK,RLCS(R2)       ;TEST IF CONTROLLER READY
015166  001407                                  BEQ     3$                      ;NO LOOP UNTIL READY
015170  053762  003046  000000                  BIS     RLDRV,RLCS(R2)          ;SET DRIVE NUMBER
015176  032762  000001  000000                  BIT     #DRDYMSK,RLCS(R2)       ;TEST IF DRIVE BUSY
015204  001005                                  BNE     5$                      ;NO - SKIP
015206                                  3$:     WAITMS  #3                      ;WAIT 300 MS
015220                                  5$:     CLRVEC  RLVEC                   ;RELEASE VEC
(3)  015220  013700  003044                     MOV     RLVEC,R0
(3)  015224  104436                             TRAP    C$CVEC
015226  005737  003464                          TST     PWRFLG                  ;PWR FAIL SET
015232  001402                                  BEQ     7$                      ;NO
015234  005337  003464                          DEC     PWRFLG
015240                                  7$:     CLRVEC  ERRVEC
(3)  015240  013700  003244                     MOV     ERRVEC,R0
(3)  015244  104436                             TRAP    C$CVEC
015246                                          BRESET                          ;TAKE CARE OF LSI-11
(3)  015246  104433                             TRAP    C$RESET

015250                                  ENDCLN
(3)  015250                             L10017:
(3)  015250  104412                             TRAP    C$CLEAN

015252                                  BGNDU
015252  000240                                  NOP
015254                                  ENDDU
(3)  015254                             L10020:
(3)  015254  104453                             TRAP    C$DU

015256                                  ENDMOD
```

```
                                        .SBTTL  GLOBAL SUBROUTINES

015256                                  BGNMOD  GLBSUB


015256  012737  000160  002116  TIME:   MOV     #160,L$DLY              ;GET OUTER DELAY LOOP
015264  005237  003476                  INC     TIM.US                  ;US-WAIT ROUTINE INDICATOR
015270  013737  003466  003472          MOV     XDELAY,MININC           ;SAVE ORIGINAL US-WAIT
015276  005437  003466                  NEG     XDELAY                  ;GET NEGATIVE OF FACTOR
015302                                  READBUS                         ;Q - BUS?
(3)  015302  104407                     TRAP    C$RDBU
015304                                  BCOMPLETE 2$                    ;BRANCH - IF YES
(2)  015304  103420                     BCS     2$
015306                          1$:     DELAY   #1.                     ;WAIT
(2)  015306  012727  000001             MOV     ##1.,(PC)+
(2)  015312  000000                     .WORD   0
(2)  015314  013727  002116             MOV     L$DLY,(PC)+
(2)  015320  000000                     .WORD   0
(2)  015322  005367  177772             DEC     -6(PC)
(2)  015326  001375                     BNE     .-4
(2)  015330  005367  177756             DEC     -22(PC)
(2)  015334  001367                     BNE     .-20
015336  005237  003466                  INC     XDELAY                  ;WAIT FACTOR EXPIRED?
015342  002761                          BLT     1$                      ;BRANCH - IF NO
015344  000422                          BR      4$                      ;GET TIME
015346  012737  000065  002116  2$:     MOV     #65,L$DLY               ;GET OUTER DELAY LOOP
015354                          3$:     DELAY   #1.                     ;WAIT WITH RESPECT TO FONZ BUS
(2)  015354  012727  000001             MOV     ##1.,(PC)+
(2)  015360  000000                     .WORD   0
(2)  015362  013727  002116             MOV     L$DLY,(PC)+
(2)  015366  000000                     .WORD   0
(2)  015370  005367  177772             DEC     -6(PC)
(2)  015374  001375                     BNE     .-4
(2)  015376  005367  177756             DEC     -22(PC)
(2)  015402  001367                     BNE     .-20
015404  005237  003466                  INC     XDELAY                  ;WAIT FACTOR EXPIRED?
015410  002761                          BLT     3$                      ;BRANCH - IF NO
015412  063737  003472  003132  4$:     ADD     MININC,TEMPO            ;GET TIME EXPIRED
015420  000207                          RTS     PC                      ;RETURN


015422  012737  000160  002116  XTIME:  MOV     #160,L$DLY              ;GET OUTER DELAY LOOP
015430  005037  003476                  CLR     TIM.US                  ;MS. WAIT INDICATOR
015434  013737  003470  003502          MOV     YDELAY,MAJINC           ;SAVE ORIGINAL WAIT MS
015442  006337  003470                  ASL     YDELAY                  ;MULTIPLY BY FACTOR 4
015446  006337  003470                  ASL     YDELAY                  ;---------
015452  005437  003470                  NEG     YDELAY                  ;GET NEGATIVE OF RESULT
015456                                  READBUS                         ;Q - BUS?
(3)  015456  104407                     TRAP    C$RDBU
015460                                  BNCOMPLETE      1$              ;BRANCH - IF NO
(2)  015460  103023                     BCC     1$
015462  012737  000150  002116          MOV     #150,L$DLY              ;GET OUTER DELAY LOOP
015470                          2$:     DELAY   #20                     ;WAIT WITH RESPECT TO FONZ BUS
(2)  015470  012727  000020             MOV     ##20,(PC)+
(2)  015474  000000                     .WORD   0
(2)  015476  013727  002116             MOV     L$DLY,(PC)+
```

```
  (2)  015502  000000                          .WORD   0
  (2)  015504  005367  177772                  DEC     -6(PC)
  (2)  015510  001375                          BNE     .-4
  (2)  015512  005367  177756                  DEC     -22(PC)
  (2)  015516  001367                          BNE     .-20
 1446  015520  005237  003470                  INC     YDELAY                  ;WAIT FACTOR EXPIRED
 1447  015524  002761                          BLT     2$                      ;BRANCH - IF NO
 1448  015526  000417                          BR      3$                      ;GET TIME
 1449  015530                          1$:     DELAY   #10                     ;WAIT
  (2)  015530  012727  000010                  MOV     ##10,(PC)+
  (2)  015534  000000                          .WORD   0
  (2)  015536  013727  002116                  MOV     L$DLY,(PC)+
  (2)  015542  000000                          .WORD   0
  (2)  015544  005367  177772                  DEC     -6(PC)
  (2)  015550  001375                          BNE     .-4
  (2)  015552  005367  177756                  DEC     -22(PC)
  (2)  015556  001367                          BNE     .-20
 1450  015560  005237  003470                  INC     YDELAY                  ;WAIT FACTOR EXPIRED?
 1451  015564  002761                          BLT     1$                      ;BRANCH - IF NO
 1452  015566  063737  003502  003474   3$:    ADD     MAJINC,TEMP             ;GET EXPIRED TIME
 1453  015574  000207                          RTS     PC                      ;RETURN
 1454
 1455
 1456
 1457  015576                          BGNSRV
 1458
 1459                                  ;TRAP HANDLER. INDICATES OCCURRENCE OF A TRAP.
 1460
 1461  015576  005237  003462          TRPHAN: INC     TRPFLG
 1462
 1463  015602                          ENDSRV
  (3)  015602                          L10021:
  (2)  015602  000002                          RTI
 1464
 1465  015604                          BGNSRV
 1466
 1467                                  ;INTERRUPT HANDLER. ABORTS WAIT TIMER AND STORES RL11 REGISTERS.
 1468
 1469  015604                          INTHLR:
 1470
 1471  015604  012237  003060                  MOV     (R2)+,T.CS              ;STORE RL REGISTERS
 1472  015610  012237  003062                  MOV     (R2)+,T.BA
 1473  015614  012237  003064                  MOV     (R2)+,T.DA
 1474  015620  011237  003066                  MOV     (R2),T.MP
 1475  015624  012737  177777  003022          MOV     #-1,DONE                ;SET DONE FLAG
 1476  015632  013702  003042                  MOV     RLBAS,R2                ;RESTORE R2
 1477  015636                                  ABORTWAIT
 1478
 1479  015662                          ENDSRV
  (3)  015662                          L10022:
  (2)  015662  000002                          RTI
 1480
```

```
                                        ;       ERROR LIMIT CHECKING ROUTINE
                                        ;       DROPS DRIVE IF ERROR LIMIT EXCEEDED

015664  027737  165362  013566  CKERLM: CMP     @ERRPOINT,ERLIMW        ;TEST IF ERROR LIMIT EXCEEDED
015672  002453                          BLT     1$              ;NO - SKIP
015674                                  INLOOP                  ;CHECK IF IN ERROR LOOP
(3)  015674  104420                     TRAP    C$INLP
015676                                  BCOMPLETE       1$      ;YES - SKIP
(2)  015676  103451                     BCS     1$
015700                                  PRINTF  #FMT25,ERLIMW,#MEXERS
(9)  015700  012746  010513             MOV     #MEXERS,-(SP)
(8)  015704  013746  013566             MOV     ERLIMW,-(SP)
(7)  015710  012746  011637             MOV     #FMT25,-(SP)
(6)  015714  012746  000003             MOV     #3,-(SP)
(3)  015720  010600                     MOV     SP,R0
(4)  015722  104417                     TRAP    C$PNTF
(4)  015724  062706  000010             ADD     #10,SP
015730                                  PRINTF  #FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
(11) 015730  005046                     CLR     -(SP)
(11) 015732  153716  003047             BISB    RLDRV+1,(SP)
(10) 015736  012746  006152             MOV     #DRVNAM,-(SP)
(9)  015742  013746  003042             MOV     RLBAS,-(SP)
(8)  015746  012746  006141             MOV     #BASADD,-(SP)
(7)  015752  012746  011026             MOV     #FMT5,-(SP)
(6)  015756  012746  000005             MOV     #5,-(SP)
(3)  015762  010600                     MOV     SP,R0
(4)  015764  104417                     TRAP    C$PNTF
(4)  015766  062706  000014             ADD     #14,SP
015772                                  PRINTF  #FMT3
(7)  015772  012746  011012             MOV     #FMT3,-(SP)
(6)  015776  012746  000001             MOV     #1,-(SP)
(3)  016002  010600                     MOV     SP,R0
(4)  016004  104417                     TRAP    C$PNTF
(4)  016006  062706  000004             ADD     #4,SP
016012                                  DODU    PSETNM          ;DROP DRIVE
(3)  016012  013700  003456             MOV     PSETNM,R0
(3)  016016  104451                     TRAP    C$DODU
016020                                  DOCLN                   ;GO TO CLEAN UP
(3)  016020  104444                     TRAP    C$DCLN
016022  000207                  1$:     RTS     PC

                                        ;       READ AND STORE ALL RL11 REGISTERS
016024  016237  000000  003060  READRL: MOV     RLCSR(R2),T.CS  ;GET CS REG
016032  016237  000002  003062          MOV     RLBA(R2),T.BA   ;GET BUS ADDRESS REG
016040  016237  000004  003064          MOV     RLDA(R2),T.DA   ;GET DISK ADDRESS
016046  016237  000006  003066          MOV     RLMP(R2),T.MP   ;GET MULTI-PURPOSE REG
016054  000207                          RTS     PC              ;RETURN

                                        ;       WAIT FOR CONTROLLER TIMEOUT TO FORCE INTERRUPT ROUTINE
016056  011646                  WAITIN: MOV     (SP),-(SP)      ;MAKE ROOM FOR ERROR POINTER
016060  005066  000002                  CLR     2(SP)           ;CLEAR FOR POINTER
016064  032762  000200  000000          BIT     #CRDYMSK,RLCSR(R2)      ;TEST IF CONTROLLER READY
016072  001420                          BEQ     4$              ;NO - SKIP TO WAIT
016074  004737  016024                  JSR     PC,READRL       ;READ ALL RL REGS
```

```
016100  005737  003022                  TST     DONE            ;TEST IF INTERRUPT OCCURRED
016104  001435                          BEQ     5$              ;NO - GO SET NO INTERRUPT ERR FLAG
016106  012766  006316  000002  1$:     MOV     #MTOSLOW,2(SP)  ;ELSE SET TOO SLOW ERROR POINTER
016114  032737  002000  003060          BIT     #OPIERR,T.CS    ;TEST IF OPI SET
016122  001403                          BEQ     2$              ;NO - SKIP
016124  012766  006336  000002          MOV     #MDRRES,2(SP)   ;SET MESSAGE FOR NO DRIVE RESPONSE
016132  000207                  2$:     RTS     PC              ;RETURN
016134                          4$:     WAITMS  #3              ;WAIT 300 MS FOR TIMEOUT
016146  032762  000200  000000          BIT     #CRDYMSK,RLCS(R2)       ;TEST IF READY NOW SET
016154  001006                          BNE     3$              ;YES - SKIP
016156  004737  016024                  JSR     PC,READRL       ;READ RL REGS
016162  012766  006407  000002          MOV     #MCONHNG,2(SP)  ;SET MESSAGE FOR CONTROLLER HUNG
016170  000760                          BR      2$              ;SKIP
016172  005737  003022          3$:     TST     DONE            ;ELSE CHECK IF INTERRUPT OCCURRED
016176  001343                          BNE     1$              ;YES - SKIP TO SET TOO SLOW
016200  004737  016024          5$:     JSR     PC,READRL       ;READ RL REGS
016204  012766  006354  000002          MOV     #MNOINT,2(SP)   ;ELSE SET NO INTERRUPT FLAG
016212  000747                          BR      2$              ;GO TO RETURN

                                ;       OPERATION AND TEST INITIALIZE ROUTINE
016214  005037  003020          TSTINT: CLR     OPFLAG          ;CLEAR OPERATION FLAGS
016220  105037  003461                  CLRB    NOERCT          ;RESET INHIBIT ERROR COUNTING
016224  005037  003030                  CLR     MORECE          ;RESET MORE COMPARE ERRORS
016230  000207                          RTS     PC

                                ;       GET STATUS AND GET STATUS WITH RESET ROUTINE
016232  013746  003142          GSTATR: MOV     TEMP4,-(SP)     ;STORE TEMP4
016236  012737  000013  003142          MOV     #GETSTAT!DRSET,TEMP4    ;SET FOR RESET
016244  000412                          BR      GSTATG
016246  013746  003142          GSTATC: MOV     TEMP4,-(SP)     ;STORE TEMP4
016252  012737  000003  003142          MOV     #GETSTAT,TEMP4  ;SET FOR NO RESET
016260  000404                          BR      GSTATG
016262  013746  003142          GSTAT:  MOV     TEMP4,-(SP)     ;STORE TEMP4
016266  005037  003142                  CLR     TEMP4           ;SET FOR SAVE L. AND T. REGS
016272  010346                  GSTATG: MOV     R3,-(SP)        ;STORE R3
016274  013703  003016                  MOV     SSINDX,R3       ;GET SUBROUTINE INDEX
016300  005723                          TST     (R3)+           ;BUMP IT FOR NEXT ENTRY
016302  016663  000004  002420          MOV     4(SP),SUBSTK(R3) ;INSERT THIS CALL
016310  162763  000004  002420          SUB     #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
016316  010337  003016                  MOV     R3,SSINDX       ;STORE IT BACK
016322  010046                          MOV     R0,-(SP)        ;STORE R0
016324  010146                          MOV     R1,-(SP)        ;STORE R1
016326  012737  000002  003032          MOV     #2,ERRSWI       ;SET FOR NO ERROR RETURN
016334  032737  000010  003142          BIT     #DRSET,TEMP4    ;TEST IF DRIVE RESET
016342  001460                          BEQ     11$             ;NO - SKIP
016344  032762  040000  000000          BIT     #DRVERR,RLCS(R2) ;TEST IF DRIVE ERROR SET
016352  001405                          BEQ     49$             ;NO - SKIP
016354                                  WAITMS  #3              ;WAIT FOR 300 MS FOR DRIVE TO SETTLE
016366  012701  000062          49$:    MOV     #50.,R1         ;INITIALIZE WAIT COUNT
016372  004737  016262          50$:    JSR     PC,GSTAT        ;GET DRIVE STATUS
016376  017062                          3$
016400  032737  000001  003060          BIT     #DRDYMSK,T.CS   ;TEST IF DRIVE READY
016406  001054                          BNE     5$              ;YES - GO DO CLEAR
016410  032737  000020  003066          BIT     #HOSTAT,T.MP    ;ELSE TEST IF HEADS OUT
016416  001010                          BNE     51$             ;YES - BYPASS RELOAD WAIT FLAG SETTING
016420  032737  144000  003066          BIT     #SPDSTAT!HCESTAT!WDESTAT,T.MP ;TEST IF DRIVE HAS ERROR
```

```
                                                                                ;THAT CAUSED HEADS TO
                                                                                ;UNLOAD
016426  001444                          BEQ     5$                      ;NO - SKIP
016430  052737  040000  003020          BIS     #RELDWT,OPFLAG          ;ELSE SET WAIT FLAG
016436  000440                          BR      5$                      ;SKIP TO CLEAR
016440  032737  040000  003060  51$:    BIT     #DRVERR,T.CS            ;TEST IF DRIVE ERROR NOW
016446  001034                          BNE     5$                      ;YES - SKIP TO CLEAR
016450                                  WAITMS  #1                      ;WAIT FOR DRIVE TO GET ERROR, RDY, OR HEADS OUT
016462  005301                          DEC     R1                      ;DEC WAIT COUNTER
016464  001342                          BNE     50$                     ;IF NOT DONE, LOOP
016466  012703  010375                  MOV     #MUNDEF,R3              ;MESSAGE FOR UNDEFINED STATE
016472                                  ERRHRD  10001.,,ERR1
(4)  016472  104456                     TRAP    C$ERHRD
(5)  016474  023421                     .WORD   10001
(5)  016476  000000                     .WORD   0
(5)  016500  011724                     .WORD   ERR1
016502  000565                          BR      14$                     ;EXIT
016504  005737  003142          11$:    TST     TEMP4                   ;TEST IF SAVE REGISTERS
016510  001013                          BNE     5$                      ;NO SKIP
016512  012701  000004                  MOV     #4,R1                   ;SET SAVE COUNT
016516  012703  003060                  MOV     #L.MP+2,R3              ;SET ADDRESS OF FIRST SAVE
016522  014346                  8$:     MOV     -(R3),-(SP)             ;PUT REG ON STACK
016524  005301                          DEC     R1                      ;DEC COUNT
016526  001375                          BNE     8$                      ;LOOP UNTIL ALL SAVED
016530  012737  000003  003054          MOV     #GETSTAT,L.DA           ;SET FOR GET STATUS
016536  000403                          BR      6$                      ;SKIP
016540  013737  003142  003054  5$:     MOV     TEMP4,L.DA              ;INSERT PRESET FOR STATUS
016546                          6$:
016546  005037  003022                  CLR     DONE                    ;CLEAR INTERRUPT FLAG
016552  013737  003046  003050          MOV     RLDRV,L.CS              ;SET UP TO GET STATUS
016560  042737  002000  003050          BIC     #BIT10,L.CS             ;CLEAR FOR DRIVE 4 - 7 SPEC'D
016566  052737  000104  003050          BIS     #GTSTAT,L.CS
016574  013762  003054  000004          MOV     L.DA,RLDA(R2)           ;LOAD RL REGS
016602  013762  003050  000000          MOV     L.CS,RLCSR(R2)          ;LOAD CS REG
016610                                  WAITUS  #1                      ;WAIT 100 US FOR INTERRUPT
016622  005737  003022                  TST     DONE                    ;CHECK IF INTERRUPT OCCURRED
016626  001504                          BEQ     1$                      ;NO - SKIP
016630  013737  003066  003074  4$:     MOV     T.MP,T.STAT             ;STORE MP REGISTER
016636  042737  177770  003074          BIC     #^C<STAMSK>,T.STAT ;CLEAR ALL BUT STATE
016644  032737  000010  003054          BIT     #DRSET,L.DA             ;TEST IF RESET WAS SPECIFIED
016652  001503                          BEQ     3$                      ;NO - SKIP TO EXIT
016654  032737  040000  003020          BIT     #RELDWT,OPFLAG          ;TEST IF RELOAD WAIT FLAG SET
016662  001427                          BEQ     12$                     ;NO - SKIP
016664  012701  001130                  MOV     #600.,R1                ;SET WAIT COUNT FOR 60 SECONDS
016670  032762  000001  000000  13$:    BIT     #DRDYMSK,RLCS(R2) ;TEST IF DRIVE NOW READY
016676  001021                          BNE     12$                     ;YES - SKIP
016700                                  WAITMS  #1                      ;CALL WAIT
016712  005301                          DEC     R1                      ;DEC COUNT
016714  001365                          BNE     13$                     ;LOOP IF NOT 0
016716  004737  016262                  JSR     PC,GSTAT                ;GET DRIVE STATUS
016722  017062                          3$                              ;ERROR RETURN
016724  012703  010442                  MOV     #MRLFAL,R3              ;SET RESULT MESSAGE POINTER
016730                                  ERRHRD  10003.,,ERR1
(4)  016730  104456                     TRAP    C$ERHRD
(5)  016732  023423                     .WORD   10003
(5)  016734  000000                     .WORD   0
```

```
 (5)  016736  011724                          .WORD   ERR1
1616  016740  000446                          BR      14$             ;GO TO EXIT
1617  016742                          12$:    WAITUS  #10.            ;WAIT FOR 1MS
1618  016754  004737  016262                  JSR     PC,GSTAT        ;GET DRIVE STATUS
1619  016760  017062                          3$
1620  016762  032737  100000  003060          BIT     #ANYERR,T.CS    ;TEST IF ANY ERROR
1621  016770  001434                          BEQ     3$              ;NO - SKIP
1622  016772  032737  001000  003066          BIT     #VCSTAT,T.MP    ;CHECK IF VOLUME CHECK RESET
1623  017000  001403                          BEQ     7$              ;YES SKIP
1624  017002  012703  006443                  MOV     #VCNRST,R3      ;SET REASON POINTER
1625  017006  000417                          BR      2$              ;EXIT
1626  017010  032737  040000  003060  7$:     BIT     #DRVERR,T.CS    ;CHECK IF DRIVE ERROR
1627  017016  001405                          BEQ     9$              ;NO - SKIP
1628  017020                                  ERRHRD  10004.,,ERR6
 (4)  017020  104456                          TRAP    C$ERHRD
 (5)  017022  023424                          .WORD   10004
 (5)  017024  000000                          .WORD   0
 (5)  017026  012226                          .WORD   ERR6
1629  017030  000412                          BR      14$             ;EXIT
1630  017032  012703  006464          9$:     MOV     #UNXERR,R3      ;SET REASON POINTER
1631  017036  000403                          BR      2$              ;EXIT
1632  017040  004737  016056          1$:     JSR     PC,WAITIN       ;WAIT FOR INTERRUPT
1633  017044  012603                          MOV     (SP)+,R3        ;STORE REASON POINTER FOR RETURN
1634  017046                          2$:     ERRHRD  10002.,,ERR1
 (4)  017046  104456                          TRAP    C$ERHRD
 (5)  017050  023422                          .WORD   10002
 (5)  017052  000000                          .WORD   0
 (5)  017054  011724                          .WORD   ERR1
1635  017056  005037  003032          14$:    CLR     ERRSWI          ;CLEAR FOR ERROR RETURN
1636  017062  005737  003142          3$:     TST     TEMP4           ;TEST IF REGISTERS WERE SAVED
1637  017066  001007                          BNE     22$             ;NO - SKIP
1638  017070  012703  003050                  MOV     #L.CS,R3        ;SET POINTER TO RESTORE
1639  017074  012701  000004                  MOV     #4,R1           ;SET REGISTER COUNT
1640  017100  012623                  20$:    MOV     (SP)+,(R3)+     ;RESTORE REG
1641  017102  005301                          DEC     R1              ;DEC COUNT
1642  017104  001375                          BNE     20$             ;LOOP UNTIL ALL ARE RESTORED
1643  017106  162737  000002  003016  22$:    SUB     #2,SSINDX       ;REMOVE ENTRY FROM SUBROUT STACK
1644  017114  012601                          MOV     (SP)+,R1        ;RESTORE R1
1645  017116  012600                          MOV     (SP)+,R0        ;RESTORE R0
1646  017120  012603                          MOV     (SP)+,R3        ;RESTORE R3
1647  017122  012637  003142                  MOV     (SP)+,TEMP4     ;RESTORE TEMP4
1648  017126  005737  003032                  TST     ERRSWI          ;TEST IF ERROR RETURN
1649  017132  001403                          BEQ     99$             ;YES - SKIP
1650  017134  063716  003032                  ADD     ERRSWI,(SP)     ;ADD IN ERROR RETURN
1651  017140  000207                          RTS     PC
1652  017142  017616  000000          99$:    MOV     @(SP),(SP)      ;SET ERROR RETURN ADDRESS
1653  017146  000207                          RTS     PC
1654
1655
1656                                  ;       SEEK ROUTINE
1657  017150  012737  177777  003134  XSEEKT: MOV     #-1,TEMP1       ;SET SPECIAL TIMING SEEK FLAG
1658  017156  000402                          BR      XSEEK1
1659  017160  005037  003134          XSEEK:  CLR     TEMP1           ;CLEAR SPECIAL SEEK FOR TIMING FLAG
1660  017164  010346                  XSEEK1: MOV     R3,-(SP)        ;STORE R3
1661  017166  013703  003016                  MOV     SSINDX,R3       ;GET SUBROUTINE INDEX
1662  017172  005723                          TST     (R3)+           ;BUMP IT FOR NEXT ENTRY
```

```
017174  016663  000002  002420          MOV     2(SP),SUBSTK(R3) ;INSERT THIS CALL
017202  162763  000004  002420          SUB     #4,SUBSTK(R3)    ;ADJUST IT TO CALLING LOCATION
017210  010337  003016                  MOV     R3,SSINDX        ;STORE IT BACK
017214  010046                          MOV     R0,-(SP)
017216  010146                          MOV     R1,-(SP)
017220  010546                          MOV     R5,-(SP)         ;STORE REG
017222  012737  000002  003032          MOV     #2,ERRSWI        ;SET FOR NO ERROR RETURN
017230  005037  003112                  CLR     DIFAUG           ;CLEAR DIFFERENCE AUGMENT (FOR SEEKING
                                                                 ;    PAST GUARD BAND)
017234  004737  022340                  JSR     PC,GETPOS        ;GET PRESENT POSITION
017240  017672                          65$
017242  013737  003120  003114          MOV     CURCYL,OLDCYL    ;MOVE CURRENT TO OLD CYLINDER
017250  023737  003116  002316          CMP     NEWCYL,HLMTW     ;TEST IF NEW IS GREATER THAN 255
017256  003427                          BLE     3$               ;NO - SKIP
017260  163737  002316  003116          SUB     HLMTW,NEWCYL     ;ELSE SUBTRACT 255.
017266  013737  003116  003112          MOV     NEWCYL,DIFAUG    ;STORE DIFFERENCE AS AUGMENT
017274  013737  002316  003116          MOV     HLMTW,NEWCYL     ;SET NEWCYL AS 255.
017302  022737  000001  002312          CMP     #1,T.DRIVE
017310  001424                          BEQ     6$
017312  162737  000001  003116          SUB     #1,NEWCYL
017320  012737  000001  003124          MOV     #1,DESSGN
017326  012737  000001  003122          MOV     #1,DESDIF
017334  000451                          BR      18$
017336  005737  003116          3$:     TST     NEWCYL           ;TEST IF NEWCYL HAS NEGATIVE VALUE
017342  100007                          BPL     6$               ;NO - SKIP
017344  005437  003116                  NEG     NEWCYL           ;ELSE MAKE IT POSITIVE
017350  013737  003116  003112          MOV     NEWCYL,DIFAUG    ;AND STORE IT AS AUGMENT
017356  005037  003116                  CLR     NEWCYL           ;AND SET NEWCYL TO 0
017362  013705  003120          6$:     MOV     CURCYL,R5        ;COMPUTE DIFFERENCE AND NEW CYLINDER
017366  163705  003116                  SUB     NEWCYL,R5        ;SUB NEWCYL FROM CURCYL
017372  100005                          BPL     13$              ;IF DIFF IS POSITIVE - SKIP(REV SEEK)
017374  012737  000001  003124          MOV     #1,DESSGN        ;ELSE SET SIGN FOR FORWARD
017402  005405                          NEG     R5               ;MAKE DIFFERENCE POSITIVE
017404  000402                          BR      14$              ;SKIP
017406  005037  003124          13$:    CLR     DESSGN           ;SET SIGN FOR REVERSE
017412  010537  003122          14$:    MOV     R5,DESDIF        ;STORE DIFFERENCE
017416  005737  003112                  TST     DIFAUG           ;IS THERE A DIFFERENCE AUGMENT
017422  001416                          BEQ     18$              ;NO - SKIP
017424  023737  003116  002316          CMP     NEWCYL,HLMTW     ;CHECK IF NEW CYL IS 255.
017432  001007                          BNE     17$              ;NO - SKIP
017434  012737  000001  003124          MOV     #1,DESSGN        ;ELSE FORCE SIGN FOR FORWARD
                                                                 ;(INNER GUARD BAND)
017442  022737  000001  002312          CMP     #1,T.DRIVE
017450  001003                          BNE     18$
017452  063737  003112  003122  17$:    ADD     DIFAUG,DESDIF
017460                          18$:
017460  012705  003050                  MOV     #L.CS,R5         ;GET L REG ADDRESS
017464  012715  000106                  MOV     #SEEK,(R5)       ;SET FOR SEEK
017470  053715  003046                  BIS     RLDRV,(R5)       ;INSERT DRIVE NUMBER
017474  042725  002000                  BIC     #BIT10,(R5)+     ;CLEAR IF DRIVE 4 - 7 SPEC'D
017500  005025                          CLR     (R5)+            ;CLEAR BUS ADDRESS
017502  013715  003122                  MOV     DESDIF,(R5)      ;LOAD DIFFERENCE
017506  012700  000007                  MOV     #7,R0            ;SET TO SHIFT DIFFERENCE
017512  006315                  21$:    ASL     (R5)
017514  005300                          DEC     R0
017516  001375                          BNE     21$              ;LOOP UNTIL ALIGNED
```

```
017520  005737  003124                  TST     DESSGN          ;TEST SIGN
017524  001402                          BEQ     23$             ;SKIP IF 0
017526  052715  000004                  BIS     #DIRBIT,(R5)    ;ELSE INSERT SIGN
017532  005737  003126          23$:    TST     DESHD           ;TEST IF HEAD 0
017536  001402                          BEQ     25$             ;YES - SKIP
017540  052715  000020                  BIS     #HDSEL,(R5)     ;ELSE SET HEAD BIT
017544  052725  000001          25$:    BIS     #MBSET0,(R5)+   ;INSERT MARKER BIT
017550  004737  020276                  JSR     PC,RDYCHK       ;CHECK IF DRIVE READY
017554  017672                          65$
017556  005037  003022                  CLR     DONE            ;CLEAR INTERRUPT FLAG
017562  005737  003134                  TST     TEMP1           ;CHECK IF SPECIAL SEEK FLAG SET
017566  001041                          BNE     65$             ;YES - SKIP, DO NOT START SEEK
017570  014562  000004                  MOV     -(R5),RLDA(R2)  ;LOAD RL REGISTERS
017574  014562  000002                  MOV     -(R5),RLBA(R2)
017600  014562  000000                  MOV     -(R5),RLCS(R2)
017604                          30$:    WAITUS  #10.
017616  005737  003022                  TST     DONE            ;TEST IF INTERRUPT DONE
017622  001012                          BNE     32$             ;YES - SKIP
017624  004737  016056                  JSR     PC,WAITIN       ;GO WAIT FOR INTERRUPT
017630  012603                          MOV     (SP)+,R3        ;GET RESULT MESSAGE POINTER
017632                                  ERRHRD  10005.,,ERR1
(4)  017632  104456                     TRAP    C$ERHRD
(5)  017634  023425                     .WORD   10005
(5)  017636  000000                     .WORD   0
(5)  017640  011724                     .WORD   ERR1
017642  005037  003032                  CLR     ERRSWI          ;CLEAR FOR ERROR RETURN
017646  000411                          BR      65$
017650  005737  003060          32$:    TST     T.CS            ;TEST IF ANY ERROR
017654  100006                          BPL     65$             ;NO - SKIP
017656                                  ERRHRD  10006.,,ERR6
(4)  017656  104456                     TRAP    C$ERHRD
(5)  017660  023426                     .WORD   10006
(5)  017662  000000                     .WORD   0
(5)  017664  012226                     .WORD   ERR6
017666  005037  003032                  CLR     ERRSWI          ;CLEAR FOR ERROR RETURN
017672  162737  000002  003016  65$:    SUB     #2,SSINDX       ;REMOVE ENTRY FROM SUBROUT STACK
017700  012605                          MOV     (SP)+,R5        ;RESTORE REGISTERS
017702  012601                          MOV     (SP)+,R1
017704  012600                          MOV     (SP)+,R0
017706  012603                          MOV     (SP)+,R3
017710  005737  003032                  TST     ERRSWI          ;TEST IF ERROR RETURN
017714  001403                          BEQ     99$             ;YES - SKIP
017716  063716  003032                  ADD     ERRSWI,(SP)     ;ADD IN ERROR RETURN
017722  000207                          RTS     PC
017724  017616  000000          99$:    MOV     @(SP),(SP)      ;SET ERROR RETURN ADDRESS
017730  000207                          RTS     PC

                                ;       POSITION HEADS ROUTINE. POSITIONS HEADS USING 1 CYLINDER SEEKS
                                ;       TO CYLINDER SPECIFIED IN R5 BY THE CALLING ROUTINE
017732  010346                  POSHDS: MOV     R3,-(SP)        ;SAVE REGS
017734  013703  003016                  MOV     SSINDX,R3       ;GET SUBROUTINE INDEX
017740  005723                          TST     (R3)+           ;BUMP IT FOR NEXT ENTRY
017742  016663  000002  002420          MOV     2(SP),SUBSTK(R3) ;INSERT THIS CALL
017750  162763  000004  002420          SUB     #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
017756  010337  003016                  MOV     R3,SSINDX       ;STORE IT BACK
```

```
 1824  017762  010346                          MOV     R3,-(SP)
 1825  017764  010446                          MOV     R4,-(SP)
 1826  017766  012737  000002  003032          MOV     #2,ERRSWI       ;SET FOR NO ERROR RETURN
 1827  017774  004737  022340                  JSR     PC,GETPOS       ;GET CURRENT POSITION
 1828  020000  020240                          PH65$
 1829  020002  012704  000012                  MOV     #10.,R4         ;SET RETRY COUNT
 1830  020006                        BGNSEG
  (3)  020006  104404                          TRAP    C$BSEG
 1831  020010                        1$:       INLOOP                  ;CHECK IF IN ERROR LOOP
  (3)  020010  104420                          TRAP    C$INLP
 1832  020012                                   BNCOMPLETE      5$      ;NO - SKIP
  (2)  020012  103012                          BCC     5$
 1833  020014  004737  022340                  JSR     PC,GETPOS       ;ELSE GET POSITION
 1834  020020  020236                          60$
 1835  020022  023737  003120  003116          CMP     CURCYL,NEWCYL   ;CHECK IF AT INTENDED POSITION
 1836  020030  001017                          BNE     8$              ;NO - SKIP
 1837  020032  004737  020636                  JSR     PC,ONSWAP       ;SWAP OLDCYL AND NEWCYL
 1838  020036  000414                          BR      8$              ;SKIP
 1839  020040  013737  003120  003114  5$:     MOV     CURCYL,OLDCYL   ;IN NOT LOOPING, STORE CURCYL AS OLDCYL
 1840  020046  023705  003120                  CMP     CURCYL,R5       ;CHECK IF HDS AT FINAL POSITION
 1841  020052  001471                          BEQ     60$             ;YES - GO TO EXIT
 1842  020054  003003                          BGT     7$              ;IF CURCYL > FINAL POSITION - SKIP
 1843  020056  005237  003116                  INC     NEWCYL          ;ELSE BUMP NEWCYL (MOVE HDS IN)
 1844  020062  000402                          BR      8$              ;SKIP
 1845  020064  005337  003116          7$:     DEC     NEWCYL          ;DEC NEWCYL (MOVE HDS OUT)
 1846  020070  004737  017160          8$:     JSR     PC,XSEEK        ;DO SEEK
 1847  020074  020236                          60$
 1848  020076  012701  005670                  MOV     #3000.,R1       ;SET WAIT COUNT 300 MS
 1849  020102  004737  022054                  JSR     PC,RDYWAIT      ;WAIT FOR DRIVE READY
 1850  020106  020236                          60$
 1851  020110  005737  003060                  TST     T.CS            ;TEST IF ANY ERROR
 1852  020114  100007                          BPL     10$             ;NO - SKIP
 1853  020116                                   ERRHRD  10008.,,ERR6
  (4)  020116  104456                          TRAP    C$ERHRD
  (5)  020120  023430                          .WORD   10008
  (5)  020122  000000                          .WORD   0
  (5)  020124  012226                          .WORD   ERR6
 1854  020126  005037  003032                  CLR     ERRSWI          ;CLEAR FOR ERROR ERROR RETURN
 1855  020132  000441                          BR      60$
 1856  020134  004737  022340          10$:    JSR     PC,GETPOS       ;GET POSITION
 1857  020140  020236                          60$
 1858  020142  023737  003120  003116          CMP     CURCYL,NEWCYL   ;CHECK IF ARRIVED AT DESIRED PLACE
 1859  020150  001003                          BNE     15$             ;NO - SKIP
 1860  020152  012704  000012          14$:    MOV     #10.,R4         ;ELSE INIT RETRY COUNT
 1861  020156  000714                          BR      1$              ;GO DO NEXT SEEK
 1862  020160  005737  003124          15$:    TST     DESSGN          ;TEST IF GOING IN
 1863  020164  001017                          BNE     17$             ;YES - SKIP
 1864  020166  023737  003120  003116          CMP     CURCYL,NEWCYL   ;CHECK IF HEADS DID NOT MOVE IN
 1865  020174  003366                          BGT     14$             ;YES - SKIP
 1866  020176  005304                  16$:    DEC     R4              ;DEC RETRY COUNT
 1867  020200  001333                          BNE     8$              ;DO ANOTHER SEEK IF NOT 0
 1868  020202  012703  007323                  MOV     #HDMOVF,R3      ;ELSE SET RESULT MESSAGE POINTER
 1869  020206                                   ERRHRD  10009.,,ERR1
  (4)  020206  104456                          TRAP    C$ERHRD
  (5)  020210  023431                          .WORD   10009
  (5)  020212  000000                          .WORD   0
```

```
 (5)  020214  011724                                .WORD   ERR1
1870  020216  005037  003032                        CLR     ERRSWI          ;CLEAR FOR ERROR ERROR RETURN
1871  020222  000405                                BR      60$
1872  020224  023737  003120  003116  17$:          CMP     CURCYL,NEWCYL   ;HDS SHOULD MOVE OUT, CHK THEY DID
1873  020232  002747                                BLT     14$             ;YES - SKIP
1874  020234  000760                                BR      16$             ;ELSE GO DEC AND RETRY
1875  020236                          20$:
1876  020236                          60$:
1877  020236                          ENDSEG
 (3)  020236                          10000$:
 (3)  020236  104405                                TRAP    C$ESEG
1878  020240  162737  000002  003016  PH65$:        SUB     #2,SSINDX       ;REMOVE ENTRY FROM SUBROUT STACK
1879  020246  012604                                MOV     (SP)+,R4        ;RESTORE REGISTERS
1880  020250  012600                                MOV     (SP)+,R0
1881  020252  012603                                MOV     (SP)+,R3
1882  020254  005737  003032                        TST     ERRSWI          ;TEST IF ERROR RETURN
1883  020260  001403                                BEQ     99$             ;YES - SKIP
1884  020262  063716  003032                        ADD     ERRSWI,(SP)     ;ADD IN ERROR RETURN
1885  020266  000207                                RTS     PC
1886  020270  017616  000000          99$:          MOV     @(SP),(SP)      ;SET ERROR RETURN ADDRESS
1887  020274  000207                                RTS     PC
1888
1890                                  ;             DRIVE READY TEST ROUTINE. CHECKS DRIVE IS READY. IF NOT, WAIT
1891                                  ;             500MS FOR READY TO SET.
1892  020276  010346                  RDYCHK:       MOV     R3,-(SP)        ;STORE REGS
1893  020300  013703  003016                        MOV     SSINDX,R3       ;GET SUBROUTINE INDEX
1894  020304  005723                                TST     (R3)+           ;BUMP IT FOR NEXT ENTRY
1895  020306  016663  000002  002420                MOV     2(SP),SUBSTK(R3) ;INSERT THIS CALL
1896  020314  162763  000004  002420                SUB     #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
1897  020322  010337  003016                        MOV     R3,SSINDX       ;STORE IT BACK
1898  020326  010046                                MOV     R0,-(SP)
1899  020330  010146                                MOV     R1,-(SP)
1900  020332  010446                                MOV     R4,-(SP)
1901  020334  012737  000002  003032                MOV     #2,ERRSWI       ;SET FOR NO ERROR RETURN
1902  020342  012701  011610                        MOV     #5000.,R1       ;SET WAIT COUNT
1903  020346  004737  016262          1$:           JSR     PC,GSTAT        ;GET DRIVE STATUS
1904  020352  020506                                4$
1905  020354  032737  000001  003060                BIT     #DRDYMSK,T.CS   ;TEST IF DRIVE READY
1906  020362  001053                                BNE     5$              ;YES - EXIT
1907  020364                                        WAITUS  #1
1908  020376  005301                                DEC     R1              ;DEC WAIT COUNT
1909  020400  001362                                BNE     1$              ;LOOP IF NOT 0
1910  020402  012703  007760                        MOV     #MDRDY,R3       ;SET RESULT MESSAGE POINTER
1911  020406  012704  010645                        MOV     #C500MS,R4      ;SET CONDITION MESSAGE POINTER
1912  020412                                        ERRHRD  10010.,,ERR5
 (4)  020412  104456                                TRAP    C$ERHRD
 (5)  020414  023432                                .WORD   10010
 (5)  020416  000000                                .WORD   0
 (5)  020420  012156                                .WORD   ERR5
1913  020422  012701  000062                        MOV     #50.,R1         ;SET WAIT COUNT FOR 5 SECONDS
1914  020426  004737  016262          2$:           JSR     PC,GSTAT        ;GET DRIVE STATUS
1915  020432  020506                                4$
1916  020434  032737  000001  003060                BIT     #DRDYMSK,T.CS   ;TEST IF DRIVE READY
1917  020442  001007                                BNE     3$              ;YES - SKIP
1918  020444                                        WAITMS  #1              ;WAIT FOR 100MS
1919  020456  005301                                DEC     R1              ;DEC WAIT COUNTER
```

```
020460  001362                          BNE     2$              ;LOOP UNTIL TIME DONE
020462  032737  100000  003060  3$:     BIT     #ANYERR,T.CS    ;TEST IF ANYERR SET
020470  001406                          BEQ     4$              ;NO - SKIP
020472                                  ERRHRD  10011.,,ERR6    ;REPORT ALL ERRORS
(4)  020472  104456                     TRAP    C$ERHRD
(5)  020474  023433                     .WORD   10011
(5)  020476  000000                     .WORD   0
(5)  020500  012226                     .WORD   ERR6
020502  005337  003254                  DEC     ERRCNT          ;REDUCE ERROR COUNT FOR DUAL ERRORS
020506  005037  003032          4$:     CLR     ERRSWI          ;CLEAR FOR ERROR RETURN
020512  162737  000002  003016  5$:     SUB     #2,SSINDX       ;REMOVE ENTRY FROM SUBROUT STACK
020520  012604                          MOV     (SP)+,R4        ;RESTORE REGS
020522  012601                          MOV     (SP)+,R1
020524  012600                          MOV     (SP)+,R0
020526  012603                          MOV     (SP)+,R3
020530  005737  003032                  TST     ERRSWI          ;TEST IF ERROR RETURN
020534  001403                          BEQ     99$             ;YES - SKIP
020536  063716  003032                  ADD     ERRSWI,(SP)     ;ADD IN ERROR RETURN
020542  000207                          RTS     PC
020544  017616  000000          99$:    MOV     @(SP),(SP)      ;SET ERROR RETURN ADDRESS
020550  000207                          RTS     PC

                                ;       CHOOSE HEAD ROUTINE. PICKS HEAD 0 UNLESS SPECIFIC HEAD IS
                                ;       SELECTED BY SOFTWARE PARAMETER.
020552  005037  003126          CHOSHD: CLR     DESHD           ;CLEAR TO HEAD 0
020556  032737  010000  013556          BIT     #HEADLM,MISWIW  ;TEST IF HEAD SPECIFIED
020564  001403                          BEQ     1$              ;NO - SKIP
020566  013737  013564  003126          MOV     HEADW,DESHD     ;INSERT SPECIFIED HEAD
020574  000207                  1$:     RTS     PC

                                ;       SWAP HEAD ROUTINE. CHANGES SELECTED HEAD TO HEAD 1
                                ;       UNLESS HEAD 0 SPECIFICALLY SELECTED BY SOFTWARE PARAMETER.
020576  032737  010000  013556  SWAPHD: BIT     #HEADLM,MISWIW  ;TEST IF HEAD SPECIFIED
020604  001011                          BNE     2$              ;YES - TAKE ABORT EXIT
020606  005737  003126                  TST     DESHD           ;TEST IF HEAD ONE USED
020612  001006                          BNE     2$              ;YES - TAKE ABORT EXIT
020614  012737  000001  003126          MOV     #1,DESHD        ;ELSE SET FOR HEAD ONE
020622  062716  000002                  ADD     #2,(SP)         ;BUMP PAST ABORT RETURN
020626  000207                          RTS     PC              ;RETURN
020630  017616  000000          2$:     MOV     @(SP),(SP)      ;GET ABORT DESTINATION
020634  000207                  3$:     RTS     PC

                                ;       SWAP OLD CYLINDER AND NEW CYLINDER ROUTINE.
020636  010046                  ONSWAP: MOV     R0,-(SP)        ;STORE R0
020640  013700  003114                  MOV     OLDCYL,R0       ;MOVE OLD TO R0
020644  013737  003116  003114          MOV     NEWCYL,OLDCYL   ;MOVE NEW TO OLD
020652  010037  003116                  MOV     R0,NEWCYL       ;PUT OLD IN NEW
020656  012600                          MOV     (SP)+,R0        ;RESTORE R0
020660  000207                          RTS     PC

                                ;       BAD SECTOR FILES VALID CHECK ROUTINE. CHECKS IF BAD SECTOR
                                ;       FILES HAVE BEEN READ AND STORED. IF NOT, REPORT AND FORCE
                                ;       FILES TO LOOK LIKE ALL SECTORS OK.
020662  005737  003510          CKBSVD: TST     BSFVAL          ;TEST IF BAD SECTORS STORED
020666  001051                          BNE     5$              ;YES - EXIT
020670                                  PRINTF  #FMT9,#BSNSTR   ;REPORT
```

```
  (8)  020670  012746  007550                MOV     #BSNSTR,-(SP)
  (7)  020674  012746  011212                MOV     #FMT9,-(SP)
  (6)  020700  012746  000002                MOV     #2,-(SP)
  (3)  020704  010600                        MOV     SP,R0
  (4)  020706  104417                        TRAP    C$PNTF
  (4)  020710  062706  000006                ADD     #6,SP
 1973  020714                                PRINTF  #FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
  (11) 020714  005046                        CLR     -(SP)
  (11) 020716  153716  003047                BISB    RLDRV+1,(SP)
  (10) 020722  012746  006152                MOV     #DRVNAM,-(SP)
  (9)  020726  013746  003042                MOV     RLBAS,-(SP)
  (8)  020732  012746  006141                MOV     #BASADD,-(SP)
  (7)  020736  012746  011026                MOV     #FMT5,-(SP)
  (6)  020742  012746  000005                MOV     #5,-(SP)
  (3)  020746  010600                        MOV     SP,R0
  (4)  020750  104417                        TRAP    C$PNTF
  (4)  020752  062706  000014                ADD     #14,SP
 1974  020756                                PRINTF  #FMT3
  (7)  020756  012746  011012                MOV     #FMT3,-(SP)
  (6)  020762  012746  000001                MOV     #1,-(SP)
  (3)  020766  010600                        MOV     SP,R0
  (4)  020770  104417                        TRAP    C$PNTF
  (4)  020772  062706  000004                ADD     #4,SP
 1975  020776  012737  177777  003512        MOV     #-1,SBSFIL      ;FORCE FILES TO NO ENTRIES
 1976  021004  012737  177777  003706        MOV     #-1,FBSFIL
 1977  021012  000207                 5$:    RTS     PC
 1978
 1980                                 ;      READ HEADERS ROUTINE.
 1981  021014  012737  000001  003142 XRDHDC: MOV     #1,TEMP4        ;SET FLAG TO BYPASS REG STORAGE
 1982  021022  000402                        BR      XRDHDG          ;GO DO IT
 1983  021024  005037  003142        XRDHD:  CLR     TEMP4           ;SET FLAG TO SAVE T. AMD L. REGS
 1984  021030  010346                 XRDHDG: MOV     R3,-(SP)        ;STORE REGISTERS
 1985  021032  013703  003016                MOV     SSINDX,R3       ;GET SUBROUTINE INDEX
 1986  021036  005723                        TST     (R3)+           ;BUMP IT FOR NEXT ENTRY
 1987  021040  016663  000002  002420        MOV     2(SP),SUBSTK(R3) ;INSERT THIS CALL
 1988  021046  162763  000004  002420        SUB     #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
 1989  021054  010337  003016                MOV     R3,SSINDX       ;STORE IT BACK
 1990  021060  010046                        MOV     R0,-(SP)
 1991  021062  010146                        MOV     R1,-(SP)
 1992  021064  010446                        MOV     R4,-(SP)
 1993  021066  012737  000002  003032        MOV     #2,ERRSWI       ;SET FOR NO ERROR RETURN
 1994  021074  005737  003142                TST     TEMP4           ;TEST IF REGISTERS TO BE SAVED
 1995  021100  001007                        BNE     2$              ;NO - SKIP
 1996  021102  012703  003060                MOV     #L.MP+2,R3      ;SET POINTER FOR REGS
 1997  021106  012701  000004                MOV     #4,R1           ;SET COUNT
 1998  021112  014346                 1$:    MOV     -(R3),-(SP)     ;SAVE REGISTER
 1999  021114  005301                        DEC     R1              ;DEC COUNT
 2000  021116  001375                        BNE     1$              ;LOOP UNTIL ALL ARE SAVED
 2001  021120  004737  020276        2$:    JSR     PC,RDYCHK       ;CHECK DRIVE READY
 2002  021124  021374                        65$
 2003  021126  005037  003022                CLR     DONE            ;CLEAR INTERRUPT FLAG
 2004  021132  012701  003050                MOV     #L.CS,R1        ;GET ADDRESS OF LOAD REGS
 2005  021136  013711  003046                MOV     RLDRV,(R1)      ;LOAD DRIVE NUMBER
 2006  021142  042711  002000                BIC     #BIT10,(R1)     ;CLEAR FOR DRIVE 4 - 7 SPEC'D
 2007  021146  052721  000110                BIS     #RDHEAD,(R1)+   ;INSERT COMMAND
 2008  021152  005021                        CLR     (R1)+           ;CLEAR BA
```

```
021154  005021                          CLR     (R1)+           ;CLEAR DA
021156  014162  000004                  MOV     -(R1),RLDA(R2)  ;LOAD RL11 REGS
021162  014162  000002                  MOV     -(R1),RLBA(R2)
021166  014162  000000                  MOV     -(R1),RLCSR(R2)
021172                          3$:     WAITUS  #10.            ;WAIT 1MS FOR INTERRUPT
021204  005737  003022                  TST     DONE            ;TEST IN INTERRUPT FLAG SET
021210  001460                          BEQ     14$             ;NO - SKIP
021212  032737  000001  003060  5$:     BIT     #DRDYMSK,T.CS   ;TEST IF DRIVE READY
021220  001035                          BNE     10$             ;YES - SKIP
021222  012703  007760                  MOV     #MDRDY,R3       ;SET NO READY MESSAGE
021226  012704  010662                  MOV     #CAFDT,R4       ;CONDITION OF AFTER DATA XFER
021232                                  ERRHRD  10017.,,ERR5
(4)  021232  104456                     TRAP    C$ERHRD
(5)  021234  023441                     .WORD   10017
(5)  021236  000000                     .WORD   0
(5)  021240  012156                     .WORD   ERR5
021242  012701  000062                  MOV     #50.,R1         ;SET WAIT COUNT FOR 5 SECONDS
021246  004737  016262          4$:     JSR     PC,GSTAT        ;GET STATUS
021252  021370                          60$
021254  032737  000001  003060          BIT     #DRDYMSK,T.CS   ;TEST IF DRIVE HAS COME READY
021262  001403                          BEQ     11$             ;NO - SKIP
021264  005037  003032                  CLR     ERRSWI          ;CLEAR ERROR SWITCH
021270  000411                          BR      10$             ;SKIP
021272  005301                  11$:    DEC     R1              ;DEC WAIT COUNT
021274  001364                          BNE     4$              ;LOOP UNTIL TIME DONE
021276  012704  010673                  MOV     #C5SEC,R4       ;SET CONDITION AFTER 5 SECONDS
021302                                  ERRHRD  10014.,,ERR5
(4)  021302  104456                     TRAP    C$ERHRD
(5)  021304  023436                     .WORD   10014
(5)  021306  000000                     .WORD   0
(5)  021310  012156                     .WORD   ERR5
021312  000426                          BR      60$             ;EXIT
021314  005737  003060          10$:    TST     T.CS            ;CHECK FOR ANY ERRORS
021320  100005                          BPL     12$             ;NO - SKIP
021322                                  ERRHRD  10016.,,ERR6    ;REPORT ALL ERRORS
(4)  021322  104456                     TRAP    C$ERHRD
(5)  021324  023440                     .WORD   10016
(5)  021326  000000                     .WORD   0
(5)  021330  012226                     .WORD   ERR6
021332  000416                          BR      60$
021334  012701  003070          12$:    MOV     #HDWRD2,R1      ;GET POINTER
021340  016221  000006                  MOV     RLMP(R2),(R1)+  ;STORE LAST TWO HEADER WORDS
021344  016221  000006                  MOV     RLMP(R2),(R1)+
021350  000411                          BR      65$             ;EXIT
021352  004737  016056          14$:    JSR     PC,WAITIN       ;WAIT FOR INTERRUPT
021356  012603                          MOV     (SP)+,R3        ;GET RESULTS
021360                                  ERRHRD  10015.,,ERR1    ;REPORT
(4)  021360  104456                     TRAP    C$ERHRD
(5)  021362  023437                     .WORD   10015
(5)  021364  000000                     .WORD   0
(5)  021366  011724                     .WORD   ERR1
021370  005037  003032          60$:    CLR     ERRSWI          ;CLEAR FOR ERROR ERROR RETURN
021374  005737  003142          65$:    TST     TEMP4           ;TEST IF REGISTERS WERE SAVED
021400  001007                          BNE     22$             ;NO - SKIP
021402  012703  003050                  MOV     #L.CS,R3        ;SET POINTER TO RESTORE REGS
021406  012701  000004                  MOV     #4,R1           ;SET COUNT
```

```
021412  012623                  20$:    MOV     (SP)+,(R3)+     ;RESTORE REGISTER
021414  005301                          DEC     R1              ;DEC COUNT
021416  001375                          BNE     20$             ;LOOP UNTIL ALL ARE RESTORED
021420  162737  000002  003016  22$:    SUB     #2,SSINDX       ;REMOVE ENTRY FROM SUBROUT STACK
021426  012604                          MOV     (SP)+,R4        ;RESTORE REGS
021430  012601                          MOV     (SP)+,R1
021432  012600                          MOV     (SP)+,R0
021434  012603                          MOV     (SP)+,R3
021436  005737  003032                  TST     ERRSWI          ;TEST IF ERROR RETURN
021442  001403                          BEQ     99$             ;YES - SKIP
021444  063716  003032                  ADD     ERRSWI,(SP)     ;ADD IN ERROR RETURN
021450  000207                          RTS     PC
021452  017616  000000          99$:    MOV     @(SP),(SP)      ;SET ERROR RETURN ADDRESS
021456  000207                          RTS     PC

                                ;       VERIFY HEADERS ROUTINE. COMPARES 40 HEADERS FOR CONTENT AND
                                ;       SEQUENCE.
021460  010346                  VERHDR: MOV     R3,-(SP)        ;STORE REGS
021462  013703  003016                  MOV     SSINDX,R3       ;GET SUBROUTINE INDEX
021466  005723                          TST     (R3)+           ;BUMP IT FOR NEXT ENTRY
021470  016663  000002  002420          MOV     2(SP),SUBSTK(R3) ;INSERT THIS CALL
021476  162763  000004  002420          SUB     #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
021504  010337  003016                  MOV     R3,SSINDX       ;STORE IT BACK
021510  010046                          MOV     R0,-(SP)
021512  010146                          MOV     R1,-(SP)
021514  010446                          MOV     R4,-(SP)
021516  010546                          MOV     R5,-(SP)
021520  012737  000002  003032          MOV     #2,ERRSWI       ;SET FOR NO ERROR RETURN
021526  052737  000002  003020          BIS     #HDRCMP,OPFLAG  ;SET HEADER COMPARE FLAG
021534  005037  003030                  CLR     MORECE          ;CLEAR MORE ERRORS FLAG
021540  012704  004102                  MOV     #IBUFF,R4       ;SET POINTER TO HEADERS
021544  012705  003132                  MOV     #TEMP0,R5       ;SET POINTER TO WORK AREA
021550  005003                          CLR     R3              ;CLEAR FOR WORD COUNTER
021552  011415                          MOV     (R4),(R5)       ;MOVE HDR WORD TO WORK AREA
021554  011401                          MOV     (R4),R1         ;PUT WORD IN REG 1
021556  042701  000177                  BIC     #177,R1 ;CLEAR ALL BUT CYLINDER
021562  012700  000007                  MOV     #7,R0           ;SET SHIFT COUNT
021566  006201                  3$:     ASR     R1              ;SHIFT
021570  005300                          DEC     R0              ;DEC
021572  001375                          BNE     3$              ;LOOP
021574  020137  003116                  CMP     R1,NEWCYL       ;CHECK IF CYLINDER PART GOOD
021600  001407                          BEQ     4$              ;YES - SKIP
021602                                  ERRHRD  10018.,,ERR10   ;REPORT ERROR
021602  104456                          TRAP    C$ERHRD
021604  023442                          .WORD   10018
021606  000000                          .WORD   0
021610  013320                          .WORD   ERR10
021612  005037  003032                  CLR     ERRSWI          ;CLEAR FOR ERROR ERROR RETURN
021616  000456                          BR      65$
021620  012701  000050          4$:     MOV     #40.,R1         ;SET HEADER COUNT
021624  042715  000100                  BIC     #HDHSEL,(R5)    ;CLEAR HEAD SELECT AND 0 BIT
021630  005737  003126                  TST     DESHD           ;ARE WE USING HD 0?
021634  001402                          BEQ     5$              ;YES - SKIP
021636  052715  000100                  BIS     #HDHSEL,(R5)    ;INSERT HEAD BIT
021642  005065  000002          5$:     CLR     2(R5)           ;CLEAR 2ND WORD OF WORK AREA
021646  021524                  6$:     CMP     (R5),(R4)+      ;TEST FIRST WORD OK
```

```
021650  001410                          BEQ     6$              ;YES - SKIP
021652  005744                          TST     -(R4)           ;ELSE SET POINTER FOR ERROR
021654                                  ERRHRD  10018.,,ERR10   ;REPORT
(4)  021654  104456                     TRAP    C$ERHRD
(5)  021656  023442                     .WORD   10018
(5)  021660  000000                     .WORD   0
(5)  021662  013320                     .WORD   ERR10
021664  005037  003032                  CLR     ERRSWI          ;CLEAR FOR ERROR RETURN
021670  005724                          TST     (R4)+           ;RESET POINTER
021672  005203                  8$:     INC     R3              ;BUMP WORD COUNTER
021674  005724                          TST     (R4)+           ;TEST 2ND WORD IS 0
021676  001410                          BEQ     12$             ;YES - SKIP
021700  022544                          CMP     (R5)+,-(R4)     ;ADJUST POINTERS FOR REPORT
021702                                  ERRHRD  10018.,,ERR10   ;REPORT
(4)  021702  104456                     TRAP    C$ERHRD
(5)  021704  023442                     .WORD   10018
(5)  021706  000000                     .WORD   0
(5)  021710  013320                     .WORD   ERR10
021712  005037  003032                  CLR     ERRSWI          ;CLEAR FOR ERROR RETURN
021716  024524                          CMP     -(R5),(R4)+     ;RESET POINTERS
021720  005724                  12$:    TST     (R4)+           ;BUMP PAST ECC WORD
021722  005203                          INC     R3              ;BUMP WORD COUNTER
021724  005215                          INC     (R5)            ;BUMP SECTOR OF EXPECTED HEADER
021726  011500                          MOV     (R5),R0         ;MOVE EXPECTED HDR TO R0
021730  042700  177700                  BIC     #^CHDSEC,R0     ;CLEAR ALL BUT SECTOR
021734  022700  000050                  CMP     #40.,R0         ;TEST IF AT SECTOR 40
021740  001002                          BNE     15$             ;NO - SKIP
021742  042715  000077                  BIC     #HDSEC,(R5)     ;CLEAR SECTOR TO 0
021746  005203                  15$:    INC     R3              ;BUMP HDR WORD COUNTER
021750  005301                          DEC     R1              ;DEC HEADER COUNT
021752  001335                          BNE     6$              ;LOOP IF NOT YET DONE
021754  162737  000002  003016  65$:    SUB     #2,SSINDX       ;REMOVE ENTRY FROM SUBROUT STACK
021762  012605                          MOV     (SP)+,R5        ;RESTORE REGISTERS
021764  012604                          MOV     (SP)+,R4
021766  012601                          MOV     (SP)+,R1
021770  012600                          MOV     (SP)+,R0
021772  012603                          MOV     (SP)+,R3
021774  005737  003032                  TST     ERRSWI          ;TEST IF ERROR RETURN
022000  001403                          BEQ     99$             ;YES - SKIP
022002  063716  003032                  ADD     ERRSWI,(SP)     ;ADD IN ERROR RETURN
022006  000207                          RTS     PC
022010  017616  000000          99$:    MOV     @(SP),(SP)      ;SET ERROR RETURN ADDRESS
022014  000207                          RTS     PC

                                ;       POSITION HEAD BIT FROM HEADER OR MULTIPURPOSE REGISTER TO LSB.
022016  013705  003066          POSHW1: MOV     HDWRD1,R5       ;START FOR POSITION HD BIT IN WD 1
022022  000402                          BR      POSHD0          ;SKIP
022024  013705  003066          POSHSB: MOV     T.MP,R5 ;START FOR POSITION HD BIT IN MP
022030  010146                  POSHD0: MOV     R1,-(SP)        ;STORE R1
022032  042705  177677                  BIC     #^CHSSTAT,R5    ;CLEAR ALL BUT HEAD SEL BIT
022036  012701  000006                  MOV     #6,R1           ;SET SHIFT COUNT
022042  006205                  1$:     ASR     R5              ;SHIFT FOR RIGHT JUSTIFY
022044  005301                          DEC     R1
022046  001375                          BNE     1$
022050  012601                          MOV     (SP)+,R1        ;RESTORE R1
022052  000207                          RTS     PC              ;RETURN
```

```
                                        ;       WAIT FOR READY ROUTINE. DURATION OF WAIT PASSED TO THE ROUTINE
                                        ;       FROM THE CALLING ROUTINE IN R1.
022054  010346                          P.DYWAIT:       MOV     R3,-(SP)        ;STORE R3
022056  013703  003016                          MOV     SSINDX,R3       ;GET SUBROUTINE INDEX
022062  005723                                  TST     (R3)+           ;BUMP IT FOR NEXT ENTRY
022064  016663  000002  002420                  MOV     2(SP),SUBSTK(R3) ;INSERT THIS CALL
022072  162763  000004  002420                  SUB     #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
022100  010337  003016                          MOV     R3,SSINDX       ;STORE IT BACK
022104  010046                                  MOV     R0,-(SP)
022106  010146                                  MOV     R1,-(SP)
022110  010446                                  MOV     R4,-(SP)
022112  012737  000002  003032                  MOV     #2,ERRSWI       ;SET FOR NO ERROR RETURN
022120  004737  016262                  5$:     JSR     PC,GSTAT        ;GET DRIVE STATUS
022124  022274                                  10$
022126  032737  000001  003060                  BIT     #DRDYMSK,T.CS   ;CHECK IF READY
022134  001061                                  BNE     9$              ;YES - SKIP
022136  005301                                  DEC     R1              ;DEC WAIT COUNT
022140  001406                                  BEQ     7$              ;SKIP IF 0
022142                                          WAITUS  #1
022154  000761                                  BR      5$
022156  012703  007760                  7$:     MOV     #MDRDY,R3       ;SET NAME MESSAGE PTR
022162                                          ERRHRD  10020.,,ERR3    ;REPORT READY ERROR
(4)     022162  104456                          TRAP    C$ERHRD
(5)     022164  023[illegible]4                 .WORD   10020
(5)     022166  000000                          .WORD   0
(5)     022170  012040                          .WORD   ERR3
022172  012701  000062                          MOV     #50.,R1         ;SET WAIT COUNT FOR 5 SECONDS
022176  004737  016262                  6$:     JSR     PC,GSTAT        ;GET DRIVE STATUS
022202  022274                                  10$
022204  032737  000001  003060                  BIT     #DRDYMSK,T.CS   ;TEST IF DRIVE READY
022212  001016                                  BNE     8$              ;YES - SKIP
022214                                          WAITMS  #1              ;WAIT 100 MS
022226  005301                                  DEC     R1              ;DEC WAIT COUNT
022230  001362                                  BNE     6$              ;LOOP UNTIL TIME DONE
022232  012704  010673                          MOV     #C5SEC,R4       ;SET CONDITION AFTER 5 SECDS
022236                                          ERRHRD  10021.,,ERR5
(4)     022236  104456                          TRAP    C$ERHRD
(5)     022240  023445                          .WORD   10021
(5)     022242  000000                          .WORD   0
(5)     022244  012156                          .WORD   ERR5
022246  000410                                  BR      11$             ;EXIT
022250  032737  100000  003060          8$:     BIT     #ANYERR,T.CS    ;TEST IF ANY ERROR SET
022256  001406                                  BEQ     10$             ;NO - SKIP
022260                                          ERRHRD  10022.,,ERR6    ;REPORT ALL ERRORS
(4)     022260  104456                          TRAP    C$ERHRD
(5)     022262  023446                          .WORD   10022
(5)     022264  000000                          .WORD   0
(5)     022266  012226                          .WORD   ERR6
022270  005337  003254                  11$:    DEC     ERRCNT          ;DEC FOR DOUBLE ERROR REPORT
022274  005037  003032                  10$:    CLR     ERRSWI          ;CLEAR FOR ERROR ERROR RETURN
022300  162737  000002  003016          9$:     SUB     #2,SSINDX       ;REMOVE ENTRY FROM SUBROUT STACK
022306  012604                                  MOV     (SP)+,R4        ;RESTORE REGISTERS
022310  012601                                  MOV     (SP)+,R1
022312  012600                                  MOV     (SP)+,R0
022314  012603                                  MOV     (SP)+,R3        ;RESTORE R3
```

```
022316  005737  003032                  TST     ERRSWI          ;TEST IF ERROR RETURN
022322  001403                          BEQ     99$             ;YES - SKIP
022324  063716  003032                  ADD     ERRSWI,(SP)     ;ADD IN ERROR RETURN
022330  000207                          RTS     PC
022332  017616  000000          99$:    MOV     @(SP),(SP)      ;SET ERROR RETURN ADDRESS
022336  000207                          RTS     PC

                                ;       GET POSITION ROUTINE. READS A HEADER FROM CURRENT CYLINDER
                                ;       (WHERE IT IS PRESENTLY POSITIONED) AND STORES CYLINDER
                                ;       NUMBER IN CURCYL.
022340  010346                  GETPOS: MOV     R3,-(SP)        ;STORE REGISTERS
022342  013703  003016                  MOV     SSINDX,R3       ;GET SUBROUTINE INDEX
022346  005723                          TST     (R3)+           ;BUMP IT FOR NEXT ENTRY
022350  016663  000002  002420          MOV     2(SP),SUBSTK(R3) ;INSERT THIS CALL
022356  162763  000004  002420          SUB     #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
022364  010337  003016                  MOV     R3,SSINDX       ;STORE IT BACK
022370  010046                          MOV     R0,-(SP)
022372  010546                          MOV     R5,-(SP)
022374  004737  021024                  JSR     PC,XRDHD        ;DO READ HEADER
022400  022430                          65$
022402  013703  003066                  MOV     HDWRD1,R3       ;GET HEADER WORD
022406  012705  000007                  MOV     #7,R5           ;SET SHIFT COUNT
022412  006203                  4$:     ASR     R3              ;SHIFT TO RIGHT JUSTIFY
022414  005305                          DEC     R5
022416  001375                          BNE     4$
022420  042703  177000                  BIC     #177000,R3
022424  010337  003120                  MOV     R3,CURCYL       ;STORE AS CURRENT CYLINDER
022430  162737  000002  003016  65$:    SUB     #2,SSINDX       ;REMOVE ENTRY FROM SUBROUT STACK
022436  012605                          MOV     (SP)+,R5        ;RESTORE REGISTERS
022440  012600                          MOV     (SP)+,R0
022442  012603                          MOV     (SP)+,R3
022444  005737  003032                  TST     ERRSWI          ;TEST IF ERROR RETURN
022450  001403                          BEQ     99$             ;YES - SKIP
022452  063716  003032                  ADD     ERRSWI,(SP)     ;ADD IN ERROR RETURN
022456  000207                          RTS     PC
022460  017616  000000          99$:    MOV     @(SP),(SP)      ;SET ERROR RETURN ADDRESS
022464  000207                          RTS     PC

                                ;       VERIFY POSITION ROUTINE. READS A HEADER (USING GETPOS) AND
                                ;       CHECKS HEADS ARE POSITIONED AT NEW CYLINDER (CURCYL = NEWCYL).
022466  010346                  VERPOS: MOV     R3,-(SP)        ;STORE R3
022470  013703  003016                  MOV     SSINDX,R3       ;GET SUBROUTINE INDEX
022474  005723                          TST     (R3)+           ;BUMP IT FOR NEXT ENTRY
022476  016663  000002  002420          MOV     2(SP),SUBSTK(R3) ;INSERT THIS CALL
022504  162763  000004  002420          SUB     #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
022512  010337  003016                  MOV     R3,SSINDX       ;STORE IT BACK

022516  012737  000002  003032          MOV     #2,ERRSWI       ;SET FOR NO ERROR RETURN
022524  004737  022340                  JSR     PC,GETPOS       ;GET POSITION
022530  022556                          65$
022532  023737  003116  003120          CMP     NEWCYL,CURCYL   ;CHECK IF CURRENT CYL IS NEW CYL
022540  001406                          BEQ     1$              ;YES - SKIP
022542                                  ERRHRD  10022.,,ERR8
(4)  022542  104456                     TRAP    C$ERHRD
(5)  022544  023446                     .WORD   10022
(5)  022546  000000                     .WORD   0
```

```
  (5)  022550  013160                                .WORD   ERR8
 2249  022552  005037  003032                        CLR     ERRSWI          ;CLEAR FOR ERROR ERROR RETURN
 2250  022556                              1$:
 2251  022556  162737  000002  003016     65$:      SUB     #2,SSINDX       ;REMOVE ENTRY FROM SUBROUT STACK
 2252  022564  012603                                MOV     (SP)+,R3        ;RESTORE R3
 2253  022566  005737  003032                        TST     ERRSWI          ;TEST IF ERROR RETURN
 2254  022572  001403                                BEQ     99$             ;YES - SKIP
 2255  022574  063716  003032                        ADD     ERRSWI,(SP)     ;ADD IN ERROR RETURN
 2256  022600  000207                                RTS     PC
 2257  022602  017616  000000              99$:      MOV     @(SP),(SP)      ;SET ERROR RETURN ADDRESS
 2258  022606  000207                                RTS     PC
 2259
 2261                                      ;         READ ALL HEADERS ROUTINE. 40 HEADERS ARE READ AND STORED
 2262                                      ;         IN IBUFF.
 2263  022610  010346                      RDALHD:   MOV     R3,-(SP)        ;STORE REGISTERS
 2264  022612  013703  003016                        MOV     SSINDX,R3       ;GET SUBROUTINE INDEX
 2265  022616  005723                                TST     (R3)+           ;BUMP IT FOR NEXT ENTRY
 2266  022620  016663  000002  002420                MOV     2(SP),SUBSTK(R3) ;INSERT THIS CALL
 2267  022626  162763  000004  002420                SUB     #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
 2268  022634  010337  003016                        MOV     R3,SSINDX       ;STORE IT BACK
 2269  022640  010046                                MOV     R0,-(SP)
 2270  022642  010146                                MOV     R1,-(SP)
 2271  022644  010446                                MOV     R4,-(SP)
 2272  022646  012737  000002  003032                MOV     #2,ERRSWI       ;SET FOR NO ERROR RETURN
 2273  022654  012701  000050                        MOV     #40.,R1         ;SET HEADER COUNT
 2274  022660  052737  100000  003020                BIS     #HDR40,OPFLAG   ;SET 40 HDR OP FLAG
 2275  022666  012703  004102                        MOV     #IBUFF,R3       ;SET POINTER TO STORE HDRS
 2276  022672  013704  003042                        MOV     RLBAS,R4        ;GET BASE ADDRESS
 2277  022676  062704  000006                        ADD     #RLMP,R4        ;MAKE IT POINT TO MP REG
 2278  022702  012737  000010  003050                MOV     #10,L.CS        ;LOAD FOR READ HEADER, NO INTERRUPT
 2279  022710  053737  003046  003050                BIS     RLDRV,L.CS      ;INSERT DRIVE NUMBER
 2280  022716  042737  002000  003050                BIC     #BIT10,L.CS     ;CLEAR FOR DRIVE 4 - 7 SPEC'D
 2281  022724  005037  003052                        CLR     L.BA            ;CLEAR BA
 2282  022730  005037  003054                        CLR     L.DA            ;CLEAR DA
 2283  022734  005737  003126                        TST     DESHD           ;TEST IF HEAD 0
 2284  022740  001403                                BEQ     3$              ;YES - SKIP
 2285  022742  052737  000020  003054                BIS     #HDSEL,L.DA     ;ELSE INSERT HEAD 0
 2286  022750  013762  003054  000004     3$:       MOV     L.DA,RLDA(R2)   ;LOAD RLDA REG
 2287  022756  013762  003052  000002               MOV     L.BA,RLBA(R2)   ;LOAD RLBA
 2288  022764  032762  000200  000000               BIT     #CRDYMSK,RLCS(R2)       ;TEST IF CONTROLLER READY
 2289  022772  001003                                BNE     6$              ;YES - SKIP
 2290  022774  004737  020276                        JSR     PC,RDYCHK       ;ELSE CHECK READY
 2291  023000  023116                                65$
 2292  023002  013762  003050  000000     6$:       MOV     L.CS,RLCS(R2)   ;LOAD RLCS REG
 2293  023010  012700  077777                        MOV     #77777,R0       ;SET COUNT FOR WAIT
 2294  023014  032762  000200  000000     7$:       BIT     #CRDYMSK,RLCS(R2) ;CHECK THAT OPERATION COMPLETED
 2295  023022  001016                                BNE     8$              ;YES - SKIP
 2296  023024  005300                                DEC     R0              ;DEC COUNT
 2297  023026  001372                                BNE     7$              ;SKIP IF NOT YET 0
 2298  023030  004737  016024                        JSR     PC,READRL       ;ELSE GET ALL REGISTERS
 2299  023034  004737  016056                        JSR     PC,WAITIN       ;ELSE WAIT FOR TIMEOUT
 2300  023040  012603                                MOV     (SP)+,R3        ;GET RESULT MESSAGE POINTER
 2301  023042                                        ERRHRD  10025.,,ERR1
  (4)  023042  104456                                TRAP    C$ERHRD
  (5)  023044  023451                                .WORD   10025
  (5)  023046  000000                                .WORD   0
```

```
  (5)  023050  011724                          .WORD   ERR1
 2302  023052  005037  003032                   CLR     ERRSWI          ;CLEAR FOR ERROR RETURN
 2303  023056  000417                           BR      65$
 2304  023060  005737  003060          8$:     TST     T.CS            ;TEST FOR ANY ERRORS
 2305  023064  100007                           BPL     12$             ;NO - SKIP
 2306  023066                                   ERRHRD  10026.,,ERR6
  (4)  023066  104456                           TRAP    C$ERHRD
  (5)  023070  023452                           .WORD   10026
  (5)  023072  000000                           .WORD   0
  (5)  023074  012226                           .WORD   ERR6
 2307  023076  005037  003032                   CLR     ERRSWI          ;CLEAR FOR ERROR RETURN
 2308  023102  000405                           BR      65$
 2309  023104  011423                  12$:     MOV     (R4),(R3)+      ;STORE HEADER WORDS
 2310  023106  011423                           MOV     (R4),(R3)+
 2311  023110  011423                           MOV     (R4),(R3)+
 2312  023112  005301                           DEC     R1              ;DEC HEADER COUNT
 2313  023114  001332                           BNE     6$
 2314  023116  162737  000002  003016  65$:     SUB     #2,SSINDX       ;REMOVE ENTRY FROM SUBROUT STACK
 2315  023124  012604                           MOV     (SP)+,R4        ;RESTORE REGISTERS
 2316  023126  012601                           MOV     (SP)+,R1
 2317  023130  012600                           MOV     (SP)+,R0
 2318  023132  012603                           MOV     (SP)+,R3
 2319  023134  005737  003032                   TST     ERRSWI          ;TEST IF ERROR RETURN
 2320  023140  001403                           BEQ     99$             ;YES - SKIP
 2321  023142  063716  003032                   ADD     ERRSWI,(SP)     ;ADD IN ERROR RETURN
 2322  023146  000207                           RTS     PC
 2323  023150  017616  000000          99$:     MOV     @(SP),(SP)      ;SET ERROR RETURN ADDRESS
 2324  023154  000207                           RTS     PC
 2325
 2326
 2328                                   ;       GENERATE DATA ROUTINE. PATTERN TO BE GENERATED IS GIVEN
 2329                                   ;       IN THE WORD FOLLOWING THE CALL. 128 WORDS ARE GENERATED
 2330                                   ;       IN OBUFF.
 2331  023156  010146                   DATGEN: MOV     R1,-(SP)        ;STORE REGISTERS
 2332  023160  010346                           MOV     R3,-(SP)
 2333  023162  010446                           MOV     R4,-(SP)
 2334  023164  012701  004502                   MOV     #OBUFF,R1       ;SET POINTER TO OBUFF
 2335  023170  012504                           MOV     (R5)+,R4        ;GET DATA PATTERN SELECTOR
 2336  023172  006304                           ASL     R4              ;ADJUST IT FOR INDEXING
 2337  023174  016403  002374                   MOV     PATTBL(R4),R3   ;GET ADDRESS OF PATTERN
 2338  023200  011321                           MOV     (R3),(R1)+      ;MOVE FIRST PATTERN WORD
 2339  023202  001421                           BEQ     5$              ;SKIP IF PATTERN IS 0
 2340  023204  021327  177777                   CMP     (R3),#-1        ;CHECK IF PATTERN IS ALL 1'S
 2341  023210  001416                           BEQ     5$              ;YES - SKIP
 2342  023212  020427  000010                   CMP     R4,#8.          ;TEST IF PATTERN 5
 2343  023216  001403                           BEQ     3$              ;YES - SKIP
 2344  023220  020427  000020                   CMP     R4,#16.         ;CHECK IF PATTERN 9 OR 10
 2345  023224  002413                           BLT     6$              ;NO - SKIP
 2346  023226  005723                   3$:     TST     (R3)+           ;BUMP SOURCE POINTER
 2347  023230  012321                           MOV     (R3)+,(R1)+     ;MOVE TWO MORE WORDS FORM SOURCE
 2348  023232  012321                           MOV     (R3)+,(R1)+
 2349  023234  012704  000015                   MOV     #13.,R4         ;SET COUNT
 2350  023240  012703  004502                   MOV     #OBUFF,R3       ;RESET POINTER
 2351  023244  000406                           BR      8$
 2352  023246  012703  004502          5$:     MOV     #OBUFF,R3       ;ELSE SET OBUFF AS PATTERN SOURCE
 2353  023252  000401                           BR      7$              ;GO TO FILL
```

```
023254  005723                  6$:     TST     (R3)+               ;BUMP SOURCE POINTER
023256  012704  000017          7$:     MOV     #15.,R4             ;SET MOVE COUNT
023262  012321                  8$:     MOV     (R3)+,(R1)+         ;MOVE 15 WORDS INTO BUFFER
023264  005304                          DEC     R4
023266  001375                          BNE     8$
023270  012703  004502                  MOV     #OBUFF,R3           ;SET SOURCE TO TOP OF OBUFF
023274  012704  000160                  MOV     #112.,R4            ;SET COUNT FOR REST OF BUFFER
023300  012321                  10$:    MOV     (R3)+,(R1)+         ;REPEAT PATTERN IN BUFFER
023302  005304                          DEC     R4
023304  001375                          BNE     10$
023306  012604                          MOV     (SP)+,R4            ;RESTORE REGISTERS
023310  012603                          MOV     (SP)+,R3
023312  012601                          MOV     (SP)+,R1
023314  000205                          RTS     R5                  ;RETURN

                                ;       DATA COMPARE ROUTINE. COMPARES THE CONTENTS OF IBUFF AND OBUFF.
                                ;       ERROR REPORTING IS LIMITED BY SOFTWARE PARAMETER.
023316  010346                  DATCOM: MOV     R3,-(SP)            ;STORE R3
023320  013703  003016                  MOV     SSINDX,R3           ;GET SUBROUTINE STACK INDEX
023324  005723                          TST     (R3)+               ;BUMP INDEX TO NEXT ENTRY
023326  016663  000002  002420          MOV     2(SP),SUBSTK(R3)    ;INSERT THIS CALL
023334  162763  000004  002420          SUB     #4,SUBSTK(R3)       ;ADJUST IT TO CALLING LOCATION
023342  010337  003016                  MOV     R3,SSINDX           ;STORE IT BACK
023346  010146                          MOV     R1,-(SP)            ;STORE OTHER REGISTERS
023350  010446                          MOV     R4,-(SP)
023352  010546                          MOV     R5,-(SP)
023354  052737  000001  003020          BIS     #DATACMP,OPFLAG     ;SET DATA COMPARE FLAG
023362  005037  003030                  CLR     MORECE              ;CLEAR MORE ERROR FLAG
023366  012705  004502                  MOV     #OBUFF,R5           ;SET POINTERS TO DATA FOR COMPARE
023372  012704  004102                  MOV     #IBUFF,R4
023376  012703  000001                  MOV     #1,R3               ;SET WORD COUNTER
023402  012701  000200                  MOV     #128.,R1            ;SET COMPARE COUNT
023406  022425                  5$:     CMP     (R4)+,(R5)+         ;COMPARE DATA
023410  001052                          BNE     10$                 ;ERROR - SKIP TO REPORT
023412  005203                  7$:     INC     R3                  ;BUMP WORD COUNT
023414  005301                          DEC     R1                  ;DEC COMPARE COUNT
023416  001373                          BNE     5$                  ;LOOP IF NOT 0
023420  042737  000001  003020  9$:     BIC     #DATACMP,OPFLAG     ;CLEAR DATA COMPARE FLAG
023426  005737  003032                  TST     ERRSWI              ;TEST IF ANY COMPARE ERRORS
023432  001021                          BNE     15$                 ;NO - SKIP
023434  012701  000200                  MOV     #128.,R1            ;SET REPORT VALUE
023440                                  PRINTB  #FMT27,#TCERR,MORECE,#RESE6,R1
(11) 023440  010146                     MOV     R1,-(SP)
(10) 023442  012746  010577             MOV     #RESE6,-(SP)
(9)  023446  013746  003030             MOV     MORECE,-(SP)
(8)  023452  012746  007624             MOV     #TCERR,-(SP)
(7)  023456  012746  011673             MOV     #FMT27,-(SP)
(6)  023462  012746  000005             MOV     #5,-(SP)
(3)  023466  010600                     MOV     SP,R0
(4)  023470  104414                     TRAP    C$PNTB
(4)  023472  062706  000014             ADD     #14,SP
023476  162737  000002  003016  15$:    SUB     #2,SSINDX           ;REMOVE ENTRY FROM SUBROUT STACK
023504  012605                          MOV     (SP)+,R5            ;RESTORE REGS
023506  012604                          MOV     (SP)+,R4
023510  012601                          MOV     (SP)+,R1
023512  012603                          MOV     (SP)+,R3
```

```
 2401  023514  005737  003032                  TST     ERRSWI          ;TEST IF ERROR RETURN
 2402  023520  001403                          BEQ     99$             ;YES - SKIP
 2403  023522  063716  003032                  ADD     ERRSWI,(SP)     ;ADD IN ERROR RETURN
 2404  023526  000207                          RTS     PC
 2405  023530  017616  000000          99$:    MOV     @(SP),(SP)      ;SET ERROR RETURN ADDRESS
 2406  023534  000207                          RTS     PC
 2407  023536  023737  003030  013570  10$:    CMP     MORECE,DCLIMW   ;TEST IF COMPARE ERRORS LIMIT EXCEEDED
 2408  023544  002011                          BGE     13$             ;YES - SKIP
 2409  023546  024445                          CMP     -(R4),-(R5)     ;SET PTRS BACK TO ERROR WORDS
 2410  023550                                  ERRHRD  10035.,,ERR10   ;REPORT ERROR
  (4)  023550  104456                          TRAP    C$ERHRD
  (5)  023552  023463                          .WORD   10035
  (5)  023554  000000                          .WORD   0
  (5)  023556  013320                          .WORD   ERR10
 2411  023560  005037  003032                  CLR     ERRSWI          ;CLEAR ERROR SWITCH
 2412  023564  022425                          CMP     (R4)+,(R5)+     ;BUMP PTRS PAST ERROR WORDS
 2413  023566  000711                          BR      7$              ;DO NEXT COMPARE
 2414  023570  005237  003030          13$:    INC     MORECE          ;BUMP ERROR COUNTER
 2415  023574  000706                          BR      7$              ;DO NEXT COMPARE
```

```
                                        ;       WRITE AND READ DATA ROUTINE.

023576  012737  177777  003134  XWRITT: MOV     #-1,TEMP1           ;SET SPECIAL WRITE FOR TIMING FLAG
023604  000402                          BR      XWRIT1
023606  005037  003134          XWRITE: CLR     TEMP1               ;CLEAR SPECIAL WRITE FLAG
023612  012737  000112  003150  XWRIT1: MOV     #WTDATA,TEMP7       ;SET FOR WRITE
023620  023737  002316  003120          CMP     HLMTW,CURCYL        ;TEST IF CYLINDER 255 (BAD SEC)
023626  001006                          BNE     1$                  ;NO - SKIP
023630  005737  003126                  TST     DESHD               ;TEST IF HEAD 1 (BAD SECTOR FILES)
023634  001403                          BEQ     1$                  ;NO - SKIP
023636  052737  004000  003020          BIS     #BADADD,OPFLAG      ;SET BAD ADDRESS FLAG
023644  000403                  1$:     BR      XREADG              ;SKIP TO EXECUTE
023646  012737  000114  003150  XREAD:  MOV     #RDDATA,TEMP7       ;SET FOR READ
023654  010346                  XREADG: MOV     R3,-(SP)            ;STORE R3
023656  013703  003016                  MOV     SSINDX,R3           ;SET SUBROUTINE INDEX
023662  005723                          TST     (R3)+               ;BUMP TO NEXT STACK ENTRY
023664  016663  000002  002420          MOV     2(SP),SUBSTK(R3)    ;INSERT THIS CALL
023672  162763  000004  002420          SUB     #4,SUBSTK(R3)       ;ADJUST TO POINT TO CALL
023700  010337  003016                  MOV     R3,SSINDX           ;STORE IT BACK
023704  010046                          MOV     R0,-(SP)
023706  010146                          MOV     R1,-(SP)            ;STORE OTHER REGISTERS
023710  010446                          MOV     R4,-(SP)
023712  004737  020276                  JSR     PC,RDYCHK           ;CHECK IF DRIVE READY
023716  024304                          65$
023720  012703  003050                  MOV     #L.CS,R3            ;GET ADDRESS OF LOAD REGS
023724  013713  003150                  MOV     TEMP7,(R3)          ;SET COMMAND
023730  053713  003046                  BIS     RLDRV,(R3)          ;INSERT DRIVE NUMBER
023734  042713  002000                  BIC     #BIT10,(R3)         ;CLEAR FOR DRIVE 4 - 7 SPEC'D
023740  032723  000004                  BIT     #BIT2,(R3)+         ;TEST IF WRITE DATA
023744  001403                          BEQ     3$                  ;YES - SKIP
023746  012723  004102                  MOV     #IBUFF,(R3)+        ;ELSE SET BA FOR READ
023752  000402                          BR      4$
023754  012723  004502          3$:     MOV     #OBUFF,(R3)+        ;SET BA FOR WRITE
023760  013713  003120          4$:     MOV     CURCYL,(R3)         ;GET CURRENT CYLINDER
023764  012704  000007                  MOV     #7,R4               ;ALIGN IT IN DA
023770  006313                  5$:     ASL     (R3)
023772  005304                          DEC     R4
023774  001375                          BNE     5$
023776  005737  003126                  TST     DESHD               ;TEST IF HEAD 0
024002  001402                          BEQ     7$                  ;YES - SKIP
024004  052713  000100                  BIS     #HSMSK,(R3)         ;SET FOR HEAD 1
024010  053723  003130          7$:     BIS     DESSEC,(R3)+        ;INSERT DESIRED SECTOR
024014  012713  177600                  MOV     #177600,(R3)        ;INSERT WORD COUNT
024020  005737  003134                  TST     TEMP1               ;CHECK IF SPECIAL WRITE FOR TIMING
024024  001402                          BEQ     8$                  ;NO - SKIP
024026  012713  177777                  MOV     #177777,(R3)        ;ELSE SET FOR 1 WORD TRANSFER
024032  032737  004000  003020  8$:     BIT     #BADADD,OPFLAG      ;TEST IF BAD ADDRESS FLAG SET
024040  001414                          BEQ     2$                  ;NO - SKIP
024042  042737  173777  003020          BIC     #^CBADADD,OPFLAG    ;CLEAR ALL BUT THIS FLAG
024050  012703  010501                  MOV     #MWRTAB,R3          ;SET RESULT MESSAGE POINTER
024054                                  ERRHRD  10032.,,ERR1
(4)  024054  104456                     TRAP    C$ERHRD
(5)  024056  023460                     .WORD   10032
(5)  024060  000000                     .WORD   0
(5)  024062  011724                     .WORD   ERR1
```

```
024064  005037  003020                  CLR     OPFLAG          ;CLEAR ALL FLAGS
024070  000503                          BR      64$
024072  005037  003022          2$:     CLR     DONE            ;CLEAR INTERRUPT FLAG
024076  005737  003134                  TST     TEMP1           ;CHECK IF SPECIAL WRITE FLAG SET
024102  001100                          BNE     65$             ;YES - DO NOT START WRITE
024104  011362  000006                  MOV     (R3),RLMP(R2)   ;LOAD RL REGS
024110  014362  000004                  MOV     -(R3),RLDA(R2)
024114  014362  000002                  MOV     -(R3),RLBA(R2)
024120  014362  000000                  MOV     -(R3),RLCS(R2)
024124                          10$:    WAITUS  #3000.          ;WAIT 300MS FOR INTERRUPT
024136  005737  003022                  TST     DONE            ;CHECK IF INTERRUPT
024142  001010                          BNE     14$             ;YES - SKIP
024144  004737  016056                  JSR     PC,WAITIN       ;WAIT FOR INTERRUPT
024150  012603                          MOV     (SP)+,R3        ;GET RESULT MESSAGE
024152                                  ERRHRD  10030.,,ERR1
(4)  024152  104456                     TRAP    C$ERHRD
(5)  024154  023456                     .WORD   10030
(5)  024156  000000                     .WORD   0
(5)  024160  011724                     .WORD   ERR1
024162  000446                          BR      64$
024164  032737  000001  003060  14$:    BIT     #DRDYMSK,T.CS   ;TEST IF DRIVE READY
024172  001033                          BNE     20$             ;YES - SKIP
024174  012703  007760                  MOV     #MDRDY,R3       ;SET RESULT MESSAGE
024200  012704  010662                  MOV     #CAFDT,R4       ;CONDITION AFTER DATA XFER
024204                                  ERRHRD  10032.,,ERR5
(4)  024204  104456                     TRAP    C$ERHRD
(5)  024206  023460                     .WORD   10032
(5)  024210  000000                     .WORD   0
(5)  024212  012156                     .WORD   ERR5
024214  012701  000062                  MOV     #50.,R1         ;SET WAIT COUNT FOR 5 SECDS
024220  004737  016262          17$:    JSR     PC,GSTAT        ;GET DRIVE STATUS
024224  024300                          64$
024226  032737  000001  003060          BIT     #DRDYMSK,T.CS   ;TEST IF DRIVE READY NOW
024234  001012                          BNE     20$             ;YES - SKIP
024236  005301                          DEC     R1              ;DEC WAIT COUNT
024240  001367                          BNE     17$             ;LOOP IF NOT TIME DONE
024242  012704  010673                  MOV     #C5SEC,R4       ;SET CONDITION 5 SECONDS
024246                                  ERRHRD  10033.,,ERR5
(4)  024246  104456                     TRAP    C$ERHRD
(5)  024250  023461                     .WORD   10033
(5)  024252  000000                     .WORD   0
(5)  024254  012156                     .WORD   ERR5
024256  005037  003032                  CLR     ERRSWI          ;CLEAR ERROR SWITCH
024262  005737  003060          20$:    TST     T.CS            ;CHECK IF ANY ERROR
024266  100006                          BPL     65$             ;NO - SKIP
024270                                  ERRHRD  10031.,,ERR6
(4)  024270  104456                     TRAP    C$ERHRD
(5)  024272  023457                     .WORD   10031
(5)  024274  000000                     .WORD   0
(5)  024276  012226                     .WORD   ERR6
024300  005037  003032          64$:    CLR     ERRSWI          ;CLEAR ERROR SWITCH
024304  162737  000002  003016  65$:    SUB     #2,SSINDX       ;REMOVE ENTRY FROM SUBROUT STACK
024312  012604                          MOV     (SP)+,R4        ;RESTORE REGISTERS
024314  012601                          MOV     (SP)+,R1
024316  012600                          MOV     (SP)+,R0
024320  012603                          MOV     (SP)+,R3
```

```
024322  005737  003032                    TST     ERRSWI          ;TEST IF ERROR RETURN
024326  001403                            BEQ     99$             ;YES - SKIP
024330  063716  003032                    ADD     ERRSWI,(SP)     ;ELSE ADD IN ERROR RETURN
024334  000207                            RTS     PC
024336  017616  000000          99$:      MOV     @(SP),(SP)      ;ADJUST FOR ERROR RETURN
024342  000207                            RTS     PC

                                ;         BAD SECTOR CHECK ROUTINE. CHECKS IF SECTOR SPECIFIED IN CURCYL,
                                ;         DESHD, AND DESSEC IS LISTED AS BAD IN THE BAD SECTOR FILES.
024344  010046                  BSCHK:    MOV     R0,-(SP)        ;STORE REGISTERS
024346  010146                            MOV     R1,-(SP)
024350  010346                            MOV     R3,-(SP)
024352  005037  003034                    CLR     BSFLAG          ;CLEAR FLAG
024356  012703  003706                    MOV     #FBSFIL,R3      ;GET POINTER TO FACTORY FILE
024362  022713  177777                    CMP     #-1,(R3)        ;CHECK IF ALL ONES
024366  001005                            BNE     4$              ;NO SKIP TO TEST
024370  012703  003512          2$:       MOV     #SBSFIL,R3      ;ELSE SET POINTER TO SOFTWARE FILE
024374  022713  177777                    CMP     #-1,(R3)        ;CHECK IF ALL ONES
024400  001431                            BEQ     20$             ;YES - EXIT
024402  013700  003116          4$:       MOV     NEWCYL,R0       ;BUILD HEADER OF ADDRESS IN QUESTION
024406  012701  000007                    MOV     #7,R1           ;POSITION CYLINDER
024412  006300                  5$:       ASL     R0
024414  005301                            DEC     R1
024416  001375                            BNE     5$
024420  005737  003126                    TST     DESHD           ;CHECK IF HEAD 0
024424  001402                            BEQ     7$              ;YES - SKIP
024426  052700  000100                    BIS     #BIT6,R0        ;INSERT HEAD 1
024432  053700  003130          7$:       BIS     DESSEC,R0       ;INSERT SECTOR
024436  022300                  8$:       CMP     (R3)+,R0        ;CHECK THIS WORD IN FILE
024440  001402                            BEQ     12$             ;YES - EXIT,ERROR
024442  101005                            BHI     15$             ;EXIT- NO ERROR
024444  000774                            BR      8$
024446  012737  000001  003034  12$:      MOV     #1,BSFLAG       ;SET ERROR FLAG
024454  000403                            BR      20$             ;GO TO EXIT
024456  020327  003706          15$:      CMP     R3,#FBSFIL      ;DONE BOTH FILES?
024462  003342                            BGT     2$              ;NO GO DO SOFTWARE FILE
024464  012603                  20$:      MOV     (SP)+,R3        ;ELSE RESTORE REGISTERS
024466  012601                            MOV     (SP)+,R1
024470  012600                            MOV     (SP)+,R0
024472  005737  003034                    TST     BSFLAG          ;CHECK IF ERROR
024476  001003                            BNE     99$             ;YES - SKIP
024500  062716  000002                    ADD     #2,(SP)         ;ELSE BUMP ERROR RETURN
024504  000207                            RTS     PC
024506  017616  000000          99$:      MOV     @(SP),(SP)      ;SET FOR ERROR RETURN
024512  000207                            RTS     PC

                                ;         REPORT OPERATION ROUTINE. PRINTS SUBROUTINE TRACE SEQUENCE AND
                                ;         OPERATION BEING PERFORMED PORTION OF ALL
                                ;         ERROR MESSAGES.
024514  010446                  RPTOP:    MOV     R4,-(SP)
024516  005737  003016                    TST     SSINDX          ;TEST SUBROUTINE INDEX 0
024522  001433                            BEQ     1$              ;SKIP IF 0
024524  012704  000002                    MOV     #2,R4           ;SET INDEXER TO FIRST ENTRY
024530                                    PRINTB  #FMT9,#SEQMES   ;PRINT ''SUBROUTINE CALL SEQ''
(8)  024530  012746  007514               MOV     #SEQMES,-(SP)
(7)  024534  012746  011212               MOV     #FMT9,-(SP)
```

```
 (6)  024540  012746  000002                 MOV     #2,-(SP)
 (3)  024544  010600                         MOV     SP,R0
 (4)  024546  104414                         TRAP    C$PNTB
 (4)  024550  062706  000006                 ADD     #6,SP
2564  024554                          3$:    PRINTB  #FMT16,SUBSTK(R4)        ;PRINT CALLING LOCATION
 (8)  024554  016446  002420                 MOV     SUBSTK(R4),-(SP)
 (7)  024560  012746  011365                 MOV     #FMT16,-(SP)
 (6)  024564  012746  000002                 MOV     #2,-(SP)
 (3)  024570  010600                         MOV     SP,R0
 (4)  024572  104414                         TRAP    C$PNTB
 (4)  024574  062706  000006                 ADD     #6,SP
2565  024600  062704  000002                 ADD     #2,R4            ;BUMP INDEX
2566  024604  020437  003016                 CMP     R4,SSINDX        ;CHECK IF ALL PRINTED
2567  024610  003761                         BLE     3$               ;LOOP IF NOT ALL PRINTED YET
2568  024612                          1$:    PRINTB  #FMT4,ERHEAD,#TSTLAB     ;PRINT ERROR HEADER
 (9)  024612  012746  006501                 MOV     #TSTLAB,-(SP)
 (8)  024616  013746  003026                 MOV     ERHEAD,-(SP)
 (7)  024622  012746  011015                 MOV     #FMT4,-(SP)
 (6)  024626  012746  000003                 MOV     #3,-(SP)
 (3)  024632  010600                         MOV     SP,R0
 (4)  024634  104414                         TRAP    C$PNTB
 (4)  024636  062706  000010                 ADD     #10,SP
2569  024642  042737  030000  003020         BIC     #SEEKOP!RORWOP,OPFLAG    ;CLEAR SK & RD OR WRT FLAG
2570  024650  013701  003050                 MOV     L.CS,R1          ;GET COMMAND EXECUTED
2571  024654  042701  177741                 BIC     #177741,R1       ;STRIP ALL BUT FUNCTION CODE
2572  024660  022701  000006                 CMP     #6,R1    ;TEST IF SEEK OPERATION
2573  024664  001003                         BNE     2$               ;NO - SKIP
2574  024666  052737  010000  003020         BIS     #SEEKOP,OPFLAG   ;ELSE SET SEEK FLAG
2575  024674  022701  000012          2$:    CMP     #12,R1           ;TEST IF WRITE
2576  024700  001003                         BNE     20$              ;NO - SKIP
2577  024702  052737  020000  003020         BIS     #RORWOP,OPFLAG   ;SET RD OR WRT FLAG
2578  024710  022701  000014          20$:   CMP     #14,R1           ;TEST IF READ
2579  024714  001003                         BNE     22$              ;NO - SKIP
2580  024716  052737  020000  003020         BIS     #RORWOP,OPFLAG   ;SET RD OR WRT FLAG
2581  024724                          22$:   PRINTB  #FMT1,#MOPER,OPMSGS(R1) ;PRINT OPERATION
 (9)  024724  016146  002240                 MOV     OPMSGS(R1),-(SP)
 (8)  024730  012746  005527                 MOV     #MOPER,-(SP)
 (7)  024734  012746  010773                 MOV     #FMT1,-(SP)
 (6)  024740  012746  000003                 MOV     #3,-(SP)
 (3)  024744  010600                         MOV     SP,R0
 (4)  024746  104414                         TRAP    C$PNTB
 (4)  024750  062706  000010                 ADD     #10,SP
2582  024754  020127  000004                 CMP     R1,#4            ;CHECK IF GET STATUS
2583  024760  001007                         BNE     4$               ;NO - SKIP
2584  024762  032737  000010  003054         BIT     #DRSET,L.DA      ;TEST IF RESET INCLUDED
2585  024770  001403                         BEQ     4$               ;NO - SKIP
2586  024772  012701  000016                 MOV     #16,R1           ;SET TO PRINT WITH RESET
2587  024776  000436                         BR      9$
2588  025000  032737  007777  003020  4$:    BIT     #COMPOP,OPFLAG   ;TEST IF ANY OTHER OPERATION
2589  025006  001424                         BEQ     8$               ;NO - SKIP
2590  025010  013704  003020                 MOV     OPFLAG,R4        ;SET UP TO DETERMINE WHICH ONE
2591  025014  012701  000020                 MOV     #20,R1           ;PRESET THE POINTER
2592  025020  032704  000001          5$:    BIT     #BIT00,R4        ;CHECK THE BIT
2593  025024  001003                         BNE     6$               ;IF SET - SKIP
2594  025026  005721                         TST     (R1)+            ;BUMP POINTER
2595  025030  006204                         ASR     R4
```

```
 025032  000772                          BR      5$
 025034                          6$:     PRINTB  #FMT2,OPMSGS(R1)
 025034  016146  002240                  MOV     OPMSGS(R1),-(SP)
 025040  012746  011007                  MOV     #FMT2,-(SP)
 025044  012746  000002                  MOV     #2,-(SP)
 025050  010600                          MOV     SP,R0
 025052  104414                          TRAP    C$PNTB
 025054  062706  000006                  ADD     #6,SP
 025060  032737  100000  003020  8$:     BIT     #HDR40,OPFLAG   ;TEST IF 40 HEADER OPERATION
 025066  001415                          BEQ     10$             ;NO - SKIP
 025070  012701  000050                  MOV     #50,R1          ;ELSE PRINT IT
 025074                          9$:     PRINTB  #FMT2,OPMSGS(R1)
 025074  016146  002240                  MOV     OPMSGS(R1),-(SP)
 025100  012746  011007                  MOV     #FMT2,-(SP)
 025104  012746  000002                  MOV     #2,-(SP)
 025110  010600                          MOV     SP,R0
 025112  104414                          TRAP    C$PNTB
 025114  062706  000006                  ADD     #6,SP
 025120  000434                          BR      15$             ;SKIP
 025122  032737  010000  003020  10$:    BIT     #SEEKOP,OPFLAG  ;TEST IF SEEK
 025130  001430                          BEQ     15$             ;NO - SKIP
 025132                                  PRINTB  #FMT13,#FRMWD,OLDCYL,#DIFWD,DESDIF,#SGNWD,DESSGN,#HDWD,DESHD
 025132  013746  003126                  MOV     DESHD,-(SP)
 025136  012746  007455                  MOV     #HDWD,-(SP)
 025142  013746  003124                  MOV     DESSGN,-(SP)
 025146  012746  007450                  MOV     #SGNWD,-(SP)
 025152  013746  003122                  MOV     DESDIF,-(SP)
 025156  012746  007442                  MOV     #DIFWD,-(SP)
 025162  013746  003114                  MOV     OLDCYL,-(SP)
 025166  012746  007473                  MOV     #FRMWD,-(SP)
 025172  012746  011233                  MOV     #FMT13,-(SP)
 025176  012746  000011                  MOV     #11,-(SP)
 025202  010600                          MOV     SP,R0
 025204  104414                          TRAP    C$PNTB
 025206  062706  000024                  ADD     #24,SP
 025212  032737  020000  003020  15$:    BIT     #RORWOP,OPFLAG  ;TEST IF READ OR WRITE SET
 025220  001424                          BEQ     17$             ;NO - SKIP
 025222                                  PRINTB  #FMT22,#CYLWD,CURCYL,#HDWD,DESHD,#SECWD,DESSEC
 025222  013746  003130                  MOV     DESSEC,-(SP)
 025226  012746  007461                  MOV     #SECWD,-(SP)
 025232  013746  003126                  MOV     DESHD,-(SP)
 025236  012746  007455                  MOV     #HDWD,-(SP)
 025242  013746  003120                  MOV     CURCYL,-(SP)
 025246  012746  007466                  MOV     #CYLWD,-(SP)
 025252  012746  011562                  MOV     #FMT22,-(SP)
 025256  012746  000007                  MOV     #7,-(SP)
 025262  010600                          MOV     SP,R0
 025264  104414                          TRAP    C$PNTB
 025266  062706  000020                  ADD     #20,SP
 025272  004737  025744          17$:    JSR     PC,CLRPARM      ;CLEAR PARAM TABLE
 025276  012604                          MOV     (SP)+,R4        ;RESTORE R4
 025300  000207                          RTS     PC

                                 ;       REPORT REASON ROUTINE
                                 ;       PRINTS REASON PORTION FOR ALL ERROR REPORTS.
 025302  010146                  RPTRES: MOV     R1,-(SP)        ;STORE R1
```

```
 2616  025304  010346                          MOV     R3,-(SP)          ;STORE R3
 2617  025306  010446                          MOV     R4,-(SP)          ;STORE R4
 2618  025310  012701  003076                  MOV     #RESPARM,R1       ;GET START OF PARAM
 2619  025314  012103                          MOV     (R1)+,R3          ;GET NUMBER OF PARAM
 2620  025316                                  PRINTB  #FMT1.1,#MRSLT,(R1)      ;PRINT NAME
  (9)  025316  011146                          MOV     (R1),-(SP)
  (8)  025320  012746  005536                  MOV     #MRSLT,-(SP)
  (7)  025324  012746  011000                  MOV     #FMT1.1,-(SP)
  (6)  025330  012746  000003                  MOV     #3,-(SP)
  (3)  025334  010600                          MOV     SP,R0
  (4)  025336  104414                          TRAP    C$PNTB
  (4)  025340  062706  000010                  ADD     #10,SP
 2621  025344  021127  010352                  CMP     (R1),#MNDRST      ;TEST IF MESSAGE IS NO DRV STATUS
 2622  025350  001453                          BEQ     6$                ;YES - SKIP REST OF REPORT
 2623  025352  012704  011217                  MOV     #FMT11,R4         ;PRISET FOR FORMAT 11
 2624  025356  022127  010345                  CMP     (R1)+,#MCYLOC     ;CHECK IF REPORTING CYLINDER LOC
 2625  025362  001002                          BNE     3$                ;NO - SKIP
 2626  025364  012704  011225                  MOV     #FMT12,R4         ;ELSE CHANGE TO FORMAT 12
 2627  025370  005303                    3$:   DEC     R3                ;DEC PARAM COUNT
 2628  025372  001442                          BEQ     6$                ;IF 0 - EXIT
 2629  025374                                  PRINTB  R4,#RESE3,(R1)+   ;REPORT IS VALUE
  (9)  025374  012146                          MOV     (R1)+,-(SP)
  (8)  025376  012746  010561                  MOV     #RESE3,-(SP)
  (7)  025402  010446                          MOV     R4,-(SP)
  (6)  025404  012746  000003                  MOV     #3,-(SP)
  (3)  025410  010600                          MOV     SP,R0
  (4)  025412  104414                          TRAP    C$PNTB
  (4)  025414  062706  000010                  ADD     #10,SP
 2630  025420                                  PRINTB  R4,#RESE4,(R1)+   ;REPORT SB VALUE
  (9)  025420  012146                          MOV     (R1)+,-(SP)
  (8)  025422  012746  010565                  MOV     #RESE4,-(SP)
  (7)  025426  010446                          MOV     R4,-(SP)
  (6)  025430  012746  000003                  MOV     #3,-(SP)
  (3)  025434  010600                          MOV     SP,R0
  (4)  025436  104414                          TRAP    C$PNTB
  (4)  025440  062706  000010                  ADD     #10,SP
 2631  025444  162703  000002                  SUB     #2,R3             ;DEC PARAM COUNT
 2632  025450  001413                          BEQ     6$                ;IF 0 - EXIT
 2633  025452                                  PRINTB  #FMT1,#RESE5,(R1)+   ;REPORT CONDITION
  (9)  025452  012146                          MOV     (R1)+,-(SP)
  (8)  025454  012746  010572                  MOV     #RESE5,-(SP)
  (7)  025460  012746  010773                  MOV     #FMT1,-(SP)
  (6)  025464  012746  000003                  MOV     #3,-(SP)
  (3)  025470  010600                          MOV     SP,R0
  (4)  025472  104414                          TRAP    C$PNTB
  (4)  025474  062706  000010                  ADD     #10,SP
 2634  025500  012604                    6$:   MOV     (SP)+,R4          ;RESTORE REGS
 2635  025502  012603                          MOV     (SP)+,R3
 2636  025504  012601                          MOV     (SP)+,R1
 2637  025506  000207                          RTS     PC                ;RETURN
 2638
 2639                                    ;     REPORT PHYSICAL ADDRESS OF DEVICE UNDER TEST
 2640                                    ;     AND ALL REGISTER CONTENTS.
 2641  025510                            RPTREM: PRINTB  #FMT5,#BASADD,RLBAS,#DRVNAM,<B,RLDRV+1>
 (11)  025510  005046                          CLR     -(SP)
 (11)  025512  153716  003047                  BISB    RLDRV+1,(SP)
```

```
  (10) 025516  012746  006152                MOV     #DRVNAM,-(SP)
  (9)  025522  013746  003042                MOV     RLBAS,-(SP)
  (8)  025526  012746  006141                MOV     #BASADD,-(SP)
  (7)  025532  012746  011026                MOV     #FMT5,-(SP)
  (6)  025536  012746  000005                MOV     #5,-(SP)
  (3)  025542  010600                        MOV     SP,R0
  (4)  025544  104414                        TRAP    C$PNTB
  (4)  025546  062706  000014                ADD     #14,SP
2642                                   ;     REPORT RL11 REGISTERS
2643   025552                                PRINTB  #FMT6,#CSNAM,#DANAM,#BANAM,#MPNAM,#CYLWD,#HDWD
  (13) 025552  012746  007455                MOV     #HDWD,-(SP)
  (12) 025556  012746  007466                MOV     #CYLWD,-(SP)
  (11) 025562  012746  006255                MOV     #MPNAM,-(SP)
  (10) 025566  012746  006243                MOV     #BANAM,-(SP)
  (9)  025572  012746  006250                MOV     #DANAM,-(SP)
  (8)  025576  012746  006236                MOV     #CSNAM,-(SP)
  (7)  025602  012746  011046                MOV     #FMT6,-(SP)
  (6)  025606  012746  000007                MOV     #7,-(SP)
  (3)  025612  010600                        MOV     SP,R0
  (4)  025614  104414                        TRAP    C$PNTB
  (4)  025616  062706  000020                ADD     #20,SP
2644   025622                                PRINTB  #FMT8,#LAB1,L.CS,L.DA,L.BA,L.MP
  (12) 025622  013746  003056                MOV     L.MP,-(SP)
  (11) 025626  013746  003052                MOV     L.BA,-(SP)
  (10) 025632  013746  003054                MOV     L.DA,-(SP)
  (9)  025636  013746  003050                MOV     L.CS,-(SP)
  (8)  025642  012746  006262                MOV     #LAB1,-(SP)
  (7)  025646  012746  011160                MOV     #FMT8,-(SP)
  (6)  025652  012746  000006                MOV     #6,-(SP)
  (3)  025656  010600                        MOV     SP,R0
  (4)  025660  104414                        TRAP    C$PNTB
  (4)  025662  062706  000016                ADD     #16,SP
2645   025666                                PRINTB  #FMT7,#LAB2,T.CS,T.DA,T.BA,T.MP,CURCYL,DESHD
  (14) 025666  013746  003126                MOV     DESHD,-(SP)
  (13) 025672  013746  003120                MOV     CURCYL,-(SP)
  (12) 025676  013746  003066                MOV     T.MP,-(SP)
  (11) 025702  013746  003062                MOV     T.BA,-(SP)
  (10) 025706  013746  003064                MOV     T.DA,-(SP)
  (9)  025712  013746  003060                MOV     T.CS,-(SP)
  (8)  025716  012746  006275                MOV     #LAB2,-(SP)
  (7)  025722  012746  011110                MOV     #FMT7,-(SP)
  (6)  025726  012746  000010                MOV     #10,-(SP)
  (3)  025732  010600                        MOV     SP,R0
  (4)  025734  104414                        TRAP    C$PNTB
  (4)  025736  062706  000022                ADD     #22,SP
2646   025742  000207                        RTS     PC
2647
2648                                   ;     CLEAR PARAMETER BLOCK FOR REPORTING
2649   025744  010546                  CLRPARM:        MOV     R5,-(SP)        ;STORE R5
2650   025746  012701  003076                MOV     #RESPARM,R1     ;GET ADDRESS OF BLOCK
2651   025752  012705  000005                MOV     #5,R5           ;SET COUNT
2652   025756  005021                  2$:   CLR     (R1)+           ;CLEAR WORD
2653   025760  005305                        DEC     R5              ;DEC COUNT
2654   025762  001375                        BNE     2$              ;LOOP UNTIL 0
2655   025764  012701  003076                MOV     #RESPARM,R1     ;RESET POINTER
2656   025770  012605                        MOV     (SP)+,R5        ;RESTORE R5
```

```
 2657  025772  000207                    RTS     PC
 2658
 2659  025774                    ENDMOD
```

```
                                        .TITLE  CZRLJB0 RL01/02 DRIVE TEST 2

                                        .SBTTL  *TEST 1         **OUTER GUARD BAND DETECTION

025774                                  BGNMOD  HRDWTST
025774                                  BGNTST                  ;TEST 1
(3) 025774                                                                                      T1::

025774  012737  006507  003026                  MOV     #P2T03E,ERHEAD  ;SET ERROR HEADER
026002  004737  016214                          JSR     PC,TSTINT       ;INITIALIZE TEST
026006  004737  016232                          JSR     PC,GSTATR       ;CLEAR DRIVE
026012  026214                                  T1965$
026014  004737  020552                          JSR     PC,CHOSHD       ;GO CHOSE HEAD
026020  005005                          T197$:  CLR     R5              ;CLEAR FOR POSITION TO 0
026022  004737  017732                          JSR     PC,POSHDS       ;POSITION HEADS
026026  026214                                  T1965$
026030                                  BGNSUB
(3) 026030                                                                                      T1.1:
(3) 026030  104402                              TRAP    C$BSUB
026032  012737  177777  003116                  MOV     #-1,NEWCYL      ;SET FOR GUARD BAND SEEK
026040  004737  017160                          JSR     PC,XSEEK        ;DO SEEK
026044  026170                                  60$
026046  012701  000002                          MOV     #2,R1           ;INITIALIZE WAIT COUNT
026052  032762  000001  000000          8$:     BIT     #DRDYMSK,RLCS(R2) ;TEST IF DRIVE READY
026060  001414                                  BEQ     9$              ;NO-SKIP
026062  004737  016262                          JSR     PC,GSTAT        ;GET DRIVE STATUS
026066  026170                                  60$
026070  012703  007760                          MOV     #MDRDY,R3       ;SET NAME MESSAGE PTR
026074  012704  010634                          MOV     #C10MS,R4       ;SET CONDITION MESSAGE PTR
026100                                          ERRHRD  301.,,ERR4      ;REPORT READY ERROR
(4) 026100  104456                              TRAP    C$ERHRD
(5) 026102  000455                              .WORD   301
(5) 026104  000000                              .WORD   0
(5) 026106  012106                              .WORD   ERR4
026110  000427                                  BR      60$             ;EXIT TEST
026112  005301                          9$:     DEC     R1              ;DEC WAIT COUNT
026114  001406                                  BEQ     12$             ;SKIP IF 0
026116                                          WAITUS  #10.            ;WAIT 1MS
026130  000750                                  BR      8$              ;LOOP
026132  012701  000226                  12$:    MOV     #150.,R1        ;SET WAIT COUNT FOR 15 MS
026136  004737  022054                          JSR     PC,RDYWAIT      ;WAIT FOR READY & REPORT IF NOT READY
026142  026170                                  60$

026144  004737  022340                          JSR     PC,GETPOS       ;GET POSITION
026150  026170                                  60$
026152  005737  003120                          TST     CURCYL          ;CHECK IF HEADS STILL AT 0
026156  001404                                  BEQ     15$             ;YES-SKIP
026160                                          ERRHRD  302.,,ERR8      ;ELSE REPORT CYLINDER ERROR
(4) 026160  104456                              TRAP    C$ERHRD
(5) 026162  000456                              .WORD   302
(5) 026164  000000                              .WORD   0
(5) 026166  013160                              .WORD   ERR8
026170                                  15$:
026170  012737  000002  003032          60$:    MOV     #2,ERRSWI       ;INIT ERROR SWITCH
026176                                  ENDSUB
```

```
  (3)  026176                          L10024:
  (3)  026176  104403                          TRAP    C$ESUB
 2706  026200                                  ESCAPE  TST             ;EXIT TEST IF ERROR
  (3)  026200  104410                          TRAP    C$ESCAPE
  (3)  026202  000012                          .WORD   L10023-.
 2707  026204  004737  020576                  JSR     PC,SWAPHD       ;GO SWAP TO HEAD 1 OR END TEST
 2708  026210  026214                          17$                     ;ABORT RETURN
 2709  026212  000702                          BR      T197$           ;REDO TEST
 2710  026214                          17$:
 2711  026214                          T1965$:
 2712
 2713  026214                          ENDTST
  (3)  026214                          L10023:
  (3)  026214  104401                          TRAP    C$ETST
 2714
```

```
                                        .SBTTL  *TEST 2         **INCREMENTAL FORWARD SEEK HEAD 0
026216                                  BGNTST                  ;TEST 2
(3) 026216                                                                                      T2::
026216  012737  006525  003026                  MOV     #P2T04E,ERHEAD  ;SET ERROR HEADER
026224  004737  016214                          JSR     PC,TSTINT       ;INITIALIZE TEST
026230  004737  016232                          JSR     PC,GSTATR       ;CLEAR DRIVE
026234  026424                                  T2065$
026236  004737  020552                          JSR     PC,CHOSHD       ;GO CHOSE HEAD
026242  005737  003126                          TST     DESHD           ;TEST IF THIS IS HEAD 0
026246  001402                                  BEQ     2$              ;YES - SKIP
026250                                          EXIT    TST             ;ELSE EXIT TEST
(3) 026250  104432                              TRAP    C$EXIT
(3) 026252  000152                              .WORD   L10025-.
026254  013705  013560                  2$:     MOV     LOLIMW,R5       ;CLEAR TO POSITION HEADS TO LOLIMIT
026260  004737  017732                          JSR     PC,POSHDS       ;POSITION HEADS
026264  026424                                  T2065$
026266                                  BGNSUB
(3) 026266                                                                                      T2.1:
(3) 026266  104402                              TRAP    C$BSUB
026270  004737  022340                  T206$:  JSR     PC,GETPOS       ;GET POSITION
026274  026414                                  60$
026276                                          INLOOP                  ;CHECK IF IN ERROR LOOP
(3) 026276  104420                              TRAP    C$INLP
026300                                          BNCOMPLETE      5$      ;NO - SKIP
(2) 026300  103007                              BCC     5$
026302  023737  003120  003116                  CMP     CURCYL,NEWCYL   ;CHECK IF POSITIONED AT DESIRED LOC
026310  001003                                  BNE     5$              ;NO - SKIP
026312  004737  020636                          JSR     PC,ONSWAP       ;ELSE SWAP NEW AND OLD CYLINDERS
026316  000405                                  BR      7$              ;SKIP
026320  013737  003120  003116          5$:     MOV     CURCYL,NEWCYL   ;PLACE CURRENT INTO NEW
026326  005237  003116                          INC     NEWCYL          ;BUMP FOR ONE CYLINDER SEEK
026332                                  7$:
026332  004737  017160                          JSR     PC,XSEEK        ;DO SEEK
026336  026414                                  60$
026340  012701  000226                          MOV     #150.,R1        ;SET WAIT TIME 15 MS
026344  004737  022054                          JSR     PC,RDYWAIT      ;WAIT FOR READY
026350  026414                                  60$

026352  004737  022466                          JSR     PC,VERPOS       ;GO VERIFY POSITON
026356  026414                                  60$

026360  032737  000002  013556                  BIT     #ALLSEC,MISWIW  ;TEST IF CHECK ALL SECTORS
026366  001406                                  BEQ     11$             ;NO-SKIP
026370  004737  022610                          JSR     PC,RDALHD       ;GO READ ALL HEADERS
026374  026414                                  60$
026376  004737  021460                          JSR     PC,VERHDR       ;GO VERIFY HEADER
026402  026414                                  60$
026404                                  11$:
026404  023737  013562  003116                  CMP     HILIMW,NEWCYL   ;CHECK IF HILIMIT REACHED
026412  103726                                  BLO     T206$           ;NO-LOOP
026414  012737  000002  003032          60$:    MOV     #2,ERRSWI       ;INIT ERROR SWITCH
026422                                  ENDSUB
(3) 026422                              L10026:
(3) 026422  104403                              TRAP    C$ESUB
026424                                  T2065$:
```

```
 2763  026424                    ENDTST
  (3)  026424                    L10025:
  (3)  026424  104401                    TRAP    C$ETST
```

```
                                        .SBTTL  *TEST 3         **INCREMENTAL REVERSE SEEK HEAD 0
026426                                  BGNTST                  ;TEST 3
(3) 026426                                                                                      T3::
026426  012737  006545  003026                  MOV     #P2T05E,ERHEAD  ;SET ERROR HEADER
026434  004737  016214                          JSR     PC,TSTINT       ;INITIALIZE TEST
026440  004737  016232                          JSR     PC,GSTATR       ;CLEAR DRIVE
026444  026634                                  T2165$
026446  004737  020552                          JSR     PC,CHOSHD       ;GO CHOSE HEAD
026452  005737  003126                          TST     DESHD           ;TEST IF HEAD 0 SELECTED
026456  001402                                  BEQ     2$              ;YES - SKIP
026460                                          EXIT    TST             ;ELSE EXIT TEST
(3) 026460  104432                              TRAP    C$EXIT
(3) 026462  000152                              .WORD   L10027-.
026464  013705  013562                  2$:     MOV     HILIMW,R5       ;SET TO POSITION HDS TO HILIMIT
026470  004737  017732                          JSR     PC,POSHDS       ;POSITION HEADS
026474  026634                                  T2165$
026476                                  BGNSUB
(3) 026476                                                                                      T3.1:
(3) 026476  104402                              TRAP    C$BSUB
026500  004737  022340                  T216$:  JSR     PC,GETPOS       ;GET POSITION
026504  026624                                  60$
026506                                          INLOOP                  ;CHECK IF IN ERROR LOOP
(3) 026506  104420                              TRAP    C$INLP
026510                                          BNCOMPLETE      5$      ;NO - SKIP
(2) 026510  103007                              BCC     5$
026512  023737  003120  003116                  CMP     CURCYL,NEWCYL   ;CHECK IF POSITIONED AT DES LOC
026520  001003                                  BNE     5$              ;NO - SKIP
026522  004737  020636                          JSR     PC,ONSWAP       ;ELSE SWAP OLD AND NEW CYLINDERS
026526  000405                                  BR      7$              ;SKIP
026530  013737  003120  003116          5$:     MOV     CURCYL,NEWCYL   ;PUT CURRENT INTO NEW
026536  005337  003116                          DEC     NEWCYL          ;DEC FOR ONE CYLINDER REVERSE SEEK
026542  004737  017160                  7$:     JSR     PC,XSEEK        ;SEEK TO IT
026546  026624                                  60$
026550  012701  000226                          MOV     #150.,R1        ;SET WAIT FOR 15 MS
026554  004737  022054                          JSR     PC,RDYWAIT      ;WAIT FOR READY
026560  026624                                  60$

026562  004737  022466                          JSR     PC,VERPOS       ;VERIFY POSITION
026566  026624                                  60$

026570  032737  000002  003020                  BIT     #ALLSEC,OPFLAG  ;TEST IF USE ALL SECTORS
026576  001406                                  BEQ     11$             ;NO-SKIP
026600  004737  022610                          JSR     PC,RDALHD       ;ELSE READ ALL THE HDRS
026604  026624                                  60$
026606  004737  021460                          JSR     PC,VERHDR       ;VERIFY THE HEADERS
026612  026624                                  60$
026614                                  11$:
026614  023737  013560  003116                  CMP     LOLIMW,NEWCYL   ;CHECK IF REACHED LOLIMIT
026622  103726                                  BLO     T216$           ;NO - LOOP
026624  012737  000002  003032          60$:    MOV     #2,ERRSWI       ;INIT ERROR SWITCH
026632                                  ENDSUB
(3) 026632                              L10030:
(3) 026632  104403                              TRAP    C$ESUB
026634                                  T2165$:
026634                                  ENDTST
(3) 026634                              L10027:
```

```
(3)  026634  104401                    TRAP    C$ETST
```

```
                                        .SBTTL  *TEST 4         **INCREMENTAL FORWARD SEEK HEAD 1
026636                                  BGNTST                  ;TEST 4
026636                                                                                          T4::
026636  012737  006565  003026                  MOV     #P2T06E,ERHEAD  ;SET ERROR HEADER
026644  004737  016214                          JSR     PC,TSTINT       ;INITIALIZE TEST
026650  004737  016232                          JSR     PC,GSTATR       ;CLEAR DRIVE
026654  027060                                  T2265$
026656  005037  003126                          CLR     DESHD           ;SET HEAD TO 0
026662  013705  013560                          MOV     LOLIMW,R5       ;CLEAR FOR POSITION HDS TO LOLIMIT
026666  004737  017732                          JSR     PC,POSHDS       ;POSITION HDS
026672  027060                                  T2265$
026674  012737  000001  003126                  MOV     #1,DESHD        ;SET TO HEAD 1
026702  032737  010000  013556                  BIT     #HEADLM,MISWIW  ;TEST IF HEAD SPECIFIED
026710  001405                                  BEQ     2$              ;NO - SKIP
026712  005737  013564                          TST     HEADW           ;TEST IF IT IS HEAD 0
026716  001002                                  BNE     2$              ;NO - SKIP
026720                                          EXIT    TST             ;ELSE EXIT TEST
026720  104432                                  TRAP    C$EXIT
026722  000136                                  .WORD   L10031-.
026724                                  2$:
026724                                  BGNSUB
026724                                                                                          T4.1:
026724  104402                                  TRAP    C$BSUB
026726  004737  022340                  T227$:  JSR     PC,GETPOS       ;GET CURRENT POSITION
026732                                          INLOOP                  ;CHECK IF IN ERROR LOOP
026732  104420                                  TRAP    C$INLP
026734                                          BNCOMPLETE 5$           ;NO - SKIP
026734  103007                                  BCC     5$
026736  023737  003120  003116                  CMP     CURCYL,NEWCYL   ;CHECK IF AT DESIRED LOCATION
026744  001003                                  BNE     5$              ;NO - SKIP
026746  004737  020636                          JSR     PC,ONSWAP       ;SWAP OLD AND NEW CYLINDER
026752  000405                                  BR      7$              ;SKIP
026754  013737  003120  003116          5$:     MOV     CURCYL,NEWCYL   ;MOVE CURRENT INTO NEW
026762  005237  003116                          INC     NEWCYL          ;BUMP NEWCYL FOR ONE CYL FWRD SEEK
026766                                  7$:
026766  004737  017160                          JSR     PC,XSEEK        ;DO SEEK
026772  027050                                  60$
026774  012701  000226                          MOV     #150.,R1        ;SET WAIT COUNT 15 MS
027000  004737  022054                          JSR     PC,RDYWAIT      ;WAIT FOR READY
027004  027050                                  60$
027006  004737  022466                          JSR     PC,VERPOS       ;VERIFY POSITION IS CORRECT
027012  027050                                  60$
027014  032737  000002  013556                  BIT     #ALLSEC,MISWIW  ;CHECK IF USE ALL SECTORS
027022  001406                                  BEQ     9$              ;NO-SKIP
027024  004737  022610                          JSR     PC,RDALHD       ;ELSE READ ALL HEADERS
027030  027050                                  60$
027032  004737  021460                          JSR     PC,VERHDR       ;VERIFY HEADERS
027036  027050                                  60$
027040                                  9$:
027040  023737  013562  003116                  CMP     HILIMW,NEWCYL   ;CHECK IF DONE
027046  101327                                  BHI     T227$           ;NO - LOOP
027050  012737  000002  003032          60$:    MOV     #2,ERRSWI       ;INIT ERROR SWITCH
027056                                  ENDSUB
027056                                  L10032:
027056  104403                                  TRAP    C$ESUB
```

```
 2859  027060                          T2265$:
 2860  027060                          ENDTST
  (3)  027060                          L10031:
  (3)  027060  104401                          TRAP    C$ETST
 2861
```

```
                                        .SBTTL  *TEST 5         **INNER GUARD BAND DETECTION

027062                                  BGNTST                  ;TEST 5
 (3)  027062                                                                                    T5::

027062  012737  006605  003026                  MOV     #P2T07E,ERHEAD  ;SET ERROR HEADER
027070  004737  016214                          JSR     PC,TSTINT       ;INITIALIZE TEST
027074  004737  016232                          JSR     PC,GSTATR       ;CLEAR DRIVE
027100  027266                                  T2365$
027102  004737  020552                          JSR     PC,CHOSHD       ;GO CHOSE HEAD
027106  013705  002316                  T233$:  MOV     HLMTW,R5        ;SET FOR POSITION TO 255.
027112  004737  017732                          JSR     PC,POSHDS       ;POSITION HEADS
027116  027266                                  T2365$
027120                                  BGNSUB
 (3)  027120                                                                                    T5.1:
 (3)  027120  104402                            TRAP    C$BSUB
027122  013737  002324  003116                  MOV     GBND,NEWCYL     ;SET FOR INNER GUARD BAND SEEK
027130  004737  017160                          JSR     PC,XSEEK        ;DO IT
027134  027242                                  60$
027136  012701  000001                          MOV     #1.,R1          ;INITIALIZE WAIT COUNT
027142  032762  000001  000000          7$:     BIT     #DRDYMSK,RLCS(R2) ;CHECK IF READY
027150  001414                                  BEQ     9$              ;NO-SKIP
027152  004737  016262                          JSR     PC,GSTAT        ;GET DRIVE STATUS
027156  027242                                  60$
027160  012703  007760                          MOV     #MDRDY,R3       ;SET NAME MESSAGE PTR
027164  012704  010634                          MOV     #C10MS,R4       ;SET CONDITION MESSAGE PTR
027170                                          ERRHRD  701...,ERR4     ;REPORT READY ERROR
 (4)  027170  104456                            TRAP    C$ERHRD
 (5)  027172  001275                            .WORD   701
 (5)  027174  000000                            .WORD   0
 (5)  027176  012106                            .WORD   ERR4
027200  000420                                  BR      60$             ;EXIT TEST
027202  005301                          9$:     DEC     R1              ;DEC WAIT COUNT
027204  001406                                  BEQ     11$             ;SKIP IF 0
027206                                          WAITUS  #10.            ;WAIT 1MS
027220  000750                                  BR      7$              ;LOOP
027222  012701  000226                  11$:    MOV     #150.,R1        ;SET WAIT COUNT 15 MS
027226  004737  022054                          JSR     PC,RDYWAIT      ;GO WAIT FOR READY
027232  027242                                  60$

027234  004737  022466                          JSR     PC,VERPOS       ;GO VERIFY POSITION IS 255
027240  027242                                  60$
027242  012737  000002  003032          60$:    MOV     #2,ERRSWI       ;INIT ERROR SWITCH
027250                                  ENDSUB
 (3)  027250                            L10034:
 (3)  027250  104403                            TRAP    C$ESUB
027252                                          ESCAPE  TST             ;EXIT TEST IF ERROR
 (3)  027252  104410                            TRAP    C$ESCAPE
 (3)  027254  000012                            .WORD   L10033-.
027256  004737  020576                          JSR     PC,SWAPHD       ;GO SWAP TO HEAD 1 OR END TEST
027262  027266                                  15$                     ;ABORT RETURN
027264  000710                                  BR      T233$           ;REPEAT THE TESTS
027266                                  15$:
027266                                  T2365$:
```

```
 2908  027266                          ENDTST
  (3)  027266                          L10033:
  (3)  027266  104401                          TRAP    C$ETST
 2909
```

```
                                        .SBTTL  *TEST 6         **INCREMENTAL REVERSE SEEK HEAD 1
 027270                                 BGNTST                  ;TEST 6
 027270                                                                                         T6::
 027270  012737  006623  003026                 MOV     #P2T08E,ERHEAD  ;SET ERROR HEADER
 027276  004737  016214                         JSR     PC,TSTINT       ;INITIALIZE TEST
 027302  004737  016232                         JSR     PC,GSTATR       ;GET STATUS & CLEAR
 027306  027514                                 T2465$
 027310  005037  003126                         CLR     DESHD           ;SET TO HEAD 0
 027314  013705  013562                         MOV     HILIMW,R5       ;SET TO POSITION HDS AT HILIMIT
 027320  004737  017732                         JSR     PC,POSHDS       ;POSITION HDS
 027324  027514                                 T2465$
 027326  012737  000001  003126                 MOV     #1,DESHD        ;SET TO SELECT HD 1
 027334  032737  010000  013556                 BIT     #HEADLM,MISWIW  ;TEST IF HEAD SPECIFIED
 027342  001405                                 BEQ     2$              ;NO - SKIP
 027344  005737  013564                         TST     HEADW           ;TEST IF HEAD SPECIFIED IS 0
 027350  001002                                 BNE     2$              ;NO - SKIP
 027352                                         EXIT    TST             ;ESLE EXIT TEST
 027352  104432                                 TRAP    C$EXIT
 027354  000140                                 .WORD   L10035-.
 027356                                 2$:
 027356                                 BGNSUB
 027356                                                                                         T6.1:
 027356  104402                                 TRAP    C$BSUB
 027360  004737  022340                 T247$:  JSR     PC,GETPOS       ;GET CURRENT POSITION
 027364  027504                                 60$
 027366                                         INLOOP                  ;CHECK IF IN ERROR LOOP
 027366  104420                                 TRAP    C$INLP
 027370                                         BNCOMPLETE      5$      ;NO - SKIP
 027370  103007                                 BCC     5$
 027372  023737  003120  003116                 CMP     CURCYL,NEWCYL   ;CHECK IF POSITIONED AT DESIRED LOC
 027400  001003                                 BNE     5$              ;NO - SKIP
 027402  004737  020636                         JSR     PC,ONSWAP       ;ELSE SWAP OLD AND NEW CYLINDER
 027406  000405                                 BR      7$              ;SKIP
 027410  013737  003120  003116         5$:     MOV     CURCYL,NEWCYL   ;MOV CUR TO NEW
 027416  005337  003116                         DEC     NEWCYL          ;DEC NEWCYL FOR 1 CYL REV SEEK
 027422  004737  017160                 7$:     JSR     PC,XSEEK        ;DO SEEK
 027426  027504                                 60$
 027430  012701  000226                         MOV     #150.,R1                ;SET WAIT FOR 15 MS
 027434  004737  022054                         JSR     PC,RDYWAIT      ;WAIT FOR READY
 027440  027504                                 60$
 027442  004737  022466                         JSR     PC,VERPOS       ;VERIFY POSITION
 027446  027504                                 60$
 027450  032737  000002  013556                 BIT     #ALLSEC,MISWIW  ;TEST IF ALL SECTORS
 027456  001406                                 BEQ     9$              ;NO-EXIT
 027460  004737  022610                         JSR     PC,RDALHD       ;READ ALL HEADERS
 027464  027504                                 60$
 027466  004737  021460                         JSR     PC,VERHDR       ;VERIFY HEADER
 027472  027504                                 60$
 027474                                 9$:
 027474  023737  013560  003116                 CMP     LOLIMW,NEWCYL   ;CHECK IF AT LOLIMIT
 027502  103726                                 BLO     T247$           ;NO - LOOP
 027504  012737  000002  003032         60$:    MOV     #2,ERRSWI       ;INIT ERROR SWITCH
 027512                                 ENDSUB
 027512                                 L10036:
 027512  104403                                 TRAP    C$ESUB
```

```
 2958  027514                          T2465$:
 2959  027514                          ENDTST
  (3)  027514                          L10035:
  (3)  027514  104401                          TRAP    C$ETST
```

```
                                        .SBTTL  *TEST 7         **SEEK TESTS
027516                                  BGNTST          ;TEST 7
(3) 027516                                                                              T7::
027516  012737  006643  003026                  MOV     #P2T09E,ERHEAD  ;SET ERROR HEADER
027524  004737  016214                          JSR     PC,TSTINT       ;INITIALIZE TEST
027530  004737  016232                          JSR     PC,GSTATR       ;CLEAR DRIVE
027534  030024                                  T2565$
027536  004737  020552                          JSR     PC,CHOSHD       ;GO CHOSE HEAD
027542  013705  013560                          MOV     LOLIMW,R5       ;SET TO POSTION HEADS TO LOLIMIT
027546  004737  017732                          JSR     PC,POSHDS       ;POSITION HDS TO LOWLIMIT
027552  030024                                  T2565$
027554  004737  022340                  T256$:  JSR     PC,GETPOS       ;GET CURRENT POSITION
027560  030024                                  T2565$
027562  013737  003120  003116                  MOV     CURCYL,NEWCYL   ;PUT CURRENT INTO NEW
027570  012704  002444                          MOV     #T25TBL,R4      ;SET POINTER TO TABLE OF SEEK DIFF FOR RL01
027574  022737  000001  002312  T258$:  CMP     #1,T.DRIVE      ;CHECK TYPE OF DRIVE
027602  001402                                  BEQ     T2588$          ;BRANCH IF RL01
027604  012704  002472                          MOV     #T25TB2,R4      ;POINT TO THE RL02 TABLE OF CYLINDERS

027610  012405                  T2588$: MOV     (R4)+,R5        ;PUT FIRST IN R5
027612  013701  013562                          MOV     HILIMW,R1       ;GET HILIMIT
027616  163701  013560                          SUB     LOLIMW,R1       ;SUBTRACT LOLIMIT
027622  021401                                  CMP     (R4),R1         ;CHECK IF NEW DIFFERENCE IS IN BOUNDS
027624  101073                                  BHI     T2517$$         ;NO - SKIP TEST
027626  060537  003116                  T257$:  ADD     R5,NEWCYL       ;ADD TO PRESENT POSITION
027632  023737  003116  013560                  CMP     NEWCYL,LOLIMW   ;CHECK IF AT OR PAST LOLIMIT
027640  002004                                  BGE     9$              ;NO - SKIP
027642  013737  013560  003116                  MOV     LOLIMW,NEWCYL   ;ELSE SET TO LOLIMIT
027650  000407                                  BR      11$
027652  023737  003116  013562  9$:     CMP     NEWCYL,HILIMW   ;CHECK IF AT HILIMIT OR GREATER
027660  003403                                  BLE     11$             ;NO - SKIP
027662  013737  013562  003116                  MOV     HILIMW,NEWCYL   ;ELSE SET FOR HILIMIT
027670                                  11$:
027670                                  BGNSUB
(3) 027670                                                                              T7.1:
(3) 027670  104402                              TRAP    C$BSUB
027672                                          INLOOP                  ;CHECK IF IN ERROR LOOP
(3) 027672  104420                              TRAP    C$INLP
027674                                          BNCOMPLETE      13$     ;NO - SKIP
(2) 027674  103011                              BCC     13$
027676  004737  022340                          JSR     PC,GETPOS       ;GET CURRENT POSITION
027702  027746                                  60$
027704  023737  003120  003116                  CMP     CURCYL,NEWCYL   ;CHECK IF HEADS AT DESIRED POSITION
027712  001002                                  BNE     13$             ;NO - SKIP
027714  004737  020636                          JSR     PC,ONSWAP       ;ELSE SWAP CURRENT AND NEW CYLINDERS
027720  004737  017160                  13$:    JSR     PC,XSEEK        ;DO SEEK
027724  027746                                  60$
027726  012701  005670                          MOV     #3000.,R1       ;SET WAIT COUNT
027732  004737  022054                          JSR     PC,RDYWAIT      ;WAIT FOR READY
027736  027746                                  60$
027740  004737  022466                          JSR     PC,VERPOS       ;VERIFY POSITION
027744  027746                                  60$
027746  012737  000002  003032  60$:    MOV     #2,ERRSWI       ;INITIALIZE ERROR SWITCH
027754                                  ENDSUB
(3) 027754                              L10040:
(3) 027754  104403                              TRAP    C$ESUB
```

```
 3010  027756                                  ESCAPE  TST              ;EXIT TEST IF ERROR
  (3)  027756  104410                          TRAP    C$ESCAPE
  (3)  027760  000044                          .WORD   L10037-.
 3011  027762  023737  013562  003116          CMP     HILIMW,NEWCYL    ;CHECK IF SEEK WAS TO HILIMIT
 3012  027770  001002                          BNE     15$              ;NO - SKIP
 3013  027772  005405                          NEG     R5               ;ELSE SET R5 TO REPEAT DIFF IN REVERSE
 3014  027774  000714                          BR      T257$
 3015  027776  023737  013560  003116  15$:    CMP     LOLIMW,NEWCYL    ;TEST IF LAST SEEK WAS TO LOLIMIT
 3016  030004  001310                          BNE     T257$            ;NO - GO DO SEEK TEST
 3017  030006  021437  002316                  CMP     (R4),HLMTW       ;CHECK IF ALL TABLE DIFF USED
 3018  030012  001276                          BNE     T2588$           ;NO - SKIP
 3019  030014  004737  020576          T2517$: JSR     PC,SWAPHD        ;GO SWAP TO HEAD 1 OR END TEST
 3020  030020  030024                          T2565$                   ;ABORT RETURN
 3021  030022  000654                          BR      T256$            ;REPEAT TEST HEAD 1
 3022  030024                          T2565$:
 3023  030024                          ENDTST
  (3)  030024                          L10037:
  (3)  030024  104401                          TRAP    C$ETST
```

```
                                        .SBTTL  *TEST 8         **FORWARD OSCILLATING SEEK
030026                                  BGNTST          ;TEST 8
(3)  030026                                                                                     T8::
030026  012737  006646  003026                  MOV     #P2T10E,ERHEAD  ;SET ERROR HEADER
030034  004737  016214                          JSR     PC,TSTINT       ;INITIALIZE TEST
030040  004737  016232                          JSR     PC,GSTATR       ;CLEAR DRIVE
030044  030322                                  T2665$
030046  004737  020552                          JSR     PC,CHOSHD       ;GO CHOSE HEAD
030052  012705  000001                  T266$:  MOV     #1,R5           ;LOAD R5 FOR FIRST SEEK
030056  032737  020000  013556                  BIT     #HICYL,MISWIW   ;TEST IF HI CYLINDER SPECED
030064  001402                                  BEQ     2$              ;NO - SKIP
030066  013705  013562                          MOV     HILIMW,R5       ;ELSE SET UPPER LIMIT
030072  005037  003116                  2$:     CLR     NEWCYL          ;SET TO SEEK TO CYL 0
030076  032737  040000  013556                  BIT     #LOCYL,MISWIW   ;CHECK IF LO CYL SPEC'D
030104  001403                                  BEQ     5$              ;NO - SKIP
030106  013737  013560  003116                  MOV     LOLIMW,NEWCYL   ;ELSE SET LOWER LIMIT
030114  004737  017160                  5$:     JSR     PC,XSEEK        ;DO SEEK
030120  030322                                  T2665$
030122  012701  005670                          MOV     #3000.,R1       ;SET WAIT COUNT FOR 120 MS
030126  004737  022054                          JSR     PC,RDYWAIT      ;WAIT FOR READY
030132  030322                                  T2665$
030134  004737  022340                  T267$:  JSR     PC,GETPOS       ;GET HEAD POSITION
030140  030322                                  T2665$
030142  010537  003116                          MOV     R5,NEWCYL       ;LOAD NEW CYLINDER INTO NEWCYL
030146                                  BGNSUB
(3)  030146                                                                                     T8.1:
(3)  030146  104402                             TRAP    C$BSUB
030150                                          INLOOP                  ;CHECK IF IN ERROR LOOP
(3)  030150  104420                             TRAP    C$INLP
030152                                          BNCOMPLETE      18$     ;NO - SKIP
(2)  030152  103011                             BCC     18$
030154  004737  022340                          JSR     PC,GETPOS       ;GET POSITION
030160  030256                                  60$
030162  023737  003120  003116                  CMP     CURCYL,NEWCYL   ;CHECK IF HEADS AT DESIRED LOC
030170  001002                                  BNE     18$             ;NO - SKIP
030172  004737  020636                          JSR     PC,ONSWAP               ;SWAP OLD AND NEW
030176  004737  017160                  18$:    JSR     PC,XSEEK        ;DO SEEK
030202  030256                                  60$
030204  012701  005670                          MOV     #3000.,R1       ;SET WAIT COUNT 120 MS
030210  004737  022054                          JSR     PC,RDYWAIT      ;WAIT FOR READY
030214  030256                                  60$
030216  004737  022466                          JSR     PC,VERPOS       ;VERIFY HEAD POSITION
030222  030256                                  60$
030224  005737  003124                          TST     DESSGN          ;TEST IF JUST SEEK REV
030230  001412                                  BEQ     60$             ;YES - SKIP
030232  005037  003116                          CLR     NEWCYL          ;ELSE SET TO SEEK TO 0
030236  032737  040000  013556                  BIT     #LOCYL,MISWIW   ;CHECK IF LO LIMIT SPEC'D
030244  001754                                  BEQ     18$             ;NO - SKIP
030246  013737  013560  003116                  MOV     LOLIMW,NEWCYL   ;ELSE SET LOW LIMIT FOR SEEK
030254  000750                                  BR      18$
030256  012737  000002  003032          60$:    MOV     #2,ERRSWI       ;INIT ERROR SWITCH
030264                                  ENDSUB
(3)  030264                             L10042:
(3)  030264  104403                             TRAP    C$ESUB
030266                                          ESCAPE  TST             ;EXIT TEST IF ERROR
(3)  030266  104410                             TRAP    C$ESCAPE
```

```
  (3)  030270  000032                                .WORD   L10041-.
 3073  030272  032737  020000  013556                BIT     #HICYL,MISWIW   ;TEST IF UPPER LIMIT SPEC'D
 3074  030300  001004                                BNE     20$             ;YES - SKIP
 3075  030302  005205                                INC     R5              ;BUMP R5
 3076  030304  020537  002324                        CMP     R5,GBND ;ALL CYLINDERS DONE
 3077  030310  001311                                BNE     T267$           ;NO - GO DO NEXT CYLINDER
 3078  030312  004737  020576            20$:        JSR     PC,SWAPHD       ;GO SWAP TO HEAD 1 OR END TEST
 3079  030316  030322                                T2665$                  ;ABORT RETURN
 3080  030320  000654                                BR      T266$           ;GO DO TESTS
 3081  030322                            T2665$:
 3082  030322                            ENDTST
  (3)  030322                            L10041:
  (3)  030322  104401                                TRAP    C$ETST
```

```
                                        .SBTTL  *TEST 9         **REVERSE OSCILLATING SEEK
030324                                  BGNTST                  ;TEST 9
 (3) 030324                                                                                    T9::
030324  012737  006661  003026                  MOV     #P2T11E,ERHEAD  ;SET ERROR HEADER
030332  004737  016214                          JSR     PC,TSTINT       ;INITIALIZE TEST
030336  004737  016232                          JSR     PC,GSTATR       ;CLEAR DRIVE
030342  030620                                  T2765$
030344  004737  020552                          JSR     PC,CHOSHD       ;GO CHOSE HEAD
030350  013737  002316  003116          T275$:  MOV     HLMTW,NEWCYL    ;SEEK OUT TO 255.
030356  032737  020000  013556                  BIT     #HICYL,MISWIW   ;TEST IF UPPER LIMIT SPEC'D
030364  001403                                  BEQ     2$              ;NO - SKIP
030366  013737  013562  003116                  MOV     HILIMW,NEWCYL   ;ELSE SET UPPER LIMIT
030374  013705  002322                  2$:     MOV     NXTHL,R5        ;SET R5 FOR FIRST SEEKS
030400  032737  040000  013556                  BIT     #LOCYL,MISWIW   ;CHECK IF LO LIMIT SPEC'D
030406  001402                                  BEQ     5$              ;NO - SKIP
030410  013705  013560                          MOV     LOLIMW,R5       ;SET LOWER LIMIT
030414  004737  017160                  5$:     JSR     PC,XSEEK        ;DO SEEK
030420  030620                                  T2765$
030422  012701  005670                          MOV     #3000.,R1       ;SET WAIT TO 120 MS
030426  004737  022054                          JSR     PC,RDYWAIT      ;WAIT FOR DRIVE READY
030432  030620                                  T2765$
030434  004737  022340                  T276$:  JSR     PC,GETPOS       ;GET POSITION
030440  030620                                  T2765$
030442  010537  003116                          MOV     R5,NEWCYL       ;SET FOR NEXT SEEK
030446                                  BGNSUB
 (3) 030446                                                                                    T9.1:
 (3) 030446  104402                             TRAP    C$BSUB
030450                                          INLOOP                  ;CHECK IF IN ERROR LOOP
 (3) 030450  104420                             TRAP    C$INLP
030452                                          BNCOMPLETE      18$     ;NO - SKIP
 (2) 030452  103011                             BCC     18$
030454  004737  022340                          JSR     PC,GETPOS       ;ELSE GET POSITION
030460  030560                                  60$
030462  023737  003120  003116                  CMP     CURCYL,NEWCYL   ;CHECK IF AT DESIRED CYL
030470  001002                                  BNE     18$             ;NO - SKIP
030472  004737  020636                          JSR     PC,ONSWAP       ;ELSE SWAP OLD AND NEW CYL
030476  004737  017160                  18$:    JSR     PC,XSEEK        ;DO SEEK
030502  030560                                  60$
030504  012701  005670                          MOV     #3000.,R1       ;SET WAIT FOR 120 MS
030510  004737  022054                          JSR     PC,RDYWAIT      ;WAIT FOR READY
030514  030560                                  60$
030516  004737  022466                          JSR     PC,VERPOS       ;VERIFY POSITION
030522  030560                                  60$
030524  005737  003124                          TST     DESSGN          ;CHECK IF JUST SEEK FWD
030530  001013                                  BNE     60$             ;YES - SKIP
030532  013737  002316  003116                  MOV     HLMTW,NEWCYL    ;ELSE SEEK TO TO 255
030540  032737  020000  013556                  BIT     #HICYL,MISWIW   ;TEST IF HILIMIT SPEC'D
030546  001753                                  BEQ     18$             ;NO - SKIP
030550  013737  013562  003116                  MOV     HILIMW,NEWCYL   ;SET TO UPPER LIMIT
030556  000747                                  BR      18$
030560  012737  000002  003032          60$:    MOV     #2,ERRSWI       ;INIT ERROR SWITCH
030566                                  ENDSUB
 (3) 030566                             L10044:
 (3) 030566  104403                             TRAP    C$ESUB
030570                                          ESCAPE  TST             ;EXIT TEST IF ERROR
 (3) 030570  104410                             TRAP    C$ESCAPE
```

```
  (3)  030572  000026                          .WORD   L10043-.
 3132  030574  032737  040000  013556          BIT     #LOCYL,MISWIW   ;TEST IF LOLIMIT SPEC'D
 3133  030602  001002                          BNE     20$             ;YES - SKIP
 3134  030604  005305                          DEC     R5              ;DEC CYLINDER COUNT
 3135  030606  100312                          BPL     T276$           ;IF STILL POSITIVE, DO SEEKS AGAIN
 3136  030610  004737  020576          20$:    JSR     PC,SWAPHD       ;GO SWAP TO HEAD 1 OR END TEST
 3137  030614  030620                          T2765$                  ;ABORT RETURN
 3138  030616  000654                          BR      T275$           ;LOOP AGAIN
 3139  030620                          T2765$:
 3140  030620                          ENDTST
  (3)  030620                          L10043:
  (3)  030620  104401                          TRAP    C$ETST
 3141
 3142  030622                          ENDMOD
 3143
 3144
 3145
```

```
                                        .SBTTL  PARAMETER CODING
030622                                  BGNMOD  HRDPRM
030622                                  BGNHRD
(3)  030622  000030                             .WORD L10045-L$HARD/2
030624                                  GPRML   CNTYPE,CNT,1,YES
(4)  030624  005130                             .WORD   T$CODE
(4)  030626  030770                             .WORD   CNTYPE
(4)  030630  000001                             .WORD   1
030632                                  GPRMA   CSRMSG,CSR,0,160000,177776,YES
(4)  030632  000031                             .WORD   T$CODE
(4)  030634  030704                             .WORD   CSRMSG
(4)  030636  160000                             .WORD   T$LOLIM
(4)  030640  177776                             .WORD   T$HILIM
030642                                  GPRMA   VECMSG,VECT,0,0,776,YES
(4)  030642  001031                             .WORD   T$CODE
(4)  030644  030720                             .WORD   VECMSG
(4)  030646  000000                             .WORD   T$LOLIM
(4)  030650  000776                             .WORD   T$HILIM
030652                                  GPRMD   DRMSG,DRSB,0,3400,0,7,YES
(4)  030652  004032                             .WORD   T$CODE
(4)  030654  030762                             .WORD   DRMSG
(4)  030656  003400                             .WORD   3400
(4)  030660  000000                             .WORD   T$LOLIM
(4)  030662  000007                             .WORD   T$HILIM
030664                                  GPRML   DRTYPE,TYPDR,1,YES
(4)  030664  003130                             .WORD   T$CODE
(4)  030666  030740                             .WORD   DRTYPE
(4)  030670  000001                             .WORD   1
030672                                  GPRMD   BRMSG,PRIOR,0,340,0,7,YES
(4)  030672  002032                             .WORD   T$CODE
(4)  030674  030727                             .WORD   BRMSG
(4)  030676  000340                             .WORD   340
(4)  030700  000000                             .WORD   T$LOLIM
(4)  030702  000007                             .WORD   T$HILIM

030704                                  ENDHRD
(2)                                             .EVEN
(3)  030704                             L10045:

030704  052502  020123  042101          CSRMSG: .ASCIZ  /BUS ADDRESS/
        030712  051104  051505  000123
030720  042526  052103  051117          VECMSG: .ASCIZ  /VECTOR/
        030726     000
030727     102  020122  042514          BRMSG:  .ASCIZ  /BR LEVEL/
        030734  042526  000114
030740  051104  053111  020105          DRTYPE: .ASCIZ  /DRIVE TYPE = RL01/
        030746  054524  042520  036440
        030754  051040  030114  000061
030762  051104  053111  000105          DRMSG:  .ASCIZ  /DRIVE/
030770  046122  030461     000          CNTYPE: .ASCIZ  /RL11/
030775                                  ENDMOD
        030776                                  .EVEN

030776                                  BGNMOD  SFTPRM
030776                                  BGNSFT
(3)  030776  000053                             .WORD L10046-L$SOFT/2
```

```
 3170
 3172  031000                          GPRML   CYLQ,MISWI,1,YES
  (4)  031000  000130                            .WORD   T$CODE
  (4)  031002  031126                            .WORD   CYLQ
  (4)  031004  000001                            .WORD   1
 3173  031006                          GPRML   SECQ,MISWI,2,YES
  (4)  031006  000130                            .WORD   T$CODE
  (4)  031010  031142                            .WORD   SECQ
  (4)  031012  000002                            .WORD   2
 3179
 3181  031014                          GPRML   LOLIMQ,MISWI,40000,YES
  (4)  031014  000130                            .WORD   T$CODE
  (4)  031016  031157                            .WORD   LOLIMQ
  (4)  031020  040000                            .WORD   40000
 3182  031022                                    XFERF   1$
  (5)  031022  006044                            .WORD   T$CODE
 3183  031024                                    GPRMD   LIMVAL,LOLIM,D,255.,0,253.,YES
  (4)  031024  001052                            .WORD   T$CODE
  (4)  031026  031176                            .WORD   LIMVAL
  (4)  031030  000377                            .WORD   255.
  (4)  031032  000000                            .WORD   T$LOLIM
  (4)  031034  000375                            .WORD   T$HILIM
 3184  031036                          1$:     GPRML   HILIMQ,MISWI,20000,YES
  (4)  031036  000130                            .WORD   T$CODE
  (4)  031040  031204                            .WORD   HILIMQ
  (4)  031042  020000                            .WORD   20000
 3185  031044                                    XFERF   2$
  (5)  031044  006044                            .WORD   T$CODE
 3186  031046                                    GPRMD   LIMVAL,HILIM,D,255.,0,255.,YES
  (4)  031046  002052                            .WORD   T$CODE
  (4)  031050  031176                            .WORD   LIMVAL
  (4)  031052  000377                            .WORD   255.
  (4)  031054  000000                            .WORD   T$LOLIM
  (4)  031056  000377                            .WORD   T$HILIM
 3187  031060                          2$:     GPRML   HEADQ,MISWI,10000,YES
  (4)  031060  000130                            .WORD   T$CODE
  (4)  031062  031225                            .WORD   HEADQ
  (4)  031064  010000                            .WORD   10000
 3188  031066                                    XFERF   3$
  (5)  031066  006044                            .WORD   T$CODE
 3189  031070                                    GPRMD   HEADV,HEAD,D,17,0,1,YES
  (4)  031070  003052                            .WORD   T$CODE
  (4)  031072  031247                            .WORD   HEADV
  (4)  031074  000017                            .WORD   17
  (4)  031076  000000                            .WORD   T$LOLIM
  (4)  031100  000001                            .WORD   T$HILIM
 3191  031102                          3$:     GPRMD   ERLIMQ,ERLIM,D,377,0,377,YES
  (4)  031102  004052                            .WORD   T$CODE
  (4)  031104  031272                            .WORD   ERLIMQ
  (4)  031106  000377                            .WORD   377
  (4)  031110  000000                            .WORD   T$LOLIM
  (4)  031112  000377                            .WORD   T$HILIM
 3193  031114                                    GPRMD   DCLIMQ,DCLIM,D,377,1,377,YES
  (4)  031114  005052                            .WORD   T$CODE
  (4)  031116  031314                            .WORD   DCLIMQ
  (4)  031120  000377                            .WORD   377
```

```
  (4)  031122  000001                          .WORD   T$LOLIM
  (4)  031124  000377                          .WORD   T$HILIM
 3195  031126                          ENDSFT
  (2)                                          .EVEN
  (3)  031126                          L10046:
 3196
 3198  031126  051525  020105  046101  CYLQ:   .ASCIZ  /USE ALL CYL/
       031134  020114  054503  000114
 3199  031142  051525  020105  046101  SECQ:   .ASCIZ  /USE ALL SECT/
       031150  020114  042523  052103
       031156     000
 3206  031157     114  053517  051440  LOLIMQ: .ASCIZ  /LOW SEEK LIMIT/
       031164  042505  020113  044514
       031172  044515  000124
 3207  031176  040526  052514  000105  LIMVAL: .ASCIZ  /VALUE/
 3208  031204  050125  042520  020122  HILIMQ: .ASCIZ  /UPPER SEEK LIMIT/
       031212  042523  045505  046040
       031220  046511  052111     000
 3209  031225     125  042523  047440  HEADQ:  .ASCIZ  /USE ONLY ONE SURF/
       031232  046116  020131  047117
       031240  020105  052523  043122
       031246     000
 3210  031247     127  040510  020124  HEADV:  .ASCIZ  /WHAT SURF (0 OR 1)/
       031254  052523  043122  024040
       031262  020060  051117  030440
       031270  000051
 3212  031272  047111  052520  020124  ERLIMQ: .ASCIZ  /INPUT ERROR LIMIT/
       031300  051105  047522  020122
       031306  044514  044515  000124
 3214  031314  040504  040524  041440  DCLIMQ: .ASCIZ  /DATA CMP ERR LMT/
       031322  050115  042440  051122
       031330  046040  052115     000
 3216          031336                          .EVEN
 3217  031336                          ENDMOD
 3218
 3219  031336                          LASTAD
  (2)                                          .EVEN
  (4)  031336  000000                          .WORD   0
  (4)  031340  000000                          .WORD   0
  (3)  031342                          L$LAST::
 3220
 3221          000001                          .END
```

```
ADR    = 000020 G        92#
AFMID    003224        495#
AFMIDU   003226        496#
ALLCYL= 000001         110#
ALLSEC= 000002         111#   2751   2798   2848   2947
ANYERR= 100000         163#   1620   1921   2185
ARMID    003230        497#
ARMIDU   003232        498#
ASSEMB= 000010           8
BADADD= 004000         142#   2428   2464   2466
BAMSK  = 000060        174#
BANAM    006243        677#   2643
BASADD   006141        672#   1152   1332   1361   1374   1492   1973   2641
BELL     010555        813#
BHSTAT= 000010         200#
BIT0   = 000001 G       92#
BIT00  = 000001 G       92#    110    132    151   2592
BIT01  = 000002 G       92#    111    131    152
BIT02  = 000004 G       92#    112    133    153
BIT03  = 000010 G       92#    113    134    154
BIT04  = 000020 G       92#    135
BIT05  = 000040 G       92#    136
BIT06  = 000100 G       92#    137
BIT07  = 000200 G       92#    138
BIT08  = 000400 G       92#    139
BIT09  = 001000 G       92#    140
BIT1   = 000002 G       92#
BIT10  = 002000 G       92#    141   1593   1712   2006   2280   2445
BIT11  = 004000 G       92#    142
BIT12  = 010000 G       92#    114    143
BIT13  = 020000 G       92#    115    144
BIT14  = 040000 G       92#    116    145
BIT15  = 100000 G       92#    117    146   1051
BIT2   = 000004 G       92#   2446
BIT3   = 000010 G       92#
BIT4   = 000020 G       92#
BIT5   = 000040 G       92#
BIT6   = 000100 G       92#   2535
BIT7   = 000200 G       92#
BIT8   = 000400 G       92#
BIT9   = 001000 G       92#   1015
BOE    = 000400 G       92#
BRMSG    030727       3155   3161#
BSCHK    024344       2518#
BSFLAG   003034        427#   2521*  2541*  2548
BSFVAL   003510        530#   1970
BSNSTR   007550        772#   1972
BYPSNM   007501        769#
CAFDT    010662        831#   2019   2488
CAMSK    002326        255#   1286*  1294*
CCYLUP   010653        830#
CHOSHD   020552       1940#   2673   2723   2771   2872   2967   3031   3090
CKBSVD   020662       1970#
CKDATA= 000102         120#
CKERLM   015664        931    945    959    974    989   1094   1108   1130   1144   1158   1487#
CLKADR   003506        526#   1217*
```

```
CLKCSB= 172542          215#
CLKCSR= 172540          214#
CLKCTR= 172544          216#
CLKFLG  003504          525#   1216*  1219*
CLNCOD  015124 G       1385#
CLRBYT  002320          252#   1289*  1298*
CLRPAR  025744         2609    2649#
CNT   = 000012           99#   3150
CNTYPE  030770         315C    3164#
COMPOP= 007777          130#   2588
CONHNG= 000004          153#
CONTIN  014016         1252#
COSTAT= 000040          202#
COUNT   003250          509#
CRDYMS= 000200          172#   1013   1322   1368   1391   1508   1519   2288   2294
CSNAM   006236          676#   2643
CSR   = 000000           94#   3151
CSRMSG  030704         3151    3159#
CURCYL  003120          459#   1674   1691   1835   1839   1840   1858   1864   1872   2221*  2246   2424   2451
                       2608    2645   2700   2735   2739   2783   2787   2833   2837   2934   2938   2973   2998
                       3053    3112
CYLQ    031126         3172    3198#
CYLTBL  002620          334#
CYLUP = 000004          133#
CYLWD   007466          767#   2608   2643
C$AU  = 000052            8#
C$AUTO= 000061            8#   1379
C$BRK = 000022            8#
C$BSEG= 000004            8#   1830
C$BSUB= 000002            8#   2677   2730   2778   2829   2876   2929   2993   3048   3107
C$CEFG= 000045            8#
C$CLCK= 000062            8#   1217
C$CLEA= 000012            8#   1404
C$CLOS= 000035            8#
C$CLP1= 000006            8#
C$CVEC= 000036            8#   1378   1397   1401
C$DCLN= 000044            8#   1335   1495
C$DODU= 000051            8#   1334   1365   1377   1494
C$DRPT= 000024            8#
C$DU  = 000053            8#   1408
C$EDIT= 000003            8#     63
C$ERDF= 000055            8#
C$ERHR= 000056            8#   1578   1615   1628   1634   1739   1744   1853   1869   1912   1923   2020   2031
                       2035    2043   2092   2104   2111   2173   2183   2187   2248   2301   2306   2410   2468
                       2483    2489   2498   2502   2688   2702   2887
C$ERRO= 000060            8#
C$ERSF= 000054            8#
C$ERSO= 000057            8#
C$ESCA= 000010            8#   2706   2901   3010   3072   3131
C$ESEG= 000005            8#   1877
C$ESUB= 000003            8#   2705   2761   2808   2858   2900   2957   3009   3071   3130
C$ETST= 000001            8#   2713   2763   2810   2860   2908   2959   3023   3082   3140
C$EXIT= 000032            8#   2726   2774   2827   2927
C$GETB= 000026            8#
C$GETW= 000027            8#
C$GMAN= 000043            8#
```

```
C$GPHR= 000042          8#   1270
C$GPLO= 000030          8#
C$GPRI= 000040          8#
C$INIT= 000011          8#   1338
C$INLP= 000020          8#   1489   1831   2733   2781   2831   2932   2994   3049   3108
C$MANI= 000050          8#
C$MEM = 000031          8#
C$MSG = 000023          8#    932    946    960    975    990   1095   1109   1131   1145   1159
C$OPEN= 000034          8#
C$PNTB= 000014          8#   1033   1066   1080   1089   1152   1153   1155   2395   2563   2564   2568   2581
                     2597    2601   2605   2608   2620   2629   2630   2633   2641   2643   2644   2645
C$PNTF= 000017          8#   1331   1332   1333   1360   1361   1363   1372   1374   1376   1491   1492   1493
                     1972    1973   1974
C$PNTS= 000016          8#
C$PNTX= 000015          8#
C$QIO = 000377          8#
C$RDBU= 000007          8#   1422   1442
C$REFG= 000047          8#   1225   1229   1250   1253   1256
C$RESE= 000033          8#   1221   1402
C$REVI= 000003          8#     63
C$RFLA= 000021          8#
C$RPT = 000025          8#
C$SEFG= 000046          8#
C$SPRI= 000041          8#   1220   1304   1390
C$SVEC= 000037          8#   1303   1354   1388
C$TPRI= 000013          8#
C10MS   010634        828#   2687   2886
C5SEC   010673        832#   2030   2182   2497
C50UMS  010645        829#   1911
DANAM   006250        678#   2643
DATACM= 000001        132#   2380   2391
DATCOM  023316       2371#
DATGEN  023156       2331#
DCKERR= 004000        168#   1043   1067
DCLIM = 000012        107#   3193
DCLIMQ  031314       3193    3214#
DCLIMW  013570       1195#   2407
DESDIF  003122        460#   1684*  1698*  1707*  1714   2605
DESHD   003126        462#   1722   1940*  1943*  1950   1952*  2097   2283   2426   2456   2533   2605   2608
                     2645    2724   2772   2818*  2822*  2918*  2922*
DESSEC  003130        463#   2459   2536   2608
DESSGN  003124        461#   1683*  1694*  1697*  1703*  1719   1862   2605   3063   3122
DIAGMC= 000000          8
DIFAUG  003112        456#   1670*  1678*  1689*  1699   1707
DIFWD   007442        763#   2605
DIRBIT= 000004        183#   1721
DIRMSK  002330        256#   1287*  1295*
DLTERR= 010000        166#   1047
DONE    003022        422#   1475*  1511   1524   1591*  1598   1728*  1735   2003*  2014   2471*  2479
DRDYMS= 000001        175#   1325   1370   1394   1562   1607   1905   1916   2016   2024   2166   2177   2485
                     2493    2682   2881
DRMSG   030762       3153    3163#
DRSB  = 000010         98#   3153
DRSELT= 000004        112#   1222
DRSET = 000010        188#   1538   1554   1602   2584
DRTYPE  030740       3154    3162#
```

```
DRVCNT  003110          455#   1235*  1259   1263*  1266*
DRVERR= 040000          164#   1556   1572   1626
DRVNAM  006152          673#   1152   1332   1361   1374   1492   1973   2641
DRVNAV  006157          674#
DSESTA= 000400          204#
DSMSK = 001400          171#
DSPCOD  013572 G       1199#
EF.CON= 000036 G         92#   1253
EF.NEW= 000035 G         92#   1256
EF.PWR= 000034 G         92#   1225
EF.RES= 000037 G         92#   1250
EF.STA= 000040 G         92#   1229
ERHEAD  003026          424#   2568   2669*  2719*  2767*  2814*  2868*  2914*  2963*  3027*  3086*
ERLIM = 000010          106#   3191
ERLIMQ  031272         3191    3212#
ERLIMW  013566         1194#   1487   1491
ERRCNT  003254          511#   1237   1242   1262   1924*  2188*
ERRPOI  003252          510#    923*   935*   949*   963*   978*   995*  1098*  1112*  1134*  1150*  1242*  1262*
                       1267*   1487
ERRSWI  003032          426#   1553*  1635*  1648   1650   1669*  1740*  1745*  1751   1753   1826*  1854*  1870*
                       1882    1884   1901*  1925*  1931   1933   1993*  2026*  2044*  2057   2059   2077*  2093*
                       2105*   2112*  2131   2133   2163*  2189*  2195   2197   2226   2228   2243*  2249*  2253
                       2255    2272*  2302*  2307*  2319   2321   2392   2401   2403   2411*  2499*  2503*  2509
                       2511    2704*  2760*  2807*  2857*  2899*  2956*  3008*  3070*  3129*
ERRVEC  003244          505#   1354   1378   1388   1401
ERR1    011724 G        920#   1578   1615   1634   1739   1869   2043   2301   2468   2483
ERR10   013320 G       1146#   2092   2104   2111   2410
ERR2    011772 G        934#
ERR3    012040 G        948#   2173
ERR4    012106 G        962#   2688   2887
ERR5    012156 G        977#   1912   2020   2031   2183   2489   2498
ERR6    012226 G        992#   1628   1744   1853   1923   2035   2187   2306   2502
ERR7    013110 G       1097#
ERR8    013160 G       1111#   2248   2702
ERR9    013254 G       1133#
EVL   = 000004 G         92#
EXACYL  003240          502#
EXHCYL  003236          501#
EXOCYL  003234          500#
EXROT   003242          503#
E$END = 002100            8#
E$LOAD= 000035            8#     63
FBSFIL  003706          533#   1976*  2522   2543
FMTOP1  010701          834#
FMTOP2  010730          835#
FMTOP3  010752          836#
FMT1    010773          837#   2581   2633
FMT1.1  011000          838#   2620
FMT11   011217          847#   2623
FMT12   011225          848#   2626
FMT13   011233          849#   2605
FMT14   011277          850#   1153
FMT15   011331          851#   1080   1155
FMT16   011365          852#   2564
FMT17   011376          853#   1066
FMT18   011420          854#
```

```
FMT19   011452          855#
FMT2    011007          839#   2597   2601
FMT20   011507          856#
FMT21   011537          857#
FMT22   011562          858#   2608
FMT23   011616          859#
FMT24   011632          860#   1331   1360   1372
FMT25   011637          861#   1491
FMT26   011647          862#
FMT27   011673          863#   1089   2395
FMT28   011712          864#   1033
FMT3    011012          840#   1333   1363   1376   1493   1974
FMT4    011015          841#   2568
FMT5    011026          842#   1152   1332   1361   1374   1492   1973   2641
FMT6    011046          843#   2643
FMT7    011110          844#   2645
FMT8    011160          845#   2644
FMT9    011212          846#   1972   2563
FOLWRT= 000100          137#    147
FRMWD   007473          768#   2605
FWDSKO= 002000          141#    147
FWDSKS= 000400          139#    147
F$AU  = 000015            8#
F$AUTO= 000020            8#   1352   1379
F$BGN = 000040            8#     58     65     90    218    224    634    645    866    875    920    934    948
                        962    977    992   1097   1111   1133   1146   1160   1163   1171   1180   1182   1197
                       1199   1206   1212   1213   1339   1352   1385   1386   1406   1410   1415   1457   1465
                       1830   2659   2666   2667   2677   2705   2706   2713   2718   2726   2730   2761   2763
                       2766   2774   2778   2808   2810   2813   2827   2829   2858   2860   2866   2876   2900
                       2901   2908   2913   2927   2929   2957   2959   2962   2993   3009   3010   3023   3026
                       3048   3071   3072   3082   3085   3107   3130   3131   3140   3142   3148   3149   3165
                       3168   3169   3217
F$CLEA= 000007            8#   1386   1404
F$DU  = 000016            8#   1406   1408
F$END = 000041            8#     58     65     90    218    224    634    645    866    875    932    946    960
                        975    990   1095   1109   1131   1145   1159   1160   1171   1180   1182   1197   1199
                       1206   1212   1338   1339   1379   1385   1404   1408   1410   1415   1463   1479   1877
                       2659   2666   2667   2677   2705   2706   2713   2718   2726   2730   2761   2763   2766
                       2774   2778   2808   2810   2813   2827   2829   2858   2860   2866   2876   2900   2901
                       2908   2913   2927   2929   2957   2959   2962   2993   3009   3010   3023   3026   3048
                       3071   3072   3082   3085   3107   3130   3131   3140   3142   3148   3157   3165   3168
                       3195   3217
F$HARD= 000004            8#   3149   3157   3182   3185   3188
F$HW  = 000013            8#   1172   1179
F$INIT= 000006            8#   1213   1338
F$JMP = 000050            8#   2726   2774   2827   2927
F$MOD = 000000            8#     58     65     90    218    224    634    645    866    875   1160   1171   1180
                       1182   1197   1199   1206   1212   1339   1385   1410   1415   2659   2666   3142   3148
                       3165   3168   3217
F$MSG = 000011            8#    920    932    934    946    948    960    962    975    977    990    992   1095
                       1097   1109   1111   1131   1133   1145   1146   1159
F$PROT= 000021            8#   1163   1167
F$PWR = 000017            8#
F$RPT = 000012            8#
F$SEG = 000003            8#   1830   1877
F$SOFT= 000005            8#   3169   3182   3185   3188   3195
```

```
F$SRV  = 000010          8#   1457   1463   1465   1479
F$SUB  = 000002          8#   2677   2705   2730   2761   2778   2808   2829   2858   2876   2900   2929   2957
                      2993   3009   3048   3071   3107   3130
F$SW   = 000014          8#   1183   1196
F$TEST= 000001           8#   2667   2713   2718   2763   2766   2810   2813   2860   2866   2908   2913   2959
                      2962   3023   3026   3082   3085   3140
GBND     002324        254#   1285*  1293*  2877   3076
GETPOS   022340       1672   1827   1833   1856   2205#  2244   2698   2731   2779   2830   2930   2971   2996
                      3045   3051   3104   3110
GETSTA= 000003        187#   1008   1538   1541   1587
GLBDAT   002240 G     224#
GLBEQA   002240 G      90#
GLBERR   011724 G     875#
GLBSUB   015256 G    1415#
GLBTXT   005360 G     645#
GSTAT    016262      1543#   1560   1612   1618   1903   1914   2022   2164   2175   2491   2684   2883
GSTATC   016246      1540#
GSTATG   016272      1539   1542   1545#
GSTATR   016232      1537#   2671   2721   2769   2816   2870   2916   2965   3029   3088
GTSTAT= 000104        121#   1594
G$CNTO= 000200          8#
G$DELM= 000372          8#   1424   1429   1445   1449
G$DISP= 000003          8#
G$EXCP= 000400          8#
G$HILI= 000002          8#
G$LOLI= 000001          8#
G$NO   = 000000         8#
G$OFFS= 000400          8#   3150   3151   3152   3153   3154   3155   3172   3173   3181   3183   3184   3186
                      3187   3189   3191   3193
G$OFSI= 000376          8#   3150   3151   3152   3153   3154   3155   3172   3173   3181   3183   3184   3186
                      3187   3189   3191   3193
G$PRMA= 000001          8#   3151   3152
G$PRMD= 000002          8#   3153   3155   3183   3186   3189   3191   3193
G$PRML= 000000          8#   3150   3154   3172   3173   3181   3184   3187
G$RADA= 000140          8#
G$RADB= 000000          8#
G$RADD= 000040          8#   3183   3186   3189   3191   3193
G$RADL= 000120          8#   3150   3154   3172   3173   3181   3184   3187
G$RADO= 000020          8#   3151   3152   3153   3155
G$XFER= 000004          8#   3182   3185   3188
G$YES  = 000010         8#   3150   3151   3152   3153   3154   3155   3172   3173   3181   3183   3184   3186
                      3187   3189   3191   3193
HADONE   003024       423#   1244*
HCESTA= 040000        210#   1566
HCRCER= 004000        169#   1030   1037
HDALIG= 000010        113#   1222
HDCYL    002332       257#   1288*  1296*
HDHSEL= 000100        196#   2096   2099
HDMOVF   007323       740#   1868
HDRCMP= 000002        131#   2078
HDR40  = 100000       146#   2274   2598
HDSEC  = 000077       195#   2118   2121
HDSEL  = 000020       184#   1724   2285
HDWD     007455       765#   2605   2608   2643
HDWRD1   003066       443#   1118   2140   2215
HDWRD2   003070       444#   2037
```

```
HDWRD3  003072          445#
HEAD  = 000006          105#   3189
HEADLM= 010000          114#   1941    1948    2823    2923
HEADQ   031225         3187    3209#
HEADV   031247         3189    3210#
HEADW   013564         1193#   1943    2825    2925
HFIN    003204          487#
HFINU   003206          488#
HFOUT   003210          489#
HFOUTU  003212          490#
HICYL = 020000          115#   1300    3033    3073    3092    3125
HILIM = 000004          104#   3186
HILIMQ  031204         3184    3208#
HILIMW  013562         1192#   1302*   2758    2775    2855    2919    2980    2989    2991    3011    3035    3094    3127
HLMTW   002316          251#   1284*   1292*   1302    1675    1677    1679    1701    2424    2873    3017    3091    3124
HNFERR= 010000          167#   1028
HOE   = 100000 G         92#
HOSTAT= 000020          201#   1564
HPTCOD  013536 G       1171#
HRDPRM  030622 G       3148#
HRDWTS  025774 G       2666#
HRIN    003214          491#
HRINU   003216          492#
HROUT   003220          493#
HROUTU  003222          494#
HSMSK = 000100          179#   2458
HSSTAT= 000100          203#   2144
IBE   = 010000 G         92#
IBUFF   004102          535#   1075    2080    2275    2383    2448
IDU   = 000040 G         92#
IER   = 020000 G         92#
INITCO  013616 G       1212#
INOUTS= 000020          135#    147
INTEBL= 000100          173#
INTHLR  015604         1303    1469#
ISR   = 000100 G         92#
IXE   = 004000 G         92#
I$AU  = 000041            8#
I$AUTO= 000041            8#   1352#   1379#
I$CLN = 000041            8#   1386#   1404#
I$DU  = 000041            8#   1406#   1408#
I$HRD = 000041         3149#   3157#
I$INIT= 000041            8#   1213#   1338#
I$MOD = 000041            8#     58#     65#     90#    218#    224#    634#    645#    866#    875#   1160#   1171#   1180#
                       1182#   1197#   1199#   1206#   1212#   1339#   1385#   1410#   1415#   2659#   2666#   3142#   3148#
                       3165#   3168#   3217#
I$MSG = 000041            8#    920#    932#    934#    946#    948#    960#    962#    975#    977#    990#    992#   1095#
                       1097#   1109#   1111#   1131#   1133#   1145#   1146#   1159#
I$PROT= 000040            8#   1163#
I$PTAB= 000041            8#
I$PWR = 000041            8#
I$RPT = 000041            8#
I$SEG = 000041            8#   1830#   1877#   2667    2677    2718    2730    2766    2778    2813    2829    2866    2876
                       2913    2929    2962    2993    3026    3048    3085    3107
I$SETU= 000041            8#
I$SFT = 000041         3169#   3195#
```

```
I$SRV = 000041          8#   1457#  1463#  1465#  1479#
I$SUB = 000041          8#   2667   2677#  2705#  2718   2730#  2761#  2766   2778#  2808#  2813   2829#  2858#
                     2866    2876#  2900#  2913   2929#  2957#  2962   2993#  3009#  3026   3048#  3071#  3085
                     3107#   3130#
I$TST = 000041          8#   2667#  2677   2706   2713#  2718#  2726   2730   2763#  2766#  2774   2778   2810#
                     2813#   2827   2829   2860#  2866#  2876   2901   2908#  2913#  2927   2929   2959#  2962#
                     2993    3010   3023#  3026#  3048   3072   3082#  3085#  3107   3131   3140#
JJJ     002314        250#
J$JMP = 000167          8#
LAB     013770       1245#
LABACF  007273        737#
LABACR  007307        738#
LABEXP  007206        732#
LABHCF  007243        735#
LABHCR  007257        736#
LABIN   007163        729#
LABMID  007171        730#
LABOCF  007217        733#
LABOCR  007231        734#
LABOUT  007200        731#
LAB1    006262        680#   2644
LAB2    006275        681#   2645
LIMVAL  031176       3183    3186   3207#
LOCERR  003460        514#
LOCYL = 040000        116#   1245   3037   3066   3096   3132
LOE   = 040000 G       92#
LOLIM = 000002        103#   3183
LOLIMQ  031157       3181    3206#
LOLIMW  013560       1191#   1247*  2727   2805   2819   2954   2968   2981   2985   2987   3015   3039   3068
                     3098
LOT   = 000010 G       92#
L$ACP   002110 G       63#
L$APT   002036 G       63#
L$AUT   002070 G       63#
L$AUTO  014566 G       63    1352#
L$CCP   002106 G       63#
L$CLEA  015124 G       63    1386#
L$CO    002032 G       63#
L$DEPO  002011 G       63#
L$DESC  002122 G       63      66#
L$DESP  002076 G       63#
L$DEVP  002060 G       63#
L$DISP  013574 G       63    1204#
L$DLY   002116 G       63#   1418*  1424   1428*  1429   1436*  1444*  1445   1449
L$DTP   002040 G       63#
L$DTYP  002034 G       63#
L$DU    015252 G       63    1406#
L$DUT   002072 G       63#
L$DVTY  002226 G       63      67#
L$EF    002052 G       63#
L$ENVI  002044 G       63#
L$ETP   002102 G       63#
L$EXP1  002046 G       63#
L$EXP4  002064 G       63#
L$EXP5  002066 G       63#
L$HARD  030624 G       63    3149#
```

```
L$HIME   002120 G      63#
L$HPCP   002016 G      63#
L$HPTP   002022 G      63#
L$HW     013540 G      63     1172#
L$ICP    002104 G      63#
L$INIT   013616 G      63     1213#
L$LADP   002026 G      63#
L$LAST   031342 G      63     3219#
L$LOAD   002100 G      63#
L$LUN    002074 G      63#
L$MREV   002050 G      63#
L$NAME   002000 G      63#
L$PRIO   002042 G      63#
L$PROT   013530 G      63     1163#
L$PRT    002112 G      63#
L$REPP   002062 G      63#
L$REV    002010 G      63#
L$SOFT   031000 G      63     3169#
L$SPC    002056 G      63#
L$SPCP   002020 G      63#
L$SPTP   002024 G      63#
L$STA    002030 G      63#
L$SW     013556 G      63     1183#
L$TEST   002114 G      63#
L$TIML   002014 G      63#
L$UNIT   002012 G      63#    1227   1235   1263
L.BA     003052       436#    2281*  2287   2644
L.CS     003050       435#    1592*  1593*  1594*  1596   1638   1709   2004   2047   2278*  2279*  2280*  2292
                     2442     2570   2644
L.DA     003054       437#    1587*  1589*  1595   1602   2282*  2285*  2286   2584   2644
L.MP     003056       438#    1583   1996   2644
L10000   011770       932#
L10001   012036       946#
L10002   012104       960#
L10003   012154       975#
L10004   012224       990#
L10005   013106      1095#
L10006   013156      1109#
L10007   013252      1131#
L10010   013316      1145#
L10011   013526      1159#
L10013   013554      1172    1179#
L10014   013572      1183    1196#
L10015   014564      1338#
L10016   015122      1379#
L10017   015250      1404#
L10020   015254      1408#
L10021   015602      1463#
L10022   015662      1479#
L10023   026214      2706    2713#
L10024   026176      2705#
L10025   026424      2726    2763#
L10026   026422      2761#
L10027   026634      2774    2810#
L10030   026632      2808#
L10031   027060      2827    2860#
```

```
L10032  027056          2858#
L10033  027266          2901    2908#
L10034  027250          2900#
L10035  027514          2927    2959#
L10036  027512          2957#
L10037  030024          3010    3023#
L10040  027754          3009#
L10041  030322          3072    3082#
L10042  030264          3071#
L10043  030620          3131    3140#
L10044  030566          3130#
L10045  030704          3149    3157#
L10046  031126          3169    3195#
MAJINC  003502           524#   1438*   1452
MAPROX  007153           728#
MBADAD  006022           247     668#
MBADSF  006043           669#
MBSET0= 000001           182#   1725
MCERR   007771           260     780#
MCONHN  006407           686#   1522
MCYLOC  010345           806#   1117    2624
MCYLUP  005560           238     660#
MDATCP  005442           236     653#
MDCRC   010013           782#   1045
MDHEDR  002000 G          58#
MDLT    010040           784#   1049
MDRDY   007760           779#   1910    2018    2172    2487    2686    2885
MDRERR  010102           261     786#
MDRRES  006336           684#   1516
MDRVST  010130           796#   1102
MDSERR  010113           275     795#
MERRS   010550           812#   1033
MEXERS  010513           811#   1491
MFLERR  010272           263     804#
MFMTER  006073           670#
MFOLWR  005630           242     663#
MFWDSK  005701           244     665#
MFWSKO  005732           246     666#
MGTSTA  005430           230     652#
MHCERR  010212           269     800#
MHCRC   010003           781#   1035
MHDERR  010255           264     803#
MHDRCP  005461           237     654#
MHFCRC  010052           785#   1041
MHNF    010024           783#   1039
MININC  003472           520#   1420*   1432
MINOUT  005607           240     662#
MISWI = 000000           102#   3172    3173    3181    3184    3187
MISWIW  013556          1184#   1222*   1245    1300    1941    1948    2751    2823    2848    2923    2947    3033    3037
                        3066    3073    3092    3096    3125    3132
MITEST= 100000           117#   1222
MNDRST  010352           266     807#   2621
MNEERR  010320           262     805#
MNOCLR  006423           687#
MNOINT  006354           685#   1527
MOPER   005527           657#   2581
```

```
MOPERR  010245    265    802#   1032
MORECE  003030    425#   1071*  1078   1081*  1086   1089   1148   1156*  1533*  2079*  2381*  2395   2407
                 2414*
MOUTIN  005570    241    661#
MPNAM   006255    679#   2643
MQUALS= 003760    147#
MREAD   005364    234    648#
MREADH  005375    232    649#
MRESKO  005766    245    667#
MREVSK  005650    243    664#
MRLFAL  010442    809#   1614
MRSLT   005536    658#   1033   1153   2620
MSEEK   005360    231    647#
MSPERR  010143    272    797#
MSTERR  010176    271    799#
MTMBS   006120    671#
MTOSLO  006316    683#   1513
MULOAD  005547    239    659#
MUNDEF  010375    808#   1577
MWDERR  010230    268    801#
MWGERR  010161    273    798#
MWORD   006310    682#   1080   1153   1155
MWRCHK  005405    229    650#
MWRITE  005416    233    651#
MWRSET  005513    235    656#
MWRTAB  010501    810#   2467
M40HDR  005477    248    655#
NEWCYL  003116    458#   1125   1675   1677*  1678   1679*  1682*  1o86   1688*  1689   1690*  1692   1701
                 1835    1843*  1845*  1858   1864   1872   1961   1962*  2090   2246   2528   2678*  2735
                 2739*   2740*  2758   2783   2787*  2788*  2805   2833   2837*  2838*  2855   2877*  2934
                 2938*   2939*  2954   2973*  2984*  2985   2987*  2989   2991*  2998   3011   3015   3036*
                 3039*   3047*  3053   3065*  3068*  3091*  3094*  3106*  3112   3124*  3127*
NOCLR = 000010    154#
NOCTLR  007645    774#   1360
NOERCT  003461    515#    921    993   1532*
NOIRPT= 000002    152#
NOOP  = 000100    127#
NOPWR   006176    675#   1331
NOTRDY  007703    775#   1372
NXMERR= 020000    165#
NXTHL   002322    253#   1283*  1297*  3095
NXTPAS  014036   1258#   1273   1275
OBUFF   004502    536#   1074   2334   2350   2352   2359   2382   2450
OFIN    003154    475#
OFINU   003156    476#
OFMID   003160    477#
OFMIDU  003162    478#
OFOUT   003164    479#
OFOUTU  003166    480#
OLDCYL  003114    457#   1674*  1839*  1960   1961*  2605
ONSWAP  020636   1837    1959#  2737   2785   2835   2936   3000   3055   3114
OPFLAG  003020    421#   1531*  1570*  1604   2078*  2274*  2380*  2391*  2428*  2464   2466*  2469*  2569*
                 2574*   2577*  2580*  2588   2590   2598   2603   2606   2798
OPIERR= 002000    170#   1026   1069   1514
OPMSGS  002240    228#   2581   2597   2601
OPR004  007425    762#
```

```
OPR1A   007376          759#
OPR1B   007402          760#
OPR12   007357          758#
ORIN    003170          481#
ORINU   003172          482#
ORMID   003174          483#
ORMIDU  003176          484#
OROUT   003200          485#
OROUTU  003202          486#
OUTINS= 000040          136#    147
O$APTS= 000000            8#     63
O$AU  = 000000            8#     63
O$BGNR= 000000            8#     63
O$BGNS= 000001            8#     56#     63
O$DU  = 000001            8#     56#     63
O$ERRT= 000000            8#     63
O$GNSW= 000001            8#     56#     63
O$POIN= 000001            8#     56#     63
O$SETU= 000000            8#     63    3219
PART1 = ****** U         59    691    741    787    825   1200   1306   1758   3175   3201
PART2 = 000001 G          2#     62    473    707   1203   1815   1966   2064   2233   2327   3171   3180   3192
                       3197   3205   3213
PASCNT  003246          508#
PASNEW  014044         1257   1261#
PASNUM  003454          512#   1236*  1261*
PATTBL  002374          278#   2337
PAT1    005102          278    538#
PAT10   005356          287    632#
PAT2    005104          279    539#
PAT3    005144          280    556#
PAT4    005204          281    573#
PAT5    005244          282    590#
PAT6    005252          283    594#
PAT7    005312          284    611#
PAT8    005314          285    613#
PAT9    005354          286    630#
PH65$   020240         1828   1878#
PNT   = 001000 G         92#
POSHDS  017732         1818#  2675   2728   2776   2820   2874   2920   2969
POSHDO  022030         2141   2143#
POSHSB  022024         2142#
POSHWT  022016         2140#
PRI   = 002000 G         92#
PRIOR = 000004           96#   3155
PRI00 = 000000 G         92#
PRI01 = 000040 G         92#
PRI02 = 000100 G         92#
PRI03 = 000140 G         92#
PRI04 = 000200 G         92#
PRI05 = 000240 G         92#
PRI06 = 000300 G         92#
PRI07 = 000340 G         92#
PSETNM  003456          513#   1243*  1264*  1265*  1268   1334   1365   1377   1494
PWCON   014314         1228   1254   1290   1300#
PWRFLG  003464          517#   1227*  1272   1274*  1318   1398   1400*
P2T03E  006507          708#   2669
```

P2T04E	006525	709#	2719											
P2T05E	006545	710#	2767											
P2T06E	006565	711#	2814											
P2T07E	006605	712#	2868											
P2T08E	006623	713#	2914											
P2T09E	006643	714#	2963											
P2T10E	006646	715#	3027											
P2T11E	006661	716#	3086											
P2T12E	006674	717#												
P2T13E	006706	718#												
P2T14E	006722	719#												
P2T15E	006743	720#												
P2T16E	006766	721#												
P2T17E	007007	722#												
P2T18E	007041	723#												
P2T19E	007063	724#												
RDALHD	022610	2263#	2753	2800	2850	2949								
RDDATA=	000114	125#	2430											
RDHEAD=	000110	123#	2007											
RDNOHR=	000116	126#												
RDYCHK	020276	1726	1892#	2001	2290	2440								
RDYWAI	022054	1849	2154#	2695	2745	2792	2843	2894	2943	3004	3043	3059	3102	3118
READRL	016024	1499#	1510	1521	1526	2298								
RELDWT=	040000	145#	1570	1604										
RESE3	010561	816#	1080	1153	1155	2629								
RESE4	010565	817#	1080	1153	1155	2630								
RESE5	010572	820#	2633											
RESE6	010577	821#	1089	2395										
RESPAR	003076	449#	2618	2650	2655									
RESTAR	014006	1230	1249#											
RESTBL	002334	260#	1060											
REVSKO=	001000	140#	147											
REVSKS=	000200	138#	147											
RLBA =	000002	157#	1500	1732*	2011*	2287*	2476*							
RLBAS	003042	431#	1152	1269	1305	1332	1356	1361	1374	1476	1492	1973	2276	2641
RLCS =	000000	156#	1011*	1013	1323*	1325	1357	1369*	1370	1391	1393*	1394	1519	1556
		1607	1733*	2288	2292*	2294	2477*	2682	2881					
RLCSR =	000000	162#	1499	1508	1596*	2012*								
RLDA =	000004	158#	1008*	1501	1595*	1731*	2010*	2286*	2475*					
RLDRV	003046	433#	1010	1152	1321	1332	1361	1367	1374	1393	1492	1592	1711	1973
		2005	2279	2444	2641									
RLMP =	000006	159#	1017	1502	2038	2039	2277	2474*						
RLVEC	003044	432#	1303	1397										
RORWOP=	020000	144#	2569	2577	2580	2606								
RPTOP	024514	925	937	951	965	980	1000	1100	1115	1136	1151	2559#		
RPTREM	025510	929	943	957	972	987	1063	1106	1127	1142	2641#			
RPTRES	025302	928	942	956	971	986	1061	1105	1126	1141	2615#			
RSTRT	013724	1236#	1251											
SAMSK =	000077	178#												
SBSFIL	003512	532#	1975*	2525										
SECQ	031142	3173	3199#											
SECWD	007461	766#	2608											
SEEK =	000106	122#	1710											
SEEKOP=	010000	143#	2569	2574	2603									
SEQMES	007514	770#	2563											
SETDON	014072	1248	1260	1265#										

```
SFTPRM  030776 G        3168#
SGNWD   007450           764#   2605
SKTMES  007073           725#
SPDSTA= 004000           207#   1566
SPTCOD  013554 G        1182#
SRTMES  007105           726#
SSINDX  003016           418#   1224*  1546   1550*  1643*  1661   1665*  1746*  1819   1823*  1878*  1893   1897*
                        1926*   1985   1989*  2052*  2068   2072*  2125*  2155   2159*  2190*  2206   2210*  2222*
                        2237    2241*  2251*  2264   2268*  2314*  2372   2376*  2396*  2432   2436*  2504*  2560
                        2566
STAMES  007537           771#   1066
STAMSK= 000007           199#   1601
STATE2  010604           822#
STATE3  010614           823#
STATE5  010624           824#
STOSTA= 010000           208#
SUBSTK  002420           291#   1548*  1549*  1663*  1664*  1821*  1822*  1895*  1896*  1987*  1988*  2070*  2071*
                        2157*   2158*  2208*  2209*  2239*  2240*  2266*  2267*  2374*  2375*  2434*  2435*  2564
SVCBGL= 000001            11#
SVCGBL= 000000             8#     58     63     66     67     90    224    645    875    920    934    948    962
                         977    992   1097   1111   1133   1146   1163   1171   1172   1182   1183   1199   1204
                        1212   1213   1352   1385   1386   1406   1415   2666   3148   3149   3168   3169   3219#
SVCINS= 000000             8#     12#    63     66     67    932    946    960    975    990   1033   1066   1080
                        1089   1095   1109   1131   1145   1152   1153   1155   1159   1172   1183   1204   1217
                        1218   1220   1221   1225   1226   1229   1230   1250   1251   1253   1254   1256   1257
                        1270   1271   1303   1304   1331   1332   1333   1334   1335   1338   1354   1360   1361
                        1363   1365   1372   1374   1376   1377   1378   1379   1388   1390   1397   1401   1402
                        1404   1408   1422   1423   1424   1429   1442   1443   1445   1449   1463   1479   1489
                        1490   1491   1492   1493   1494   1495   1578   1615   1628   1634   1739   1744   1830
                        1831   1832   1853   1869   1877   1912   1923   1972   1973   1974   2020   2031   2035
                        2043   2092   2104   2111   2173   2183   2187   2248   2301   2306   2395   2410   2468
                        2483   2489   2498   2502   2563   2564   2568   2581   2597   2601   2605   2608   2620
                        2629   2630   2633   2641   2643   2644   2645   2677   2688   2702   2705   2706   2713
                        2726   2730   2733   2734   2761   2763   2774   2778   2781   2782   2808   2810   2827
                        2829   2831   2832   2858   2860   2876   2887   2900   2901   2908   2927   2929   2932
                        2933   2957   2959   2993   2994   2995   3009   3010   3023   3048   3049   3050   3071
                        3072   3082   3107   3108   3109   3130   3131   3140   3149   3150   3151   3152   3153
                        3154   3155   3157   3169   3172   3173   3181   3182   3183   3184   3185   3186   3187
                        3188   3189   3191   3193   3195   3219
SVCSUB= 000001             8#     10#   2677   2730   2778   2829   2876   2929   2993   3048   3107
SVCTAG= 000000             8#     13#    932    946    960    975    990   1095   1109   1131   1145   1159   1179
                        1196   1338   1379   1404   1408   1463   1479   1877   2705   2713   2761   2763   2808
                        2810   2858   2860   2900   2908   2957   2959   3009   3023   3071   3082   3130   3140
                        3157   3195
SVCTST= 000001             8#      9#   2667   2718   2766   2813   2866   2913   2962   3026   3085
SWAPHD  020576          1948#   2707   2902   3019   3078   3136
S$LSYM= 010000             8#    932#   946#   960#   975#   990#  1095#  1109#  1131#  1145#  1159#  1179#  1196#
                        1338#  1379#  1404#  1408#  1463#  1479#  1830#  2705#  2713#  2761#  2763#  2808#  2810#
                        2858#  2860#  2900#  2908#  2957#  2959#  3009#  3023#  3071#  3082#  3130#  3140#  3157#
                        3195#
TAG     003500           523#
TBLSTR  003040           429#
TBT     002560           331#
TCERR   007624           773#   1089   2395
TEMP    003474           521#   1452*  1477*
TEMPO   003132           464#   1432*  1477*  2081
```

```
TEMP1    003134    465#   1657*  1659*  1729   2420*  2422*  2461   2472
TEMP2    003136    466#
TEMP3    003140    467#   1003*  1018*  1019   1064   1066
TEMP4    003142    468#   1537   1538*  1540   1541*  1543   1544*  1554   1580   1589   1636   1647*  1981*
                  1983*   1994   2045
TEMP5    003144    469#
TEMP6    003146    470#
TEMP7    003150    471#   2423*  2430*  2443
TEMP8    003152    472#
TIME     015256   1012    1418#  1597   1617   1734   1907   2013   2170   2478   2692   2891
TIM.US   003476    522#   1419*  1437*
TOSLOW=  000001    151#
TRPFLG   003462    516#   1353*  1358   1461*
TRPHAN   015576   1354    1388   1461#
TSTINT   016214   1531#   2670   2720   2768   2815   2869   2915   2964   3028   3087
TSTLAB   006501    690#   2568
TYPDR =  000006     97#   3154
T$ARGC=  000010     63#   1033#  1066#  1080#  1089#  1152#  1153#  1155#  1331#  1332#  1333#  1360#  1361#
                  1363#   1372#  1374#  1376#  1491#  1492#  1493#  1972#  1973#  1974#  2395#  2563#  2564#
                  2568#   2581#  2597#  2601#  2605#  2608#  2620#  2629#  2630#  2633#  2641#  2643#  2644#
                  2645#
T$CODE=  005052   3150#   3151#  3152#  3153#  3154#  3155#  3172#  3173#  3181#  3182#  3183#  3184#  3185#
                  3186#   3187#  3188#  3189#  3191#  3193#
T$ERRN=  001275     8#   1578#  1615#  1628#  1634#  1739#  1744#  1853#  1869#  1912#  1923#  2020#  2031#
                  2035#   2043#  2092#  2104#  2111#  2173#  2183#  2187#  2248#  2301#  2306#  2410#  2468#
                  2483#   2489#  2498#  2502#  2688#  2702#  2887#
T$EXCP=  000000   3151#   3152#  3153#  3155#  3183#  3186#  3189#  3191#  3193#
T$FLAG=  000040   2706#   2726#  2774#  2827#  2901#  2927#  3010#  3072#  3131#
T$GMAN=  000000     8#
T$HILI=  000377   3151#   3152#  3153#  3155#  3183#  3186#  3189#  3191#  3193#
T$LAST=  000001     8#   3219#
T$LOLI=  000001   3151#   3152#  3153#  3155#  3183#  3186#  3189#  3191#  3193#
T$LSYM=  010000     8#    932    946    960    975    990   1095   1109   1131   1145   1159   1179   1196
                  1338    1379   1404   1408   1463   1479   2705   2713   2761   2763   2808   2810   2858
                  2860    2900   2908   2957   2959   3009   3023   3071   3082   3130   3140   3157   3195
T$LTNO=  000011   3219#
T$NEST=  177777     8#     58#    65#    90#   218#   224#   634#   645#   866#   875#   920#   932#   934#
                   946#   948#   960#   962#   975#   977#   990#   992#  1095#  1097#  1109#  1111#  1131#
                  1133#   1145#  1146#  1159#  1160#  1163#  1167#  1171#  1172#  1179#  1180#  1182#  1183#
                  1196#   1197#  1199#  1206#  1212#  1213#  1338#  1339#  1352#  1379#  1385#  1386#  1404#
                  1406#   1408#  1410#  1415#  1457#  1463#  1465#  1479#  1830#  1877#  2659#  2666#  2667#
                  2677#   2705#  2713#  2718#  2730#  2761#  2763#  2766#  2778#  2808#  2810#  2813#  2829#
                  2858#   2860#  2866#  2876#  2900#  2908#  2913#  2929#  2957#  2959#  2962#  2993#  3009#
                  3023#   3026#  3048#  3071#  3082#  3085#  3107#  3130#  3140#  3142#  3148#  3149#  3157#
                  3165#   3168#  3169#  3182   3185   3188   3195#  3217#
T$NS0 =  000000    58#    65     90#   218    224#   634    645#   866    875#  1160   1163#  1167   1171#
                  1180    1182#  1197   1199#  1206   1212#  1339   1352#  1379   1385#  1410   1415#  2659
                  2666#   3142   3148#  3165   3168#  3217
T$NS1 =  000005    920#    932    934#   946    948#   960    962#   975    977#   990    992#  1095   1097#
                  1109    1111#  1131   1133#  1145   1146#  1159   1172#  1179   1183#  1196   1213#  1338
                  1386#   1404   1406#  1408   1457#  1463   1465#  1479   1830#  1877   2667#  2713   2718#
                  2763    2766#  2810   2813#  2860   2866#  2908   2913#  2959   2962#  3023   3026#  3082
                  3085#   3140   3149#  3157   3169#  3182   3185   3188   3195
T$NS2 =  000002   2677#   2705   2730#  2761   2778#  2808   2829#  2858   2876#  2900   2929#  2957   2993#
                  3009    3048#  3071   3107#  3130
T$PTNU=  000000     8#
```

```
T$SAVL= 177777          8#
T$SEGL= 177777          8#   1830#  1877#
T$SEK0= 010000       1830#   1877
T$SUBN= 000001          8#   2667#  2677#  2718#  2730#  2766#  2778#  2813#  2829#  2866#  2876#  2913#  2929#
             2962#   2993#  3026#  3048#  3085#  3107#
T$TAGL= 177777          8#
T$TAGN= 010047          8#    920#   934#   948#   962#   977#   992#  1097#  1111#  1133#  1146#  1163#  1172#
          1183#   1213#  1352#  1386#  1406#  1457#  1465#  2667#  2677#  2718#  2730#  2766#  2778#
          2813#   2829#  2866#  2876#  2913#  2929#  2962#  2993#  3026#  3048#  3085#  3107#  3149#
          3169#
T$TEMP= 000000         65#    218#   634#   866#   932#   946#   960#   975#   990#  1095#  1109#  1131#  1145#
          1159#   1160#  1167#  1179#  1180#  1196#  1197#  1204#  1206#  1338#  1339#  1379#  1404#
          1408#   1410#  1463#  1479#  1877#  2659#  2705#  2706#  2713#  2726#  2761#  2763#  2774#
          2808#   2810#  2827#  2858#  2860#  2900#  2901#  2908#  2927#  2957#  2959#  3009#  3010#
          3023#   3071#  3072#  3082#  3130#  3131#  3140#  3142#  3150#  3151#  3152#  3153#  3154#
          3155#   3157#  3165#  3172#  3173#  3181#  3183#  3184#  3186#  3187#  3189#  3191#  3193#
          3195#   3217#
T$TEST= 000011          8#   2667#  2677   2718#  2730   2766#  2778   2813#  2829   2866#  2876   2913#  2929
          2962#   2993   3026#  3048   3085#  3107   3219
T$TSTM= 177777          8#    932    946    960    975    990   1033   1066   1080   1089   1095   1109   1131
          1145    1152   1153   1155   1159   1217   1220   1221   1225   1229   1250   1253   1256
          1270    1303   1304   1331   1332   1333   1334   1335   1338   1354   1360   1361   1363
          1365    1372   1374   1376   1377   1378   1379   1388   1390   1397   1401   1402   1404
          1408    1422   1442   1489   1491   1492   1493   1494   1495   1578   1615   1628   1634
          1739    1744   1830   1831   1853   1869   1877   1912   1923   1972   1973   1974   2020
          2031    2035   2043   2092   2104   2111   2173   2183   2187   2248   2301   2306   2395
          2410    2468   2483   2489   2498   2502   2563   2564   2568   2581   2597   2601   2605
          2608    2620   2629   2630   2633   2641   2643   2644   2645   2677   2688   2702   2705
          2706    2713   2726   2730   2733   2761   2763   2774   2778   2781   2808   2810   2827
          2829    2831   2858   2860   2876   2887   2900   2901   2908   2927   2929   2932   2957
          2959    2993   2994   3009   3010   3023   3048   3049   3071   3072   3082   3107   3108
          3130    3131   3140
T$TSTS= 000001          8#   2667#  2718#  2766#  2813#  2866#  2913#  2962#  3026#  3085#
T$$AUT= 010016       1352#   1379
T$$CLE= 010017       1386#   1404
T$$DU = 010020       1406#   1408
T$$HAR= 010045       3149#   3157
T$$HW = 010013       1172#   1179
T$$INI= 010015       1213#   1338
T$$MSG= 010011        920#    932    934#   946    948#   960    962#   975    977#   990    992#  1095   1097#
          1109    1111#  1131   1133#  1145   1146#  1159
T$$PRO= 010012       1163#
T$$SEG= 010000       1830#   1877#
T$$SOF= 010046       3169#   3195
T$$SRV= 010022       1457#   1463   1465#  1479
T$$SUB= 010044       2677#   2705   2730#  2761   2778#  2808   2829#  2858   2876#  2900   2929#  2957   2993#
          3009    3048#  3071   3107#  3130
T$$SW = 010014       1183#   1196
T$$TES= 010043       2667#   2706   2713   2718#  2726   2763   2766#  2774   2810   2813#  2827   2860   2866#
          2901    2908   2913#  2927   2959   2962#  3010   3023   3026#  3072   3082   3085#  3131
          3140
T.BA    003062        440#   1472*  1500*  2645
T.CS    003060        439#   1004   1023   1067   1069   1471*  1499*  1514   1562   1572   1620   1626   1742
          1851    1905   1916   1921   2016   2024   2033   2166   2177   2185   2304   2485   2493
          2500    2645
T.DA    003064        441#   1473*  1501*  2645
```

```
T.DRIV   002312          249#   1279*  1281   1680   1705   2975
T.MP     003066          442#   1021   1474*  1502*  1564   1566   1600   1622   2142   2645
T.STAT   003074          447#   1103   1600*  1601*
T1       025774 G       1204    2067#
T1.1     026030         2677#
T1965$   026214         2672    2676   2711#
T197$    026020         2674#   2709
T2       026216 G       1204    2718#
T2.1     026266         2730#
T206$    026270         2731#   2759
T2065$   026424         2722    2729   2762#
T216$    026500         2779#   2806
T2165$   026634         2770    2777   2809#
T2265$   027060         2817    2821   2859#
T227$    026726         2830#   2856
T233$    027106         2873#   2904
T2365$   027266         2871    2875   2906#
T2465$   027514         2917    2921   2958#
T247$    027360         2930#   2955
T25TBL   002444          303#   2974
T25TB2   002472          316#   2977
T2517$   030014         2983    3019#
T256$    027554         2971#   3021
T2565$   030024         2966    2970   2972   3020   3022#
T257$    027626         2984#   3014   3016
T258$    027574         2975#
T2588$   027610         2976    2979#  3018
T266$    030052         3032#   3080
T2665$   030322         3030    3041   3044   3046   3079   3081#
T267$    030134         3045#   3077
T275$    030350         3091#   3138
T276$    030434         3104#   3135
T2765$   030620         3089    3100   3103   3105   3137   3139#
T3       026426 G       1204    2766#
T3.1     026476         2778#
T33TBL   002520          330#
T4       026636 G       1204    2813#
T4.1     026724         2829#
T5       027062 G       1204    2866#
T5.1     027120         2876#
T6       027270 G       1204    2913#
T6.1     027356         2929#
T7       027516 G       1204    2962#
T7.1     027670         2993#
T8       030026 G       1204    3026#
T8.1     030146         3048#
T9       030324 G       1204    3085#
T9.1     030446         3107#
UAM    = 000200 G         92#
ULOAD  = 000010          134#
UNDTST   007412          761#
UNXERR   006464          689#   1630
VALDES   007127          727#
VCNRST   006443          688#   1624
VCSTAT=  001000          205#   1622
VECMSG   030720         3152    3160#
```

```
VECT   = 000002          95#   3152
VERHDR   021460        2067#   2755   2802   2852   2951
VERPOS   022466        2236#   2748   2795   2845   2897   2945   3006   3061   3120
WAITIN   016056        1506#   1632   1737   2041   2299   2481
WCMSK  = 017777         191#
WCRNG  = 160000         192#
WDESTA= 100000          211#   1566
WGESTA= 002000          206#
WLSTAT= 020000          209#
WRTSWI   003036         428#
WTDATA= 000112          124#   2423
XDELAY   003466         518#   1012*  1420   1421*  1425*  1430*  1477*  1597*  1617*  1734*  1907*  2013*  2170*
                       2478*   2692*  2891*
XRDHD    021024        1983#   2213
XRDHDC   021014        1981#
XRDHDG   021030        1982    1984#
XREAD    023646        2430#
XREADG   023654        2429    2431#
XSEEK    017160        1659#   1846   2679   2742   2789   2840   2878   2940   3001   3040   3056   3099   3115
XSEEKT   017150        1657#
XSEEK1   017164        1658    1660#
XTIME    015422        1328    1396   1436#  1518   1558   1574   1609   1918   2179
XWRITE   023606        2422#
XWRITT   023576        2420#
XWRIT1   023612        2421    2423#
X$ALWA= 000000           8#
X$FALS= 000040           8#    3182   3185   3188
X$OFFS= 000400           8#    3182   3185   3188
X$TRUE= 000020           8#
YDELAY   003470         519#   1328*  1396*  1438   1439*  1440*  1441*  1446*  1450*  1477*  1518*  1558*  1574*
                       1609*   1918*  2179*
.      = 031342           5#     66#   330#   331#   511#   532#   533#   535#   536#   869#  1424   1429   1445
                       1449    2706   2726   2774   2827   2901   2927   3010   3072   3131   3166#  3182   3185
                       3188    3216#
```

ABORTW	30#	1477													
BCOMPL	1251	1254	1257	1271	1423	1490									
BGNAUT	1352														
BGNCLN	1386														
BGNDU	1406														
BGNHRD	3149														
BGNHW	1172														
BGNINI	1213														
BGNMOD	58	90	224	645	875	1171	1182	1199	1212	1385	1415	2666	3148	3168	
BGNMSG	920	934	948	962	977	992	1097	1111	1133	1146					
BGNPRO	1163														
BGNSEG	1830														
BGNSFT	3169														
BGNSRV	1457	1465													
BGNSUB	2677	2730	2778	2829	2876	2929	2993	3048	3107						
BGNSW	1183														
BGNTST	2667	2718	2766	2813	2866	2913	2962	3026	3085						
BNCOMP	1218	1226	1230	1443	1832	2734	2782	2832	2933	2995	3050	3109			
BRESET	1221	1402													
CLOCK	1217														
CLRVEC	1378	1397	1401												
DELAY	1424	1429	1445	1449											
DESCRI	66														
DEVTYP	67														
DISPAT	1204														
DOCLN	1335	1495													
DODU	1334	1365	1377	1494											
ENDAUT	1379														
ENDCLN	1404														
ENDDU	1408														
ENDHRD	3157														
ENDHW	1179														
ENDINI	1338														
ENDMOD	65	218	634	866	1160	1180	1197	1206	1339	1410	2659	3142	3165	3217	
ENDMSG	932	946	960	975	990	1095	1109	1131	1145	1159					
ENDPRO	1167														
ENDSEG	1877														
ENDSFT	3195														
ENDSRV	1463	1479													
ENDSUB	2705	2761	2808	2858	2900	2957	3009	3071	3130						
ENDSW	1196														
ENDTST	2713	2763	2810	2860	2908	2959	3023	3082	3140						
EQUALS	92														
ERRHRD	1578	1615	1628	1634	1739	1744	1853	1869	1912	1923	2020	2031	2035	2043	2092
	2104	2111	2173	2183	2187	2248	2301	2306	2410	2468	2483	2489	2498	2502	2688
	2702	2887													
ESCAPE	2706	2901	3010	3072	3131										
EXIT	2726	2774	2827	2927											
GETTIM	37#														
GPHARD	1270														
GPRMA	3151	3152													
GPRMD	3153	3155	3183	3186	3189	3191	3193								
GPRML	3150	3154	3172	3173	3181	3184	3187								
HEADER	63														
INLOOP	1489	1831	2733	2781	2831	2932	2994	3049	3108						
LASTAD	3219														

M$BYTE	63#														
M$CHEC	2726#	2774#	2827#	2927#											
M$CNTO	3150#	3151#	3152#	3153#	3154#	3155#	3172#	3173#	3181#	3183#	3184#	3186#	3187#	3189#	3191#
	3193#														
M$COUN	1033#	1066#	1080#	1089#	1152#	1153#	1155#	1331#	1332#	1333#	1360#	1361#	1363#	1372#	1374#
	1376#	1491#	1492#	1493#	1972#	1973#	1974#	2395#	2563#	2564#	2568#	2581#	2597#	2601#	2605#
	2608#	2620#	2629#	2630#	2633#	2641#	2643#	2644#	2645#						
M$DATA	63#	66#	67#												
M$DECR	65#	218#	634#	866#	932#	946#	960#	975#	990#	1095#	1109#	1131#	1145#	1159#	1160#
	1167#	1179#	1180#	1196#	1197#	1206#	1338#	1339#	1379#	1404#	1408#	1410#	1463#	1479#	1877#
	2659#	2705#	2713#	2761#	2763#	2808#	2810#	2858#	2860#	2900#	2908#	2957#	2959#	3009#	3023#
	3071#	3082#	3130#	3140#	3142#	3157#	3165#	3195#	3217#						
M$DEFA	3150#	3151#	3152#	3153#	3154#	3155#	3172#	3173#	3181#	3183#	3184#	3186#	3187#	3189#	3191#
	3193#														
M$ENDE	65#	218#	634#	866#	932#	946#	960#	975#	990#	1095#	1109#	1131#	1145#	1159#	1160#
	1179#	1180#	1196#	1197#	1206#	1338#	1339#	1379#	1404#	1408#	1410#	1463#	1479#	1877#	2659#
	2705#	2713#	2761#	2763#	2808#	2810#	2858#	2860#	2900#	2908#	2957#	2959#	3009#	3023#	3071#
	3082#	3130#	3140#	3142#	3157#	3165#	3195#	3217#							
M$ERRI	1578#	1615#	1628#	1634#	1739#	1744#	1853#	1869#	1912#	1923#	2020#	2031#	2035#	2043#	2092#
	2104#	2111#	2173#	2183#	2187#	2248#	2301#	2306#	2410#	2468#	2483#	2489#	2498#	2502#	2688#
	2702#	2887#													
M$ESCA	2706#	2901#	3010#	3072#	3131#										
M$ESCS	2706#	2901#	3010#	3072#	3131#										
M$EXCP	3151#	3152#	3153#	3155#	3183#	3186#	3189#	3191#	3193#						
M$EXIT	2726#	2774#	2827#	2927#											
M$EXSE	2726#	2774#	2827#	2927#											
M$EXTJ	2726#	2774#	2827#	2927#											
M$GEN	58#	63#	66#	67#	90#	224#	645#	875#	920#	932#	934#	946#	948#	960#	962#
	975#	977#	990#	992#	1095#	1097#	1109#	1111#	1131#	1133#	1145#	1146#	1159#	1163#	1171#
	1172#	1179#	1182#	1183#	1196#	1199#	1204#	1212#	1213#	1338#	1352#	1379#	1385#	1386#	1404#
	1406#	1408#	1415#	1457#	1463#	1465#	1479#	1877#	2666#	2667#	2677#	2705#	2713#	2718#	2730#
	2761#	2763#	2766#	2778#	2808#	2810#	2813#	2829#	2858#	2860#	2866#	2876#	2900#	2908#	2913#
	2929#	2957#	2959#	2962#	2993#	3009#	3023#	3026#	3048#	3071#	3082#	3085#	3107#	3130#	3140#
	3148#	3149#	3157#	3168#	3169#	3195#	3219#								
M$GETS	65#	218#	634#	866#	932#	946#	960#	975#	990#	1095#	1109#	1131#	1145#	1159#	1160#
	1167#	1179#	1180#	1196#	1197#	1206#	1338#	1339#	1379#	1404#	1408#	1410#	1463#	1479#	1877#
	2659#	2705#	2713#	2761#	2763#	2808#	2810#	2858#	2860#	2900#	2908#	2957#	2959#	3009#	3023#
	3071#	3082#	3130#	3140#	3142#	3157#	3165#	3182#	3185#	3188#	3195#	3217#			
M$GETT	2706#	2726#	2774#	2827#	2901#	2927#	3010#	3072#	3131#	3182#	3185#	3188#			
M$GNGB	58#	63#	66#	67#	90#	224#	645#	875#	920#	934#	948#	962#	977#	992#	1097#
	1111#	1133#	1146#	1163#	1171#	1172#	1182#	1183#	1199#	1204#	1212#	1213#	1352#	1385#	1386#
	1406#	1415#	1457#	1465#	2666#	3148#	3149#	3168#	3169#	3219#					
M$GNIN	63#	66#	67#	932#	946#	960#	975#	990#	1033#	1066#	1080#	1089#	1095#	1109#	1131#
	1145#	1152#	1153#	1155#	1159#	1172#	1183#	1204#	1217#	1218#	1220#	1221#	1225#	1226#	1229#
	1230#	1250#	1251#	1253#	1254#	1256#	1257#	1270#	1271#	1303#	1304#	1331#	1332#	1333#	1334#
	1335#	1338#	1354#	1360#	1361#	1363#	1365#	1372#	1374#	1376#	1377#	1378#	1379#	1388#	1390#
	1397#	1401#	1402#	1404#	1408#	1422#	1423#	1424#	1429#	1442#	1443#	1445#	1449#	1463#	1479#
	1489#	1490#	1491#	1492#	1493#	1494#	1495#	1578#	1615#	1628#	1634#	1739#	1744#	1830#	1831#
	1832#	1853#	1869#	1877#	1912#	1923#	1972#	1973#	1974#	2020#	2031#	2035#	2043#	2092#	2104#
	2111#	2173#	2183#	2187#	2248#	2301#	2306#	2395#	2410#	2468#	2483#	2489#	2498#	2502#	2563#
	2564#	2568#	2581#	2597#	2601#	2605#	2608#	2620#	2629#	2630#	2633#	2641#	2643#	2644#	2645#
	2677#	2688#	2702#	2705#	2706#	2713#	2726#	2730#	2733#	2734#	2761#	2763#	2774#	2778#	2781#
	2782#	2808#	2810#	2827#	2829#	2831#	2832#	2858#	2860#	2876#	2887#	2900#	2901#	2908#	2927#
	2929#	2932#	2933#	2957#	2959#	2993#	2994#	2995#	3009#	3010#	3023#	3048#	3049#	3050#	3071#
	3072#	3082#	3107#	3108#	3109#	3130#	3131#	3140#	3149#	3150#	3151#	3152#	3153#	3154#	3155#
	3157#	3169#	3172#	3173#	3181#	3182#	3183#	3184#	3185#	3186#	3187#	3188#	3189#	3191#	3193#

	3195#	3219#													
M$GNLS	1877#														
M$GNSU	2677#	2730#	2778#	2829#	2876#	2929#	2993#	3048#	3107#						
M$GNTA	932#	946#	960#	975#	990#	1095#	1109#	1131#	1145#	1159#	1179#	1196#	1338#	1379#	1404#
	1408#	1463#	1479#	2705#	2713#	2761#	2763#	2808#	2810#	2858#	2860#	2900#	2908#	2957#	2959#
	3009#	3023#	3071#	3082#	3130#	3140#	3157#	3195#							
M$GNTE	2667#	2718#	2766#	2813#	2866#	2913#	2962#	3026#	3085#						
M$HAPT	63#														
M$HNAP	63#														
M$INCR	58#	90#	224#	645#	875#	920#	932#	934#	946#	948#	960#	962#	975#	977#	990#
	992#	1033#	1066#	1080#	1089#	1095#	1097#	1109#	1111#	1131#	1133#	1145#	1146#	1152#	1153#
	1155#	1159#	1163#	1171#	1172#	1182#	1183#	1199#	1212#	1213#	1217#	1220#	1221#	1225#	1229#
	1250#	1253#	1256#	1270#	1303#	1304#	1331#	1332#	1333#	1334#	1335#	1338#	1352#	1354#	1360#
	1361#	1363#	1365#	1372#	1374#	1376#	1377#	1378#	1379#	1385#	1386#	1388#	1390#	1397#	1401#
	1402#	1404#	1406#	1408#	1415#	1422#	1442#	1457#	1465#	1489#	1491#	1492#	1493#	1494#	1495#
	1578#	1615#	1628#	1634#	1739#	1744#	1830#	1831#	1853#	1869#	1877#	1912#	1923#	1972#	1973#
	1974#	2020#	2031#	2035#	2043#	2092#	2104#	2111#	2173#	2183#	2187#	2248#	2301#	2306#	2395#
	2410#	2468#	2483#	2489#	2498#	2502#	2563#	2564#	2568#	2581#	2597#	2601#	2605#	2608#	2620#
	2629#	2630#	2633#	2641#	2643#	2644#	2645#	2666#	2667#	2677#	2688#	2702#	2705#	2706#	2713#
	2718#	2726#	2730#	2733#	2761#	2763#	2766#	2774#	2778#	2781#	2808#	2810#	2813#	2827#	2829#
	2831#	2858#	2860#	2866#	2876#	2887#	2900#	2901#	2908#	2913#	2927#	2929#	2932#	2957#	2959#
	2962#	2993#	2994#	3009#	3010#	3023#	3026#	3048#	3049#	3071#	3072#	3082#	3085#	3107#	3108#
	3130#	3131#	3140#	3148#	3149#	3168#	3169#								
M$LDR0	1217#	1220#	1225#	1229#	1250#	1253#	1256#	1270#	1304#	1334#	1365#	1377#	1378#	1390#	1397#
	1401#	1494#													
M$MCHI	8#														
M$MCLO	8#														
M$POP	65#	218#	634#	866#	932#	946#	960#	975#	990#	1095#	1109#	1131#	1145#	1159#	1160#
	1167#	1179#	1180#	1196#	1197#	1206#	1338#	1339#	1379#	1404#	1408#	1410#	1463#	1479#	1877#
	2659#	2705#	2713#	2761#	2763#	2808#	2810#	2858#	2860#	2900#	2908#	2957#	2959#	3009#	3023#
	3071#	3082#	3130#	3140#	3142#	3157#	3165#	3195#	3217#						
M$PRIN	1033#	1066#	1080#	1089#	1152#	1153#	1155#	1331#	1332#	1333#	1360#	1361#	1363#	1372#	1374#
	1376#	1491#	1492#	1493#	1972#	1973#	1974#	2395#	2563#	2564#	2568#	2581#	2597#	2601#	2605#
	2608#	2620#	2629#	2630#	2633#	2641#	2643#	2644#	2645#						
M$PUSH	58#	90#	224#	645#	875#	920#	934#	948#	962#	977#	992#	1097#	1111#	1133#	1146#
	1163#	1171#	1172#	1182#	1183#	1199#	1212#	1213#	1352#	1385#	1386#	1406#	1415#	1457#	1465#
	1830#	2666#	2667#	2677#	2718#	2730#	2766#	2778#	2813#	2829#	2866#	2876#	2913#	2929#	2962#
	2993#	3026#	3048#	3085#	3107#	3148#	3149#	3168#	3169#						
M$PUT	1033#	1066#	1080#	1089#	1152#	1153#	1155#	1303#	1331#	1332#	1333#	1354#	1360#	1361#	1363#
	1372#	1374#	1376#	1388#	1491#	1492#	1493#	1972#	1973#	1974#	2395#	2563#	2564#	2568#	2581#
	2597#	2601#	2605#	2608#	2620#	2629#	2630#	2633#	2641#	2643#	2644#	2645#			
M$PUT1	1033#	1066#	1080#	1089#	1152#	1153#	1155#	1303#	1331#	1332#	1333#	1354#	1360#	1361#	1363#
	1372#	1374#	1376#	1388#	1491#	1492#	1493#	1972#	1973#	1974#	2395#	2563#	2564#	2568#	2581#
	2597#	2601#	2605#	2608#	2620#	2629#	2630#	2633#	2641#	2643#	2644#	2645#			
M$RADI	3150#	3151#	3152#	3153#	3154#	3155#	3172#	3173#	3181#	3183#	3184#	3186#	3187#	3189#	3191#
	3193#														
M$RNR0	1217#	1270#													
M$SETS	58#	90#	224#	645#	875#	920#	934#	948#	962#	977#	992#	1097#	1111#	1133#	1146#
	1163#	1171#	1172#	1182#	1183#	1199#	1212#	1213#	1352#	1385#	1386#	1406#	1415#	1457#	1465#
	1830#	2666#	2667#	2677#	2718#	2730#	2766#	2778#	2813#	2829#	2866#	2876#	2913#	2929#	2962#
	2993#	3026#	3048#	3085#	3107#	3148#	3149#	3168#	3169#						
M$SVC	932#	946#	960#	975#	990#	1033#	1066#	1080#	1089#	1095#	1109#	1131#	1145#	1152#	1153#
	1155#	1159#	1217#	1220#	1221#	1225#	1229#	1250#	1253#	1256#	1270#	1303#	1304#	1331#	1332#
	1333#	1334#	1335#	1338#	1354#	1360#	1361#	1363#	1365#	1372#	1374#	1376#	1377#	1378#	1379#
	1388#	1390#	1397#	1401#	1402#	1404#	1408#	1422#	1442#	1489#	1491#	1492#	1493#	1494#	1495#
	1578	1615	1628	1634	1739	1744	1830#	1831#	1853	1869	1877#	1912	1923	1972#	1973#

```
          1974#   2020    2031    2035    2043    2092    2104    2111    2173    2183    2187    2248    2301    2306    2395#
          2410    2468    2483    2489    2498    2502    2563#   2564#   2568#   2581#   2597#   2601#   2605#   2608#   2620#
          2629#   2630#   2633#   2641#   2643#   2644#   2645#   2677#   2688    2702    2705#   2706#   2713#   2726#   2730#
          2733#   2761#   2763#   2774#   2778#   2781#   2808#   2810#   2827#   2829#   2831#   2858#   2860#   2876#   2887
          2900#   2901#   2908#   2927#   2929#   2932#   2957#   2959#   2993#   2994#   3009#   3010#   3023#   3048#   3049#
          3071#   3072#   3082#   3107#   3108#   3130#   3131#   3140#
M$TLAB     932#    946#    960#    975#    990#   1033#   1066#   1080#   1089#   1095#   1109#   1131#   1145#   1152#   1153#
          1155#   1159#   1217#   1220#   1221#   1225#   1229#   1250#   1253#   1256#   1270#   1303#   1304#   1331#   1332#
          1333#   1334#   1335#   1338#   1354#   1360#   1361#   1363#   1365#   1372#   1374#   1376#   1377#   1378#   1379#
          1388#   1390#   1397#   1401#   1402#   1404#   1408#   1422#   1442#   1489#   1491#   1492#   1493#   1494#   1495#
          1578#   1615#   1628#   1634#   1739#   1744#   1830#   1831#   1853#   1869#   1877#   1912#   1923#   1972#   1973#
          1974#   2020#   2031#   2035#   2043#   2092#   2104#   2111#   2173#   2183#   2187#   2248#   2301#   2306#   2395#
          2410#   2468#   2483#   2489#   2498#   2502#   2563#   2564#   2568#   2581#   2597#   2601#   2605#   2608#   2620#
          2629#   2630#   2633#   2641#   2643#   2644#   2645#   2677#   2688#   2702#   2705#   2706#   2713#   2726#   2730#
          2733#   2761#   2763#   2774#   2778#   2781#   2808#   2810#   2827#   2829#   2831#   2858#   2860#   2876#   2887#
          2900#   2901#   2908#   2927#   2929#   2932#   2957#   2959#   2993#   2994#   3009#   3010#   3023#   3048#   3049#
          3071#   3072#   3082#   3107#   3108#   3130#   3131#   3140#
M$TSTL     932#    946#    960#    975#    990#   1033#   1066#   1080#   1089#   1095#   1109#   1131#   1145#   1152#   1153#
          1155#   1159#   1217#   1220#   1221#   1225#   1229#   1250#   1253#   1256#   1270#   1303#   1304#   1331#   1332#
          1333#   1334#   1335#   1338#   1354#   1360#   1361#   1363#   1365#   1372#   1374#   1376#   1377#   1378#   1379#
          1388#   1390#   1397#   1401#   1402#   1404#   1408#   1422#   1442#   1489#   1491#   1492#   1493#   1494#   1495#
          1578#   1615#   1628#   1634#   1739#   1744#   1830#   1831#   1853#   1869#   1877#   1912#   1923#   1972#   1973#
          1974#   2020#   2031#   2035#   2043#   2092#   2104#   2111#   2173#   2183#   2187#   2248#   2301#   2306#   2395#
          2410#   2468#   2483#   2489#   2498#   2502#   2563#   2564#   2568#   2581#   2597#   2601#   2605#   2608#   2620#
          2629#   2630#   2633#   2641#   2643#   2644#   2645#   2677#   2688#   2702#   2705#   2706#   2713#   2726#   2730#
          2733#   2761#   2763#   2774#   2778#   2781#   2808#   2810#   2827#   2829#   2831#   2858#   2860#   2876#   2887#
          2900#   2901#   2908#   2927#   2929#   2932#   2957#   2959#   2993#   2994#   3009#   3010#   3023#   3048#   3049#
          3071#   3072#   3082#   3107#   3108#   3130#   3131#   3140#
M$WORD      63#   1204#   1578#   1615#   1628#   1634#   1739#   1744#   1853#   1869#   1912#   1923#   2020#   2031#   2035#
          2043#   2092#   2104#   2111#   2173#   2183#   2187#   2248#   2301#   2306#   2410#   2468#   2483#   2489#   2498#
          2502#   2688#   2702#   2726#   2774#   2827#   2887#   2927#   3150#   3151#   3152#   3153#   3154#   3155#   3172#
          3173#   3181#   3182#   3183#   3184#   3185#   3186#   3187#   3188#   3189#   3191#   3193#   3219
M$XFER    3182#   3185#   3188#
POINTE      56
PRINTB    1033    1066    1080    1089    1152    1153    1155    2395    2563    2564    2568    2581    2597    2601    2605
          2608    2620    2629    2630    2633    2641    2643    2644    2645
PRINTF    1331    1332    1333    1360    1361    1363    1372    1374    1376    1491    1492    1493    1972    1973    1974
READBU    1422    1442
READEF    1225    1229    1250    1253    1256
SETPRI    1220    1304    1390
SETVEC    1303    1354    1388
STCLK      42#
SVC         6#       8
WAITMS     25#    1328    1396    1518    1558    1574    1609    1918    2179
WAITUS     20#    1012    1597    1617    1734    1907    2013    2170    2478    2692    2891
XFER      2726#   2774#   2827#   2927#
XFERF     3182    3185    3188

. ABS.  031342     000

 ERRORS DETECTED:  0

 CZRLJB,CZRLJB/CRF=SVC33/ML,CZRLJB.MAC
 RUN-TIME: 84 89 10 SECONDS
```

RUN-TIME RATIO: 485/184=2.6
CORE USED: 16K (31 PAGES)