

Rituo 620 type

Multifunctional section function of engraving machine

X1: is forward running,

X2: Multi-step speed command 1,

X3: Multi-step speed command 2,

X4: Multi-stage speed command 3.

X2, X3, X4 can be freely combined to form 7 speeds. External Weihong card X2, X3, X4 correspond to low, medium and high speed respectively.

If you need an external analog signal to control the frequency, change P-003 to 2, and connect the analog signal to the GND and FV port.

The factory reset is to change P-001 to 11111.

The special parameter values of the restoration engraving machine are:

P-001 changed to 22222

The following figure is a special parameter table for the 620 series inverter engraving machine. The following parameters have been set before leaving the factory。

Parameters Table	Parameter	Changed value
P-002	Run	1 terminal operation
P-003	Frequency	0 keyboard frequency
P-005	Upper	400.00
P-007	acceleration	20.00
P-008	deceleration	20.00
P-009	Keyboard	00.00
P-101	Multi-speed	50.00
P-102	Multi-speed	100.00
P-103	Multi-speed	150.00
P-104	Multi-speed	250.00

P-105	Multi-speed	300.00
P-106	Multi-speed	350.00
P-107	Multi-speed frequency 7	400.00
P-202	FV Analog maximum frequency	400.00
P-302	X2Input terminal function	11Multi-speed frequency1
P-303	X3Input terminal function	12Multi-speed frequency2
P-304	X4Input terminal function	13Multi-speed frequency3
P-318	Power-on terminal operation protection	0 Allow to run
P-402	Motor rated frequency	400.00
P-414	V/F curve selection	4 Constant torque 1 V/F curve