



Business
Success

Products
and
Services

Resources

FAQ

Contact

Log in

Discontinuation Notice of Compliancy Report function

Starting December 2025, the **Compliancy Report issue category** when generating a new support request will no longer be available.



Configuring the Threat Suppression Engine (TSE) Settings from the SMS

Product / Version includes:

TippingPoint SMS All



Last updated: 2024/07/26



Solution ID: KA-0017153



Category: Configure , Troubleshoot , Deploy

Summary


The TSE is a line-speed hardware engine that contains all the functions needed for Intrusion Prevention, including IP defragmentation, TCP flow reassembly, statistical analysis, traffic shaping, flow blocking, flow state tracking, and application-layer parsing of over 170 network protocols.

The TSE reconstructs and inspects flow payloads by parsing the traffic at the application layer. As each new packet of the traffic flow arrives, the engine re-evaluates the traffic for malicious content. The instant the engine detects malicious traffic, it blocks all current and all subsequent packets pertaining to the traffic flow. The block of the traffic and packets ensures that the attack never reaches its destination.

You can configure the global settings for the Threat Suppression Engine (TSE). These options include the following:

- **Connection Table Timeout:** The value for the global connection table timeout. This value is 30-1800 seconds. This value applies to all blocked streams in the connection table and determines the time that elapses before that connection is cleared from the connection table. Before that period of time elapses, any incoming packets for that stream are blocked at the box. After the connection is cleared, the incoming connection is all to the blocked list. Separate settings are available to

Please [log in](#) to initiate the conversation.



- **Trusted Streams:** Specifies the global timeout interval for the trust table. This value determines the time interval that elapses before the trusted connection is cleared from the trust table.
- **Asymmetric Network:** The dynamic sharing and bandwidth used to increase network traffic performance. If you configure the device through the TSE configuration for an asymmetric network, the SYN flood detection or DDoS filters will be disabled. The TSE will not see both sides of a TCP connection.
- **Quarantine:** Specifies the global timeout for the quarantine table. For quarantined hosts in the quarantine table, this value determines the time interval that elapses before the host is cleared from the table. After the host is cleared (the timeout interval expires), quarantined addresses can be automatically released if that option is selected.

 If you unmanage and remanage a device, the quarantine settings are reset to the default values.

- **GZIP Decompression:** When enabled, permits decompression of GZIP HTTP responses.
- **IDS Mode:** This mode automatically configures the device to operate like an Intrusion Detection System (IDS).
 - Performance protection is disabled.
 - Adaptive Filtering mode is set to Manual.
 - Filters currently set to Block are not switched to Permit, and Block filters can still be set.

 You must reboot the device before the change takes effect.

- **HTTP Response Processing:** Specifies inspection of encoded HTTP responses.
 - Accelerated inspection of responses: Hardware acceleration detects, and decodes encoded HTTP responses.
 - Inspection of responses: Enables strict detection and decoding of encoded HTTP responses.
 - Ignore responses: The device does not detect or decode encoded HTTP responses.
- **DNS Reputation:** You can return the NXDOMAIN (domain name) response to DNS domain queries blocked by Reputation.
- **HTTP Mode:** You can enable the HTTP Mode for the device. Allows all TCP ports to be treated as HTTP ports for inspection purposes. Enable t.  Please [log in](#) to initiate the conversation. 


Procedure:

1. Log in to the SMS from a client.
2. On the SMS toolbar, navigate to **Devices > All Devices** and expand the tab.
3. Select a device from the display window and do one of the following:
 - Right-click and select **Edit > Device Configuration**.
 - On the top menu, select **Edit > Details > Device Configuration**.
 - Double-click the device and click on **Device Configuration**.
4. On the Device Configuration Wizard screen, click the **TSE Setting** tab.
5. The Device Configuration (TSE Settings) screen displays.
6. Make desired changes.
7. Click **OK** to update the device.

Reference: SMS User Guide



Was this article helpful?



English



Feedback

Support &
Help

FAQ

Contact by
Sales

Resources

Automation
Center

Download

Please [log in](#) to initiate the conversation.

Policies &
Vulnerability

Support
Policies

Privacy

About Trend

Trend Micro

Home & Home
Office Support

Partner Portal



Education
Portal

Vulnerability
Response

Trend Micro
YouTube
Channel

Online Help
Center

Service Status

TrendConnect
Mobile App

Copyright © 2026 Trend Micro Incorporated. All rights reserved.



Please [log in](#) to initiate the conversation.

