BrewMate KT-200 Electric Kettle

User Manual

1. Specifications

Capacity: 1.7 litres. Power: 1500 W, 230 V. Body: stainless steel with a cool-touch handle. Cord length: 75 cm on a 360-degree base.

2. First use

Before the first use, fill the kettle to the MAX mark, boil the water and throw it away. Repeat this two times to remove any smell from the factory.

3. Boiling water

Fill water between the MIN (0.5 litre) and MAX (1.7 litre) marks. Close the lid, place the kettle on the base and press the switch. The blue light turns on. The kettle switches off by itself when the water boils.

4. Safety features

Auto shut-off: the kettle switches off 3 seconds after the water boils. Boil-dry protection: if the kettle is switched on with no water, it switches off and shows error E1. Let it cool for 10 minutes before you fill it again.

5. Error codes

E1: the kettle was switched on with no water. Let it cool for 10 minutes, then fill it. E2: the base is not detected. Clean the base contacts with a dry cloth and place the kettle again. E3: the temperature sensor has failed. Stop using the kettle and claim the warranty.

6. Cleaning and descaling

Wipe the outside with a damp cloth. Never put the kettle in water or in a dishwasher. Descale once a month in hard-water areas: fill half the kettle with water and add 1 cup of white vinegar, leave it for 1 hour, then boil it and rinse two times.

7. Warranty

The BrewMate KT-200 has a 2-year warranty from the date of purchase. The warranty does not cover damage from boiling liquids other than water, such as milk or soup.