

Acid Drip

Bassline synth, DRIFT synth and drum machine. Quick reference guide (V5)

Acid Pad Layout

1 Step 1	2 Step 2	3 Step 3	4 Step 4	5 Step 5	6 Step 6	7 Step 7	8 Step 8
9 KEY	10 RIFF	11 SOUND	12 WALK	13 FX	14 TEMPO	15 PLEN	16 PAT>

Bottom row labels only show in FUNC mode. Steps 9-16 are the same 8 pads.

Step Editing

ACTION	RESULT
Short press pad	Toggle step on/off
Long press x1	Toggle accent
Long press x2	Toggle glide
Hold pad + turn CUT	Set step note

Core Chords

CHORD	ACTION
1+2	Play / Stop
1+2 hold 0.5s	Reset current engine (acid/DRIFT). Drums: hold 1s in drum mode
7+8	Enter / exit FUNC mode
9+10	Switch to drums, or back to acid/DRIFT
9+10+11 hold 0.5s	Acid to DRIFT and back. No-op from drums
11+12+13+14 hold 1s	Acid Walks easter egg
12+13	Enter / exit chain-build mode
15+16 hold 1s	Toggle MIX EDIT mode

Save / Load (hold 7+8)

Tap 3/4/5/6	Load slot 1/2/3/4
Hold 3/4/5/6 for 1s	Save to slot 1/2/3/4
Hold 3+4+5+6 for 1s	Clear acid from all 4 slots (drum mode: clears drums instead)

Each slot saves acid, DRIFT and the drum beat together, plus play/stop state. Works from any screen.

FUNC Mode (hold 7+8 to enter)

PAD	FUNCTION	OPTIONS
9	KEY	Root note: C D Eb F G Ab Bb B
10	RIFF	DFLT / SQNCE / FUNK / MINI / JUMP / RAVE / SYNC / DARK
11	SOUND	SAW / SQR / SINE / PWM / CSAW / CSQR / CSIN / SUBSQ
12	WALK	OFF / 4TH / OCTWAVE / 5TH / BOUNCE / MIN3RD / VAMP3 / RANDOM
13	FX	Enter FX assign sub-mode
14	TEMPO	Preset BPM or tap tempo
15	PLEN	Pattern length: 1/2/3/4/6/8/12/16
16	PAT>	FWD / CW / ALT / REV / SKIP2 / SKIP3 / PING / RND

FX Assign (FUNC, pad 13): press a top-row pad to pick an effect (None / Oct Up / Retrigger / Stutter / Maj Step / Min Step / Dom7 Step / Dim Step), then press any step pad to assign it. Tap the effect pad again to deselect. Long-hold pad 1 to clear all.

Pattern Chaining

Link the 4 save slots into a sequence of up to 16 positions, with repeats.

1	Tap 12+13 to enter chain-build mode
2	Tap 3/4/5/6 to append that slot. Tap the same pad again to repeat it
3	Tap 12+13 again to exit and start playback

Each position plays one full loop of that slot's own pattern length. Acid only, not drum mode. Chains are not saved to EEPROM.

MIX EDIT

Hold 15+16 for 1s to trim the level of each engine independently.

POT	ENGINE
CUT	Acid
RES	DRIFT
DCY	Drums

Levels save to EEPROM automatically. Hold 15+16 again to exit.

DRIFT Synth

A second, independent synth voice. Sums into the drums output (GP2).

Switching Engines

CURRENTLY ON	9+10	9+10+11 (HOLD 0.5S)
Acid	Go to drums	Go to DRIFT
DRIFT	Go to drums	Back to acid
Drums	Back to acid/DRIFT	No-op

DRIFT is only reachable from the acid screen. From drums, go back to acid first, then 9+10+11. Acid, DRIFT and drums can all play at once, switching only changes which one the pads/pots control.

DRIFT FUNC Mode (7+8)	
PAD	FUNCTION
9	SND1, engine page 1 of 2
10	SND2, engine page 2 of 2
11	FOLW, pitch mode
12	ECHO, delay
13	VERB, reverb size
14	PATT, 8 pattern slots
15	EVOL, EVOLVE mutation
16	REC, pot motion recorder

SND1
<i>SUBSIN / DTSQR / FMBEL / RINGM / CLICK / FOLDR / PWM / UNISN</i>
SND2
<i>SAW / SUBDIV / NOIZ / VOWEL / ARPG / GONG / CRUSH / GATE</i>
FOLW (pitch mode)
<i>F+8 / F-8 / F+5 / F+3 (follow acid's last note, plus an interval) / FOLW (plain follow) / ARP+ / AR+- / WALK</i>
EVOL (EVOLVE intensity)
<i>OFF / OCTL / ADD1 / DEEP / STUT / HVY / WILD / MAX</i>

PATT, EVOLVE & REC	
PATT	8 slots (S1-S8) for DRIFT's own step patterns. Tap loads, hold saves. Note/pitch is set separately by FOLW.
EVOLVE	Periodically nudges the DRIFT line away from its recorded pattern and back. Intensity sets how far and how often.
REC	Short-tap to start/stop recording pot movement over one loop. Recorded lanes play back automatically; unrecorded pots stay live. Long-press to clear.

Beat Machine

Switch with pads 9+10. Sequencer state is preserved across all three engines.

Drum Instruments	
1	Kick
2	Hi-hat (closed)
3	Snare
4	Rim
5	Tom
6	Bass 2
7	Clap
8	Open hat
<i>Short-tap any pad 1-16 to load that pattern. Pads 1-5 also double as drum edit pads (short tap = select, long hold = edit). Pads 6-8 are select-only.</i>	
Per-Drum Editing (hold pad 1-5)	
CUT	Pitch
RES	Decay length
DCY	Volume
Custom Pattern (Pad 16)	
Quick tap	Enter custom edit mode
Tap while editing	Toggle step 16 for current voice
Turn any pot	Set pitch/length/volume for current voice
Hold 0.5s	Cycle to next drum voice
Hold 1s	Exit and save
Hold 1.5s	Wipe pattern and restart

16 Preset Patterns			
1 BASIC	2 HOUSE	3 TECHNO	4 ACID TRACK
5 HI STATE	6 FUNKY	7 SWING	8 BREAKBEAT
9 MINIMAL	10 LATIN	11 PACIFIC ST	12 BLUE MONDAY
13 DRUM N BASS	14 VODOOO RAY	15 BUILD DOWN	16 CUSTOM
Sync In / Out: hold pad 14 at power-on for a SYNC MODE menu. Press pad 1 for Sync In (external clock drives this device's tempo) or pad 2 for Sync Out (this device sends a 24 PPQN clock to other gear). Either way GP2 is taken from drum/DRIFT audio for that session, and requires the PCB switch in the SYNC position.			

Beat Machine FUNC (7+8)	
LABEL	FUNCTION
PTCH	Global pitch, stacks on per-drum
DRIV	Drive / saturation, bit crush at top
FILT	Bipolar DJ filter (low/high sweep)
CHNC	Chance - thin or add ghost hits
HMNZ	Humanize - velocity & timing jitter
SWNG	Swing on odd 16th steps
ACNT	Accent depth, on/off-beat emphasis
FILL	Procedural fill engine, see below

Fill Engine
Pads 1-4 (frequency): <i>OFF / 1 BAR / 2 BAR / 4 BAR</i>
Pads 5-8 (type): <i>HATS / CLAP / SNARE / KIT</i>
<i>Pots control the fill voice's pitch, decay and volume while FILL is selected. Density accelerates into the landing beat.</i>