
NORMAL PROCEDURES		
	EXTERNAL SAFETY INSPECTION 3	INTERNAL SAFETY INSPECTION 3
GENERAL	POWER ON 3	CARGO CABIN INSPECTION 4
	POWER OFF 5	
GENERAL CHECKS FOR	TROOP/ PARATROOP 6	MEDEVAC 6
SPECIFIC CONFIGURATION	CARGO 6	
PRELOADING	AM109 CHADS PREFLIGHT 7 CHECKLIST	WINCH PRELOADING 8 INSPECTION
	LOAD PLANNING 9	GENERAL LOADING PREPARATION 10
	VEHICLE ONLOADING 12	GENERAL WINCHING 13 PREPARATION
LOADING	INTERNAL/EXTERNA	L/SELF-WINCHING 13
	PALLETIZED OR FLOOR	CARGO ONLOADING 15



GENERAL

EXTERNAL SAFETY INSPECTION

1.	Chocks	.A.R.
----	--------	-------

2.	Flaps and Propeller Areas	CLEAR
----	---------------------------	-------

INTERNAL SAFETY INSPECTION

1.	Galley	CHECK / OFF
2.	WIPER selectors	OFF
3.	IFF panel	OFF
4.	Landing gear lever	DOWN / LOCKED
5.	Flaps lever	A.R.
6.	GUST LOCK lever	LOCKED
7.	Weather radar	OFF
R	Hydraulics numns	MAN / OFF

POWER ON

1.	Circuit breakers	CHECK
2.	MISC Master Switches	OFF
3.	BAT & GEN master switches	ON
4.	Batteries	ON / CHECK
5.	[GPU (if available)	ON / CHECK]
6.	B/U BAT Pushbuttons	CHECK
7	INAV lights	ONI

C.L.Q.R.H. C-295M-VT01

8.	WARNING and CAUTION master lights	
9.	Parking brake	A.R.
10.	[Hvdraulic system	MAN / CHECK / A.R.1

CARGO CABIN INSPECTION

1.	Water heater & oven	OFF
2.	First aid kit (1)	ON BOARD / CHECK
3.	Oxygen bottles (2)	CHECK / GREEN BAND
4.	Oxygen masks (4)	CHECK
5.	ToiletC	LEAN / GOOD CONDITION
6.	Cargo winch access	CLOSED AND LATCHED
7.	Oxygen bottles (2)	CHECK / GREEN BAND
8.	Oxygen masks (2)	CHECK
9.	Therapeutic masks (2)	CHECK
10.	Halon extinguisher	CHECK / GREEN BAND
11.	Water extinguisher	CHECK / SECURED
12.	Life vest	CHECK
13.	Emergency door pin	REMOVE
14.	Emergency door CH	IECK / HANDLE SECURED
15.	First aid kits (4)	ON BOARD / CHECK
NP-4	Revision 3	

16.	Paratroop door pins (2)REM	OVE
17.	EXIT lights (4)CH	IECK
18.	Aisle lamps (5)CH	IECK
19.	Cargo ramp cylinder actuators	.A.R.
20.	Attendant control panel	.A.R.
21.	Ramp and cargo stored equipment CHECKED SECURED	AND
22.	ELTGOOD CONDIT	TION

POWER OFF

1 BAT BUS TIF Switch

• •		
2.	OXYGEN Panel	OFF
3.	Brake Temperature	OFF
4.	EXTERNAL LT panel	OFF
5.	FLT DECK LT panel	OFF
6.	Emergency Lights	OFF
7.	INTERNAL LT panel	A.R.
8.	Batteries	OFF
9.	MSTR ELECT (BAT and GEN) switches	OFF

OFF

GENERAL CHECKS FOR SPECIFIC CONFIGURATION

TROOP/PARATROOP

1.	Center row seats (if fitted)	PROPERLY INSTALLED
2.	Seats and belts	GOOD CONDITION
3.	Life vests	A.R.
4.	Loose equipment	STOWED / SECURED

MEDEVAC

1.	Stretchers	PROPERLY INSTALLED
2.	Stretchers harnesses	CHECK
3.	Seats and belts	GOOD CONDITION
4.	Life vests	A.R.
5.	Electrical receptacles	GOOD CONDITION / A.R.
6.	Loose equipment	STOWED / SECURED

CARGO

1.	Straps/Chains	CHECK
2.	Tiedown rings	CHECK
3.	Loading/Offloading auxiliary equipment	AVAILABLE
4.	Loose equipment STO	WED / SECURED

PRELOADING

AM109 CHADS PREFLIGHT CHECKLIST

WARNING

A complete preflight inspection of the CHADS must be accomplished prior to departure from homebase and/or before cargo airdrop. Failure to perform a complete operational checkout prior to using it could result in damage to the cargo, aircraft, and injury or death to personnel.

1. Airdrop (RH) control handleLOCK

CAUTION

The control handle should move smoothly from REL to LOCK position. If resistance is encountered, return the handle to the approximate vertical position and then back to LOCK. Do not attempt to force the handle to the LOCK position.

CAUTION

The control handle should move smoothly from the RELEASE to the FULL LOCK position. Do not force the handle in any direction.

3 Airdrop (RH) siderails and locks CHECKED CAUTION Do not kick the detent locks to check that they do not retract. Force exerted by doing so may alter adjustments of the assembly. 4. Logistic (LH) siderails and locks CHECKED CAUTION Do not kick the detent locks to check that they do not retract. Force exerted by doing so may alter adjustments of the assembly. Airdrop (RH) control handleREL 5. Airdrop (RH) control handleLOCK / AD 6. 7. Logistic (LH) control handle and locks..... CHECKED FOR OPERATION Logistic (LH) control handle RELEASE 8. 9. Ramp siderail assemblies.......CHECKED 11. Pallet buffer stops.......CHECKED 12. AM109 preflight checklist......COMPLETE WINCH PRELOADING INSPECTION 1. Pulley assembly.......DEPLOY 2. 3.

Wirings and electrical leads CHECK

4

5.

6.	Control pendant	CONNECT SOCKET FR10
7.	Aircraft	ENERGIZED
8.	Winch	ENERGIZE
9.	Winch cable	REEL OUT
10.	Winch cable stop	CHECK POSITION
11.	Full-in limit switch and light	CHECK
12.	Full-out limit switch and light	CHECK
13.	Cable on drum	CHECK
14.	Winch cable	GOOD POSITION
	No broken wires or kinks a cable. If broken wires are debe used.	re allowed for the winch
	CAUT	ION
	Kinks are sharp, permanent on the cable may be caugh cause cable fouling. Cable internal broken wires that can	nt in the cable guide and es with kinks may have
15.	Control pendantCHEC	K OTHER SOCKETS / A.R.
16.	Winch hook and cable	A.R.
17.	Power Off Checklist	COMPLETE
LO	AD PLANNING	

Dimensions, weights, nature of cargo to be airlifted

Dimensions and critical points CHECKED

1.

2.

C.L.Q.R.H. C-295M-VT01

3.	Desired aircraft balance conditionDETERMINED
4.	Aircraft limitations CHECKED
5.	Placement of hazardous materialsDETERMINED
6.	Loading sequenceDETERMINED
7.	Cargo floor limitations CHECKED
8.	Resulting aircraft balance conditionCOMPUTED
9.	Final load distributionDETERMINED
GE	NERAL LOADING PREPARATION
1.	Systems, auxiliary equip., and aircraft config CHECKED
	All systems required for mission work properly; aircraft equipment and configuration fits mission requirements.
2.	Cargo door and rampOPEN
	Gather from cargo door all stowed equipment required for loading operation; install aft fuselage support legs and (if required) auxiliary loading ramps.
3.	Cargo documentation CHECKED
4.	Engine, brakes, and tire pressureCHECKED
5.	Fueled items
	Fuel quantities in tanks of vehicles or wheeled cargo; items susceptible of containing trapped fuel (drained, purged, and vented); cans for carrying additional fuel must be of an airlift-approved type; reject items yielding strong fuel odors.
6.	Fuel, battery, and oil capsTIGHTENED
7.	Tanker-type vehiclesCHECKED
8.	Weight, dimensions, and CGOBTAINED
9.	Contact pressuresCOMPUTED
NP-	10

10.	Shoring requirementsDETERMINED
11.	Hazardous materialsCHECKED
	Check presence of dangerous materials, compatibility, packing, labeling, etc. are according to ICAO and other applicable regulations.
12.	General cargo conditionCHECKED
	Package condition; soil contamination or pests; vehicle leakages.
13.	Equip. on shipping dollies/additional cargo on vehicles
	Engines, propellers, etc. firmly secured to shipping dolly; all cargo on or in vehicles does not exceed maximum allowable weight for airlift and properly restrained.
14.	Chocks for main and nose gear SEPARATE / CHECKED

LOADING

VEHICLE ONLOADING

1.	General loading preparation checklistCOMPLETE
	Paratroop doors closed; door handles folded; seats upright and secured; if required remove static line anchor cables and roller trays.
2.	Auxiliary loading ramps aligned for axle width CHECKED
3.	VentilationCHECKED
	To ensure ventilation in cargo cabin, open crew door, escape hatch, and flight deck windows, as required.
4.	Loading crew dutiesASSIGNED, PERSONNEL BRIEFED
5.	Vehicles to be loaded/prime mover aligned, low gear, four-wheel drive
6.	Vehicles on board, transmission and gear lever as requiredACCOMPLISHED
	NOTE
	If an axle is placed on the aircraft ramp, ensure filler neck is above fuel tank with the ramp closed.
7.	Brakes and ignition SET / OFF
	WARNING
	Vehicle driver must remain at controls while initial safety restraint is applied.
8.	Tiedown COMPUTED, INSTALLED, CHECKED
9.	Vehicle onloading checklistCOMPLETE
10.	

GENERAL WINCHING PREPARATION

1.	Power on checklist	COMPLETE
2.	Winch preloading inspection checklist	COMPLETE
3.	External winch inspection (only self winching)	COMPLETE
4.	Loading crew dutiesASIGNED, PERSONN	NEL BRIEFEC
5.	Cargo cabin and ramp area CLEAR OF	OBSTACLES
6.	Steering yoke (if required)	INSTALLED
7.	Aft fuselage support legs	INSTALLED
8.	Approach shoring (if required)	IN PLACE
9.	Auxiliary loading ramps	INSTALLED
10.	Chocks	AVAII ABI F

WARNING

The use of chocks while the vehicle is on the inclined aircraft ramp is forbidden. Should the loading operation need to be stopped when the whole or part of the vehicle is on the ramp, temporarily secure the vehicle by means of tiedown devices.

INTERNAL/EXTERNAL/SELF-WINCHING

WARNING

The steering control device shall always be positioned aft. At no time personnel will be in the path of the load, between the cargo attaching point of the cable and the winch, or directly aft of the item being loaded.

- 1. General winching preparation checklistCOMPLETE
- 2. Winching vehicle (external winching only) POSITIONED

C.L.Q.R.H. C-295M-VT01

3. Vehicle to be loadedALIGNED

Line up wheels of vehicle with auxiliary loading ramps. If required, re-adjust auxiliary loading ramps to proper axle width.

- 4. Snatch blocks (if required)......INSTALLED

For winching pallets or airdrop platforms, attach hook to a chain bridle rigged across two side rings.

WARNING

Load attaching points must be substantial enough to withstand winch pull. If necessary, install a chain bridle on two load symmetrical points.

- Cable slack removed (initial tension), snatch block, cable-toload attachment, and cable path......CHECKED
- 8. Remaining items to be loaded ON BOARD
- 9. Load restraint/locking of pallets ... COMPUTED, COMPLETE
- 10. Winching checklistCOMPLETE
- 11. After Loading checklist......COMPLETE

PALLETIZED OR FLOOR CARGO ONLOADING

WARNING

Prior to beginning the onloading operation, install at least two pallet stops forward of the preplanned position for the front end of the first pallet.

1.	Locks on both sidesRETRACTED (As required)
2.	Aft fuselage support legs INSTALLED (As required)
3.	Cargo cabin and ramp areaCLEAR AND UNOBSTRUCTED
4.	Pallet inspectionCOMPLETE
	Condition; cargo-to-pallet restraint; position of side pallet D-rings.
	CAUTION
	Lower or secure in vertical position side pallet D-rings not in use for restraint.
5.	Loading crew dutiesASSIGNED, PERSONNEL, BRIEFED
6.	ChocksIN PLACE
7.	Loading vehicle APPROACHED AND ALIGNED
8.	Loading vehicle brakeSET
9.	Auxiliary loading rampINSTALLED (If required)

10. Pallet, platform, or load...... TRANSFERRED TO AIRCRAFT

WARNING

When transferring pallets, platforms, or vehicles to the cargo cabin, all personnel must keep aft of the item being loaded at all times. If at any time the load is required to be pulled, use extreme caution.

CAUTION

Do not use CHADS locks as reference pallet stops. Striking may result in damage to the CHADS.

	0 ,
11.	Left side detents/restraint LOCKED / INSTALLED
12.	Remaining pallets, platforms, or loadTRANSFERRED TO AIRCRAFT
13.	CHADS right control handleFULL LOCKED
14.	Positive engagement of locks on both sides CHECKED
	Detents on both sides are visible. If pallets cannot be locked with the CHADS, use tiedown rings to secure pallets directly to cargo floor.
15.	Ramp detent lock-flangesENGAGED
16.	Pallet buffer stopsINSTALLED
	WARNING
	If personnel is to be carried forward of the pallets, install a pallet buffer stop on each restraint track (four stops).
17.	Palletized/floor cargo loading checklistCOMPLETE

18. After Loading checklist......COMPLETE

OFFLOADING

OFFLOADING PALLETS, VEHICLES, GENERAL CARGO

1.	ASSIGNED, PERSONNEL, BRIEFED
2.	Aft fuselage support legs INSTALLED (As required)
3.	Auxiliary loading ramps INSTALLED (As required)
4.	Offloading vehicle or equipmentIN PLACE
5.	VentilationA.R.
6.	Vehicle/cargo CHECKED (As required)
7.	Cargo cabin and ramp area CLEAR OF OBSTACLES
8.	Winch cableATTACHED TO LOAD (As required)
9.	Tiedowns REMOVED
10.	CHADS locks on both sidesUNLOCKED (As required)
11.	OffloadCOMPLETE
12.	Offload checklistCOMPLETE
12	New onload/After Loading checklist COMPLETE

EMBARKING/DISEMBARKING PERSONNEL

1.	I. Cargo cabin and ramp area CLEAR	OF OBSTACLES
2.	2. Ramp and cargo door/crew door	OPEN
3.	B. Personnel ON BOARD	/ DISEMBARKED
	WARNING	
	Before starting personnel offboarding, chave come to a complete stop.	check propellers
4.	1. Seat belts	A.R.
5.	5. Passenger manifest	CHECKED
6.	S. Passenger briefing	COMPLETE
7.	7. Baggage/ loose equipment SECUR	ED/OFFLOADED
8.	B. Personnel embarking/disembarking checkli	stCOMPLETE
9.	After Loading checklist	COMPLETE

AFTER LOADING

1.	Ramp and cargo doorCLOSED AND CHECKED
2.	Telescopic barsCONNECTED (If required)
3.	Loose equipment STOWED, SECURED
4.	Load condition CHECKED
5.	Cargo tiedown
	Check CHADS detent lock engagement and handle positions for all pallets. Check tiedowns for wheeled cargo and floor loads.
6.	Cargo and passenger manifestsCHECKED
7.	Weight and balance formCOMPLETE
	WARNING
	For computing and filling up aircraft weight and balance form after loading and immediately before takeoff, visually verify all load positions. Do not use weight and balance data obtained during load planning, since actual load positions may differ from those preplanned.
8.	After Loading checklistCOMPLETE

Intentionally Left Blank