}

R247 10K R115 R268 R124 10K R0201 DNP DNP DNP DNP DNP DNP MCU_BOOTMODE[02:00]: PLL Config, set to '000' for 19.2MHz input frequency. MCU_BOOTMODE[05:03]: Primary Boot Mode A, set to '001' for primary boot is eMMC set to '000' for primary boot is MMC/SD MCU_BOOTMODE06: MCU Only, set to 0, Normal boot mode. MCU_BOOTMODE[09:08]: POST Config, set to 0. R113 R246 R140 R114 R267 R125 > R144 10K 10K