/S_10_3V3								
R133 10K 1% R0201	R232 10K 1% R0201	R258 10K 1% R0201 DNP	R136 10K 1% R0201	R241 10K 1% R0201 DNP	R270 10K 10K R0201 DNP	R231 10K 1% R0201 DNP	1	
+	-	$\vdash$	$\overline{}$	$\overline{}$	$\overline{}$	$\overline{}$	AD20_SYS_BOOTMODE	0[13,25] SYS_BOOTMODE0: Primary Boot Mode B, set to 1.
							1	SYS_BOOTMODE[3:1]: Backup Boot Mode, set to '101', MMC/SD card.
						Ħ	0 >>> V6_SYS_BOOTMODE4[1 0 ->>> V5_SYS_BOOTMODE5[1 0 ->>> AB27_SYS_BOOTMODE6	0.25] SYS_BOOTMODE(6:4): Primary Boot Mode Config, set to '000' for eMMC(MMC0) set to '100' for SD Card(MMC1) (6(13.25)
-   '	1 '	1 7	1 7	$\Gamma = I$	1 1	1 4	AB24_SYS_BOOTMODE	
R123 10K 1% R0201 DNP	R233 10K 1% R0201 DNP	R259 10K 1% R0201	R135 10K 1% R0201 DNP	R238 10K 1% R0201	R269 10K 1% R0201	R218 10K 1% R0201	1	