

UAV Wall — setup

A wall of live video feeds, composed onto one canvas and sent into a Pexip VMR as a single participant. This guide covers opening it, and installing the optional extras if you want recording, your own video files, or audio.

Before you start

Mac	Apple silicon (M1 or later), macOS 14 or newer. Intel Macs are not supported. This page covers the first run.
Windows	Windows 11, x64. The app arrives as a folder rather than a single icon — its first run is page 2 .
To install	Nothing . The app is self-contained. Extras are optional and covered later in this guide.
For a VMR	The conference alias and, if it has one, its PIN.

Opening it the first time — Mac

The app is not signed by an identified developer, so macOS blocks it once. This is expected and only happens on the first run.

- 1 Drag **UAV Wall** to your **Applications** folder.
- 2 Double-click it. macOS refuses and says it cannot verify the developer. Click **Done**.
- 3 Open **System Settings** › **Privacy & Security**, scroll to the bottom, and click **Open Anyway** next to the UAV Wall message.
- 4 Double-click the app again and click **Open**. It will start normally every time after this.

It opens onto a working wall. Four demo clips are built in and loop continuously, so you can try the layouts and send to a VMR without any cameras or setup.

If it says the app is damaged — or nothing happens at all — macOS has quarantined it because it arrived over the network. Open **Terminal** (Applications › Utilities) and paste this one line, then open the app again:

```
xattr -dr com.apple.quarantine "/Applications/UAV Wall.app"
```

That clears the download marker. It does not change the app, and you only ever need it once.

Opening it the first time — Windows

On Windows the app is a portable folder: everything it needs travels inside it, and the folder is also where it keeps its settings. There is no installer and nothing else to download.

- 1 If it arrived as **UAV Wall.zip**, right-click it and choose **Extract All...** — anywhere you like (Desktop or Documents is fine). **Don't run it from inside the zip window**: that looks like a folder but isn't one, and the app will not find its own files.
- 2 Open the extracted **UAV Wall** folder and double-click **uavwall.exe**.
- 3 Windows shows a blue “**Windows protected your PC**” screen the first time, because the app is not signed. Click **More info**, then **Run anyway**. It starts normally every time after this.

It opens onto a working wall. Four demo clips are built in and loop continuously, so you can try the layouts and send to a VMR without any cameras or setup.

Where things are kept

Settings `uavwall.conf` inside the UAV Wall folder — the folder *is* the installation. Moving the folder moves everything with it.

Recordings `Videos\UAV Wall` in your user profile.

One Windows difference that matters for phones and wearables. If you plan to stream from a phone or bodycam into the wall (page 5), install **ffmpeg** first (page 4, one command). Without it the video from most phones arrives heavily broken up on Windows — with it, the app cleans the stream up automatically.

The basics

Putting feeds on the canvas

Sources are listed down the left. Switch one on with its toggle, then use a layout button — **1-UP**, **2×2**, **3×3** or **PIP** — to place whatever is connected. Drag a tile to move it, drag its corner to resize. Double-click any tile or card to punch that feed full screen, and again to go back. **A / B / C** store layouts: click to recall, press and hold to save.

Sending it to a VMR

Type `alias@server` into **DESTINATION**, add the PIN if the VMR has one, and press **SEND TO VMR**. Everyone in the conference sees the composed canvas as one participant's video. **Settings › Canvas & sending** switches it to the presentation stream instead, so it appears alongside the participants rather than as one of them.

Adding your own sources

An IP camera (RTSP)

Settings › Feeds › **+ ADD FEED**, then type the camera's address, e.g.

`rtsp://10.0.1.50:554/stream1`. Works straight away — nothing to install.

A phone, wearable or drone (RTMP/SRT)

These push video out rather than serving it, so the app runs a receiver for them. See page 5 — nothing to install (on Windows, `ffmpeg` improves the picture; page 4).

A video file

Settings › Feeds › **+ ADD FILE**. Needs `ffmpeg` — see page 4.

Recording

Capture any feed, or the whole canvas, to an MP4 in your Movies (Mac) or Videos (Windows) folder. Needs `ffmpeg` — see page 4.

Cameras with a password. Put it in the address as `rtsp://user:pass@host/path`. It is stored in plain text in the app's settings file, so do not use a camera whose password matters.

Where things are kept

Mac Settings in `~/Library/Application Support/UAV Wall/uavwall.conf`, recordings in `~/Movies/UAV Wall`.

Windows Settings in the UAV Wall folder itself, recordings in `Videos\UAV Wall` — see page 2.

Installing ffmpeg

Needed for adding your own video files, recording, listening to a feed's audio, and sending a feed's audio into the VMR — and on Windows it also makes phone and wearable streams arrive clean (page 5). Everything else — the demo clips, RTSP cameras, layouts, sending the canvas — works without it.

Why isn't it included? ffmpeg is licensed under the GPL. Bundling it would add licensing obligations to this app, so you install it yourself instead, direct from its own distributor. The app finds it automatically afterwards.

On Windows — one command

Open **Terminal** (press the Windows key, type `terminal`) and paste:

```
winget install Gyan.FFmpeg
```

A few minutes. Then see **Restart UAV Wall** below — steps 1–2 are Mac-only.

Step 1 — Install Homebrew (Mac)

Homebrew installs command-line software on a Mac. Skip this if you already have it (type `brew --version` in Terminal to check).

Open **Terminal** (Applications › Utilities) and paste in one line:

```
/bin/bash -c "$(curl -fsSL https://raw.githubusercontent.com/Homebrew/install/HEAD/install.sh)"
```

It asks for your Mac password and takes a few minutes. At the end it prints two `echo` commands under **Next steps** — run those as well, or the `brew` command will not be found.

Step 2 — Install ffmpeg (Mac)

```
brew install ffmpeg
```

Restart UAV Wall

Quit the app and open it again. It looks for ffmpeg at startup, so a running app will not notice a new installation. **+ ADD FILE** and the record buttons become available.

How to tell it worked. Without ffmpeg the app shows `ffmpeg not found` — `import`, `recording` and `audio` are off along the bottom when it starts. With it installed, that message is gone.

Imported files are converted first. Adding a video file re-encodes it — a few seconds per clip, cached so adding it again is instant — because the video engine decodes some high-quality H.264 files badly.

The RTMP / SRT receiver

An IP camera serves video and the wall fetches it. A phone or wearable does the opposite — it pushes video to an address you give it. The app includes a receiver for exactly that.

Nothing to install.

- 1 Open **Settings** › **Feeds** and switch on **Receiver (RTMP/SRT)**. It should say **LISTENING** within a second or two.
- 2 Note the **NEXT · RTMP** address shown, e.g. `rtmp://10.0.1.12:1935/live/source-01`. Click it to copy it.
- 3 Press **+ ADD RECEIVER FEED**. A source appears in the list, ready and waiting.
- 4 In your streaming app on the phone, set that address as the destination and start streaming.
- 5 Switch the new source on. It shows `waiting for the device...` until the stream arrives, then goes live on its own.

Repeat for as many devices as you like — each press of **+ ADD RECEIVER FEED** gives out the next address. Every source's own push address is shown in the inspector at the bottom of the list when you select it; hover any line to see it in full, click to copy.

Two settings on the device that matter

Baseline profile	Set the encoder to Baseline — higher profiles can break the picture up. Most apps expose this directly. On Windows with ffmpeg installed (page 4) this does not matter: the app converts incoming streams automatically and any profile is fine.
Same network	The phone must be on the same Wi-Fi as this computer. A guest network or mobile data will not reach it.

If the device will not connect

- › Check the address on the device **exactly** — including `/live/`. Some apps reject an address without two parts after the host.
- › Give it a moment. A phone can take several seconds to negotiate; the source picks it up on its own.
- › Confirm the receiver says **LISTENING**. If it reports an error, something else on this computer is already using the same ports.

Something to be aware of. While the receiver is on, this computer accepts incoming video from anything on the network that knows the address. Switch it off when you have finished demonstrating.