

140
120
100
80
60
40
20
0
-20
-40
-60
-80
-100
-120

50mm

hole 0

Scale is to calibrate actual printed dimension. Check both X and Y. Measure between tick 0 and last tick

C0

C2

C1

C3

N0