## Alarm Help - MV SERIES -



ALARM ADDRESS	A11.5	ALARM NO.	1177
ALARM TEXT	PRESS SRV KEY -> ARM CCW TO BOTTOM.		
Related Signal			
CAUSE	When ATC cycle was interrupted. This is a prompt for operator •		
ACTION	Press service button the ARM will perform CCW to bottom position •		