Alarm Help - MV SERIES -



ALARM ADDRESS	A5.0	ALARM NO.	1124
ALARM TEXT	DURING T CYCLE, POWER DROP DOWN.		
Related Signal			
CAUSE	During T cycle, Main Power Drop Down •		
	1.Release all of EMG. Stop button •		
ACTION	2.Press Machine Startup button •		
	3.Press Cycle Start button to finish T cycle •		