## Alarm Help - MV SERIES -



ALARM ADDRESS	A8.3	ALARM NO.	1151
ALARM TEXT	5th NOT AT UCMP POS. M46=>5th UCMP.		
Related Sianal	Input: X6.0 , X6.1 (MV154/154APC/MV204) •		
	Output: Y4.6 (MV154/154APC/MV204) •		
CAUSE	5th Axis not at unclamp position as		
	A. move 5th axis by MPG 。		
	B. move 5th axis by JOG 。		
	C. move 5 <sup>th</sup> axis by AUTO •		
ACTION	Perform M46 for 5th Axis Unclamp •		