Alarm Help - MV SERIES -



ALARM ADDRESS	A3.2	ALARM NO.	1110
ALARM TEXT	POT UP & DOWN BOTH ON.		
Related Signal	Input: X0.0 & X0.1(MV154/154APC/MV204) , X6.0 & X6.1 (184C) •		
CAUSE	POT UP & Down Limit Switch Both ON •		
ACTION	1.Check pot up & down Sensor • 2.Cylinder for pocket up/down damaged		